



<https://xtool.es/>
 Telefono fijo: +34 937 371 351
 sales@xtool.es

Mercedes Function List V20.21

Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master ,A80Pro, A80ProMaster, NitroGT, NitroXT Edition products.

* This feature is new.

✓ This feature is supported.

This feature is not supported.

✘ This feature is partially supported.

Model	Model Series	Control Unit Groups	System Name	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Read Freeze Frame	Actuation Test	Special Functions	Coding	programming
A-Class	168	Air conditioning	STH-Stationary heater	✓	✓	✓	✓					
A-Class	168	Air conditioning	TAC-Automatic temperature	✓	✓	✓	✓		✓			
A-Class	168	Body	AB-Airbag	✓	✓	✓	✓					
A-Class	168	Body	AB-Airbag	✓	✓	✓	✓					
A-Class	168	Body	APS-Auto pilot system	✓	✓	✓	✓					
A-Class	168	Body	ATA-Anti theft alarm system	✓	✓	✓	✓					
A-Class	168	Body	HB-Heater booster	✓	✓	✓						
A-Class	168	Body	LCP-Lower control panel	✓	✓	✓	✓					
A-Class	168	Body	RFL-Radio frequency locking/electric central locking	✓	✓	✓	✓					
A-Class	168	Chassis	ESP-Electronic stability program	✓	✓	✓	✓					
A-Class	168	Chassis	ESP-Electronic stability program	✓	✓	✓	✓					
A-Class	168	Drive	ACS-Automatic clutch system	✓	✓	✓	✓					
A-Class	168	Drive	CDI-Common Rail Diesel	✓	✓	✓	✓		✓			
A-Class	168	Drive	ECM-Engine control monolith	✓	✓	✓	✓					
A-Class	168	Drive	ECM-Engine control monolith	✓	✓	✓	✓					
A-Class	168	Drive	FTC-Front transmission control	✓	✓	✓	✓					
A-Class	168	Drive	FTC2 -Front transmission	✓	✓	✓	✓					
A-Class	168	Drive	GRM-Gear recognition module	✓	✓	✓	✓		✓			
A-Class	168	Information and communication	AUDIO	✓	✓	✓	✓					
A-Class	168	Information and communication	CDC-CD changer	✓	✓	✓						
A-Class	168	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	✓	✓	✓						
A-Class	168	Information and communication	ICM-Instrument cluster with maintenance interval display	✓	✓	✓			✓			
A-Class	168	Information and communication	PTS-Parktronic system	✓	✓	✓	✓					
A-Class	168	Seats and Doors	DCM FL-Door control module front left	✓	✓	✓	✓					

A-Class	168	Seats and Doors	DCM FR-Door control module front right	√	√	√	√					
A-Class	168	Seats and Doors	DCM RL-Door control module rear left	√	√	√	√					
A-Class	168	Seats and Doors	DCM RR-Door control module rear right	√	√	√	√					
A-Class	169	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	√					
A-Class	169	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	√					
A-Class	169	Air conditioning	EKMK-Electric refrigerant compressor	√	√	√	√					
A-Class	169	Body	AB-Airbag	√	√	√	√			√		
A-Class	169	Body	AHE-Trailer recognition	√	√	√	√		√	√		
A-Class	169	Body	ATA-Anti theft alarm system	√	√	√	√		√			
A-Class	169	Body	CGW-Central gateway	√	√	√	√					
A-Class	169	Body	EZS-Electronic ignition switch	√	√	√	√					
A-Class	169	Body	HRA FL-Front left headlamp range control	√	√	√	√					
A-Class	169	Body	HRA FR-Front right headlamp range control	√	√	√	√		√			
A-Class	169	Body	MSS-Special vehicle multifunction control module	√	√	√	√					
A-Class	169	Body	MSS-Special vehicle multifunction control module	√	√	√	√		√			
A-Class	169	Body	N93/4 (Vehicle gateway control	√	√	√	√					
A-Class	169	Body	OCP-Overhead control panel	√	√	√	√		√	SP0164,	CD0140, CD0142, CD0143,	
A-Class	169	Body	SAM-Signal acquisition and actuation module	√	√	√	√			SP0215,		
A-Class	169	Body	System diagnosis(CAN)	√	√	√	√					
A-Class	169	Chassis	ES-Electrical power steering	√	√	√	√					
A-Class	169	Chassis	ESP-Electronic stability program	√	√	√	√					
A-Class	169	Chassis	VP-Vacuum pump brake booster	√	√	√	√		√			

A-Class	169	Chassis	VP-Vacuum pump brake booster	√	√	√	√	√				
A-Class	169	Drive	BSA-Belt-driven starter/alternator	√	√	√	√					
A-Class	169	Drive	CDI-Common Rail Diesel	√	√	√						
A-Class	169	Drive	CDI-Common Rail Diesel	√	√	√	√					
A-Class	169	Drive	ESM-Electronic selector module	√	√	√	√	√		SP0152,		
A-Class	169	Drive	FCVT-Continuously variable automatic transmission	√	√	√	√			SP0153,		
A-Class	169	Drive	ME SFI-Gasoline engine control	√	√	√	√	√				
A-Class	169	Drive	ME SFI-Motor electronics	√	√	√	√					
A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√					
A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√					
A-Class	169	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	√	√	√	√					
A-Class	169	Information and communication	ASSYST PLUS-PLUS Active Service System	√	√	√	√					
A-Class	169	Information and communication	ASSYST-Active Service System	√	√	√	√					
A-Class	169	Information and communication	AUDIO	√	√	√	√			SP0161,SP0162,SP0163,	CD0133, CD0134, CD0136,	
A-Class	169	Information and communication	CDC-CD changer	√	√	√	√				CD0133, CD0134, CD0136,	
A-Class	169	Information and communication	COMAND or AUDIO	√	√	√	√				CD0002, CD0004, CD0005, CD0008, CD0015, CD001	
A-Class	169	Information and communication	COMAND or AUDIO	√	√	√	√					
A-Class	169	Information and communication	CTEL-Cellular telephone	√	√	√	√				CD0048,	
A-Class	169	Information and communication	CTEL-Cellular telephone(JAPAN)	√	√	√	√				CD0063, CD0064,	
A-Class	169	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√			SP0157,	CD0082, CD0083, CD0085, CD0086, CD0091, CD0094, CD0099, CD0103, CD0104, CD0106, CD0107, CD0109, CD0110, CD0114, CD0117, CD0121, CD0125, CD0127, CD0128	

A-Class	169	Information and communication	DAB-Digital radio	√	√	√	√					
A-Class	169	Information and communication	IC-Instrument cluster	√	√	√	√		√			
A-Class	169	Information and communication	PTS-Parktronic system	√	√	√	√					
A-Class	169	Information and communication	PTS-Parktronic system	√	√	√	√					
A-Class	169	Information and communication	SCM [MRM]-Steering column module	√	√	√	√					
A-Class	169	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√				CD0278, CD0279, CD0280,	
A-Class	169	Information and communication	SOUND-Sound system	√	√	√	√					
A-Class	169	Information and communication	TV-TV tuner	√	√	√	√					
A-Class	169	Information and communication	TV-TV tuner	√	√	√	√					
A-Class	169	Information and communication	UCI-Media interface	√	√	√	√			SP0104,SP0105,SP0106,SP0107,SP0108,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,		
A-Class	169	Information and communication	VCS-Voice control system	√	√	√	√			SP0104,SP0105,SP0106,SP0107,SP0108,SP0109,SP0110,SP0111,SP0112,SP0113,SP0114,SP0115,		
A-Class	169	Seats and Doors	DCM FL-Door control module front left	√	√	√	√		√		CD0075,	
A-Class	169	Seats and Doors	DCM FR-Door control module front right	√	√	√	√		√	SP0158,		
A-Class	169	Seats and Doors	DCM RL-Door control module rear left	√	√	√	√		√		CD0177, CD0178, CD0179, CD0180,	
A-Class	169	Seats and Doors	DCM RR-Door control module rear right	√	√	√	√		√	SP0185,SP0186,SP0187,SP0188,SP0189,SP0190,SP0191,SP0192,SP0193,		
B-Class	245	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	√					
B-Class	245	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	√				CD0026, CD0029, CD0026, CD0027, CD0028, CD0029,	

B-Class	245	Air conditioning	EKMK-Electric refrigerant compressor	√	√	√	√				CD0026, CD0029, CD0026, CD0027, CD0028, CD0029,
B-Class	245	Body	AB-Airbag	√	√	√	√				
B-Class	245	Body	AHE-Trailer recognition	√	√	√	√		√		
B-Class	245	Body	ATA-Anti theft alarm system	√	√	√			√		CD0298, CD0299, CD0300, CD0301, CD0302, CD0303,
B-Class	245	Body	CGW-Central gateway	√	√	√					
B-Class	245	Body	EZS-Electronic ignition switch	√	√	√	√				
B-Class	245	Body	MSS-Special vehicle multifunction control module	√	√	√	√				CD0044, CD0045, CD0046,
B-Class	245	Body	MSS-Special vehicle multifunction control module	√	√	√	√		√		CD0044, CD0045, CD0046,
B-Class	245	Body	N93/4 (Vehicle gateway control	√	√	√					
B-Class	245	Body	OCP-Overhead control panel	√	√	√	√		√		
B-Class	245	Body	SAM-Signal acquisition and actuation module	√	√	√	√				
B-Class	245	Body	System diagnosis(CAN)	√	√	√					
B-Class	245	Body	WSS-Weight sensing system	√	√	√	√			SP0164,	CD0044, CD0045, CD0046,
B-Class	245	Body	XALWA L-Xenon headlamp, left	√	√	√	√		√	SP0215,	
B-Class	245	Body	XALWA R-Xenon headlamp,	√	√	√	√		√		
B-Class	245	Chassis	ES-Electrical power steering	√	√	√	√				CD0213, CD0215, CD0217, CD0218,
B-Class	245	Chassis	ESP-Electronic stability program	√	√	√	√				CD0213, CD0215, CD0217, CD0218,
B-Class	245	Chassis	TPM-Tire pressure monitor	√	√	√	√				
B-Class	245	Chassis	VP-Vacuum pump brake booster	√	√	√	√		√		
B-Class	245	Chassis	VP-Vacuum pump brake booster	√	√	√	√		√		
B-Class	245	Drive	BSA-Belt-driven starter/alternator	√	√	√	√				
B-Class	245	Drive	CDI-Common Rail Diesel	√	√	√					
B-Class	245	Drive	CDI-Common Rail Diesel	√	√	√	√				
B-Class	245	Drive	ESM-Electronic selector module	√	√	√	√		√		

B-Class	245	Drive	FCVT-Continuously variable automatic transmission	√	√	√	√					
B-Class	245	Drive	ME SFI-CNG compressed natural gas	√	√	√	√		√			
B-Class	245	Drive	ME SFI-Gasoline engine control	√	√	√	√		√			
B-Class	245	Drive	ME SFI-Motor electronics	√	√	√	√					
B-Class	245	Drive	ME-Motro electronics CNGCM246 for combustion	√	√	√						
B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√				SP0152,	
B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√				SP0153,	
B-Class	245	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	√	√	√	√					
B-Class	245	Information and communication	ASSYST PLUS-PLUS Active Service System	√	√	√	√					
B-Class	245	Information and communication	ASSYST-Active Service System	√	√	√	√					
B-Class	245	Information and communication	AUDIO	√	√	√	√					
B-Class	245	Information and communication	CDC-CD changer	√	√	√	√					
B-Class	245	Information and communication	CM-Compass module	√	√	√	√					
B-Class	245	Information and communication	COMAND or AUDIO	√	√	√	√					
B-Class	245	Information and communication	COMAND or AUDIO	√	√	√	√					
B-Class	245	Information and communication	CTEL-Cellular telephone	√	√	√	√				SP0161,SP0162,SP0163,	CD0133, CD0134, CD0136,
B-Class	245	Information and communication	CTEL-Cellular telephone(JAPAN)	√	√	√	√				SP0161,SP0162,SP0163,	CD0133, CD0134, CD0136,
B-Class	245	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√					CD0002, CD0004, CD0005, CD0008, CD0015, CD0017, CD0018, CD0019,
B-Class	245	Information and communication	DAB-Digital radio	√	√	√	√					
B-Class	245	Information and communication	IC-Instrument cluster	√	√	√	√		√			CD0048,
B-Class	245	Information and communication	NAVI-Navigation system	√	√	√	√					CD0063, CD0064,

B-Class	245	Information and communication	PTS-Parktronic system	√	√	√	√			SP0157,	CD0082, CD0083, CD0085, CD0086, CD0091, CD009
B-Class	245	Information and communication	PTS-Parktronic system	√	√	√	√				
B-Class	245	Information and communication	SCM [MRM]-Steering column module	√	√	√	√				
B-Class	245	Information and communication	SDAR-Satellite radio	√	√	√	√				
B-Class	245	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√				CD0278, CD0279, CD0280,
B-Class	245	Information and communication	SOUND-Sound system	√	√	√	√				
B-Class	245	Information and communication	TELE AID-Control unit	√	√	√	√				
B-Class	245	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√				
B-Class	245	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√				
B-Class	245	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√				
B-Class	245	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√				
B-Class	245	Information and communication	TV-TV tuner	√	√	√	√			SP0104,SP0105,SP0106, SP0107,SP0108,SP0109, SP0110,SP0111,SP0112, SP0113,SP0114,SP0115,	
B-Class	245	Information and communication	TV-TV tuner	√	√	√	√			SP0104,SP0105,SP0106, SP0107,SP0108,SP0109, SP0110,SP0111,SP0112, SP0113,SP0114,SP0115,	
B-Class	245	Information and communication	UCI-Media interface	√	√	√	√				CD0075,
B-Class	245	Information and communication	VCS-Voice control system	√	√	√	√			SP0158,	
B-Class	245	Seats and Doors	DCM FL-Door control module front left	√	√	√	√	√			CD0173, CD0174, CD0175, CD0176,
B-Class	245	Seats and Doors	DCM FR-Door control module front right	√	√	√	√	√			CD0177, CD0178, CD0179, CD0180,
B-Class	245	Seats and Doors	DCM RL-Door control module rear left	√	√	√	√	√		SP0185,SP0186,SP0187, SP0188,SP0189,SP0190, SP0191,SP0192,SP0193,	

B-Class	245	Seats and Doors	DCM RR-Door control module rear right	√	√	√	√	√	SP0185,SP0186,SP0187,SP0188,SP0189,SP0190,SP0191,SP0192,SP0193,		
C-Class	202	Air conditioning	AAC-Automatic air conditioning	√	√	√					
C-Class	202	Air conditioning	STH-Stationary heater	√	√	√	√				
C-Class	202	Air conditioning	TAC-Automatic temperature	√	√	√	√	√			
C-Class	202	Body	AB-Airbag	√	√	√					
C-Class	202	Body	APS-Auto pilot system	√	√	√	√				
C-Class	202	Body	EZS-Electronic ignition switch	√	√	√	√				
C-Class	202	Body	HB-Heater booster	√	√	√					
C-Class	202	Body	HRA-Headlamp range adjustment	√	√	√					
C-Class	202	Body	LCP-Lower control panel	√	√	√	√				
C-Class	202	Body	MSS-Special vehicle multifunction control module	√	√	√	√				
C-Class	202	Body	OCP-Overhead control panel	√	√	√	√				
C-Class	202	Body	PSE-Pneumatic system equipment	√	√	√	√				
C-Class	202	Body	SAM-Signal acquisition and actuation module	√	√	√	√				
C-Class	202	Chassis	ABS-Antilock brake system	√	√	√	√				
C-Class	202	Chassis	ASR-Acceleration Slip	√	√	√	√				
C-Class	202	Chassis	ASR-Acceleration Slip	√	√	√	√				
C-Class	202	Chassis	BAS-Brake assist	√	√	√	√				
C-Class	202	Chassis	BAS-Brake assist	√	√	√	√		SP0154,		
C-Class	202	Chassis	ESP-Electronic stability program	√	√	√	√		SP0154,		
C-Class	202	Chassis	ESP-Electronic stability program	√	√	√	√		SP0154,		
C-Class	202	Chassis	ESP-Electronic stability program	√	√	√	√		SP0154,		
C-Class	202	Chassis	ESP-Electronic stability program	√	√	√	√				
C-Class	202	Chassis	ETS-Electronic traction system	√	√	√	√				
C-Class	202	Chassis	ETS-Electronic traction system	√	√	√	√				
C-Class	202	Chassis	VP-Vacuum pump brake booster	√	√	√	√	√			
C-Class	202	Drive	CDI-Common Rail Diesel	√	√	√					
C-Class	202	Drive	DFI-Electronic distributor injection system diesel	√	√	√					
C-Class	202	Drive	ESM-Electronic selector module	√	√	√	√				
C-Class	202	Drive	ETC-Electronic transmission	√	√	√	√				
C-Class	202	Drive	ETC-Electronic transmission	√	√	√	√				
C-Class	202	Drive	ETC-Electronic transmission	√	√	√	√				
C-Class	202	Drive	IFI-Electronic in-line injection system diesel	√	√	√					
C-Class	202	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√				

C-Class	202	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
C-Class	202	Drive	ME SFI-Motor electronics	√	√	√	√		√			
C-Class	202	Drive	ME2 SFI-Motor electronics 2	√	√	√	√					
C-Class	202	Information and communication	AUDIO	√	√	√	√					
C-Class	202	Information and communication	CDC-CD changer	√	√	√						
C-Class	202	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√						
C-Class	202	Information and communication	DN-Dynamic navigation by means of CTEL	√	√	√	√					
C-Class	202	Information and communication	E call [Japan]-Emergency call system	√	√	√	√					
C-Class	202	Information and communication	E call [USA]-Emergency call system	√	√	√						
C-Class	202	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√		√		SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,		
C-Class	202	Information and communication	PTS-Parktronic system	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,		
C-Class	202	Information and communication	TELE AID-Emergency call system	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,		
C-Class	202	Information and communication	TELE AID-Telematic system	√	√	√						
C-Class	202	Information and communication	UHI-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	√					
C-Class	202	Information and communication	VCS-Voice control system	√	√	√						

C-Class	202	Seats and Doors	DCM1-Door control module front driver side	√	√	√	√				CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170.
C-Class	202	Seats and Doors	DCM2-Door control module front passenger side	√	√	√	√				CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170.
C-Class	202	Seats and Doors	DCM3-Door control module rear driver side	√	√	√	√				CD0181, CD0182, CD0183,
C-Class	202	Seats and Doors	DCM4-Door control module rear passenger side	√	√	√	√				
C-Class	203	Air conditioning	AAC-Automatic air conditioning	√	√	√	√				CD0026, CD0029, CD0026, CD0027, CD0028, CD0029,
C-Class	203	Air conditioning	STH-Stationary heater	√	√	√	√	√			CD0026, CD0029, CD0026, CD0027, CD0028, CD0029,
C-Class	203	Air conditioning	STH-Stationary heater	√	√	√	√	√			CD0298, CD0299, CD0300, CD0301, CD0302, CD0303,
C-Class	203	Body	AB-Airbag	√	√	√	√				CD0298, CD0299, CD0300, CD0301, CD0302, CD0303,
C-Class	203	Body	AB-Airbag	√	√	√	√				
C-Class	203	Body	AHE-Trailer recognition	√	√	√	√	√			
C-Class	203	Body	AHE-Trailer recognition	√	√	√	√	√			
C-Class	203	Body	CGW-Central gateway	√	√	√					CD0044, CD0045, CD0046,

C-Class	203	Body	EZS-Electronic ignition switch	√	√	√	√				CD0044, CD0045, CD0046,	
C-Class	203	Body	EZS-Electronic ignition switch	√	√	√	√					
C-Class	203	Body	HRA FL-Front left headlamp range control	√	√	√	√					
C-Class	203	Body	HRA FR-Front right headlamp range control	√	√	√	√		√			
C-Class	203	Body	LCP-Lower control panel	√	√	√	√		√			
C-Class	203	Body	MSS-Special vehicle multifunction control module	√	√	√	√					
C-Class	203	Body	OCP-Overhead control panel	√	√	√	√					
C-Class	203	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√					
C-Class	203	Body	SAM F-Signal acquisition and actuation module front	√	√	√	√		√			
C-Class	203	Body	System diagnosis(CAN)	√	√	√						
C-Class	203	Body	UCP-Upper control panel	√	√	√	√			SP0165,	CD0146, CD0149, CD0150	
C-Class	203	Body	WSS-Weight sensing system	√	√	√	√			SP0165,	CD0146, CD0149, CD0150	
C-Class	203	Body	XALWA L-Xenon headlamp, left	√	√	√	√		√	SP0215,		
C-Class	203	Body	XALWA R-Xenon headlamp, right	√	√	√	√		√	SP0215,		
C-Class	203	Chassis	BAS-Brake assist	√	√	√	√					

C-Class	203	Chassis	ESP-Electronic stability program	√	√	√	√				
C-Class	203	Chassis	ESP-Electronic stability program	√	√	√	√		√		CD0212, CD0214, CD0215, CD0216, CD0217,
C-Class	203	Chassis	ESP-Electronic stability program	√	√	√	√				CD0212, CD0214, CD0215, CD0216, CD0217,
C-Class	203	Chassis	VP-Vacuum pump brake booster	√	√	√	√		√		
C-Class	203	Drive	CDI 2-Common Rail Diesel	√	√	√	√		√		
C-Class	203	Drive	CDI 2-Common Rail Diesel	√	√	√	√		√		
C-Class	203	Drive	CDI 3-Common Rail Diesel	√	√	√	√		√		
C-Class	203	Drive	CDI 3-Common Rail Diesel	√	√	√	√		√		
C-Class	203	Drive	CDI 3-Common Rail Diesel	√	√	√	√		√		
C-Class	203	Drive	CDI 4-Common Rail Diesel	√	√	√	√				
C-Class	203	Drive	DTR-Distronic	√	√	√	√				
C-Class	203	Drive	ESM-Electronic selector module	√	√	√	√		√		
C-Class	203	Drive	ETC-Electronic transmission	√	√	√	√				
C-Class	203	Drive	ETC-Electronic transmission	√	√	√	√				
C-Class	203	Drive	ETC-Electronic transmission	√	√	√	√				
C-Class	203	Drive	ETC-Electronic transmission	√	√	√	√				
C-Class	203	Drive	ME 9.7-Motor electronics 9.7	√	√	√	√		√		
C-Class	203	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√				
C-Class	203	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√				
C-Class	203	Drive	ME SFI-Motor electronics	√	√	√	√		√		
C-Class	203	Drive	ME SFI-Motor electronics	√	√	√	√				
C-Class	203	Drive	ME SFI-Motor electronics	√	√	√	√				
C-Class	203	Drive	SEQ-Sequentronic automated manual transmission	√	√	√	√			SP0154,SP0153,SP0154,	
C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√			SP0154,SP0153,SP0154,	
C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√			SP0154,SP0153,SP0154,	
C-Class	203	Information and communication	AUDIO	√	√	√	√				
C-Class	203	Information and communication	AUDIO	√	√	√	√				
C-Class	203	Information and communication	CDC-CD changer	√	√	√					
C-Class	203	Information and communication	CDC-CD changer	√	√	√	√				CD0073,


C-Class	203	Information and communication	COMAND	√	√	√	√		√			CD0073,	
C-Class	203	Information and communication	COMAND or AUDIO	√	√	√	√					CD0073,	
C-Class	203	Information and communication	COMAND or AUDIO	√	√	√	√					CD0074,	
C-Class	203	Information and communication	CTEL over K-wire-Telematic system	√	√	√							
C-Class	203	Information and communication	CTEL-Cellular telephone	√	√	√	√						
C-Class	203	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√							
C-Class	203	Information and communication	CTEL-Cellular telephone(JAPAN)	√	√	√	√						
C-Class	203	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√						
C-Class	203	Information and communication	D2B-COMAND, MCS or AUDIO	√	√	√	√						
C-Class	203	Information and communication	DAB-Digital radio	√	√	√	√						
C-Class	203	Information and communication	E call [Japan]-Emergency call system	√	√	√	√					CD0007, CD0008, CD0011, CD0012, CD0016, CD0018, CD0021, CD0024, CD0009, CD0010, CD0013, CD0015, CD0025	
C-Class	203	Information and communication	E call [Japan]-Telematic system	√	√	√	√		√			CD0007, CD0008, CD0011, CD0012, CD0016, CD0018, CD0021, CD0024, CD0009, CD0010, CD0013, CD0015, CD0025	
C-Class	203	Information and communication	E call [USA]-Telematic system	√	√	√	√						
C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√		√				
C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√		√			CD0054, CD0055, CD0057, CD0061,	

C-Class	203	Information and communication	NAVI-Navigation system	√	√	√	√				CD0077, CD0078, CD0079, CD0080, CD0082, CD0084, CD0085, CD0086, CD0087, CD0095, CD0096, CD0101, CD0102, CD0103, CD0105, CD0107, CD0108, CD0109, CD0111, CD0113, CD0116, CD0117, CD0118, CD0119, CD0120, CD0122, CD0126
C-Class	203	Information and communication	NAVI-Navigation system	√	√	√	√				CD0077, CD0078, CD0079, CD0080, CD0082, CD008
C-Class	203	Information and communication	PTS-Parktronic system	√	√	√	√				
C-Class	203	Information and communication	PTS-Parktronic system	√	√	√	√				
C-Class	203	Information and communication	SCM [MRM]-Steering column module	√	√	√	√				
C-Class	203	Information and communication	SCM [MRM]-Steering column module	√	√	√	√				
C-Class	203	Information and communication	SDAR-Satellite radio	√	√	√					
C-Class	203	Information and communication	SDAR-Satellite radio	√	√	√	√				
C-Class	203	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√				
C-Class	203	Information and communication	SOUND-Sound system	√	√	√	√				
C-Class	203	Information and communication	SOUND-Sound system	√	√	√	√				
C-Class	203	Information and communication	TELE AID-Control unit	√	√	√	√				CD0289, CD0290, CD0291,
C-Class	203	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√				
C-Class	203	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√				

C-Class	203	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√					
C-Class	203	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√					
C-Class	203	Information and communication	TELE AID-Telematic system	√	√	√	√					
C-Class	203	Information and communication	TV-TV tuner	√	√	√	√			SP0021,SP0026,SP0032,		
C-Class	203	Information and communication	TV-TV tuner	√	√	√	√			SP0021,SP0026,SP0032,		
C-Class	203	Information and communication	UCI-Media interface	√	√	√				SP0021,SP0026,SP0032,		
C-Class	203	Information and communication	UHI-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	√			SP0035,SP0036,SP0037, SP0038,SP0039,SP0040, SP0041,SP0042,SP0043, SP0044,		
C-Class	203	Information and communication	VCS-Voice control system	√	√	√				SP0127,		
C-Class	203	Information and communication	VCS-Voice control system	√	√	√				SP0132,SP0135,SP0136, SP0137,SP0138,SP0139, SP0140,SP0141,SP0142, SP0143,SP0144,SP0145, SP0150,SP0130,SP0131, SP0133,SP0134,SP0146, SP0147,SP0148,SP0149,		
C-Class	203	Seats and Doors	DCM FL-Door control module front left	√	√	√	√			SP0132,SP0135,SP0136, SP0137,SP0138,SP0139, SP0140,SP0141,SP0142, SP0143,SP0144,SP0145, SP0150,SP0130,SP0131, SP0133,SP0134,SP0146, SP0147,SP0148,SP0149,		

C-Class	203	Seats and Doors	DCM FR-Door control module front right	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0136,SP0138,SP0139,SP0146,SP0147,SP0148,SP0149,		
C-Class	203	Seats and Doors	DCM RL-Door control module rear left	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,		
C-Class	203	Seats and Doors	DCM RR-Door control module rear right	√	√	√	√				CD0075,	
C-Class	203	Seats and Doors	ESA driver-Electric seat adjustment driver	√	√	√	√				CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170,	
C-Class	203	Seats and Doors	ESA driver-Electric seat adjustment driver	√	√	√	√	√			CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170,	
C-Class	203	Seats and Doors	ESA driver-Electric seat adjustment driver (with memory)	√	√	√	√	√		SP0178,SP0179,SP0180,SP0181,SP0182,SP0183,SP0184,	CD0171,	
C-Class	203	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√	√			CD0181, CD0182, CD0183, CD0183, CD0183,	
C-Class	203	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√	√			CD0181, CD0182, CD0183, CD0183, CD0183,	
C-Class	203	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√	√			CD0181, CD0182, CD0183, CD0183, CD0183,	
CL-Class	215	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	√				

CL-Class	215	Air conditioning	LRH-Steering wheel heater	√	√	√	√	√			CD0298, CD0299, CD0300, CD0301, CD0302, CD0303.
CL-Class	215	Air conditioning	REAR AC-Rear air conditioning	√	√	√	√	√			CD0298, CD0299, CD0300, CD0301, CD0302, CD0303.
CL-Class	215	Air conditioning	STH-Stationary heater	√	√	√	√				
CL-Class	215	Air conditioning	STH-Stationary heater	√	√	√	√	√			
CL-Class	215	Air conditioning	STH-Stationary heater	√	√	√	√				
CL-Class	215	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√	√			
CL-Class	215	Body	AB-Airbag	√	√	√	√				
CL-Class	215	Body	AB-Airbag	√	√	√	√				
CL-Class	215	Body	AHE-Trailer recognition	√	√	√	√	√			
CL-Class	215	Body	CGW-Central gateway	√	√	√					
CL-Class	215	Body	EZS-Electronic ignition switch	√	√	√	√				



CL-Class	215	Body	EZS-Electronic ignition switch	√	√	√	√					
CL-Class	215	Body	EZS-Electronic ignition switch	√	√	√	√					
CL-Class	215	Body	HRA FL-Front left headlamp range control	√	√	√	√					
CL-Class	215	Body	HRA FR-Front right headlamp range control	√	√	√	√	√				
CL-Class	215	Body	HRA-Headlamp range adjustment	√	√	√	√	√				
CL-Class	215	Body	KG-Keyless Go	√	√	√	√	√		SP0165,	CD0145, CD0147, CD0148, CD0152,	
CL-Class	215	Body	MSS-Special vehicle multifunction control module	√	√	√	√	√		SP0165,	CD0145, CD0147, CD0148, CD0152,	
CL-Class	215	Body	OCP-Overhead control panel	√	√	√	√	√				
CL-Class	215	Body	OCP-Overhead control panel	√	√	√	√	√				
CL-Class	215	Body	PSE-Pneumatic system equipment	√	√	√	√	√				

CL-Class	215	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√		√			
CL-Class	215	Body	SAM FL-Front left signal acquisition and actuation module	√	√	√	√		√			
CL-Class	215	Body	SAM FR-Front right signal acquisition and actuation module	√	√	√	√		√			
CL-Class	215	Body	System diagnosis(CAN)	√	√	√						
CL-Class	215	Body	UCP-Upper control panel	√	√	√	√		√			
CL-Class	215	Body	UCP-Upper control panel	√	√	√	√		√			
CL-Class	215	Chassis	ABC-ABC active body control	√	√	√	√		√			
CL-Class	215	Chassis	ESP-Electronic stability program	√	√	√	√		√			
CL-Class	215	Chassis	TPM-Tire pressure monitor	√	√	√	√		√			
CL-Class	215	Drive	DTR-Distronic	√	√	√	√					
CL-Class	215	Drive	DTR-Distronic	√	√	√	√					
CL-Class	215	Drive	ESM-Electronic selector module	√	√	√	√		√			
CL-Class	215	Drive	ETC-Electronic transmission	√	√	√	√					
CL-Class	215	Drive	ETC-Electronic transmission	√	√	√	√					
CL-Class	215	Drive	ETC-Electronic transmission	√	√	√	√					
CL-Class	215	Drive	ME SFI 2.0-Motor electronics 2.0	√	√	√	√		√			
CL-Class	215	Drive	ME SFI 2.0-Motor electronics 2.0	√	√	√	√		√			
CL-Class	215	Drive	ME SFI 2.7-Motor electronics 2.7	√	√	√	√				CD0293, CD0294,	
CL-Class	215	Drive	ME SFI 2.7.1-Motor electronics	√	√	√	√					
CL-Class	215	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√			SP0005,SP0006,SP0007,		
CL-Class	215	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
CL-Class	215	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√				CD0223,	
CL-Class	215	Information and communication	AUDIO	√	√	√	√					
CL-Class	215	Information and communication	AUDIO	√	√	√	√					
CL-Class	215	Information and communication	CDC-CD changer	√	√	√						
CL-Class	215	Information and communication	CDC-CD changer	√	√	√	√					
CL-Class	215	Information and communication	COMAND	√	√	√	√		√			
CL-Class	215	Information and communication	COMAND or AUDIO	√	√	√	√					
CL-Class	215	Information and communication	CTEL over K-wire-Telematic system	√	√	√						
CL-Class	215	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√						

CL-Class	215	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√			SP0162,SP0174,		
CL-Class	215	Information and communication	CTEL-Telecommunication for telematics services	√	√	√	√					
CL-Class	215	Information and communication	DN-Dynamic navigation by means of CTEL	√	√	√	√					
CL-Class	215	Information and communication	E call [Japan]-Emergency call system	√	√	√	√					
CL-Class	215	Information and communication	E call [Japan]-Telematic system	√	√	√	√		√			
CL-Class	215	Information and communication	E call [USA]-Emergency call system	√	√	√						
CL-Class	215	Information and communication	E call [USA]-Telematic system	√	√	√	√				CD0008, CD0012, CD0013, CD0016, CD0017, CD0018, CD0003, CD0006, CD0010, CD0012, CD0014, CD0019, CD0022, CD0023, CD0025	
CL-Class	215	Information and communication	GPS box	√	√	√	√				CD0008, CD0012, CD0013, CD0016, CD0017, CD0018, CD0003, CD0006, CD0010, CD0012, CD0014, CD0019, CD0022, CD0023, CD0025	
CL-Class	215	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√		√		CD0031,	
CL-Class	215	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√		√		CD0047, CD0055, CD0058,	
CL-Class	215	Information and communication	NAVI-Navigation system	√	√	√	√				CD0047, CD0055, CD0058,	

CL-Class	215	Information and communication	PTS-Parktronic system	√	√	√	√	√	CD0076, CD0077, CD0078, CD0081, CD0082, CD0085, CD0087, CD0089, CD0090, CD0092, CD0093, CD0095, CD0096, CD0097, CD0098, CD0099, CD0100, CD0102, CD0103, CD0105, CD0107, CD0108, CD0111, CD0113, CD0115, CD0117, CD0118, CD0119, CD0122, CD0123, CD0126
CL-Class	215	Information and communication	SCM [MRM]-Steering column module	√	√	√	√	√	CD0076, CD0077, CD0078, CD0081, CD0082, CD0085, CD0087, CD0089, CD0090, CD0092, CD0093, CD0095, CD0096, CD0097, CD0098, CD0099, CD0100, CD0102, CD0103, CD0105, CD0107, CD0108, CD0111, CD0113, CD0115, CD0117, CD0118, CD0119, CD0122, CD0123, CD0126

CL-Class	215	Information and communication	SCM [MRM]-Steering column module	√	√	√	√	√	CD0076, CD0077, CD0078, CD0081, CD0082, CD0085, CD0087, CD0089, CD0090, CD0092, CD0093, CD0095, CD0096, CD0097, CD0098, CD0099, CD0100, CD0102, CD0103, CD0105, CD0107, CD0108, CD0111, CD0113, CD0115, CD0117, CD0118, CD0119, CD0122, CD0123, CD0126
CL-Class	215	Information and communication	SDAR-Satellite radio	√	√	√			
CL-Class	215	Information and communication	SDAR-Satellite radio	√	√	√	√		
CL-Class	215	Information and communication	SOUND-Bose sound system	√	√	√	√		
CL-Class	215	Information and communication	SOUND-Sound system	√	√	√	√		
CL-Class	215	Information and communication	TELE AID-Control unit	√	√	√	√		
CL-Class	215	Information and communication	TELE AID-Emergency call system	√	√	√	√		
CL-Class	215	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√		
CL-Class	215	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	√	√	√	√		CD0201, CD0202, CD0203, CD0204, CD0205, CD0206, CD0207, CD0208, CD0209, CD0210, CD0211
CL-Class	215	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√		
CL-Class	215	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√		CD0243, CD0245, CD0250, CD0251,
CL-Class	215	Information and communication	TELE AID-Telematic system	√	√	√	√		

CL-Class	215	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	√	√	√	√					
CL-Class	215	Information and communication	TV-TV tuner	√	√	√	√					
CL-Class	215	Information and communication	TV-TV tuner	√	√	√	√			SP0127,		
CL-Class	215	Information and communication	TV-TV tuner(AGW)	√	√	√	√			SP0127,		
CL-Class	215	Information and communication	UHI-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,		
CL-Class	215	Information and communication	VCS-Voice control system	√	√	√				SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,		
CL-Class	215	Information and communication	VCS-Voice control system	√	√	√				SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,		
CL-Class	215	Seats and Doors	DCM FL-Door control module front left	√	√	√	√		√			
CL-Class	215	Seats and Doors	DCM FR-Door control module front right	√	√	√	√		√			CD0162, CD0163, CD0164,
CL-Class	215	Seats and Doors	ESA FL-Electric seat adjustment front left	√	√	√	√					CD0162, CD0163, CD0164,

CL-Class	215	Seats and Doors	ESA FR-Electric seat adjustment front right	√	√	√	√				
CL-Class	215	Seats and Doors	OSB FL-Multicontour backrest front left	√	√	√	√				
CL-Class	215	Seats and Doors	OSB FR-Multicontour backrest front right	√	√	√	√				CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170.
CL-Class	215	Seats and Doors	RCM-Rear control module	√	√	√	√				CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170.
CL-Class	216	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	√			
CL-Class	216	Air conditioning	STH-Stationary heater with remote control	√	√	√	√	√			
CL-Class	216	Body	AB-Airbag	√	√	√	√				CD0040, CD0041, CD0042, CD0043,
CL-Class	216	Body	AHE-Trailer recognition	√	√	√	√	√			CD0040, CD0041, CD0042, CD0043,
CL-Class	216	Body	BNS-Vehicle power supply control module	√	√	√	√	√			
CL-Class	216	Body	CGW-Central gateway	√	√	√	√				
CL-Class	216	Body	COU [ZBE]-Central operating	√	√	√	√	√			
CL-Class	216	Body	Dr side SAM-Driver signal acquisition and actuation module	√	√	√	√	√			CD0139,
CL-Class	216	Body	EZS-Electronic ignition switch	√	√	√	√				
CL-Class	216	Body	EZS-Electronic ignition switch	√	√	√	√			SP0215,	
CL-Class	216	Body	KG-KEYLESS GO	√	√	√	√				
CL-Class	216	Body	KG-Keyless Go	√	√	√	√				CD0215, CD0217,
CL-Class	216	Body	OCP-Overhead control panel	√	√	√	√	√			CD0219, CD0220, CD0221, CD0222,

CL-Class	216	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√					
CL-Class	216	Body	SGR-Radar sensors control unit	√	√	√						
CL-Class	216	Body	System diagnosis(CAN)	√	√	√						
CL-Class	216	Body	UCP-Upper control panel	√	√	√	√		√			
CL-Class	216	Body	WSS-Weight sensing system	√	√	√	√					
CL-Class	216	Body	XALWA L-Xenon headlamp, left	√	√	√	√					
CL-Class	216	Body	XALWA L-Xenon headlamp, left	√	√	√	√					
CL-Class	216	Body	XALWA L-Xenon headlamp, left	√	√	√	√		√			
CL-Class	216	Body	XALWA R-Xenon headlamp,	√	√	√	√					
CL-Class	216	Body	XALWA R-Xenon headlamp,	√	√	√	√					
CL-Class	216	Body	XALWA R-Xenon headlamp,	√	√	√	√		√			
CL-Class	216	Chassis	ABC-ABC active body control	√	√	√	√		√			
CL-Class	216	Chassis	ABR-Adaptive Brake	√	√	√	√					
CL-Class	216	Chassis	ABR-Adaptive Brake	√	√	√	√		√			
CL-Class	216	Chassis	AIRmatic	√	√	√	√		√			
CL-Class	216	Chassis	DTR-Distronic	√	√	√	√				SP0002,SP0003,SP0004, SP0005,SP0006,SP0007,	
CL-Class	216	Chassis	EHPS-Electrohydraulic Power Steering	√	√	√	√				SP0009,SP0011,SP0012,	
CL-Class	216	Chassis	EPB-Electric parking brake	√	√	√	√		√		SP0009,SP0011,SP0012,	
CL-Class	216	Chassis	TPM-Tire pressure monitor	√	√	√	√		√			
CL-Class	216	Chassis	TPM-Tire pressure monitor	√	√	√	√		√			
CL-Class	216	Drive	DTR-Distronic	√	√	√	√				CD0065,	
CL-Class	216	Drive	ETC-Electronic transmission	√	√	√	√					
CL-Class	216	Drive	ETC-Electronic transmission	√	√	√	√					
CL-Class	216	Drive	FSCU-Fuel pump	√	√	√						
CL-Class	216	Drive	FSCU-Fuel pump	√	√	√						
CL-Class	216	Drive	FSCU-Fuel pump	√	√	√	√					
CL-Class	216	Drive	FSCU-Fuel pump	√	√	√						
CL-Class	216	Drive	FSCU-Fuel pump AMG	√	√	√						
CL-Class	216	Drive	ISM-Intelligent servo module	√	√	√	√				CD0132,	
CL-Class	216	Drive	ISM-Shift module	√	√	√	√				CD0132,	
CL-Class	216	Drive	ME 2.7.2-Motor electronics 2.7.2	√	√	√	√					
CL-Class	216	Drive	ME 2.7.2-Motor electronics 2.7.2	√	√	√	√					
CL-Class	216	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	√	√	√	√		√			
CL-Class	216	Drive	ME 9.7-Motor electronics 9.7	√	√	√	√		√			
CL-Class	216	Drive	MED 17.7-Motor electronics for direct injection 17.7	√	√	√	√				CD0133, CD0134, CD0135, CD0136, CD0159,	

CL-Class	216	Drive	SGR-Radar sensors control unit	√	√	√	√	√			
CL-Class	216	Information and communication	ASSYST PLUS	√	√	√	√				CD0001, CD0002, CD0007, CD0008, CD0015, CD0017, CD0018,
CL-Class	216	Information and communication	ASSYST-Active Service System	√	√	√	√				
CL-Class	216	Information and communication	COMAND	√	√	√	√	√			
CL-Class	216	Information and communication	COMAND	√	√	√	√	√			CD0049, CD0050, CD0053, CD0056, CD0057, CD005
CL-Class	216	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√	√			
CL-Class	216	Information and communication	DAB-Digital radio	√	√	√	√				
CL-Class	216	Information and communication	IC-Instrument cluster	√	√	√	√				
CL-Class	216	Information and communication	ICI-InCar Internet	√	√	√	√				
CL-Class	216	Information and communication	MFK-Multifunction camera	√	√	√	√				CD0200,
CL-Class	216	Information and communication	NSA-Night View Assist	√	√	√	√	√			CD0257, CD0263, CD0264, CD0267, CD0268, CD0269, CD0270, CD0273, CD0276,
CL-Class	216	Information and communication	PTS-PARKTRONIC	√	√	√	√	√			CD0235, CD0236, CD0242, CD0246, CD0251, CD025
CL-Class	216	Information and communication	PTS-Parktronic system	√	√	√	√	√			
CL-Class	216	Information and communication	RFK-Backup camera	√	√	√	√				
CL-Class	216	Information and communication	SCM [MRM]-Steering column module	√	√	√	√	√			
CL-Class	216	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√				
CL-Class	216	Information and communication	TELE AID-Control unit	√	√	√	√				
CL-Class	216	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√				
CL-Class	216	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√				

CL-Class	216	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√					
CL-Class	216	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√					
CL-Class	216	Information and communication	Tuner-Standard tuner	√	√	√	√					
CL-Class	216	Information and communication	Tuner-Tuner sound	√	√	√	√					
CL-Class	216	Information and communication	Tuner-Tuner sound	√	√	√	√					
CL-Class	216	Information and communication	TV-TV tuner(AGW)	√	√	√	√			SP0132,SP0135,SP0136, SP0138,SP0139,SP0140, SP0141,SP0142,SP0143, SP0144,SP0145,SP0150, SP0130,SP0131,SP0132, SP0133,SP0134,SP0136, SP0138,SP0139,SP0140, SP0141,SP0142,SP0143, SP0144,SP0145,SP0146, SP0147,SP0148,SP0149,		
CL-Class	216	Information and communication	TV-TV tuner(AGW)	√	√	√	√			SP0132,SP0135,SP0136, SP0138,SP0139,SP0140, SP0141,SP0142,SP0143, SP0144,SP0145,SP0150, SP0130,SP0131,SP0132, SP0133,SP0134,SP0136, SP0138,SP0139,SP0140, SP0141,SP0142,SP0143, SP0144,SP0145,SP0146, SP0147,SP0148,SP0149,		
CL-Class	216	Information and communication	UCI-Media interface	√	√	√	√					
CL-Class	216	Information and communication	VCS-Voice control	√	√	√	√				CD0131,	
CL-Class	216	Information and communication	ZAN-Central display	√	√	√	√		√			
CL-Class	216	Seats and Doors	DCM FL-Door control module front left	√	√	√	√		√			
CL-Class	216	Seats and Doors	DCM FR-Door control module front right	√	√	√	√		√			
CL-Class	216	Seats and Doors	DS LF-Left front dynamic seat	√	√	√	√					
CL-Class	216	Seats and Doors	DS RF-Right front dynamic seat	√	√	√	√					
CL-Class	216	Seats and Doors	DSP-Pneumatic pump for dynamic seat	√	√	√	√					

CL-Class	216	Seats and Doors	ESA FL-Electric seat adjustment front left	√	√	√	√		√			
CL-Class	216	Seats and Doors	ESA FR-Electric seat adjustment front right	√	√	√	√		√	SP0178,SP0179,SP0180,SP0181,SP0182,SP0183,SP0184,	CD0171,	
CL-Class	216	Seats and Doors	RCM-Rear control module	√	√	√	√					
CL-Class	216	Seats and Doors	TLC-Trunk lid control	√	√	√	√			SP0199,SP0200,SP0201,SP0202,SP0203,SP0204,SP0205,SP0206,	CD0184, CD0185, CD0186, CD0187,	
CL-Class	216	Seats and Doors	TLC-Trunk lid control	√	√	√	√		√			
CL-Class	X 164	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		√		CD0026, CD0029, CD0026, CD0027, CD0028, CD002	
CL-Class	X 164	Air conditioning	LRH-Steering wheel heater	√	√	√	√		√		CD0026, CD0029, CD0026, CD0027, CD0028, CD0029,	
CL-Class	X 164	Air conditioning	STH-Stationary heater with remote control	√	√	√	√		√			
CL-Class	X 164	Body	AB-Airbag	√	√	√	√					
CL-Class	X 164	Body	CGW-Central gateway	√	√	√	√				CD0298, CD0299, CD0300, CD0301, CD0302, CD030	
CL-Class	X 164	Body	EZS-Electronic ignition switch	√	√	√	√					
CL-Class	X 164	Body	EZS-Electronic ignition switch	√	√	√	√					
CL-Class	X 164	Body	HBF-Rear control field	√	√	√	√		√			
CL-Class	X 164	Body	HRA-Automatic headlamp range adjustment and headlamp control	√	√	√	√		√			
CL-Class	X 164	Body	KG-Keyless Go	√	√	√	√				CD0044, CD0045, CD0046,	
CL-Class	X 164	Body	KG-KEYLESS GO	√	√	√	√				CD0044, CD0045, CD0046,	
CL-Class	X 164	Body	OCP-Overhead control panel	√	√	√	√		√			

CL-Class	X 164	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√					
CL-Class	X 164	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
CL-Class	X 164	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
CL-Class	X 164	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
CL-Class	X 164	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
CL-Class	X 164	Body	SAM F-Signal acquisition and actuation module front	√	√	√	√		√		CD0139, CD0140,	
CL-Class	X 164	Body	System diagnosis(CAN)	√	√	√				SP0215,		
CL-Class	X 164	Body	WSS-Weight sensing system	√	√	√	√					
CL-Class	X 164	Body	XALWA L-Xenon headlamp, left	√	√	√	√				CD0212, CD0214, CD0215, CD0216, CD0217,	
CL-Class	X 164	Body	XALWA L-Xenon headlamp, left	√	√	√	√	√			CD0212, CD0214, CD0215, CD0216, CD0217,	
CL-Class	X 164	Body	XALWA R-Xenon headlamp,	√	√	√	√					
CL-Class	X 164	Body	XALWA R-Xenon headlamp,	√	√	√	√		√			
CL-Class	X 164	Chassis	DTR-Distronic	√	√	√	√					
CL-Class	X 164	Chassis	EHPS-Electrohydraulic Power Steering	√	√	√	√					
CL-Class	X 164	Chassis	ESP-Electronic stability program	√	√	√	√					
CL-Class	X 164	Chassis	Suspension	√	√	√	√		√			
CL-Class	X 164	Chassis	TPM-Tire pressure monitor	√	√	√	√					
CL-Class	X 164	Chassis	TPM-Tire pressure monitor	√	√	√	√					
CL-Class	X 164	Drive	CDI 4-Common Rail Diesel	√	√	√	√	√				
CL-Class	X 164	Drive	CDI 5-Common Rail Diesel	√	√	√	√	√				
CL-Class	X 164	Drive	CDI 6-Common Rail Diesel	√	√	√		√				
CL-Class	X 164	Drive	CDI 60LS-Common Rail Diesel Injection	√	√	√		√				
CL-Class	X 164	Drive	CDI 6BIN5-Common Rail Diesel Injection	√	√	√		√				
CL-Class	X 164	Drive	DTR-Distronic	√	√	√	√					
CL-Class	X 164	Drive	ETC-Electronic transmission	√	√	√	√				CD0293, CD0294,	
CL-Class	X 164	Drive	FSCU-Fuel pump	√	√	√						
CL-Class	X 164	Drive	HAQ-Interwheel differential lock at rear axle	√	√	√	√			SP0127,		
CL-Class	X 164	Drive	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					

CL-Class	X 164	Drive	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	√			SP0153,SP0154,	CD0066, CD0067, CD0068,	
CL-Class	X 164	Drive	ISM-Intelligent servo module	√	√	√	√			SP0254,SP0255,SP0256,		
CL-Class	X 164	Drive	ISM-Shift module	√	√	√	√					
CL-Class	X 164	Drive	ME 9.7-Motor electronics 9.7	√	√	√	√	√	√			
CL-Class	X 164	Drive	SCR-Selective Catalytic	√	√	√	√		√			
CL-Class	X 164	Drive	VG-Transfer case	√	√	√			√	√		
CL-Class	X 164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√					
CL-Class	X 164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√					
CL-Class	X 164	Information and communication	ASSYST PLUS-PLUS Active Service System	√	√	√	√					
CL-Class	X 164	Information and communication	ASSYST-Active Service System	√	√	√	√				CD0295, CD0296, CD0297,	
CL-Class	X 164	Information and communication	AUDIO	√	√	√	√				CD0295, CD0296, CD0297,	
CL-Class	X 164	Information and communication	AVE H-Rear audio video unit	√	√	√	√					
CL-Class	X 164	Information and communication	AVE H-Rear audio video unit	√	√	√	√					
CL-Class	X 164	Information and communication	CDC-CD changer	√	√	√	√					
CL-Class	X 164	Information and communication	CM-Compass module	√	√	√	√					
CL-Class	X 164	Information and communication	COMAND or AUDIO	√	√	√	√			SP0161,SP0170,SP0162, SP0163,	CD0133, CD0155, CD0159, CD0160	
CL-Class	X 164	Information and communication	COMAND or AUDIO	√	√	√	√					
CL-Class	X 164	Information and communication	CTEL-Cellular telephone	√	√	√	√					
CL-Class	X 164	Information and communication	CTEL-Cellular telephone(JAPAN)	√	√	√	√			SP0001,	CD0001, CD0002, CD0003, CD0007, CD0008, CD0011, CD0015, CD0017, CD0018, CD0020.	
CL-Class	X 164	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√				CD0050, CD0051, CD0052,	

CL-Class	X 164	Information and communication	DAB-Digital radio	√	√	√	√				CD0091, CD0107, CD0109, CD0124, CD0091, CD0107,	
CL-Class	X 164	Information and communication	IC-Instrument cluster	√	√	√	√		√		CD0091, CD0107, CD0109, CD0124, CD0091, CD0107,	
CL-Class	X 164	Information and communication	Left rear screen	√	√	√	√					
CL-Class	X 164	Information and communication	NAVI-Navigation system	√	√	√	√				CD0137, CD0137,	
CL-Class	X 164	Information and communication	PTS-Parktronic system	√	√	√	√				CD0137, CD0137,	
CL-Class	X 164	Information and communication	PTS-Parktronic system	√	√	√	√			SP0176,SP0177,	CD0161,	
CL-Class	X 164	Information and communication	RFK-Backup camera	√	√	√	√					
CL-Class	X 164	Information and communication	Right rear screen	√	√	√	√					
CL-Class	X 164	Information and communication	SCM [MRM]-Steering column module	√	√	√	√		√			
CL-Class	X 164	Information and communication	SDAR-Satellite radio	√	√	√	√					
CL-Class	X 164	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√				CD0229,	
CL-Class	X 164	Information and communication	SOUND-Sound system	√	√	√	√				CD0234, CD0238, CD0239, CD0240, CD0241, CD0244, CD0248, CD0249, CD0252, CD0255.	
CL-Class	X 164	Information and communication	TELE AID-Control unit	√	√	√	√					
CL-Class	X 164	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√					
CL-Class	X 164	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√					
CL-Class	X 164	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√					
CL-Class	X 164	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√			SP0226,		
CL-Class	X 164	Information and communication	TV-TV tuner	√	√	√	√			SP0226,		

CL-Class	X 164	Information and communication	TV-TV tuner	√	√	√	√				CD0292,	
CL-Class	X 164	Information and communication	TV-TV tuner	√	√	√				SP0035,SP0036,SP0037,SP0038,SP0039,SP0040,SP0041,SP0042,SP0043,SP0044,		
CL-Class	X 164	Information and communication	TV-TV tuner	√	√	√	√					
CL-Class	X 164	Information and communication	TV-TV tuner(AGW)	√	√	√	√					
CL-Class	X 164	Information and communication	UCI-Media interface	√	√	√				SP0058,SP0059,SP0060,SP0061,SP0062,SP0063,SP0064,SP0065,SP0066,SP0067,SP0068,SP0069,SP0070,SP0071,SP0072,SP0073,SP0074,SP0075,		
CL-Class	X 164	Information and communication	VCS-Voice control system	√	√	√						
CL-Class	X 164	Seats and Doors	DCM FL-Door control module front left	√	√	√	√	√		SP0127,		
CL-Class	X 164	Seats and Doors	DCM FR-Door control module front right	√	√	√	√	√		SP0130,SP0131,SP0132,SP0133,SP0134,SP0136,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0146,SP0147,SP0148,SP0149,		
CL-Class	X 164	Seats and Doors	DS LF-Left front dynamic seat	√	√	√	√	√				
CL-Class	X 164	Seats and Doors	DS RF-Right front dynamic seat	√	√	√	√	√				
CL-Class	X 164	Seats and Doors	DSP-Pneumatic pump for dynamic seat	√	√	√	√					
CL-Class	X 164	Seats and Doors	ERA-Electric fold-down backrest system (3rd seat row)	√	√	√	√	√				
CL-Class	X 164	Seats and Doors	ESA driver-Electric seat adjustment driver (with memory)	√	√	√	√					
CL-Class	X 164	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√					
CL-Class	X 164	Seats and Doors	HS-Seat heater	√	√	√	√	√		SP0178,SP0179,SP0180,SP0181,SP0182,SP0183,SP0184,	CD0171,	
CL-Class	X 164	Seats and Doors	REDC-Rear end door closing control module	√	√	√	√	√			CD0281, CD0282, CD0283, CD0284,	

CL-Class	X 164	Seats and Doors	REDC-Rear end door closing control module	√	√	√	√		√			
CLK-Class	208	Air conditioning	AAC-Automatic air conditioning	√	√	√						
CLK-Class	208	Air conditioning	STH-Stationary heater	√	√	√	√					
CLK-Class	208	Air conditioning	TAC-Automatic temperature control	√	√	√	√		√			
CLK-Class	208	Body	AB-Airbag	√	√	√						
CLK-Class	208	Body	APS-Auto pilot system	√	√	√	√					
CLK-Class	208	Body	EZS-Electronic ignition switch	√	√	√	√					
CLK-Class	208	Body	HRA-Headlamp range adjustment	√	√	√						
CLK-Class	208	Body	HRA-Headlamp range adjustment	√	√	√	√					
CLK-Class	208	Body	LCP-Lower control panel	√	√	√	√				SP0165,	
CLK-Class	208	Body	OCP-Overhead control panel	√	√	√	√				SP0165,	
CLK-Class	208	Body	PSE-Pneumatic system equipment	√	√	√	√					
CLK-Class	208	Body	RVC-Rollover bar soft top control module	√	√	√	√		√			
CLK-Class	208	Body	SAM-Signal acquisition and actuation module	√	√	√	√					
CLK-Class	208	Chassis	ABS-Antilock brake system	√	√	√	√					
CLK-Class	208	Chassis	ASR-Acceleration Slip Regulation	√	√	√	√					
CLK-Class	208	Chassis	BAS-Brake assist	√	√	√	√					
CLK-Class	208	Chassis	BAS-Brake assist	√	√	√	√					
CLK-Class	208	Chassis	ESP-Electronic stability program	√	√	√	√					
CLK-Class	208	Chassis	ESP-Electronic stability program	√	√	√	√					
CLK-Class	208	Chassis	VP-Vacuum pump brake booster	√	√	√	√		√			
CLK-Class	208	Drive	ESM-Electronic selector module	√	√	√	√					
CLK-Class	208	Drive	ETC-Electronic transmission control	√	√	√	√				SP0154,	
CLK-Class	208	Drive	ETC-Electronic transmission control	√	√	√					SP0154,	

CLK-Class	208	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
CLK-Class	208	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
CLK-Class	208	Drive	ME SFI-Motor electronics	√	√	√	√		√			
CLK-Class	208	Drive	ME2 SFI-Motor electronics 2	√	√	√	√					
CLK-Class	208	Drive	SEQ-Sequentronic automated manual transmission	√	√	√	√					
CLK-Class	208	Information and communication	AUDIO	√	√	√	√					
CLK-Class	208	Information and communication	CDC-CD changer	√	√	√						
CLK-Class	208	Information and communication	COMAND	√	√	√	√		√			
CLK-Class	208	Information and communication	CTEL over K-wire-Telematic system	√	√	√						
CLK-Class	208	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√						
CLK-Class	208	Information and communication	DN-Dynamic navigation by means of CTEL	√	√	√	√					
CLK-Class	208	Information and communication	E call [Japan]-Emergency call system	√	√	√	√					
CLK-Class	208	Information and communication	E call [USA]-Emergency call system	√	√	√						
CLK-Class	208	Information and communication	E call [USA]-Telematic system	√	√	√	√					
CLK-Class	208	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√					
CLK-Class	208	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√			√			
CLK-Class	208	Information and communication	PTS-Parktronic system	√	√	√	√					
CLK-Class	208	Information and communication	TELE AID-Emergency call system	√	√	√	√					
CLK-Class	208	Information and communication	TELE AID-Telematic system	√	√	√	√					
CLK-Class	208	Information and communication	TV-TV tuner	√	√	√	√				SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,	

CLK-Class	208	Information and communication	UHI-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,		
CLK-Class	208	Information and communication	VCS-Voice control system	√	√	√						
CLK-Class	208	Seats and Doors	DCM1-Door control module front driver side	√	√	√	√				CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170.	
CLK-Class	208	Seats and Doors	DCM2-Door control module front passenger side	√	√	√	√				CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170.	
CLK-Class	208	Seats and Doors	ESA FL-Electric seat adjustment front left	√	√	√	√				CD0181, CD0182, CD0183,	
CLK-Class	208	Seats and Doors	ESA FR-Electric seat adjustment front right	√	√	√	√					
CLK-Class	209	Air conditioning	AAC-Automatic air conditioning	√	√	√	√				CD0026, CD0029, CD0026, CD0027, CD0028, CD0029.	
CLK-Class	209	Air conditioning	STH-Stationary heater	√	√	√	√		√		CD0026, CD0029, CD0026, CD0027, CD0028, CD0029.	
CLK-Class	209	Air conditioning	STH-Stationary heater	√	√	√	√		√		CD0298, CD0299, CD0300, CD0301, CD0302, CD0303.	
CLK-Class	209	Body	AB-Airbag	√	√	√	√				CD0298, CD0299, CD0300, CD0301, CD0302, CD0303,	

CLK-Class	209	Body	AB-Airbag	√	√	√	√					
CLK-Class	209	Body	AHE-Trailer recognition	√	√	√	√		√			
CLK-Class	209	Body	AHE-Trailer recognition	√	√	√	√		√			
CLK-Class	209	Body	EZS-Electronic ignition switch	√	√	√	√					
CLK-Class	209	Body	HRA FL-Front left headlamp range control	√	√	√	√					
CLK-Class	209	Body	HRA FR-Front right headlamp range control	√	√	√	√		√			
CLK-Class	209	Body	HRA-Automatic headlamp range adjustment and headlamp control	√	√	√	√		√			
CLK-Class	209	Body	LCP-Lower control panel	√	√	√	√		√			
CLK-Class	209	Body	MSS-Special vehicle multifunction control module	√	√	√	√					
CLK-Class	209	Body	OCP-Overhead control panel	√	√	√	√			SP0165,		
CLK-Class	209	Body	On board electrical system(voltage supply)	√	√	√	√			SP0215,		
CLK-Class	209	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√			SP0215,		
CLK-Class	209	Body	RVC-Rollover bar soft top control module	√	√	√	√					
CLK-Class	209	Body	SAM F-Signal acquisition and actuation module front	√	√	√	√		√			
CLK-Class	209	Body	UCP-Upper control panel	√	√	√	√					
CLK-Class	209	Body	WSS-Weight sensing system	√	√	√	√					
CLK-Class	209	Chassis	ESP-Electronic stability program	√	√	√	√					

CLK-Class	209	Chassis	TPM-Tire pressure monitor	√	√	√	√					
CLK-Class	209	Drive	CDI 2-Common Rail Diesel Injection	√	√	√	√		√			
CLK-Class	209	Drive	CDI 3-Common Rail Diesel Injection3	√	√	√	√		√			
CLK-Class	209	Drive	CDI 3-Common Rail Diesel Injection3	√	√	√	√		√			
CLK-Class	209	Drive	CDI 4-Common Rail Diesel Injection	√	√	√	√					
CLK-Class	209	Drive	DTR-Distronic	√	√	√	√					
CLK-Class	209	Drive	DTR-Distronic	√	√	√	√					
CLK-Class	209	Drive	ESM-Electronic selector module	√	√	√	√		√			
CLK-Class	209	Drive	ETC-Electronic transmission control	√	√	√	√					
CLK-Class	209	Drive	ETC-Electronic transmission control	√	√	√	√					
CLK-Class	209	Drive	ETC-Electronic transmission control	√	√	√	√					
CLK-Class	209	Drive	FSCU Left-Control unit 'Left fuel pump'	√	√	√						
CLK-Class	209	Drive	FSCU Right-Control unit 'Right fuel pump'	√	√	√					CD0293, CD0294,	
CLK-Class	209	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	√	√	√	√		√			
CLK-Class	209	Drive	ME 9.7-Motor electronics 9.7	√	√	√	√		√		SP0153,SP0154,	
CLK-Class	209	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
CLK-Class	209	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
CLK-Class	209	Drive	ME SFI-Motor electronics	√	√	√	√				CD0073,	
CLK-Class	209	Drive	ME SFI-Motor electronics	√	√	√	√				CD0073,	
CLK-Class	209	Drive	SEQ-Sequentronic automated manual transmission	√	√	√	√				CD0074,	
CLK-Class	209	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√				CD0132,	

CLK-Class	209	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√					
CLK-Class	209	Information and communication	AUDIO	√	√	√	√					
CLK-Class	209	Information and communication	AUDIO	√	√	√	√					
CLK-Class	209	Information and communication	CDC-CD changer	√	√	√						
CLK-Class	209	Information and communication	CDC-CD changer	√	√	√	√					
CLK-Class	209	Information and communication	COMAND	√	√	√	√		√			
CLK-Class	209	Information and communication	COMAND or AUDIO	√	√	√	√				CD0007, CD0008, CD0011, CD0012, CD0016, CD0018, CD0021, CD0024, CD0009, CD0010, CD0013, CD0015, CD0025	
CLK-Class	209	Information and communication	CTEL over K-wire-Telematic system	√	√	√					CD0007, CD0008, CD0011, CD0012, CD0016, CD0018, CD0021, CD0024, CD0009, CD0010, CD0013, CD0015, CD0025	
CLK-Class	209	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√						
CLK-Class	209	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√					
CLK-Class	209	Information and communication	D2B-COMAND, MCS or AUDIO	√	√	√	√					
CLK-Class	209	Information and communication	E call [Japan]-Telematic system	√	√	√	√		√		CD0054, CD0055, CD0057, CD0061,	

CLK-Class	209	Information and communication	E call [USA]-Telematic system	√	√	√	√				CD0077, CD0078, CD0079, CD0080, CD0082, CD0084, CD0085, CD0086, CD0087, CD0088, CD0095, CD0096, CD0101, CD0102, CD0103, CD0105, CD0107, CD0108, CD0112, CD0115, CD0116, CD0117, CD0118, CD0119, CD0122, CD0129	
CLK-Class	209	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√					
CLK-Class	209	Information and communication	NAVI-Navigation system	√	√	√	√					
CLK-Class	209	Information and communication	PTS-Parktronic system	√	√	√	√			SP0176,SP0177,	CD0161,	
CLK-Class	209	Information and communication	SCM [MRM]-Steering column module	√	√	√	√					
CLK-Class	209	Information and communication	SCM [MRM]-Steering column module	√	√	√	√					
CLK-Class	209	Information and communication	SDAR-Satellite radio	√	√	√						
CLK-Class	209	Information and communication	SDAR-Satellite radio	√	√	√	√					
CLK-Class	209	Information and communication	SOUND-Sound system	√	√	√	√					
CLK-Class	209	Information and communication	SOUND-Sound system	√	√	√	√					
CLK-Class	209	Information and communication	TELE AID-Control unit	√	√	√	√					
CLK-Class	209	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√					
CLK-Class	209	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√					
CLK-Class	209	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√			SP0021,SP0026,SP0032,	CD0036, CD0037, CD0038, CD0039,	
CLK-Class	209	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√			SP0021,SP0026,SP0032,	CD0036, CD0037, CD0038, CD0039,	

CLK-Class	209	Information and communication	TELE AID-Telematic system	√	√	√	√			SP0035,SP0036,SP0037,SP0038,SP0039,SP0040,SP0041,SP0042,SP0043,SP0044,		
CLK-Class	209	Information and communication	TV-TV tuner	√	√	√	√			SP0127,		
CLK-Class	209	Information and communication	TV-TV tuner	√	√	√	√			SP0127,		
CLK-Class	209	Information and communication	TV-TV tuner(AGW)	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,		
CLK-Class	209	Information and communication	UHI-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,		
CLK-Class	209	Information and communication	VCS-Voice control system	√	√	√				SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,		
CLK-Class	209	Information and communication	VCS-Voice control system	√	√	√					CD0075,	
CLK-Class	209	Seats and Doors	DCM L-Door control module left	√	√	√	√		√			
CLK-Class	209	Seats and Doors	DCM R-Door control module right	√	√	√	√		√			

CLK-Class	209	Seats and Doors	ESA driver-Electric seat adjustment driver	√	√	√	√	√			CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170.
CLK-Class	209	Seats and Doors	ESA driver-Electric seat adjustment driver (with memory)	√	√	√	√	√			CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170.
CLK-Class	209	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√	√		SP0178,SP0179,SP0180,SP0181,SP0182,SP0183,SP0184,	CD0171,
CLK-Class	209	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√	√			
CLK-Class	209	Seats and Doors	RCM-Rear control module	√	√	√	√				CD0183, CD0183,
CLK-Class	209	Seats and Doors	TLC-Trunk lid control	√	√	√					CD0183, CD0183,
CLS-	219	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	√			
CLS-	219	Air conditioning	LRH-Steering wheel heater	√	√	√		√			
CLS-	219	Air conditioning	STH-Stationary heater	√	√	√	√	√			
CLS-Class	219	Body	AB-Airbag	√	√	√	√				
CLS-	219	Body	BCM-Battery control module	√	√	√	√	√			
CLS-	219	Body	CGW-Central gateway	√	√	√					
CLS-Class	219	Body	Dr side SAM-Driver signal acquisition and actuation module	√	√	√	√	√			
CLS-	219	Body	EZS-Electronic ignition switch	√	√	√	√				
CLS-Class	219	Body	HRA-Automatic headlamp range adjustment and headlamp control	√	√	√	√	√			
CLS-	219	Body	LCP-Lower control panel	√	√	√	√				
CLS-	219	Body	OCP-Overhead control panel	√	√	√	√	√			
CLS-Class	219	Body	On board electrical system(voltage supply)	√	√	√	√				

CLS-Class	219	Body	Pass side SAM-Passenger-side signal acquisition and actuation module	√	√	√	√	√				
CLS-Class	219	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	√				
CLS-Class	219	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√					
CLS-Class	219	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
CLS-Class	219	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
CLS-	219	Body	System diagnosis(CAN)	√	√	√						
CLS-	219	Body	UCP-Upper control panel	√	√	√	√	√				
CLS-	219	Body	WSS-Weight sensing system	√	√	√	√					
CLS-	219	Chassis	ABR-Adaptive Brake	√	√	√	√	√				
CLS-	219	Chassis	AIRmatic	√	√	√	√	√				
CLS-	219	Chassis	ESP-Electronic stability program	√	√	√	√					
CLS-	219	Chassis	SBC-Sensotronic Brake Control	√	√	√	√					
CLS-	219	Chassis	TPM-Tire pressure monitor	√	√	√	√					
CLS-	219	Chassis	TPM-Tire pressure monitor	√	√	√	√					
CLS-	219	Drive	CDI 4-Common Rail Diesel	√	√	√	√					
CLS-	219	Drive	DTR-Distronic	√	√	√	√					
CLS-	219	Drive	ESM-Electronic selector module	√	√	√	√	√				
CLS-	219	Drive	ETC-Electronic transmission	√	√	√	√					
CLS-	219	Drive	ETC-Electronic transmission	√	√	√	√					
CLS-Class	219	Drive	FSCU Left-Control unit 'Left fuel pump'	√	√	√					SP0008,SP0010,	
CLS-Class	219	Drive	FSCU Right-Control unit 'Right fuel pump'	√	√	√						
CLS-	219	Drive	FSCU-Fuel pump	√	√	√						
CLS-Class	219	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	√	√	√	√	√				
CLS-	219	Drive	ME 9.7-Motor electronics 9.7	√	√	√	√	√				
CLS-Class	219	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√				SP0216,SP0217,SP0218,	
CLS-Class	219	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
CLS-Class	219	Drive	MED 9.7-Motor electronics for direct injection 9.7	√	√	√	√	√				
CLS-Class	219	Drive	SEQ-Sequentronic automated manual transmission	√	√	√	√					

CLS-Class	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√				
CLS-Class	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√				
CLS-Class	219	Information and communication	ASSYST PLUS-PLUS Active Service System	√	√	√	√				
CLS-Class	219	Information and communication	ASSYST-Active Service System	√	√	√	√				
CLS-Class	219	Information and communication	AUDIO	√	√	√	√				
CLS-Class	219	Information and communication	CDC-CD changer	√	√	√	√				
CLS-Class	219	Information and communication	COMAND or AUDIO	√	√	√	√				
CLS-Class	219	Information and communication	COMAND or AUDIO	√	√	√	√				
CLS-Class	219	Information and communication	CTEL-Cellular telephone(JAPAN)	√	√	√	√				
CLS-Class	219	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√				
CLS-Class	219	Information and communication	DAB-Digital radio	√	√	√	√				
CLS-Class	219	Information and communication	GPS box	√	√	√	√				
CLS-Class	219	Information and communication	IC-Instrument cluster	√	√	√	√	√			
CLS-Class	219	Information and communication	NAVI-Navigation system	√	√	√	√				
CLS-Class	219	Information and communication	PTS-Parktronic system	√	√	√	√	√			
CLS-Class	219	Information and communication	PTS-Parktronic system	√	√	√	√				
CLS-Class	219	Information and communication	SCM [MRM]-Steering column module	√	√	√	√	√			
CLS-Class	219	Information and communication	SDAR-Satellite radio	√	√	√	√			SP0157,	
CLS-Class	219	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√			SP0176,SP0177,	
CLS-Class	219	Information and communication	TELE AID-Control unit	√	√	√	√				
CLS-Class	219	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√				
CLS-Class	219	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√				

CLS-Class	219	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√					
CLS-Class	219	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√					
CLS-Class	219	Information and communication	TV-TV tuner	√	√	√	√					
CLS-Class	219	Information and communication	TV-TV tuner	√	√	√	√					
CLS-Class	219	Information and communication	TV-TV tuner	√	√	√						
CLS-Class	219	Information and communication	TV-TV tuner	√	√	√	√					
CLS-Class	219	Information and communication	TV-TV tuner(AGW)	√	√	√	√					
CLS-Class	219	Information and communication	UCI-Media interface	√	√	√						
CLS-Class	219	Information and communication	VCS-Voice control system	√	√	√						
CLS-Class	219	Seats and Doors	DCM FL-Door control module front left	√	√	√	√		√	SP0035,SP0036,SP0037,SP0038,SP0039,SP0040,SP0041,SP0042,SP0043,SP0044,		
CLS-Class	219	Seats and Doors	DCM FR-Door control module front right	√	√	√	√		√	SP0127,		
CLS-Class	219	Seats and Doors	DCM RL-Door control module rear left	√	√	√	√		√	SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,		
CLS-Class	219	Seats and Doors	DCM RR-Door control module rear right	√	√	√	√		√	SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,		
CLS-Class	219	Seats and Doors	DS LF-Left front dynamic seat	√	√	√	√		√			

CLS-Class	219	Seats and Doors	DS RF-Right front dynamic seat	√	√	√	√	√				
CLS-Class	219	Seats and Doors	DSP-Pneumatic pump for dynamic seat	√	√	√	√					
CLS-Class	219	Seats and Doors	ESA driver-Electric seat adjustment driver (with memory)	√	√	√	√	√				
CLS-Class	219	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√	√				
CLS-	219	Seats and Doors	HS-Seat heater	√	√	√	√	√				
CLS-Class	219	Seats and Doors	LAE [LAA]-Loading floor automatically extendable	√	√	√	√	√		SP0178,SP0179,SP0180,SP0181,SP0182,SP0183,SP0184,		
CLS-	219	Seats and Doors	RWT-Rear end door control	√	√	√	√	√				
CLS-Class	219	Seats and Doors	TLC-Trunk lid control	√	√	√				SP0207,SP0208,SP0209,SP0210,SP0211,SP0212,SP0213,SP0214,		
E-Class	210	Air conditioning	AAC-Automatic air conditioning	√	√	√						
E-Class	210	Air conditioning	STH-Stationary heater	√	√	√	√					
E-Class	210	Air conditioning	TAC-Automatic temperature	√	√	√	√	√				
E-Class	210	Body	AB-Airbag	√	√	√	√					
E-Class	210	Body	AB-Airbag	√	√	√						
E-Class	210	Body	APS-Auto pilot system	√	√	√	√					
E-Class	210	Body	EZS-Electronic ignition switch	√	√	√	√					
E-Class	210	Body	HB-Heater booster	√	√	√					CD0293, CD0294,	
E-Class	210	Body	HRA-Headlamp range adjustment	√	√	√						
E-Class	210	Body	HRA-Headlamp range adjustment	√	√	√	√			SP0165,		
E-Class	210	Body	LCP-Lower control panel	√	√	√	√			SP0165,		
E-Class	210	Body	MSS-Special vehicle multifunction control module	√	√	√	√					
E-Class	210	Body	OCP-Overhead control panel	√	√	√	√				CD0223,	
E-Class	210	Body	PSE-Pneumatic system equipment	√	√	√	√				CD0223,	
E-Class	210	Body	SAM-Signal acquisition and actuation module	√	√	√	√					
E-Class	210	Chassis	ABS-Antilock brake system	√	√	√	√				CD0073,	
E-Class	210	Chassis	ASR-Acceleration Slip	√	√	√	√				CD0074,	
E-Class	210	Chassis	ASR-Acceleration Slip	√	√	√	√					
E-Class	210	Chassis	BAS-Brake assist	√	√	√	√					
E-Class	210	Chassis	BAS-Brake assist	√	√	√	√				CD0132,	
E-Class	210	Chassis	ESP-Electronic stability program	√	√	√	√					
E-Class	210	Chassis	ESP-Electronic stability program	√	√	√	√					

E-Class	210	Chassis	ESP-Electronic stability program	√	√	√	√				CD0224,	
E-Class	210	Chassis	ESP-Electronic stability program	√	√	√	√					
E-Class	210	Chassis	ETS-Electronic traction system	√	√	√	√			SP0154,	CD0224,	
E-Class	210	Chassis	ETS-Electronic traction system	√	√	√	√			SP0154,	CD0286,	
E-Class	210	Chassis	SPS Speed-sensitive power	√	√	√	√			SP0154,	CD0287,	
E-Class	210	Chassis	TPM-Tire pressure monitor	√	√	√	√			SP0154,	CD0288,	
E-Class	210	Chassis	VP-Vacuum pump brake booster	√	√	√	√		√		CD0134,	
E-Class	210	Drive	CDI 2-Common Rail Diesel	√	√	√	√		√			
E-Class	210	Drive	CDI-Common Rail Diesel	√	√	√						
E-Class	210	Drive	DFI-Electronic distributor injection system diesel	√	√	√					CD0007, CD0008, CD0011, CD0012, CD0016, CD0018, CD0021, CD0024,	
E-Class	210	Drive	ESM-Electronic selector module	√	√	√	√					
E-Class	210	Drive	ETC-Electronic transmission	√	√	√	√					
E-Class	210	Drive	ETC-Electronic transmission	√	√	√	√				CD0062,	
E-Class	210	Drive	ETC-Electronic transmission	√	√	√						
E-Class	210	Drive	IFI-Electronic in-line injection system diesel	√	√	√					CD0161,	
E-Class	210	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
E-Class	210	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
E-Class	210	Drive	ME SFI-Motor electronics	√	√	√	√		√			
E-Class	210	Drive	ME2 SFI-Motor electronics 2	√	√	√	√				CD0256, CD0258, CD0259, CD0260, CD0261, CD0262, CD0265, CD0266, CD0271, CD0272, CD0274, CD0275, CD0277,	
E-Class	210	Information and communication	AUDIO	√	√	√	√				CD0230, CD0231, CD0232, CD0233,	
E-Class	210	Information and communication	CDC-CD changer	√	√	√					CD0237, CD0247, CD0253, CD0254, CD0255,	
E-Class	210	Information and communication	COMAND	√	√	√	√		√		CD0237, CD0247, CD0253, CD0254, CD0255,	
E-Class	210	Information and communication	CTEL over K-wire-Telematic system	√	√	√						
E-Class	210	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√						
E-Class	210	Information and communication	DN-Dynamic navigation by means of CTEL	√	√	√	√					

E-Class	210	Information and communication	E call [Japan]-Emergency call system	√	√	√	√				CD0292,	
E-Class	210	Information and communication	E call [USA]-Emergency call system	√	√	√						
E-Class	210	Information and communication	E call [USA]-Telematic system	√	√	√	√					
E-Class	210	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√					
E-Class	210	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√			√			
E-Class	210	Information and communication	ICS-Information and communication system	√	√	√						
E-Class	210	Information and communication	PTS-Parktronic system	√	√	√	√				CD0075,	
E-Class	210	Information and communication	TELE AID-Emergency call system	√	√	√	√					
E-Class	210	Information and communication	TELE AID-Telematic system	√	√	√						
E-Class	210	Information and communication	TELE AID-Telematic system	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,	CD0130,	
E-Class	210	Information and communication	TV-TV tuner	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,	CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167,	
E-Class	210	Information and communication	UHI-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,	CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170,	
E-Class	210	Information and communication	VCS-Voice control system	√	√	√					CD0171,	
E-Class	210	Seats and Doors	DCM1-Door control module front driver side	√	√	√	√					
E-Class	210	Seats and Doors	DCM2-Door control module front passenger side	√	√	√	√				CD0188,	
E-Class	210	Seats and Doors	DCM3-Door control module rear driver side	√	√	√	√					
E-Class	210	Seats and Doors	DCM4-Door control module rear passenger side	√	√	√	√					

E-Class	210	Seats and Doors	ESA FL-Electric seat adjustment front left	√	√	√	√				
E-Class	210	Seats and Doors	ESA FR-Electric seat adjustment front right	√	√	√	√				
E-Class	211	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		√		
E-Class	211	Air conditioning	LRH-Steering wheel heater	√	√	√	√		√		
E-Class	211	Air conditioning	LRH-Steering wheel heater	√	√	√	*		√		
E-Class	211	Air conditioning	STH-Stationary heater	√	√	√	√		√		
E-Class	211	Body	AB-Airbag	√	√	√	√				
E-Class	211	Body	AHE-Trailer recognition	√	√	√	√		√		
E-Class	211	Body	BCM-Battery control module	√	√	√	√		√		
E-Class	211	Body	CGW-Central gateway	√	√	√	*				
E-Class	211	Body	Dr side SAM-Driver signal acquisition and actuation module	√	√	√	√		√		
E-Class	211	Body	EZS-Electronic ignition switch	√	√	√	√				
E-Class	211	Body	HRA-Automatic headlamp range adjustment and headlamp control	√	√	√	√		√		
E-Class	211	Body	LCP-Lower control panel	√	√	√	√				
E-Class	211	Body	MSS-Special vehicle multifunction control module	√	√	√	√				
E-Class	211	Body	OCP-Overhead control panel	√	√	√	√		√		
E-Class	211	Body	On board electrical system(voltage supply)	√	√	√	√				
E-Class	211	Body	Pass side SAM-Passenger-side signal acquisition and actuation module	√	√	√	√		√	SP0215,	
E-Class	211	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√		√	SP0215,	
E-Class	211	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√				
E-Class	211	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√				
E-Class	211	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√				
E-Class	211	Body	System diagnosis(CAN)	√	√	√	*				
E-Class	211	Body	UCP-Upper control panel	√	√	√	√		√		
E-Class	211	Body	WSS-Weight sensing system	√	√	√	√				
E-Class	211	Body	XALWA L-Xenon headlamp, left	√	√	√	√		√		
E-Class	211	Body	XALWA R-Xenon headlamp,	√	√	√	√		√		

E-Class	211	Drive	ME SFI-Motor electronics	√	√	√	√	√	√			
E-Class	211	Drive	ME SFI-Motor electronics	√	√	√	√	√				
E-Class	211	Drive	ME SFI-Motor electronics	√	√	√	√	√				
E-Class	211	Drive	MED 9.7-Motor electronics for direct injection 9.7	√	√	√	√	√	√			
E-Class	211	Drive	SEQ-Sequentronic automated manual transmission	√	√	√	√					
E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√					
E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√					
E-Class	211	Information and communication	ASSYST PLUS-PLUS Active Service System	√	√	√	√					
E-Class	211	Information and communication	ASSYST-Active Service System	√	√	√	√					
E-Class	211	Information and communication	AUDIO	√	√	√	√					
E-Class	211	Information and communication	CDC-CD changer	√	√	√	√					
E-Class	211	Information and communication	COMAND or AUDIO	√	√	√	√					
E-Class	211	Information and communication	COMAND or AUDIO	√	√	√	√					
E-Class	211	Information and communication	CTEL-Cellular telephone(JAPAN)	√	√	√	√				SP0157,	
E-Class	211	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√				SP0176,SP0177,	
E-Class	211	Information and communication	CTEL-Telecommunication for telematics services	√	√	√	√					
E-Class	211	Information and communication	DAB-Digital radio	√	√	√	√					
E-Class	211	Information and communication	GPS box	√	√	√	√					
E-Class	211	Information and communication	IC-Instrument cluster	√	√	√	√		√			
E-Class	211	Information and communication	NAVI-Navigation system	√	√	√	√					
E-Class	211	Information and communication	PTS-Parktronic system	√	√	√	√		√			

E-Class	211	Information and communication	PTS-Parktronic system	√	√	√	√					
E-Class	211	Information and communication	SCM [MRM]-Steering column module	√	√	√	√		√			
E-Class	211	Information and communication	SCM [MRM]-Steering column module	√	√	√	√		√			
E-Class	211	Information and communication	SDAR-Satellite radio	√	√	√	√					
E-Class	211	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√					
E-Class	211	Information and communication	TELE AID-Control unit	√	√	√	√					
E-Class	211	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√			SP0226,		
E-Class	211	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√					
E-Class	211	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√					
E-Class	211	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√			SP0021,SP0026,SP0032,		
E-Class	211	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	√	√	√	√			SP0021,SP0026,SP0032,		
E-Class	211	Information and communication	TV-TV tuner	√	√	√	√			SP0021,SP0026,SP0032,		
E-Class	211	Information and communication	TV-TV tuner	√	√	√	√			SP0035,SP0036,SP0037, SP0038,SP0039,SP0040, SP0041,SP0042,SP0043, SP0044,		
E-Class	211	Information and communication	TV-TV tuner	√	√	√	*					
E-Class	211	Information and communication	TV-TV tuner	√	√	√	√					
E-Class	211	Information and communication	TV-TV tuner(AGW)	√	√	√	√					
E-Class	211	Information and communication	UCI-Media interface	√	√	√	*					
E-Class	211	Information and communication	VCS-Voice control system	√	√	√	*			SP0119,SP0120,SP0121, SP0123,SP0124,SP0125, SP0126,		
E-Class	211	Seats and Doors	ARWT-Automatic rear-end door	√	√	√	√		√	SP0127,		
E-Class	211	Seats and Doors	DCM FL-Door control module front left	√	√	√	√		√	SP0127,		

E-Class	211	Seats and Doors	DCM FR-Door control module front right	√	√	√	√	√	SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,
E-Class	211	Seats and Doors	DCM RL-Door control module rear left	√	√	√	√	√	SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,
E-Class	211	Seats and Doors	DCM RR-Door control module rear right	√	√	√	√	√	SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,
E-Class	211	Seats and Doors	DS LF-Left front dynamic seat	√	√	√	√	√	
E-Class	211	Seats and Doors	DS RF-Right front dynamic seat	√	√	√	√	√	
E-Class	211	Seats and Doors	DSP-Pneumatic pump for dynamic seat	√	√	√	√		
E-Class	211	Seats and Doors	ESA driver-Electric seat adjustment driver	√	√	√	√	√	
E-Class	211	Seats and Doors	ESA driver-Electric seat adjustment driver (with memory)	√	√	√	√	√	
E-Class	211	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√	√	
E-Class	211	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√	√	SP0178,SP0179,SP0180,SP0181,SP0182,SP0183,SP0184,
E-Class	211	Seats and Doors	HS-Seat heater	√	√	√	√	√	
E-Class	211	Seats and Doors	HS-Seat heater	√	√	√	*		
E-Class	211	Seats and Doors	LAE [LAA]-Loading floor automatically extendable	√	√	√	√	√	
E-Class	211	Seats and Doors	RWT-Rear end door control	√	√	√	√	√	

E-Class	211	Seats and Doors	TLC-Trunk lid control	√	√	√	*				
E-Class	211	Seats and Doors	TLC-Trunk lid control	√	√	√	*			SP0207,SP0208,SP0209, SP0210,SP0211,SP0212, SP0213,SP0214,	CD0003, CD0006, CD0010, CD0012, CD0014, CD0019,
G-Class	461(16-pin diagnostic socket)	Air conditioning	STH-Stationary heater	√	√	√	√				
G-Class	461(16-pin diagnostic socket)	Body	AB-Airbag	√	√	√	√				
G-Class	461(16-pin diagnostic socket)	Body	CGW-Central gateway	√	√	√					
G-Class	461(16-pin diagnostic socket)	Chassis	ABS-Antilock brake system	√	√	√	√				
G-Class	461(16-pin diagnostic socket)	Chassis	Traction systems ABS	√	√	√	√				
G-Class	461(16-pin diagnostic socket)	Drive	CDI 2-Common Rail Diesel Injection	√	√	√	√	√			
G-Class	461(16-pin diagnostic socket)	Drive	CDI 4-Common Rail Diesel Injection	√	√	√	√				
G-Class	461(16-pin diagnostic socket)	Drive	CDI 6-Common Rail Diesel Injection	√	√	√	√				
G-Class	461(16-pin diagnostic socket)	Drive	ESM-Electronic selector module	√	√	√	√				
G-Class	461(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	√	√	√	√				
G-Class	461(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	√	√	√	√				
G-Class	461(16-pin diagnostic socket)	Drive	VG-Transfer case	√	√	√	√	√		SP0132,SP0135,SP0136, SP0137,SP0138,SP0139, SP0140,SP0141,SP0142, SP0143,SP0144,SP0145, SP0150,	

G-Class	461(16-pin diagnostic socket)	Information and communication	AUDIO	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,		
G-Class	461(16-pin diagnostic socket)	Information and communication	IC-Instrument cluster	√	√	√	√	√				
G-Class	461(16-pin diagnostic socket)	Information and communication	WSP immobilizer	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Air conditioning	LRH-Steering wheel heater	√	√	√	√	√				
G-Class	463(16-pin diagnostic socket)	Air conditioning	LRH-Steering wheel heater	√	√	√	√	√				
G-Class	463(16-pin diagnostic socket)	Air conditioning	STH-Stationary heater	√	√	√	√	√				
G-Class	463(16-pin diagnostic socket)	Body	AB-Airbag	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Body	AHE-Trailer recognition	√	√	√	√	√				
G-Class	463(16-pin diagnostic socket)	Body	AHE-Trailer recognition	√	√	√	√	√				
G-Class	463(16-pin diagnostic socket)	Body	ALWR-Headlamp range adjustment	√	√	√	√	√				
G-Class	463(16-pin diagnostic socket)	Body	EZS-Electronic ignition switch	√	√	√	√					

G-Class	463(16-pin diagnostic socket)	Body	EZS-Electronic ignition switch	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Body	MSS-Special vehicle multifunction control module	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Body	OCP-Overhead control panel	√	√	√	√		√			
G-Class	463(16-pin diagnostic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√		√			
G-Class	463(16-pin diagnostic socket)	Body	SAM F-Signal acquisition and actuation module front	√	√	√	√		√			
G-Class	463(16-pin diagnostic socket)	Body	UCP-Upper control panel	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Chassis	ABS-Antilock brake system	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	√	√	√	√		√	SP0165,SP0165,		
G-Class	463(16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	√	√	√	√			SP0165,SP0165,		
G-Class	463(16-pin diagnostic socket)	Chassis	TPM-Tire pressure monitor	√	√	√	√			SP0215,		
G-Class	463(16-pin diagnostic socket)	Chassis	Traction systems ABS	√	√	√	√			SP0215,		
G-Class	463(16-pin diagnostic socket)	Drive	CDI 2-Common Rail Diesel Injection	√	√	√	√		√			
G-Class	463(16-pin diagnostic socket)	Drive	CDI 4-Common Rail Diesel Injection	√	√	√	√					

G-Class	463(16-pin diagnostic socket)	Drive	CDI 6-Common Rail Diesel Injection	√	√	√						
G-Class	463(16-pin diagnostic socket)	Drive	CDI V-Common Rail Diesel Injection	√	√	√	√		√			
G-Class	463(16-pin diagnostic socket)	Drive	CDI V-Common Rail Diesel Injection	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Drive	ESM-Electronic selector module	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Drive	ME 9.7-Motor electronics 9.7	√	√	√	√		√			
G-Class	463(16-pin diagnostic socket)	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Drive	SCR-Selective Catalytic Reduction	√	√	√	√		√			
G-Class	463(16-pin diagnostic socket)	Drive	VG-Transfer case	√	√	√	√		√			
G-Class	463(16-pin diagnostic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	AUDIO	√	√	√	√					

G-Class	463(16-pin diagnostic socket)	Information and communication	AUDIO	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	CDC-CD changer	√	√	√						
G-Class	463(16-pin diagnostic socket)	Information and communication	CDC-CD changer	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	COMAND	√	√	√	√		√			
G-Class	463(16-pin diagnostic socket)	Information and communication	COMAND or AUDIO	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	COMAND or AUDIO	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL over K-wire-Telematic system	√	√	√						
G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√						
G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL-Cellular telephone(JAPAN)	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	D2B-COMAND, MCS or AUDIO	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	DAB-Digital radio	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	E call [Japan]-Telematic system	√	√	√	√		√			
G-Class	463(16-pin diagnostic socket)	Information and communication	E call [USA]-Telematic system	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√		√			
G-Class	463(16-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√		√			

G-Class	463(16-pin diagnostic socket)	Information and communication	NAVI-Navigation system	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	√	√	√	√		√			
G-Class	463(16-pin diagnostic socket)	Information and communication	SCM [MRM]-Steering column module	√	√	√	√		√			
G-Class	463(16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio	√	√	√						
G-Class	463(16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	SOUND-Sound system	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Control unit	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	TELE AID-Telematic system	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner	√	√	√	√					

G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner	√	√	√						
G-Class	463(16-pin diagnostic socket)	Information and communication	TV-TV tuner(AGW)	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	UCI-Media interface	√	√	√						
G-Class	463(16-pin diagnostic socket)	Information and communication	UHI-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Information and communication	VCS-Voice control system	√	√	√				SP0035,SP0036,SP0037,SP0038,SP0039,SP0040,SP0041,SP0042,SP0043,SP0044,		
G-Class	463(16-pin diagnostic socket)	Information and communication	VCS-Voice control system	√	√	√						
G-Class	463(16-pin diagnostic socket)	Seats and Doors	DCM FL-Door control module front left	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Seats and Doors	DCM FR-Door control module front right	√	√	√	√					
G-Class	463(16-pin diagnostic socket)	Seats and Doors	DCM RL-Door control module rear left	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0146,SP0147,SP0148,SP0149,SP0150		
G-Class	463(16-pin diagnostic socket)	Seats and Doors	DCM RR-Door control module rear right	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0146,SP0147,SP0148,SP0149,SP0150		
G-Class	463(16-pin diagnostic socket)	Seats and Doors	ESA driver-Electric seat adjustment driver	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0146,SP0147,SP0148,SP0149,SP0150		

G-Class	463(16-pin diagnostic socket)	Seats and Doors	ESA driver-Electric seat adjustment driver	√	√	√	√	√				
G-Class	463(16-pin diagnostic socket)	Seats and Doors	ESA driver-Electric seat adjustment driver (with memory)	√	√	√	√	√				
G-Class	463(16-pin diagnostic socket)	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√	√				
G-Class	463(16-pin diagnostic socket)	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√			SP0178,SP0179,SP0180,SP0181,SP0182,SP0183,SP0184,		
G-Class	463(16-pin diagnostic socket)	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√	√				
G-Class	463(16-pin diagnostic socket)	Seats and Doors	HS-Seat heater	√	√	√	√	√				
G-Class	463(38-pin diagnostic socket)	Air conditioning	STH-Stationary heater	√	√	√	√					
G-Class	463(38-pin diagnostic socket)	Body	AB-Airbag	√	√	√						
G-Class	463(38-pin diagnostic socket)	Body	APS-Auto pilot system	√	√	√	√					
G-Class	463(38-pin diagnostic socket)	Chassis	ABS-Antilock brake system	√	√	√	√			SP0165,		
G-Class	463(38-pin diagnostic socket)	Drive	ESM-Electronic selector module	√	√	√	√			SP0165,		
G-Class	463(38-pin diagnostic socket)	Drive	ETC-Electronic transmission control	√	√	√						
G-Class	463(38-pin diagnostic socket)	Drive	HFM-SFI-Hot film engine management	√	√	√	√					
G-Class	463(38-pin diagnostic socket)	Drive	IFI-Electronic in-line injection system diesel	√	√	√						
G-Class	463(38-pin diagnostic socket)	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
G-Class	463(38-pin diagnostic socket)	Drive	ME2 SFI-Motor electronics 2	√	√	√	√					

G-Class	463(38-pin diagnostic socket)	Information and communication	AUDIO	√	√	√	√					
G-Class	463(38-pin diagnostic socket)	Information and communication	CDC-CD changer	√	√	√						
G-Class	463(38-pin diagnostic socket)	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√						
G-Class	463(38-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√					
G-Class	463(38-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√			√			
G-Class	463(38-pin diagnostic socket)	Information and communication	VCS-Voice control system	√	√	√						
M-Class	163	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		√			
M-Class	163	Air conditioning	STH-Stationary heater	√	√	√	√					
M-Class	163	Body	AAM-All Activity Module	√	√	√	√		√			
M-Class	163	Body	AAM-All Activity Module	√	√	√	√		√			
M-Class	163	Body	AB-Airbag	√	√	√						
M-Class	163	Body	AB-Airbag	√	√	√	√					
M-Class	163	Body	DAS-Drive authorization system	√	√	√	√					
M-Class	163	Body	EAM-Extended activity module	√	√	√	√					
M-Class	163	Body	HRA-Headlamp range adjustment	√	√	√	√		√			CD0293, CD0294,
M-Class	163	Body	LCP-Lower operating panel with power window function	√	√	√	√		√			
M-Class	163	Body	SEM-Security Module	√	√	√						
M-Class	163	Chassis	BAS-Brake assist	√	√	√	√					
M-Class	163	Chassis	ESP-Electronic stability program	√	√	√	√					
M-Class	163	Chassis	ESP-Electronic stability program	√	√	√	√					
M-Class	163	Chassis	ESP-Electronic stability program	√	√	√	√					
M-Class	163	Chassis	ESP-Electronic stability program	√	√	√	√					SP0153,SP0154,
M-Class	163	Chassis	ETS-Electronic traction system	√	√	√	√					SP0153,SP0154,
M-Class	163	Chassis	ETS-Electronic traction system	√	√	√	√					SP0153,SP0154,
M-Class	163	Chassis	VP-Vacuum pump brake booster	√	√	√	√		√			SP0153,SP0154,
M-Class	163	Drive	CDI 2-Common Rail Diesel	√	√	√	√		√			CD0073,
M-Class	163	Drive	CDI V-Common Rail Diesel	√	√	√	√		√			CD0073,
M-Class	163	Drive	CDI V-Common Rail Diesel	√	√	√	√					CD0074,
M-Class	163	Drive	ESM-Electronic selector module	√	√	√	√					

M-Class	163	Drive	ETC-Electronic transmission	√	√	√	√					
M-Class	163	Drive	ETC-Electronic transmission	√	√	√						
M-Class	163	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
M-Class	163	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
M-Class	163	Drive	ME2 SFI-Motor electronics 2	√	√	√	√					
M-Class	163	Drive	VG-Transfer case	√	√	√	√					
M-Class	163	Information and communication	AUDIO	√	√	√	√					
M-Class	163	Information and communication	CDC-CD changer	√	√	√						
M-Class	163	Information and communication	COMAND	√	√	√	√	√			CD0003, CD0006, CD0010, CD0012, CD0014, CD0019, CD0022, CD0023, CD0025,	
M-Class	163	Information and communication	CTEL over K-wire-Telematic system	√	√	√						
M-Class	163	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√						
M-Class	163	Information and communication	E call [USA]-Telematic system	√	√	√	√					
M-Class	163	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√		√				
M-Class	163	Information and communication	MCS navigation-Navigation in MCS	√	√	√				SP0132,SP0135,SP0136, SP0137,SP0138,SP0139, SP0140,SP0141,SP0142, SP0143,SP0144,SP0145, SP0150,	CD0077, CD0078, CD0079, CD0080, CD0082, CD0084, CD0085, CD0086, CD0087, CD0088, CD0089, CD0090	
M-Class	163	Information and communication	MCS-Modular control system	√	√	√	√			SP0132,SP0135,SP0136, SP0137,SP0138,SP0139, SP0140,SP0141,SP0142, SP0143,SP0144,SP0145, SP0150,	CD0077, CD0078, CD0079, CD0080, CD0082, CD0084, CD0085, CD0086, CD0087, CD0088, CD0089, CD0090	
M-Class	163	Information and communication	PTS-Parktronic system	√	√	√	√					
M-Class	163	Information and communication	SDAR-Satellite radio	√	√	√						

M-Class	163	Information and communication	SOUND-Sound system	√	√	√	√				
M-Class	163	Information and communication	UHI-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	√				
M-Class	163	Information and communication	VCS-Voice control system	√	√	√					
M-Class	164	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		√		
M-Class	164	Air conditioning	EKMK-Electric refrigerant compressor	√	√	√	√				
M-Class	164	Air conditioning	LRH-Steering wheel heater	√	√	√	*		√		
M-Class	164	Air conditioning	STH-Stationary heater with remote control	√	√	√	√		√		
M-Class	164	Body	AB-Airbag	√	√	√	√				
M-Class	164	Body	CGW-Central gateway	√	√	√	*				
M-Class	164	Body	EZS-Electronic ignition switch	√	√	√	√				
M-Class	164	Body	EZS-Electronic ignition switch	√	√	√	√				
M-Class	164	Body	HBF-Rear control field	√	√	√	√		√		CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170.
M-Class	164	Body	HRA-Automatic headlamp range adjustment and headlamp control	√	√	√	√		√		CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170.
M-Class	164	Body	KG-Keyless Go	√	√	√	√				CD0171,
M-Class	164	Body	KG-KEYLESS GO	√	√	√	√				CD0281, CD0282, CD0283, CD0284.
M-Class	164	Body	OCP-Overhead control panel	√	√	√	√		√		
M-Class	164	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√				

M-Class	164	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
M-Class	164	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
M-Class	164	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
M-Class	164	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
M-Class	164	Body	SAM F-Signal acquisition and actuation module front	√	√	√	√		√		SP0215,	
M-Class	164	Body	SG BMS-Battery management system control unit	√	√	√	√					
M-Class	164	Body	SG DDW-DC/DC converter control unit	√	√	√	√					
M-Class	164	Body	System diagnosis(CAN)	√	√	√	*					
M-Class	164	Body	WSS-Weight sensing system	√	√	√	√					
M-Class	164	Body	XALWA L-Xenon headlamp, left	√	√	√	√					
M-Class	164	Body	XALWA L-Xenon headlamp, left	√	√	√	√		√			
M-Class	164	Body	XALWA R-Xenon headlamp,	√	√	√	√					
M-Class	164	Body	XALWA R-Xenon headlamp,	√	√	√	√		√			
M-Class	164	Chassis	DTR-Distronic	√	√	√	√					CD0165, CD0166, CD0167, CD0168, CD0169, CD0170.
M-Class	164	Chassis	EHPS-Electrohydraulic Power Steering	√	√	√	√					
M-Class	164	Chassis	ESP-Electronic stability program	√	√	√	√					
M-Class	164	Chassis	RBS-Regenerative braking	√	√	√	√					
M-Class	164	Chassis	Suspension	√	√	√	√		√			
M-Class	164	Chassis	TPM-Tire pressure monitor	√	√	√	√					
M-Class	164	Chassis	TPM-Tire pressure monitor	√	√	√	√					
M-Class	164	Drive	CDI 4-Common Rail Diesel	√	√	√	√		√			
M-Class	164	Drive	CDI 5-Common Rail Diesel	√	√	√	√		√			
M-Class	164	Drive	CDI 6-Common Rail Diesel	√	√	√	*		√			
M-Class	164	Drive	CDI 6-Common Rail Diesel	√	√	√	*		√			
M-Class	164	Drive	CDI 6BIN5-Common Rail Diesel Injection	√	√	√	*		√		SP0127,	
M-Class	164	Drive	DTR-Distronic	√	√	√	√					
M-Class	164	Drive	ETC-Electronic transmission	√	√	√	√		√		SP0153,SP0154,	
M-Class	164	Drive	ETC-Electronic transmission	√	√	√	√		√		SP0254,SP0255,SP0256,	
M-Class	164	Drive	FSCU Left-Control unit 'Left fuel pump'	√	√	√	*					
M-Class	164	Drive	FSCU Right-Control unit 'Right fuel pump'	√	√	√	*					
M-Class	164	Drive	FSCU-Fuel pump	√	√	√	*					
M-Class	164	Drive	FSCU-Fuel pump	√	√	√	*					
M-Class	164	Drive	HAQ-Interwheel differential lock at rear axle	√	√	√	√					

M-Class	164	Drive	HSG-Hybrid control unit	√	√	√	√		√			
M-Class	164	Drive	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					
M-Class	164	Drive	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	√					
M-Class	164	Drive	ISM-Intelligent servo module	√	√	√	√					
M-Class	164	Drive	ISM-Shift module	√	√	√	√					
M-Class	164	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	√	√	√	√	√	√			
M-Class	164	Drive	ME 9.7-Motor electronics 9.7	√	√	√	√	√	√			
M-Class	164	Drive	ME SF 17.7-Motor electronics	√	√	√	√	√	√			
M-Class	164	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√	√				
M-Class	164	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√	√		SP0161,SP0170,SP0162,SP0163,		
M-Class	164	Drive	SCR-Selective Catalytic	√	√	√	√	√	√			
M-Class	164	Drive	VG-Transfer case	√	√	√	*	√	√			
M-Class	164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√			SP0001,		
M-Class	164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√					
M-Class	164	Information and communication	ASSYST PLUS-PLUS Active Service System	√	√	√	√					
M-Class	164	Information and communication	ASSYST-Active Service System	√	√	√	√					
M-Class	164	Information and communication	AUDIO	√	√	√	√					
M-Class	164	Information and communication	AVE H-Rear audio video unit	√	√	√	√					
M-Class	164	Information and communication	AVE H-Rear audio video unit	√	√	√	√					
M-Class	164	Information and communication	CDC-CD changer	√	√	√	√					
M-Class	164	Information and communication	CM-Compass module	√	√	√	√			SP0176,SP0177,		
M-Class	164	Information and communication	COMAND or AUDIO	√	√	√	√					
M-Class	164	Information and communication	COMAND or AUDIO	√	√	√	√					

M-Class	164	Information and communication	CTEL-Cellular telephone	√	√	√	√				
M-Class	164	Information and communication	CTEL-Cellular telephone(JAPAN)	√	√	√	√				
M-Class	164	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√				
M-Class	164	Information and communication	DAB-Digital radio	√	√	√	√				
M-Class	164	Information and communication	IC-Instrument cluster	√	√	√	√		√		
M-Class	164	Information and communication	Left rear screen	√	√	√	√				
M-Class	164	Information and communication	NAVI-Navigation system	√	√	√	√				
M-Class	164	Information and communication	PTS-Parktronic system	√	√	√	√				
M-Class	164	Information and communication	PTS-Parktronic system	√	√	√	√				
M-Class	164	Information and communication	RFK-Backup camera	√	√	√	√				
M-Class	164	Information and communication	Right rear screen	√	√	√	√			SP0226,	
M-Class	164	Information and communication	SCM [MRM]-Steering column module	√	√	√	√		√	SP0226,	
M-Class	164	Information and communication	SDAR-Satellite radio	√	√	√	√				
M-Class	164	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√			SP0035,SP0036,SP0037,SP0038,SP0039,SP0040,SP0041,SP0042,SP0043,SP0044,	
M-Class	164	Information and communication	SOUND-Sound system	√	√	√	√				
M-Class	164	Information and communication	TELE AID-Control unit	√	√	√	√			SP0045,SP0046,SP0047,SP0048,SP0049,SP0050,SP0051,SP0052,SP0053,SP0054,SP0055,SP0056,SP0057,	
M-Class	164	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√			SP0045,SP0046,SP0047,SP0048,SP0049,SP0050,SP0051,SP0052,SP0053,SP0054,SP0055,SP0056,SP0057,	
M-Class	164	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√				

M-Class	164	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√			SP0127,		
M-Class	164	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√			SP0130,SP0131,SP0132, SP0133,SP0134,SP0136, SP0138,SP0139,SP0140, SP0141,SP0142,SP0143, SP0144,SP0145,SP0146, SP0147,SP0148,SP0149,		
M-Class	164	Information and communication	TV-TV tuner	√	√	√	√			SP0130,SP0131,SP0132, SP0133,SP0134,SP0136, SP0138,SP0139,SP0140, SP0141,SP0142,SP0143, SP0144,SP0145,SP0146, SP0147,SP0148,SP0149,		
M-Class	164	Information and communication	TV-TV tuner	√	√	√	√					
M-Class	164	Information and communication	TV-TV tuner	√	√	√	*					
M-Class	164	Information and communication	TV-TV tuner	√	√	√	√					
M-Class	164	Information and communication	TV-TV tuner(AGW)	√	√	√	√					
M-Class	164	Information and communication	UCI-Media interface	√	√	√	*					
M-Class	164	Information and communication	VCS-Voice control system	√	√	√	*					
M-Class	164	Seats and Doors	DCM FL-Door control module front left	√	√	√	√		√			
M-Class	164	Seats and Doors	DCM FR-Door control module front right	√	√	√	√		√			
M-Class	164	Seats and Doors	DS LF-Left front dynamic seat	√	√	√	√		√			
M-Class	164	Seats and Doors	DS RF-Right front dynamic seat	√	√	√	√		√			
M-Class	164	Seats and Doors	DSP-Pneumatic pump for dynamic seat	√	√	√	√					
M-Class	164	Seats and Doors	ESA driver-Electric seat adjustment driver (with memory)	√	√	√	√					
M-Class	164	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√			SP0178,SP0179,SP0180, SP0181,SP0182,SP0183, SP0184,		
M-Class	164	Seats and Doors	HS-Seat heater	√	√	√	√		√			
M-Class	164	Seats and Doors	REDC-Rear end door closing control module	√	√	√	√		√			
M-Class	164	Seats and Doors	REDC-Rear end door closing control module	√	√	√	√		√			

Maybach	240	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	√				
Maybach	240	Air conditioning	LRH-Steering wheel heater	√	√	√	√	√				
Maybach	240	Air conditioning	REAR AC-Rear air conditioning	√	√	√	√	√				
Maybach	240	Air conditioning	STH-Stationary heater	√	√	√	√	√				
Maybach	240	Body	AB-Airbag	√	√	√	√					
Maybach	240	Body	AB-Airbag	√	√	√	√					
Maybach	240	Body	BCG-Remote control(Rear control field)	√	√	√	√	√				
Maybach	240	Body	BNS-Vehicle power supply control module	√	√	√	√					
Maybach	240	Body	CGW-Central gateway	√	√	√						
Maybach	240	Body	CRN-Center roof node	√	√	√	√	√			CD0154, CD0135,	
Maybach	240	Body	Dr side SAM-Driver signal acquisition and actuation module	√	√	√	√	√				
Maybach	240	Body	EZS-Electronic ignition switch	√	√	√	√					
Maybach	240	Body	HBF-Rear control field	√	√	√	√	√				
Maybach	240	Body	HRA-Automatic headlamp range adjustment and headlamp control	√	√	√	√	√		SP0215,	CD0003, CD0006, CD0010, CD0012, CD0014, CD0019, CD0022, CD0023, CD0025,	
Maybach	240	Body	MSS-Special vehicle multifunction control module	√	√	√	√	√			CD0003, CD0006, CD0010, CD0012, CD0014, CD0019, CD0022, CD0023, CD0025,	
Maybach	240	Body	OCP-Overhead control panel	√	√	√	√	√				
Maybach	240	Body	Pass side SAM-Passenger-side signal acquisition and actuation module	√	√	√	√	√				
Maybach	240	Body	PSE-Pneumatic system equipment	√	√	√	√	√				
Maybach	240	Body	Rear SAM 1-Rear signal acquisition and actuation module1	√	√	√	√	√				

Maybach	240	Body	Rear SAM 2-Rear signal acquisition and actuation module2	√	√	√	√		√			
Maybach	240	Body	System diagnosis(CAN)	√	√	√	√					
Maybach	240	Body	VBF-Front control panel	√	√	√	√		√			
Maybach	240	Body	WSS-Weight sensing system	√	√	√	√					
Maybach	240	Chassis	AIRmatic	√	√	√	√		√			
Maybach	240	Chassis	ESP-Electronic stability program	√	√	√	√					
Maybach	240	Chassis	SBC-Right Sensotronic Brake Control	√	√	√	√					
Maybach	240	Chassis	SBC-Sensotronic Brake Control	√	√	√	√				CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170.	
Maybach	240	Chassis	TPM-Tire pressure monitor	√	√	√	√				CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170.	
Maybach	240	Drive	DTR-Distronic	√	√	√	√					
Maybach	240	Drive	DTR-Distronic	√	√	√	√					
Maybach	240	Drive	ESM-Electronic selector module	√	√	√	√		√		CD0026, CD0029, CD0026, CD0027, CD0028, CD0029.	
Maybach	240	Drive	ETC-Electronic transmission control	√	√	√	√				CD0026, CD0029, CD0026, CD0027, CD0028, CD0029.	
Maybach	240	Drive	ETC-Electronic transmission	√	√	√	√					
Maybach	240	Drive	FSCU-Fuel pump	√	√	√	√					
Maybach	240	Drive	ME 2.7.2-Motor electronics 2.7.2	√	√	√	√				CD0298, CD0299, CD0300, CD0301, CD0302, CD0303.	
Maybach	240	Drive	ME 2.7.2-Motor electronics 2.7.2	√	√	√	√					
Maybach	240	Drive	ME SFI 2.7.1-Motor electronics	√	√	√	√					
Maybach	240	Drive	SGR-Radar sensors control unit	√	√	√	√					
Maybach	240	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√					
Maybach	240	Information and communication	AUDIO	√	√	√	√				CD0044, CD0045, CD0046,	

Maybach	240	Information and communication	AVC-Audio video controller	√	√	√			√		CD0044, CD0045, CD0046,	
Maybach	240	Information and communication	CDC-CD changer(REAR)	√	√	√	√					
Maybach	240	Information and communication	COMAND or AUDIO	√	√	√	√					
Maybach	240	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√					
Maybach	240	Information and communication	CTEL-Telecommunication for telematics services	√	√	√	√					
Maybach	240	Information and communication	GPS box	√	√	√	√					
Maybach	240	Information and communication	ICM-Instrument cluster	√	√	√	√		√			
Maybach	240	Information and communication	KTL-Left headphone transmitter	√	√	√	√				CD0139, CD0140,	
Maybach	240	Information and communication	KTR-Right headphone transmitter	√	√	√	√					
Maybach	240	Information and communication	NAVI-Navigation system	√	√	√	√					
Maybach	240	Information and communication	PTS-Parktronic system	√	√	√	√		√	SP0170,SP0162,	CD0212, CD0214, CD0215, CD0216, CD0217,	
Maybach	240	Information and communication	SCM [MRM]-Steering column module	√	√	√	√		√		CD0212, CD0214, CD0215, CD0216, CD0217,	
Maybach	240	Information and communication	SDAR-Satellite radio	√	√	√	√					
Maybach	240	Information and communication	SOUND-Bose sound system	√	√	√	√			SP0001,		
Maybach	240	Information and communication	TELE AID-Control unit	√	√	√	√			SP0001,		
Maybach	240	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√					
Maybach	240	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√					
Maybach	240	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√					
Maybach	240	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√					
Maybach	240	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	√	√	√	√					
Maybach	240	Information and communication	TV-TV tuner	√	√	√	√					
Maybach	240	Information and communication	TV-TV tuner(AGW)	√	√	√	√			SP0176,SP0177,		

Maybach	240	Information and communication	TV-TV tuner(REAR)	√	√	√	√				
Maybach	240	Information and communication	TV-TV tuner(REAR)	√	√	√	√				
Maybach	240	Information and communication	VCS-Voice control system	√	√	√					
Maybach	240	Seats and Doors	DCM FL-Door control module front left	√	√	√	√		√		
Maybach	240	Seats and Doors	DCM FR-Door control module front right	√	√	√	√		√		CD0293, CD0294,
Maybach	240	Seats and Doors	DCM RL-Door control module rear left	√	√	√	√		√		
Maybach	240	Seats and Doors	DCM RR-Door control module rear right	√	√	√	√		√		
Maybach	240	Seats and Doors	ESA FL-Electric seat adjustment front left	√	√	√	√		√		
Maybach	240	Seats and Doors	ESA FR-Electric seat adjustment front right	√	√	√	√		√		CD0066, CD0067, CD0068,
Maybach	240	Seats and Doors	ESA LR-Left rear electrical seat adjustment	√	√	√	√		√		
Maybach	240	Seats and Doors	ESA RR-Right rear electrical seat adjustment	√	√	√	√		√		SP0127,
Maybach	240	Seats and Doors	LDCA-Electric left door closing assist	√	√	√	√				SP0127,
Maybach	240	Seats and Doors	MKL HL-Rear left multicontour backrest	√	√	√	√		√		SP0132,SP0135,SP0136, SP0137,SP0138,SP0139, SP0140,SP0141,SP0142, SP0143,SP0144,SP0145, SP0150
Maybach	240	Seats and Doors	MKL HR-Rear right multicontour backrest	√	√	√	√		√		SP0132,SP0135,SP0136, SP0137,SP0138,SP0139, SP0140,SP0141,SP0142, SP0143,SP0144,SP0145, SP0150
Maybach	240	Seats and Doors	OSB FL-Multicontour backrest front left	√	√	√	√		√		
Maybach	240	Seats and Doors	OSB FR-Multicontour backrest front right	√	√	√	√		√		
Maybach	240	Seats and Doors	PWC-Partition wall control	√	√	√	√				
Maybach	240	Seats and Doors	RDCA-Electric right door closing assist	√	√	√	√				CD0295, CD0296, CD0297,
Maybach	240	Seats and Doors	TLC-Trunk lid control	√	√	√					CD0295, CD0296, CD0297,
R-Class	251	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		√		

R-Class	251	Air conditioning	LRH-Steering wheel heater	√	√	√	*		√			
R-Class	251	Air conditioning	STH-Stationary heater with remote control	√	√	√	√		√			
R-Class	251	Body	AB-Airbag	√	√	√	√					
R-Class	251	Body	CGW-Central gateway	√	√	√	*					
R-Class	251	Body	EZS-Electronic ignition switch	√	√	√	√					CD0133, CD0155, CD0159, CD0160,
R-Class	251	Body	EZS-Electronic ignition switch	√	√	√	√					
R-Class	251	Body	HBF-Rear control field	√	√	√	√		√			
R-Class	251	Body	HRA FL-Front left headlamp range control	√	√	√	√					CD0001, CD0002, CD0003, CD0007, CD0008, CD0011, CD0015, CD0017, CD0018, CD0020,
R-Class	251	Body	HRA FR-Front right headlamp range control	√	√	√	√					CD0050, CD0051, CD0052,
R-Class	251	Body	HRA-Automatic headlamp range adjustment and headlamp control	√	√	√	√		√			
R-Class	251	Body	KG-Keyless Go	√	√	√	√					CD0091, CD0107, CD0109, CD0124, CD0091, CD0107,
R-Class	251	Body	KG-KEYLESS GO	√	√	√	√					CD0091, CD0107, CD0109, CD0124, CD0091, CD0107,
R-Class	251	Body	OCP-Overhead control panel	√	√	√	√		√			
R-Class	251	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√					CD0137, CD0137,
R-Class	251	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					CD0137, CD0137,
R-Class	251	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					CD0161,
R-Class	251	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
R-Class	251	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					

R-Class	251	Body	SAM F-Signal acquisition and actuation module front	√	√	√	√		√	SP0215,		
R-Class	251	Body	System diagnosis(CAN)	√	√	√	*					
R-Class	251	Body	WSS-Weight sensing system	√	√	√	√				CD0229,	
R-Class	251	Chassis	DTR-Distronic	√	√	√	√				CD0234, CD0238, CD0239, CD0240, CD0241, CD0244, CD0248, CD0249, CD0252, CD0255.	
R-Class	251	Chassis	EHPS-Electrohydraulic Power Steering	√	√	√	√					
R-Class	251	Chassis	ESP-Electronic stability program	√	√	√	√					
R-Class	251	Chassis	Suspension	√	√	√	√		√			
R-Class	251	Chassis	Suspension	√	√	√	√		√			
R-Class	251	Chassis	TPM-Tire pressure monitor	√	√	√	√					
R-Class	251	Chassis	TPM-Tire pressure monitor	√	√	√	√					
R-Class	251	Drive	CDI 4-Common Rail Diesel	√	√	√	√	√				
R-Class	251	Drive	CDI 6-Common Rail Diesel	√	√	√	*	√				
R-Class	251	Drive	CDI 60LS-Common Rail Diesel Injection	√	√	√	*	√			CD0292,	
R-Class	251	Drive	CDI 6BIN5-Common Rail Diesel Injection	√	√	√	*	√				
R-Class	251	Drive	DTR-Distronic	√	√	√	√					
R-Class	251	Drive	ETC-Electronic transmission	√	√	√	√	√				
R-Class	251	Drive	FSCU Left-Control unit 'Left fuel pump'	√	√	√	*					
R-Class	251	Drive	FSCU Right-Control unit 'Right fuel pump'	√	√	√	*					
R-Class	251	Drive	FSCU-Fuel pump	√	√	√	*					
R-Class	251	Drive	FSCU-Fuel pump	√	√	√	√					
R-Class	251	Drive	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√			SP0127,		
R-Class	251	Drive	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	√					
R-Class	251	Drive	ISM-Intelligent servo module	√	√	√	√			SP0153,SP0154,		
R-Class	251	Drive	ISM-Shift module	√	√	√	√			SP0255,SP0256,SP0254,		
R-Class	251	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	√	√	√	√	√	√	SP0255,SP0256,SP0254,		
R-Class	251	Drive	ME 9.7-Motor electronics 9.7	√	√	√	√	√	√			
R-Class	251	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√	√				

R-Class	251	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√	√				
R-Class	251	Drive	MED 17.7-Motor electronics for direct injection 17.7	√	√	√	√	√				
R-Class	251	Drive	MED 17.7-Motor electronics for direct injection 17.7	√	√	√	*	√				
R-Class	251	Drive	SCR-Selective Catalytic Reduction	√	√	√	√		√			
R-Class	251	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√				CD0165, CD0166, CD0167, CD0168, CD0169, CD017	
R-Class	251	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√				CD0165, CD0166, CD0167, CD0168, CD0169, CD017	
R-Class	251	Information and communication	ASSYST PLUS-PLUS Active Service System	√	√	√	√				CD0171,	
R-Class	251	Information and communication	ASSYST-Active Service System	√	√	√	√					
R-Class	251	Information and communication	AUDIO	√	√	√	√				CD0172,	
R-Class	251	Information and communication	AVE H-Rear audio video unit	√	√	√	√				CD0281, CD0282, CD0283, CD0284,	
R-Class	251	Information and communication	AVE H-Rear audio video unit	√	√	√	√			SP0161,SP0170,SP0162, SP0163,		
R-Class	251	Information and communication	CDC-CD changer	√	√	√	√				CD0026, CD0029,	
R-Class	251	Information and communication	CM-Compass module	√	√	√	√				CD0298, CD0299, CD0300, CD0301, CD0302, CD0303,	
R-Class	251	Information and communication	COMAND or AUDIO	√	√	√	√			SP0001,		
R-Class	251	Information and communication	COMAND or AUDIO	√	√	√	√					
R-Class	251	Information and communication	CTEL-Cellular telephone	√	√	√	√					
R-Class	251	Information and communication	CTEL-Cellular telephone(JAPAN)	√	√	√	√					
R-Class	251	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√					
R-Class	251	Information and communication	DAB-Digital radio	√	√	√	√					

R-Class	251	Information and communication	IC-Instrument cluster	√	√	√	√		√			
R-Class	251	Information and communication	Left rear screen	√	√	√	√					
R-Class	251	Information and communication	NAVI-Navigation system	√	√	√	√					
R-Class	251	Information and communication	PTS-Parktronic system	√	√	√	√					
R-Class	251	Information and communication	PTS-Parktronic system	√	√	√	√			SP0176,SP0177,		
R-Class	251	Information and communication	RFK-Backup camera	√	√	√	√					
R-Class	251	Information and communication	Right rear screen	√	√	√	√					
R-Class	251	Information and communication	SCM [MRM]-Steering column module	√	√	√	√		√			
R-Class	251	Information and communication	SDAR-Satellite radio	√	√	√	√					
R-Class	251	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√					
R-Class	251	Information and communication	SOUND-Sound system	√	√	√	√					
R-Class	251	Information and communication	TELE AID-Control unit	√	√	√	√					
R-Class	251	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√					
R-Class	251	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√					
R-Class	251	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√			SP0035,SP0036,SP0037, SP0038,SP0039,SP0040, SP0041,SP0042,SP0043, SP0044,		
R-Class	251	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√					
R-Class	251	Information and communication	TV-TV tuner	√	√	√	√			SP0058,SP0059,SP0060, SP0061,SP0062,SP0063, SP0064,SP0065,SP0066, SP0067,SP0068,SP0069, SP0070,SP0071,SP0072, SP0073,SP0074,SP0075,	CD0293, CD0294,	
R-Class	251	Information and communication	TV-TV tuner	√	√	√	√					
R-Class	251	Information and communication	TV-TV tuner	√	√	√	*			SP0127,		

R-Class	251	Information and communication	TV-TV tuner	√	√	√	√			SP0130,SP0131,SP0132,SP0133,SP0134,SP0136,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0146,SP0147,SP0148,SP0149,		
R-Class	251	Information and communication	TV-TV tuner(AGW)	√	√	√	√					
R-Class	251	Information and communication	UCI-Media interface	√	√	√	*				CD0223,	
R-Class	251	Information and communication	VCS-Voice control system	√	√	√	*					
R-Class	251	Seats and Doors	DCM FL-Door control module front left	√	√	√	√		√			
R-Class	251	Seats and Doors	DCM FR-Door control module front right	√	√	√	√		√			
R-Class	251	Seats and Doors	DS LF-Left front dynamic seat	√	√	√	√		√			
R-Class	251	Seats and Doors	DS RF-Right front dynamic seat	√	√	√	√		√			
R-Class	251	Seats and Doors	DSP-Pneumatic pump for dynamic seat	√	√	√	√					
R-Class	251	Seats and Doors	ESA driver-Electric seat adjustment driver (with memory)	√	√	√	√				CD0132,	
R-Class	251	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√					
R-Class	251	Seats and Doors	HS-Seat heater	√	√	√	√		√	SP0178,SP0179,SP0180,SP0181,SP0182,SP0183,SP0184,		
R-Class	251	Seats and Doors	REDC-Rear end door closing control module	√	√	√	√		√			
R-Class	251	Seats and Doors	REDC-Rear end door closing control module	√	√	√	√		√	SP0199,SP0200,SP0201,SP0202,SP0203,SP0204,SP0205,SP0206,		
S-Class	140	Air conditioning	AAC-Automatic air conditioning	√	√	√				SP0199,SP0200,SP0201,SP0202,SP0203,SP0204,SP0205,SP0206,		
S-Class	140	Body	AirBag	√	√	√						
S-Class	140	Body	KFB-Power windows,emergency opening,convenience closing,tilting/sliding roof	√	√	√						
S-Class	140	Body	PSE-Pneumatic system equipment	√	√	√						
S-Class	140	Body	PTS-Parktronic system	√	√	√						
S-Class	140	Body	RFL-Radio frequency locking/electric central locking	√	√	√	√					
S-Class	140	Chassis	BAS-Brake assist	√	√	√	√					

S-Class	140	Chassis	EGS,EAG-Electronic control for automatic transmission	√	√	√						
S-Class	140	Chassis	ESP-Electronic stability program	√	√	√	√					
S-Class	140	Chassis	SPS Speed-sensitive power	√	√	√	√					
S-Class	140	Drive	EFP,TPM,ISC-Electronic accelerator pedal,Cruise control,Idle speed control	√	√	√						
S-Class	140	Drive	ME1RE-Motor electronics 1 RE	√	√	√					CD0001, CD0002, CD0003, CD0007, CD0008, CD0011, CD0015, CD0017, CD0018, CD0020, CD0007, CD0008, CD0012, CD0016, CD0018, CD0021, CD0024	
S-Class	140	Drive	ME2 SFI-Motor electronics 2	√	√	√	√				CD0001, CD0002, CD0003, CD0007, CD0008, CD0011, CD0015, CD0017, CD0018, CD0020, CD0007, CD0008, CD0012, CD0016, CD0018, CD0021, CD0024	
S-Class	140	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√			√			
S-Class	220	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		√		CD0066, CD0067, CD0068,	
S-Class	220	Air conditioning	LRH-Steering wheel heater	√	√	√	√		√			
S-Class	220	Air conditioning	REAR AC-Rear air conditioning	√	√	√	√		√			
S-Class	220	Air conditioning	STH-Stationary heater	√	√	√	√					
S-Class	220	Air conditioning	STH-Stationary heater	√	√	√	√		√			
S-Class	220	Air conditioning	STH-Stationary heater	√	√	√	√					
S-Class	220	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√		√			
S-Class	220	Body	AB-Airbag	√	√	√	√					

S-Class	220	Body	AB-Airbag	√	√	√	√					
S-Class	220	Body	AHE-Trailer recognition	√	√	√	√		√			CD0295, CD0296, CD0297,
S-Class	220	Body	CGW-Central gateway	√	√	√						CD0295, CD0296, CD0297,
S-Class	220	Body	EZS-Electronic ignition switch	√	√	√	√					
S-Class	220	Body	EZS-Electronic ignition switch	√	√	√	√					
S-Class	220	Body	EZS-Electronic ignition switch	√	√	√	√					
S-Class	220	Body	HRA FL-Front left headlamp range control	√	√	√	√					

S-Class	220	Body	HRA FR-Front right headlamp range control	√	√	√	√	√		CD0133, CD0155, CD0159, CD0160,
S-Class	220	Body	HRA-Headlamp range adjustment	√	√	√	√	√		
S-Class	220	Body	HRA-Headlamp range adjustment	√	√	√	√	√		
S-Class	220	Body	KG-Keyless Go	√	√	√	√	√		CD0001, CD0002, CD0003, CD0007, CD0008, CD0011, CD0015, CD0017, CD0018, CD0020.
S-Class	220	Body	MSS-Special vehicle multifunction control module	√	√	√	√	√	SP0165,	CD0050, CD0051, CD0052,
S-Class	220	Body	OCP-Overhead control panel	√	√	√	√	√	SP0165,	
S-Class	220	Body	OCP-Overhead control panel	√	√	√	√	√		CD0091, CD0107, CD0109,
S-Class	220	Body	PSE-Pneumatic system equipment	√	√	√	√	√		CD0091, CD0107, CD0109, CD0124, CD0091, CD0107,
S-Class	220	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	√		
S-Class	220	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√			CD0137, CD0137,
S-Class	220	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√			CD0137, CD0137,
S-Class	220	Body	SAM FL-Front left signal acquisition and actuation module	√	√	√	√	√		
S-Class	220	Body	SAM FR-Front right signal acquisition and actuation module	√	√	√	√	√		
S-Class	220	Body	System diagnosis(CAN)	√	√	√				CD0161,
S-Class	220	Body	UCP-Upper control panel	√	√	√	√	√		
S-Class	220	Body	UCP-Upper control panel	√	√	√	√	√		
S-Class	220	Chassis	ABC-ABC active body control	√	√	√	√	√		
S-Class	220	Chassis	AIRmatic	√	√	√	√	√		
S-Class	220	Chassis	ESP-Electronic stability program	√	√	√	√	√		CD0229,
S-Class	220	Chassis	TPM-Tire pressure monitor	√	√	√	√	√		CD0234, CD0238, CD0239, CD0240, CD0241, CD0244, CD0248, CD0249, CD0252, CD0255.
S-Class	220	Drive	CDI 2-Common Rail Diesel	√	√	√	√	√		
S-Class	220	Drive	CDI 3-Common Rail Diesel Injection3	√	√	√	√	√		

S-Class	220	Drive	CDI 3-Common Rail Diesel Injection3	√	√	√	√		√		CD0292,	
S-Class	220	Drive	CDI 3-Common Rail Diesel Injection3	√	√	√	√		√			
S-Class	220	Drive	CDI V-Common Rail Diesel	√	√	√	√		√			
S-Class	220	Drive	CDI V-Common Rail Diesel	√	√	√	√					
S-Class	220	Drive	DTR-Distronic	√	√	√	√					
S-Class	220	Drive	DTR-Distronic	√	√	√	√					
S-Class	220	Drive	ESM-Electronic selector module	√	√	√	√		√	SP0005,SP0006,SP0007,		
S-Class	220	Drive	ETC-Electronic transmission	√	√	√	√					
S-Class	220	Drive	ETC-Electronic transmission	√	√	√	√					
S-Class	220	Drive	ETC-Electronic transmission	√	√	√	√					
S-Class	220	Drive	ME SFI 2.0-Motor electronics 2.0	√	√	√	√		√			
S-Class	220	Drive	ME SFI 2.0-Motor electronics 2.0	√	√	√	√		√			
S-Class	220	Drive	ME SFI 2.7-Motor electronics 2.7	√	√	√	√					
S-Class	220	Drive	ME SFI 2.7.1-Motor electronics	√	√	√	√					
S-Class	220	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
S-Class	220	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√				CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD016	
S-Class	220	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√				CD0165, CD0166, CD0167, CD0168, CD0169, CD0170, CD0165, CD0166, CD0167, CD0168, CD0169, CD0170.	
S-Class	220	Information and communication	AUDIO	√	√	√	√				CD0171,	
S-Class	220	Information and communication	AUDIO	√	√	√	√					
S-Class	220	Information and communication	CDC-CD changer	√	√	√	√				CD0184, CD0185, CD0186, CD0187,	
S-Class	220	Information and communication	CDC-CD changer	√	√	√	√				CD0184, CD0185, CD0186, CD0187,	
S-Class	220	Information and communication	COMAND	√	√	√	√		√		CD0281, CD0282, CD0283, CD0284,	

S-Class	220	Information and communication	COMAND or AUDIO	√	√	√	√					
S-Class	220	Information and communication	CTEL over K-wire-Telematic system	√	√	√						
S-Class	220	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√				SP0162,SP0174,		
S-Class	220	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√					
S-Class	220	Information and communication	CTEL-Telecommunication for telematics services	√	√	√	√					
S-Class	220	Information and communication	DN-Dynamic navigation by means of CTEL	√	√	√	√					
S-Class	220	Information and communication	E call [Japan]-Emergency call system	√	√	√	√					
S-Class	220	Information and communication	E call [Japan]-Telematic system	√	√	√	√		√			
S-Class	220	Information and communication	E call [USA]-Emergency call system	√	√	√						
S-Class	220	Information and communication	E call [USA]-Telematic system	√	√	√	√					
S-Class	220	Information and communication	GPS box	√	√	√	√					
S-Class	220	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√		√			
S-Class	220	Information and communication	NAVI-Navigation system	√	√	√	√					
S-Class	220	Information and communication	PTS-Parktronic system	√	√	√	√		√			
S-Class	220	Information and communication	SCM [MRM]-Steering column module	√	√	√	√		√			
S-Class	220	Information and communication	SCM [MRM]-Steering column module	√	√	√	√		√			
S-Class	220	Information and communication	SDAR-Satellite radio	√	√	√						
S-Class	220	Information and communication	SDAR-Satellite radio	√	√	√	√					
S-Class	220	Information and communication	SOUND-Bose sound system	√	√	√	√					
S-Class	220	Information and communication	SOUND-Sound system	√	√	√	√					
S-Class	220	Information and communication	TELE AID-Control unit	√	√	√	√					
S-Class	220	Information and communication	TELE AID-Emergency call system	√	√	√	√					
S-Class	220	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√					

S-Class	220	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√					
S-Class	220	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√					
S-Class	220	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√					
S-Class	220	Information and communication	TELE AID-Telematic system	√	√	√	√					
S-Class	220	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	√	√	√	√					
S-Class	220	Information and communication	TV-TV tuner	√	√	√	√					
S-Class	220	Information and communication	TV-TV tuner	√	√	√	√					
S-Class	220	Information and communication	TV-TV tuner(AGW)	√	√	√	√					
S-Class	220	Information and communication	UHI-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	√					
S-Class	220	Information and communication	VCS-Voice control system	√	√	√	√					
S-Class	220	Information and communication	VCS-Voice control system	√	√	√	√			SP0021,SP0026,SP0032,		
S-Class	220	Seats and Doors	DCM FL-Door control module front left	√	√	√	√	√		SP0021,SP0026,SP0032,		
S-Class	220	Seats and Doors	DCM FR-Door control module front right	√	√	√	√	√		SP0021,SP0026,SP0032,		
S-Class	220	Seats and Doors	DCM RL-Door control module rear left	√	√	√	√	√				
S-Class	220	Seats and Doors	DCM RR-Door control module rear right	√	√	√	√	√				
S-Class	220	Seats and Doors	DS LF-Left front dynamic seat	√	√	√	√	√		SP0127,		
S-Class	220	Seats and Doors	DS RF-Right front dynamic seat	√	√	√	√	√		SP0127,		
S-Class	220	Seats and Doors	DSP-Pneumatic pump for dynamic seat	√	√	√	√	√		SP0132,SP0135,SP0136, SP0137,SP0138,SP0139, SP0140,SP0141,SP0142, SP0143,SP0144,SP0145, SP0150,SP0130,SP0131, SP0146,SP0147,SP0148, SP0149,		

S-Class	220	Seats and Doors	ESA FL-Electric seat adjustment front left	√	√	√	√	√	SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0146,SP0147,SP0148,SP0149,		
S-Class	220	Seats and Doors	ESA FR-Electric seat adjustment front right	√	√	√	√	√	SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0146,SP0147,SP0148,SP0149,		
S-Class	220	Seats and Doors	ESA R-Electric seat adjustment	√	√	√	√	√			
S-Class	220	Seats and Doors	OSB FL-Multicontour backrest front left	√	√	√	√	√			
S-Class	220	Seats and Doors	OSB FR-Multicontour backrest front right	√	√	√	√	√			
S-Class	220	Seats and Doors	OSB R-Multicontour backrest	√	√	√	√	√			
SL-Class	129	Air conditioning	AAC-Automatic air conditioning	√	√	√					
SL-Class	129	Air conditioning	STH-Stationary heater	√	√	√	√			CD0001, CD0002, CD0007, CD0008, CD0015, CD0017, CD0018,	
SL-Class	129	Body	AB-Airbag	√	√	√					
SL-Class	129	Body	APS-Auto pilot system	√	√	√	√				
SL-Class	129	Body	HRA-Headlamp range adjustment	√	√	√					
SL-Class	129	Body	RFL-Radio frequency locking/electric central locking	√	√	√	√			CD0049, CD0050, CD0053, CD0056, CD0057, CD0059, CD0060,	
SL-Class	129	Chassis	ASR-Acceleration Slip	√	√	√	√				
SL-Class	129	Chassis	ASR-Acceleration Slip	√	√	√	√				
SL-Class	129	Chassis	BAS-Brake assist	√	√	√	√				
SL-Class	129	Chassis	ESP-Electronic stability program	√	√	√	√				
SL-Class	129	Chassis	ESP-Electronic stability program	√	√	√	√		SP0165,		
SL-Class	129	Chassis	ESP-Electronic stability program	√	√	√	√		SP0165,	CD0189, CD0190, CD0191, CD0192, CD0193, CD0194, CD0195, CD0196, CD0197, CD0198, CD0199,	

SL-Class	129	Chassis	ETS-Electronic traction system	√	√	√	√					CD0200,	
SL-Class	129	Drive	ETC-Electronic transmission	√	√	√							
SL-Class	129	Drive	ME1 SFI-Motor electronics	√	√	√							
SL-Class	129	Drive	ME2 SFI-Motor electronics 2	√	√	√	√						
SL-Class	129	Information and communication	AUDIO	√	√	√	√						
SL-Class	129	Information and communication	CDC-CD changer	√	√	√							
SL-Class	129	Information and communication	CTEL over K-wire-Telematic system	√	√	√						CD0257, CD0263, CD0264, CD0267, CD0268, CD0269, CD0270, CD0273, CD0276,	
SL-Class	129	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√						CD0235, CD0236, CD0242, CD0246, CD0251, CD0255,	
SL-Class	129	Information and communication	DN-Dynamic navigation by means of CTEL	√	√	√	√						
SL-Class	129	Information and communication	E call [Japan]-Emergency call system	√	√	√	√						
SL-Class	129	Information and communication	E call [USA]-Emergency call system	√	√	√							
SL-Class	129	Information and communication	E call [USA]-Telematic system	√	√	√	√						
SL-Class	129	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√						
SL-Class	129	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√			√				
SL-Class	129	Information and communication	TELE AID-Emergency call system	√	√	√	√						
SL-Class	129	Information and communication	UHI-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	√						
SL-Class	129	Information and communication	VCS-Voice control system	√	√	√							
SL-Class	230	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		√				
SL-Class	230	Air conditioning	LRH-Steering wheel heater	√	√	√	√		√				
SL-Class	230	Air conditioning	STH-Stationary heater	√	√	√	√						
SL-Class	230	Body	AB-Airbag	√	√	√	√						
SL-Class	230	Body	AB-Airbag	√	√	√	√						

SL-Class	230	Body	AMG DRVU-AMG DRIVE UNIT	√	√	√	√					
SL-Class	230	Body	BNS-Vehicle power supply control module	√	√	√	√					
SL-Class	230	Body	CGW-Central gateway	√	√	√						
SL-Class	230	Body	Dr side SAM-Driver signal acquisition and actuation module	√	√	√	√		√			
SL-Class	230	Body	EZS-Electronic ignition switch	√	√	√	√					
SL-Class	230	Body	EZS-Electronic ignition switch	√	√	√	√					
SL-Class	230	Body	HRA FL-Front left headlamp range control	√	√	√	√					
SL-Class	230	Body	HRA FR-Front right headlamp range control	√	√	√	√		√			
SL-Class	230	Body	KG-Keyless Go	√	√	√	√		√			
SL-Class	230	Body	KG-Keyless Go	√	√	√	√					
SL-Class	230	Body	LCP-Lower control panel	√	√	√	√		√			
SL-Class	230	Body	OCP-Overhead control panel	√	√	√	√		√		CD0131,	
SL-Class	230	Body	Pass side SAM-Passenger-side signal acquisition and actuation module	√	√	√	√		√			
SL-Class	230	Body	PSE-Pneumatic system equipment	√	√	√	√		√			

SL-Class	230	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√		√	SP0165,		
SL-Class	230	Body	RVC-Rollover bar/vario roof control module	√	√	√	√			SP0165,		
SL-Class	230	Body	RVC-Rollover bar/vario roof control module	√	√	√	√			SP0165,		
SL-Class	230	Body	System diagnosis(CAN)	√	√	√					CD0171,	
SL-Class	230	Body	System diagnosis(CAN)	√	√	√						
SL-Class	230	Body	WSS-Weight sensing system	√	√	√	√				CD0172,	
SL-Class	230	Body	XALWA L-Xenon headlamp, left	√	√	√	√		√		CD0184, CD0185, CD0186, CD0187,	
SL-Class	230	Body	XALWA R-Xenon headlamp, right	√	√	√	√				CD0281, CD0282, CD0283, CD0284,	
SL-Class	230	Chassis	ABC-ABC active body control	√	√	√	√		√			
SL-Class	230	Chassis	ABC-ABC active body control	√	√	√	√		√			
SL-Class	230	Chassis	ESP-Electronic stability program	√	√	√	√					
SL-Class	230	Chassis	ESP-Electronic stability program	√	√	√	√					
SL-Class	230	Chassis	SBC-Sensotronic Brake Control	√	√	√	√					
SL-Class	230	Chassis	SBC-Sensotronic Brake Control	√	√	√	√					
SL-Class	230	Chassis	SBC-Sensotronic Brake Control	√	√	√	√					
SL-Class	230	Chassis	TPM-Tire pressure monitor	√	√	√	√		√			
SL-Class	230	Chassis	TPM-Tire pressure monitor	√	√	√	√					
SL-Class	230	Drive	DTR-Distronic	√	√	√	√					
SL-Class	230	Drive	DTR-Distronic	√	√	√	√					
SL-Class	230	Drive	ESM-Electronic selector module	√	√	√	√		√			
SL-Class	230	Drive	ETC-Electronic transmission	√	√	√	√					
SL-Class	230	Drive	ETC-Electronic transmission	√	√	√	√					
SL-Class	230	Drive	ETC-Electronic transmission	√	√	√	√					
SL-Class	230	Drive	ME 2.7.2-Motor electronics 2.7.2	√	√	√	√					
SL-Class	230	Drive	ME 2.7.2-Motor electronics 2.7.2	√	√	√	√					
SL-Class	230	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	√	√	√	√		√			
SL-Class	230	Drive	ME 9.7-Motor electronics 9.7	√	√	√	√		√			
SL-Class	230	Drive	ME SFI 2.7.1-Motor electronics	√	√	√	√					
SL-Class	230	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
SL-Class	230	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√			SP0005,SP0006,SP0007,		
SL-Class	230	Drive	SEQ-Sequentronic automated manual transmission	√	√	√	√			SP0005,SP0006,SP0007,		
SL-Class	230	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√					
SL-Class	230	Information and communication	AUDIO	√	√	√	√					

SL-Class	230	Information and communication	AUDIO	√	√	√	√					
SL-Class	230	Information and communication	CDC-CD changer	√	√	√						
SL-Class	230	Information and communication	CDC-CD changer	√	√	√	√			SP0216,SP0217,SP0218,		
SL-Class	230	Information and communication	COMAND	√	√	√	√		√	SP0216,SP0217,SP0218,		
SL-Class	230	Information and communication	COMAND or AUDIO	√	√	√	√			SP0216,SP0217,SP0218,		
SL-Class	230	Information and communication	CTEL over K-wire-Telematic system	√	√	√						
SL-Class	230	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√						
SL-Class	230	Information and communication	CTEL-Cellular telephone(JAPAN)	√	√	√	√					
SL-Class	230	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√					
SL-Class	230	Information and communication	CTEL-Telecommunication for telematics services	√	√	√	√					
SL-Class	230	Information and communication	D2B-COMAND, MCS or AUDIO	√	√	√	√					
SL-Class	230	Information and communication	DAB-Digital radio	√	√	√	√					
SL-Class	230	Information and communication	E call [Japan]-Telematic system	√	√	√	√		√			
SL-Class	230	Information and communication	E call [USA]-Telematic system	√	√	√	√					
SL-Class	230	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√		√			
SL-Class	230	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√		√			
SL-Class	230	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√		√			
SL-Class	230	Information and communication	NAVI-Navigation system	√	√	√	√					
SL-Class	230	Information and communication	PTS-Parktronic system	√	√	√	√					
SL-Class	230	Information and communication	PTS-Parktronic system	√	√	√						
SL-Class	230	Information and communication	SCM [MRM]-Steering column module	√	√	√	√		√			
SL-Class	230	Information and communication	SDAR-Satellite radio	√	√	√						
SL-Class	230	Information and communication	SDAR-Satellite radio	√	√	√	√					

SL-Class	230	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√					
SL-Class	230	Information and communication	SOUND-Bose sound system	√	√	√	√					
SL-Class	230	Information and communication	SOUND-Sound system	√	√	√	√					
SL-Class	230	Information and communication	TELE AID-Control unit	√	√	√	√					
SL-Class	230	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√					
SL-Class	230	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√					
SL-Class	230	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√					
SL-Class	230	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√					
SL-Class	230	Information and communication	TELE AID-Telematic system	√	√	√	√					
SL-Class	230	Information and communication	Telephone adapter for portable CTEL-Telecommunication for telematics services	√	√	√	√					
SL-Class	230	Information and communication	TV-TV tuner	√	√	√	√					
SL-Class	230	Information and communication	TV-TV tuner	√	√	√	√					
SL-Class	230	Information and communication	TV-TV tuner	√	√	√	√					
SL-Class	230	Information and communication	TV-TV tuner	√	√	√						
SL-Class	230	Information and communication	TV-TV tuner	√	√	√	√					
SL-Class	230	Information and communication	TV-TV tuner(AGW)	√	√	√	√					
SL-Class	230	Information and communication	UCI-Media interface	√	√	√						
SL-Class	230	Information and communication	UHI-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	√				SP0127,	
SL-Class	230	Information and communication	VCS-Voice control system	√	√	√					SP0127,	

SL-Class	230	Information and communication	VCS-Voice control system	√	√	√				SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0132,SP0135,SP0136,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,		
SL-Class	230	Seats and Doors	AIRSCARF	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,		
SL-Class	230	Seats and Doors	DCM L-Door control module left	√	√	√	√			SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,		
SL-Class	230	Seats and Doors	DCM R-Door control module	√	√	√	√					
SL-Class	230	Seats and Doors	ESA FL-Electric seat adjustment front left	√	√	√	√		√			
SL-Class	230	Seats and Doors	ESA FR-Electric seat adjustment front right	√	√	√	√		√			
SL-Class	230	Seats and Doors	OSB FL-Multicontour backrest front left	√	√	√	√					
SL-Class	230	Seats and Doors	OSB FR-Multicontour backrest front right	√	√	√	√					
SLK-Class	170(16-pin diagnostic socket)	Air conditioning	AAC-Automatic air conditioning	√	√	√						
SLK-Class	170(16-pin diagnostic socket)	Air conditioning	STH-Stationary heater	√	√	√	√					

SLK-Class	170(16-pin diagnostic socket)	Air conditioning	TAC-Automatic temperature control	√	√	√	√		√			
SLK-Class	170(16-pin diagnostic socket)	Body	AB-Airbag	√	√	√						
SLK-Class	170(16-pin diagnostic socket)	Body	CCM-Multifunction control module	√	√	√	√					
SLK-Class	170(16-pin diagnostic socket)	Body	HRA-Headlamp range adjustment	√	√	√	√					
SLK-Class	170(16-pin diagnostic socket)	Body	PSE-Pneumatic system equipment	√	√	√	√					
SLK-Class	170(16-pin diagnostic socket)	Body	RFL-Radio frequency locking/electric central locking	√	√	√	√					
SLK-Class	170(16-pin diagnostic socket)	Body	VR-Vario roof	√	√	√	√		√			
SLK-Class	170(16-pin diagnostic socket)	Chassis	BAS-Brake assist	√	√	√	√					
SLK-Class	170(16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	√	√	√	√		√			
SLK-Class	170(16-pin diagnostic socket)	Chassis	ESP-Electronic stability program	√	√	√	√					
SLK-Class	170(16-pin diagnostic socket)	Chassis	VP-Vacuum pump brake booster	√	√	√	√		√			
SLK-Class	170(16-pin diagnostic socket)	Drive	ESM-Electronic selector module	√	√	√	√					
SLK-Class	170(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	√	√	√	√				SP0153,SP0154,	
SLK-Class	170(16-pin diagnostic socket)	Drive	ETC-Electronic transmission control	√	√	√	√				SP0153,SP0154,	
SLK-Class	170(16-pin diagnostic socket)	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
SLK-Class	170(16-pin diagnostic socket)	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					

SLK-Class	170(16-pin diagnostic socket)	Drive	ME SFI-Motor electronics	√	√	√	√		√			
SLK-Class	170(16-pin diagnostic socket)	Information and communication	AUDIO	√	√	√	√					
SLK-Class	170(16-pin diagnostic socket)	Information and communication	CDC-CD changer	√	√	√						
SLK-Class	170(16-pin diagnostic socket)	Information and communication	CTEL over K-wire-Telematic system	√	√	√						
SLK-Class	170(16-pin diagnostic socket)	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√						
SLK-Class	170(16-pin diagnostic socket)	Information and communication	E call [Japan]-Emergency call system	√	√	√	√					
SLK-Class	170(16-pin diagnostic socket)	Information and communication	E call [USA]-Emergency call system	√	√	√						
SLK-Class	170(16-pin diagnostic socket)	Information and communication	E call [USA]-Telematic system	√	√	√	√					
SLK-Class	170(16-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√			√		SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,	
SLK-Class	170(16-pin diagnostic socket)	Information and communication	UHI-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	√				SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,	
SLK-Class	170(16-pin diagnostic socket)	Information and communication	VCS-Voice control system	√	√	√						
SLK-Class	170(38-pin diagnostic socket)	Air conditioning	AAC-Automatic air conditioning	√	√	√						
SLK-Class	170(38-pin diagnostic socket)	Air conditioning	TAC-Automatic temperature control	√	√	√	√		√			
SLK-Class	170(38-pin diagnostic socket)	Body	AB-Airbag	√	√	√						

SLK-Class	170(38-pin diagnostic socket)	Body	CCM-Multifunction control module	√	√	√	√					
SLK-Class	170(38-pin diagnostic socket)	Body	PSE-Pneumatic system equipment	√	√	√	√					
SLK-Class	170(38-pin diagnostic socket)	Body	RFL-Radio frequency locking/electric central locking	√	√	√	√					
SLK-Class	170(38-pin diagnostic socket)	Body	VR-Vario roof	√	√	√	√		√			
SLK-Class	170(38-pin diagnostic socket)	Chassis	ABS-Antilock brake system	√	√	√	√					
SLK-Class	170(38-pin diagnostic socket)	Chassis	ASR-Acceleration Slip Regulation	√	√	√	√					
SLK-Class	170(38-pin diagnostic socket)	Chassis	BAS-Brake assist	√	√	√	√					
SLK-Class	170(38-pin diagnostic socket)	Chassis	ETS-Electronic traction system	√	√	√	√				CD0298, CD0299, CD0300, CD0301, CD0302, CD0303,	
SLK-Class	170(38-pin diagnostic socket)	Drive	ETC-Electronic transmission control	√	√	√					CD0298, CD0299, CD0300, CD0301, CD0302, CD0303,	
SLK-Class	170(38-pin diagnostic socket)	Drive	ME2 SFI-Motor electronics 2	√	√	√	√					
SLK-Class	170(38-pin diagnostic socket)	Information and communication	AUDIO	√	√	√	√					
SLK-Class	170(38-pin diagnostic socket)	Information and communication	CDC-CD changer	√	√	√						
SLK-Class	170(38-pin diagnostic socket)	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√					CD0044, CD0045, CD0046,	
SLK-Class	170(38-pin diagnostic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√			√			
SLK-Class	170(38-pin diagnostic socket)	Information and communication	UHI-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	√					

SLK-Class	170(38-pin diagnostic socket)	Information and communication	VCS-Voice control system	√	√	√						
SLK-Class	171	Air conditioning	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	√	√	√	√		√			
SLK-Class	171	Body	AB-Airbag	√	√	√	√					
SLK-Class	171	Body	CGW-Central gateway	√	√	√						
SLK-	171	Body	EZS-Electronic ignition switch	√	√	√	√					
SLK-Class	171	Body	HRA-Automatic headlamp range adjustment and headlamp control	√	√	√	√		√			
SLK-	171	Body	OCP-Overhead control panel	√	√	√	√		√			
SLK-Class	171	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√		√			
SLK-Class	171	Body	SAM F-Signal acquisition and actuation module front	√	√	√	√		√			
SLK-	171	Body	System diagnosis(CAN)	√	√	√						
SLK-	171	Body	UCP-Upper control panel	√	√	√	√		√			
SLK-	171	Body	VR-Vario roof	√	√	√	√		√			
SLK-	171	Body	WSS-Weight sensing system	√	√	√	√					
SLK-	171	Chassis	ESP-Electronic stability program	√	√	√	√					
SLK-	171	Chassis	TPM-Tire pressure monitor	√	√	√	√					
SLK-	171	Drive	ESM-Electronic selector module	√	√	√	√		√			
SLK-	171	Drive	ETC-Electronic transmission	√	√	√	√					
SLK-	171	Drive	ETC-Electronic transmission	√	√	√	√					
SLK-	171	Drive	ETC-Electronic transmission	√	√	√	√					
SLK-	171	Drive	ME 9.7-Motor electronics 9.7	√	√	√	√		√			
SLK-	171	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
SLK-	171	Drive	ME SFI-Motor electronics	√	√	√	√					
SLK-	171	Drive	ME SFI-Motor electronics	√	√	√	√					
SLK-Class	171	Drive	SEQ-Sequentronic automated manual transmission	√	√	√	√					
SLK-Class	171	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√					
SLK-Class	171	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	√	√	√	√					
SLK-Class	171	Information and communication	ASSYST PLUS-PLUS Active Service System	√	√	√	√					
SLK-Class	171	Information and communication	ASSYST-Active Service System	√	√	√	√					

SLK-Class	171	Information and communication	AUDIO	√	√	√	√					
SLK-Class	171	Information and communication	CDC-CD changer	√	√	√	√					
SLK-Class	171	Information and communication	COMAND or AUDIO	√	√	√	√					
SLK-Class	171	Information and communication	COMAND or AUDIO	√	√	√	√					
SLK-Class	171	Information and communication	CTEL-Cellular telephone(JAPAN)	√	√	√	√					
SLK-Class	171	Information and communication	CTEL-Mobile phone adapter with universal interface	√	√	√	√			SP0153,SP0154,	CD0293, CD0294,	
SLK-Class	171	Information and communication	DAB-Digital radio	√	√	√	√					
SLK-Class	171	Information and communication	GPS box	√	√	√	√					
SLK-Class	171	Information and communication	IC-Instrument cluster	√	√	√	√		√			
SLK-Class	171	Information and communication	NAVI-Navigation system	√	√	√	√					
SLK-Class	171	Information and communication	PTS-Parktronic system	√	√	√	√		√			
SLK-Class	171	Information and communication	PTS-Parktronic system	√	√	√	√					
SLK-Class	171	Information and communication	SCM [MRM]-Steering column module	√	√	√	√		√		CD0223,	
SLK-Class	171	Information and communication	SDAR-Satellite radio	√	√	√	√				CD0223,	
SLK-Class	171	Information and communication	SDAR-Satellite radio(Valid for USA)	√	√	√	√					
SLK-Class	171	Information and communication	TELE AID-Control unit	√	√	√	√			SP0157,		
SLK-Class	171	Information and communication	TELE AID-Telematic services Emergency call	√	√	√	√			SP0176,SP0177,		
SLK-Class	171	Information and communication	TELE AID-Telematic services MB Info,Roadside assistance(USA, Canada),Tele	√	√	√	√					
SLK-Class	171	Information and communication	TELE AID-Telematic services Remote door unlocking,Remote door locking	√	√	√	√					
SLK-Class	171	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	√	√	√	√					
SLK-Class	171	Information and communication	TV-TV tuner	√	√	√	√					
SLK-Class	171	Information and communication	TV-TV tuner	√	√	√	√					
SLK-Class	171	Information and communication	TV-TV tuner	√	√	√						

SLK-Class	171	Information and communication	UCI-Media interface	√	√	√						
SLK-Class	171	Information and communication	VCS-Voice control system	√	√	√						
SLK-Class	171	Seats and Doors	DCM L-Door control module left	√	√	√	√		√	SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,		
SLK-Class	171	Seats and Doors	DCM R-Door control module right	√	√	√	√		√	SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,		
SLK-Class	171	Seats and Doors	ESA driver-Electric seat adjustment driver (with memory)	√	√	√	√		√	SP0132,SP0135,SP0136,SP0137,SP0138,SP0139,SP0140,SP0141,SP0142,SP0143,SP0144,SP0145,SP0150,SP0130,SP0131,SP0133,SP0134,SP0146,SP0147,SP0148,SP0149,	CD0008, CD0012, CD0013, CD0016, CD0017, CD0018, CD0003, CD0006, CD0010, CD0014, CD0019, CD0022, CD0023, CD0025,	
SLK-Class	171	Seats and Doors	ESA passenger-Electric seat adjustment passenger	√	√	√	√		√		CD0008, CD0012, CD0013, CD0016, CD0017, CD0018, CD0003, CD0006, CD0010, CD0012, CD0014, CD0019, CD0022, CD0023, CD0025,	
SLK-	171	Seats and Doors	HS-Seat heater	√	√	√	√		√			
SLR-	199	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		√			
SLR-	199	Body	AB-Airbag	√	√	√	√					

SLR-Class	199	Body	ACL [ZLB]-Air brake (spoiler) and central locking control unit	√	√	√	√	√			
SLR-Class	199	Body	BKGS-Brake cooling and	√	√	√	√				
SLR-Class	199	Body	BNS-Vehicle power supply control module	√	√	√	√				
SLR-Class	199	Body	CGW-Central gateway	√	√	√					CD0026, CD0029, CD0026, CD0027, CD0028, CD0029,
SLR-Class	199	Body	Dr side SAM-Driver signal acquisition and actuation module	√	√	√	√	√			CD0026, CD0029, CD0026, CD0027, CD0028, CD0029,
SLR-Class	199	Body	EZS-Electronic ignition switch	√	√	√	√				
SLR-Class	199	Body	HRA FL-Front left headlamp range control	√	√	√	√		SP0165,		
SLR-Class	199	Body	HRA FR-Front right headlamp range control	√	√	√	√	√			CD0298, CD0299, CD0300, CD0301, CD0302, CD0303,
SLR-Class	199	Body	LCP-Lower control panel	√	√	√	√	√			
SLR-Class	199	Body	OCP-Overhead control panel	√	√	√	√	√			CD0044, CD0045, CD0046,
SLR-Class	199	Body	Pass side SAM-Passenger-side signal acquisition and actuation module	√	√	√	√	√			CD0044, CD0045, CD0046,
SLR-Class	199	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	√			
SLR-Class	199	Body	RS-Roadster soft top	√	√	√	√				
SLR-Class	199	Body	System diagnosis(CAN)	√	√	√					
SLR-Class	199	Body	WSS-Weight sensing system	√	√	√	√				
SLR-Class	199	Chassis	ESP-Electronic stability program	√	√	√	√				CD0139, CD0140,
SLR-Class	199	Chassis	SBC-Sensotronic Brake Control	√	√	√	√				
SLR-Class	199	Chassis	TPM-Tire pressure monitor	√	√	√	√	√			
SLR-Class	199	Chassis	TPM-Tire pressure monitor	√	√	√	√				CD0212, CD0214, CD0215, CD0216, CD0217,

SLR-Class	199	Drive	ESM-Electronic selector module	√	√	√	√	√			CD0212, CD0214, CD0215, CD0216, CD0217,	
SLR-	199	Drive	ETC-Electronic transmission	√	√	√	√					
SLR-	199	Drive	ME SFI 2.8-Motor electronics 2.8	√	√	√	√					
SLR-Class	199	Information and communication	AUDIO	√	√	√	√					
SLR-Class	199	Information and communication	CDC-CD changer	√	√	√						
SLR-Class	199	Information and communication	CTEL over K-wire-Telematic system	√	√	√						
SLR-Class	199	Information and communication	CTEL-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√						
SLR-Class	199	Information and communication	E call [Japan]-Telematic system	√	√	√	√	√				
SLR-Class	199	Information and communication	E call [USA]-Telematic system	√	√	√	√					
SLR-Class	199	Information and communication	ICM-Instrument cluster with maintenance interval display	√	√	√	√	√				
SLR-Class	199	Information and communication	SCM [MRM]-Steering column module	√	√	√	√	√				
SLR-Class	199	Information and communication	SOUND-Sound system	√	√	√	√					
SLR-Class	199	Information and communication	TELE AID-Telematic system	√	√	√	√					
SLR-Class	199	Information and communication	UHI-Cellular telephone 1 (fixed installation or portable)(D2B)	√	√	√	√					
SLR-	199	Seats and Doors	DCM L-Door control module left	√	√	√	√					
SLR-	199	Seats and Doors	DCM R-Door control module	√	√	√	√				CD0073,	
CLA-Class	117	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√	√	ACT0000,ACT0001,ACT0002,ACT0003,ACT0004,ACT0005,ACT0006,ACT0007,ACT0008,ACT0009,ACT0010,ACT0011,ACT0012,ACT0013,ACT0014,ACT0015,ACT0016,ACT0017,ACT0018,ACT0019,ACT0020,ACT0021,,ACT0022,ACT0023,ACT0024,ACT0025,ACT0026	SP1000,SP1001,SP1002,SP1003,SP1004,SP1005,SP1006,SP1007,SP1008,SP1009,SP1010,SP1011,SP1012,SP1013,SP1014,SP1015,SP1016,SP1017,SP1018,SP1019,SP1020,SP1021,SP1022,SP1023,SP1024	CD0304, CD0305, CD0306, CD0307	√
CLA-Class	117	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√		ACT0001,ACT0004,ACT0005,ACT0002,ACT0028,ACT0008,ACT0009,ACT0010,ACT0011,ACT0022,ACT0023,ACT0024,ACT0012,ACT0015,ACT0026	SP1025,SP1000,SP1004,SP1003,SP1005,SP1026,SP1007,SP1012,SP1013,SP1006,SP1027,SP1009,SP1017,SP1028,SP1029	CD0304, CD0305, CD0306	√
CLA-Class	117	Drive	N3/3-Motor electronics "OM607" for combustion engine "CRR1"	√	√	√	√	√	ACT0029,ACT0030,ACT0031,ACT0032,ACT0033,ACT0034,ACT0035,ACT0036,ACT0037,ACT0038,ACT0039,ACT0040,ACT0041,ACT0042,ACT0043	SP1030,SP1031,SP1032,SP1033,SP1034,SP1035,SP1036,SP1037,SP1038,SP1039,SP1040,SP1041,SP1042,SP1043,SP1044,	CD0308, CD0309, CD0310	√

CLA-Class	117	Information and communication	E call [Europe]-Emergency call system	√	√	√	√		ACT0044,ACT0045,ACT0046,ACT0047,ACT0048,ACT0049			
CLA-Class	117	Information and communication	IC-Instrument cluster	√	√	√	√		ACT0050,ACT0051,ACT0052,ACT0053,ACT0054,ACT0055,	SP1047,SP1048		√
CLA-Class	117	Information and communication	KOMO-Communication module Telematics services	√	√	√	√		ACT0057,ACT0058,ACT0059,ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065,			√
CLA-Class	117	Seats and Doors	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√		ACT0067,ACT0068,ACT0069,ACT0070,ACT0071,ACT0072,ACT0073,ACT0074	SP1049,SP1050		
CLA-Class	117	Information and communication	TS-Telematic system(N123/4)	√	√	√	√		ACT0075,ACT0076,ACT0077,ACT0078			√
CLA-Class	117	Body	EZS-Electronic ignition switch	√	√	√	√			SP1051,SP1052,SP1053	CD0320, CD0321, CD0322, CD0323, CD0324	
CLA-Class	117	Body	EZS-Electronic ignition lock	√	√	√	√				CD0325	
CLA-Class	117	Body	EZS-Electronic ignition lock (N73)	√	√	√	√					
CLA-Class	117	Body	EZS-Electronic ignition lock (N73)	√	√	√	√					
CLA-Class	117	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084			√
CLA-Class	117	Chassis	AMG DRVU-AMG DRIVE UNIT(N145)	√	√	√	√		ACT0085,ACT0086,ACT0087			√
CLA-Class	117	Chassis	ESP-Electronic stability program(N30/4)	√	√	√	√	√	ACT0088,ACT0089	SP1054,SP1055		√
CLA-Class	117	Information and communication	NAV-Navigation module(A2/30)	√	√	√	√		ACT0090,ACT0091,ACT0092,ACT0093			√
CLA-Class	117	Information and communication	Audio-Audio or COMAND	√	√	√	√					
CLA-Class	117	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
CLA-Class	117	Body	IMS-Interior motion sensor	√	√	√	√		ACT0094,ACT0095,ACT0096			√
CLA-Class	117	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0099,ACT0100	SP1056		√
CLA-Class	117	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√				√

CLA-Class	117	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√		ACT0101,ACT0102,ACT0103,ACT0104,ACT0105,ACT0106,ACT0107,ACT0108,ACT0109,ACT0110,ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,ACT0117,ACT0118,ACT0119,ACT0120,ACT0121,ACT0118,ACT0119,ACT0120,ACT0119,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0111,ACT0112,ACT0113,ACT0118,ACT0116,ACT0117,ACT0102,ACT0103,ACT0127,ACT0128,ACT0101,	SP1057,SP1058,SP1059,SP1060,SP1061		
CLA-Class	117	Information and communication	Audio-Audio or COMAND	√	√	√	√					
CLA-Class	117	Driver assistance system	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)	√	√	√	√		ACT0132	SP1062		√
CLA-Class	117	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					
CLA-Class	117	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					√
CLA-Class	117	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					
CLA-Class	117	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					√
CLA-Class	117	Body	Multifunction control unit-Multifunction control unit	√	√	√	√		ACT0133,ACT0134,ACT0135,ACT0136,ACT0137,ACT0138,ACT0139,ACT0140,ACT0141,ACT0142,ACT0143,ACT0144,ACT0145,ACT0146,ACT0147,ACT0148,ACT0149,ACT0150,			√
CLA-Class	117	Information and communication	SG MSND-Engine sound	√	√	√	√		ACT0151,ACT0152,ACT0153,ACT0154,ACT0155			√
CLA-Class	117	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0156,ACT0157			√
CLA-Class	117	Information and communication	SOUND-Sound system	√	√	√	√		ACT0158,ACT0159,ACT0160,ACT0161,ACT0162,ACT0163,ACT0164,ACT0165,ACT0166,ACT0167,ACT0168,ACT0169,ACT0170,ACT0171,ACT0172,ACT0173,ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0179,ACT0180,ACT0181,		CD0348	
CLA-Class	117	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0185,ACT0186,ACT0187,ACT0188,ACT0189,ACT0190,ACT0191,ACT0192,ACT0193,ACT0194,ACT0195,ACT0196,ACT0197,ACT0198,			

CLA-Class	117	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0199,ACT0186,ACT0187,ACT0189,ACT0191,ACT0192,ACT0200,ACT0195,ACT0196,ACT0201,ACT0202,ACT0194,ACT0203,ACT0204,ACT0205,ACT0197,ACT0206,ACT0198	SP1063		
CLA-Class	117	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√		ACT0207,ACT0208,ACT0209,ACT0210	SP1064	CD0349	√
CLA-Class	117	Body	HKS-Tailgate control	√	√	√	√		ACT0211,ACT0212,ACT0213	SP1065		√
CLA-Class	117	Information and communication	TV-TV tuner	√	√	√	√		ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0219,ACT0220,ACT0221,ACT0222,ACT0223		CD0350CD0351, CD0352, CD0353, CD0354, CD0355, CD0356, CD0357, CD0358, CD0359, CD0360, CD0361	
CLA-Class	117	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0230,ACT0231,ACT0232,ACT0233		CD0362CD0363, CD0364, CD0365, CD0366, CD0367, CD0368, CD0369, CD0370, CD0371, CD0372, CD0373	
CLA-Class	117	Driver assistance system	MFK-Multifunction camera	√	√	√	√		ACT0234,ACT0235	SP1066		√
CLA-Class	117	Driver assistance system	MFK-Multifunction camera(A40/11)	√	√	√	√		ACT0236,ACT0237	SP1067,SP1068		√
CLA-Class	117	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		ACT0238,ACT0239,ACT0240,ACT0241,ACT0242,ACT0243,ACT0244,ACT0245,ACT0246,ACT0247,ACT0248,ACT0249,ACT0250,ACT0251,ACT0252,	SP1069,SP1070,SP1071		√
CLA-Class	117	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√					
CLA-Class	117	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√					
CLA-Class	117	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258		CD0382	
CLA-Class	117	Air conditioning	STH-Stationary heater	√	√	√	√		ACT0259,ACT0260,ACT0261,ACT0262	SP1072		√
CLA-Class	117	Information and communication	Drive Kit Plus-Drive kit for iPhone	√	√	√	√		ACT0263,ACT0264,ACT0265,ACT0266			
CLA-Class	117	Information and communication	NAVI20-Navigation(N125/2)	√	√	√	√		ACT0267,ACT0268			
CLA-Class	117	Chassis	ES-Electrical power steering(N68)	√	√	√	√			SP1073,SP1074,SP1075		√
CLA-Class	117	Body	PSD-Control module 'Panoramic sliding roof '(A98)	√	√	√	√		ACT0269,ACT0270	SP1076		√
CLA-Class	117	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√		ACT0271			√
CLA-Class	117	Information and communication	HUD-Head up display	√	√	√	√		ACT0272,ACT0273,ACT0274	SP1077,		

CLA-Class	117	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√		ACT0275			√
CLA-Class	117	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√		ACT0276,ACT0277,ACT0278,ACT0279,ACT0280,ACT0281,	SP1078,SP1079		√
CLA-Class	117	Information and communication	SDAR-Satellite radio	√	√	√	√		ACT0283,ACT0284,ACT0285,ACT0286		CD0387CD0388, CD0389, CD0389	
CLA-Class	117	Information and communication	TB5-TV tuner Tuner unit	√	√	√	√		ACT0287,ACT0288,ACT0289,ACT0290,ACT0291,ACT0292,ACT0293,ACT0294,			
CLA-Class	117	Information and communication	TV tuner (TV)	√	√	√	√		ACT0295,ACT0296,ACT0297,ACT0298,ACT0299,ACT0300,			
CLA-Class	117	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√		ACT0302,ACT0303,ACT0304,ACT0305,ACT0306,ACT0307,ACT0308	SP1080,SP1081		√
CLA-Class	117	Information and communication	MIF-Media interface	√	√	√	√					
CLA-Class	117	Information and communication	MIF-Media interface	√	√	√	√		ACT0309			
CLA-Class	117	Body	BSN-Battery sensor(B95)	√	√	√	√					
CLA-Class	117	Body	TRM-Trailer recognition module (N28/1)	√	√	√	√		ACT0310,ACT0311,ACT0312,ACT0313,ACT0314,ACT0315,ACT0316,ACT0317,ACT0318,ACT0319,ACT0320,ACT0321	SP1082,SP1083		√
CLA-Class	117	Body	Trailer recognition module-Trailer recognition	√	√	√	√		ACT0322,ACT0323,ACT0324,ACT0325,ACT0326,ACT0327,ACT0328,ACT0329,ACT0330,ACT0331,ACT0332,ACT0333,		CD0393	√
CLA-Class	117	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√		ACT0335,ACT0336,ACT0337,ACT0338,ACT0339,ACT0340,ACT0341,ACT0342,ACT0343,ACT0344,ACT0345,ACT0346,ACT0347,ACT0348,ACT0349,ACT0350,ACT0351,ACT0352,ACT0353,ACT0354,ACT0355,ACT0356,ACT0357,ACT0358,ACT0359,ACT0360,ACT0361,ACT0362,ACT0363,ACT0364,ACT0365,ACT0366,ACT0367,ACT0368,ACT0369,ACT0370,ACT0371,ACT0372,ACT0373,ACT0374,ACT0375,ACT0376,ACT0377,ACT0378,ACT0379,			√

CLA-Class	117	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√	ACT0335,ACT0336,ACT0337,ACT0338,ACT0339,ACT0340,ACT0341,ACT0342,ACT0343,ACT0344,ACT0345,ACT0346,ACT0347,ACT0348,ACT0349,ACT0350,ACT0351,ACT0352,ACT0353,ACT0354,ACT0355,ACT0356,ACT0357,ACT0358,ACT0359,ACT0360,ACT0361,ACT0362,ACT0363,ACT0364,ACT0365,ACT0366,ACT0367,ACT0368,ACT0369,ACT0370,ACT0371,ACT0372,ACT0373,ACT0374,ACT0375,ACT0376,ACT0377,ACT0378,ACT0379,			√
CLA-Class	117	Drive	FSCU05-Control unit Fuel pump	√	√	√	√	ACT0385			√
CLA-Class	117	Driver assistance system	DTR-DISTRONIC (A89)	√	√	√	√		SP1084	CD0395	√
CLA-Class	117	Chassis	DTR-DISTRONIC (A89)	√	√	√	√		SP1084	CD0395	√
CLA-Class	117	Seats and Doors	LFD-Left front door	√	√	√	√	ACT0386,ACT0387,ACT0388,ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0397,ACT0398,ACT0399,ACT0400,ACT0401,ACT0402,ACT0403,	SP1085		√
CLA-Class	117	Seats and Doors	DCU RF-Right front door	√	√	√	√	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410,ACT0411,ACT0412,ACT0413,ACT0414,ACT0415,ACT0416,ACT0417,ACT0418,ACT0419,ACT0420,ACT0421,ACT0422,	SP1086		√
CLA-Class	117	Information and communication	TV-TV tuner	√	√	√	√	ACT0424,ACT0425,ACT0426,ACT0427,ACT0222,ACT0428,ACT0219,ACT0221			
CLA-Class	117	Information and communication	TV-TV tuner	√	√	√	√	ACT0429,ACT0430,ACT0431,ACT0229,ACT0432,ACT0433,			
CLA-Class	117	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	ACT0255,ACT0256,ACT0257,ACT0258			
CLA-Class	117	Chassis	EFB-Electronic parking brake(N128)	√	√	√	√	ACT0435,ACT0436,ACT0437,ACT0438	SP1087		√
CLA-Class	117	Driver assistance system	RFK-Backup camera	√	√	√	√	ACT0439,ACT0440	SP1088,SP1089		√
CLA-Class	117	Driver assistance system	RFK-Backup camera	√	√	√	√	ACT0439	SP1088,SP1089		√
CLA-Class	117	Body	WSS-Weight sensing system(N110)	√	√	√	√				

CLA-Class	117	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
CLA-Class	117	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
CLA-Class	117	Body	BSN-Battery sensor(B95)	√	√	√	√					
CLA-Class	117	Body	UCP-Upper control panel	√	√	√	√					
CLA-Class	117	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0442,ACT0443,ACT0444,ACT0445,ACT0446			√
CLA-Class	117	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0447,ACT0448,ACT0449,ACT0450			√
CLA-Class	117	Body	SG SW-Control unit 'Headlamp'(N71/1)	√	√	√	√		ACT0451,ACT0452,ACT0453,ACT0454,ACT0455	SP1090,SP1091,SP1092,SP1093	CD0397	√
CLA-Class	117	Body	SG SW L-Left headlamp	√	√	√	√		ACT0456,ACT0457,ACT0458,ACT0459,ACT0460,ACT0461	SP1094,SP1095,SP1096,SP1097,SP1098,SP1099,	CD0398	√
CLA-Class	117	Body	SG SW L-Left headlamp(E1n9)	√	√	√	√		ACT0462,ACT0463,ACT0464,ACT0465,ACT0466,ACT0467	SP1101,SP1102,SP1103,SP1104,SP1105,SP1106,SP1107,SP1108	CD0399	√
CLA-Class	117	Body	SG SW R-Right headlamp	√	√	√	√		ACT0468,ACT0469,ACT0470,ACT0471,ACT0472,ACT0473	SP1109,SP1110,SP1111,SP1112,SP1113,SP1114	CD0400	√
CLA-Class	117	Body	SG SW R-Right headlamp(E1n9)	√	√	√	√		ACT0474,ACT0475,ACT0476,ACT0477,ACT0478,ACT0479	SP1115,SP1116,SP1117,SP1118,SP1119,SP1120	CD0401	√
CLA-Class	117	Body	GTO-Garage door opener(A67n2)	√	√	√	√					
CLA-Class	117	Body	OCP-Control unit 'Overhead control panel'	√	√	√	√		ACT0480,ACT0481,ACT0482,ACT0483			
CLA-Class	117	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√			SP1121		
CLA-Class	117	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√					
CLA-Class	117	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
CLA-Class	117	Driver assistance system	PARK-Parking system (N62)	√	√	√	√		ACT0484,ACT0485		CD0411, CD0412	√
CLA-Class	117	Body	N32/2 (Front passenger seat control unit)	√			√		ACT0486			
CLA-Class	117	Body	N32/1 (Driver seat control unit)	√			√		ACT0487			
CLA-Class	117	Information and communication	DSI-DIRECT SELECT interface(N150)	√	√	√	√		ACT0488			√
CLA-Class	117	Drive	VG-All wheel drive	√	√	√	√		ACT0489	SP1122,SP1123,SP1124,SP1125		√
CLA-Class	117	Body	AS-Alarm siren(H3/1)	√	√	√			ACT0490			
CLA-Class	117	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT0490			
CLA-Class	117	Driver assistance system	KAB-Control unit Camera cover	√	√	√	√		ACT0491,ACT0492			√

CLA-Class	117	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√					
CLA-Class	117	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√					
CLA-Class	117	Drive	DKG-Electronic transmission control for double-plate clutch	√	√	√	√	√	ACT0493,ACT0494,ACT0495,ACT0496,ACT0497	SP1126,SP1127,SP1128	CD0423, CD0424, CD0425, CD0426	√
CLA-Class	117	Drive	FSCU-Fuel pump	√	√	√	√		ACT0498,ACT0499		CD0427, CD0428	√
CLA-Class	117	Drive	N127 (Drivetrain control unit)	√	√	√	√		ACT0500,ACT0501	SP1129,SP1130,SP1131	CD0429, CD0430, CD0431	√
CLA-Class	117	Drive	PTCU-Common powertrain controller(N127)	√	√	√	√		ACT0502,ACT0503,ACT0504,ACT0505,ACT0506,ACT0507	SP1132	CD0432, CD0433, CD0434	√
CLA-Class	117	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	√	√	√	√	√	ACT0508,ACT0509,ACT0510,ACT0511,ACT0512,ACT0513,ACT0514,ACT0515,ACT0516,ACT0517,ACT0518,ACT0519,ACT0520,ACT0521,ACT0522,ACT0523,ACT0524,ACT0525,SP1133,SP1134,SP1135,SP1136,SP1137,SP1138,SP1139,SP1140,SP1141,SP1142,SP1143,SP1144,SP1145,SP1146,SP1147,SP1148	CD0435, CD0436, CD0437, CD0438, CD0439, CD0440, CD0441, CD0442, CD0443	√	
CLA-Class	117	Drive	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"	√	√	√	√	√	ACT0528,ACT0529,ACT0530,ACT0531,ACT0532,ACT0533,ACT0534,ACT0535,ACT0536,ACT0537,ACT0538,ACT0539,SP1149,SP1150,SP1151,SP1152,SP1153,SP1154,SP1155,SP1156	CD0444, CD0445, CD0446, CD0447, CD0448, CD0449, CD0450, CD0451, CD0452	√	
CLA-Class	118	Drive	CDI-Engine Electronics CRR2 for Internal Combustion Engine	√	√	√	√	√				
CLA-Class	118	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√				
CLA-Class	118	Drive	N15/13 (Double clutch transmission control unit)	√	√	√	√					
CLA-Class	118	Drive	Y3/14n4 (Dual clutch transmission fully integrated transmission control unit)	√	√	√						
CLA-Class	118	Drive	Y3/14n4 (Dual clutch transmission fully integrated transmission control unit)	√	√	√						
CLA-Class	118	Seats and Doors	LFD-Left front door	√	√	√	√					
CLA-Class	118	Seats and Doors	DCU RF-Right front door	√	√	√	√					
CLA-Class	118	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
CLA-Class	118	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
CLA-Class	118	Body	SRS-Supplemental restraint system	√	√	√	√	√				
CLA-Class	118	Body	EZS-Electronic ignition switch	√	√	√	√					
CLA-Class	118	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					

CLA-Class	118	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
CLA-Class	118	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√					
CLA-Class	118	Information and communication	HERMES-control unit for telematics services	√	√	√	√					
CLA-Class	118	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√					
CLA-Class	118	Seats and Doors	MKS-FS-Pilot multi-profile seat	√	√	√	√					
CLA-Class	118	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√					
CLA-Class	118	Seats and Doors	MKS-BFS-Front passenger more copy the seat	√	√	√	√					
CLA-Class	118	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
CLA-Class	118	Seats and Doors	HKS-Tailgate control	√	√	√	√					
CLA-Class	118	Body	ATA-Interior motion sensor	√	√	√	√					
CLA-Class	118	Body	Trailer recognition module-Trailer recognition	√	√	√	√					
CLA-Class	118	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
CLA-Class	118	Body	PSD-Panoramic sliding roof	√	√	√	√					
CLA-Class	118	Body	AML-Ambiance light	√	√	√	√					
CLA-Class	118	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√					
CLA-Class	118	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√					
CLA-Class	118	Body	LRE-Steering wheel electronics	√	√	√	√					
CLA-Class	118	Information and communication	TPAD-Touchpad	√	√	√	√					
CLA-Class	118	Information and communication	Audio-Audio or COMAND	√	√	√	√					
CLA-Class	118	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
CLA-Class	118	Body	HE-Hand detection	√	√	√	√					
CLA-Class	118	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
CLA-Class	118	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
CLA-Class	118	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					

CLA-Class	118	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
CLA-Class	118	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
CLA-Class	118	Information and communication	IC-Instrument cluster	√	√	√	√			SP1047,SP1048,SP1157		
CLA-Class	118	Information and communication	HUD-Head up display	√	√	√	√					
CLA-Class	118	Driver assistance system	RFK-Backup camera	√	√	√	√					
CLA-Class	118	Driver assistance system	KAR-Augmented reality camera	√	√	√	√					
CLA-Class	118	Information and communication	CSM-Windshield reader system	√	√	√	√					
CLA-Class	118	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√					
CLA-Class	118	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√					
CLA-Class	118	Body	SG SW L-Left headlamp	√	√	√	√					
CLA-Class	118	Body	SG SW R-Right headlamp	√	√	√	√					
CLA-Class	118	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√					
CLA-Class	118	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√					
CLA-Class	118	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√					
CLA-Class	118	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
CLA-Class	118	Body	DCCU-Direct current charge connection unit	√	√	√	√					
CLA-Class	118	Body	SG LG-Charger	√	√	√	√					
CLA-Class	118	Body	DC/DC-DC/DC converter	√	√	√	√					
CLA-Class	118	Body	GES-Hand motion sensor	√	√	√	√					
CLA-Class	118	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
CLA-Class	118	Body	BSN-Battery sensor(B95)	√	√	√	√					
CLA-Class	118	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
CLA-Class	118	Body	FSW-Windshield wiper	√	√	√	√					
CLA-Class	118	Body	GTO-Garage door opener(A67n2)	√	√	√	√					

CLA-Class	118	Body	OCP-Overhead control panel	√	√	√	√					
CLA-Class	118	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√					
CLA-Class	118	Body	"Front passenger" seat heater	√	√	√	√					
CLA-Class	118	Body	"Driver" seat heater	√	√	√	√					
CLA-Class	118	Seats and Doors	S47/2 (Driver door switch module)	√	√	√	√					
CLA-Class	118	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	√					
CLA-Class	118	Seats and Doors	S22 (Driver's door seat adjustment switch)	√	√	√	√					
CLA-Class	118	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	√					
CLA-Class	118	Seats and Doors	S51/1 (Driver seat climate control switch group)	√	√	√	√					
CLA-Class	118	Seats and Doors	S51/2 (Front passenger seat climate control switch group)	√	√	√	√					
CLA-Class	118	Air conditioning	STH-Stationary heater	√	√	√	√					
CLA-Class	118	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
CLA-Class	118	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√					
CLA-Class	118	Chassis	Lower control panel(DRVU)	√	√	√						
CLA-Class	118	Body	WSS-Weight sensing system(N110)	√	√	√	√					
CLA-Class	118	Body	N38 (Rear switching module)	√	√	√	√					
CLA-Class	118	Information and communication	SOUND-Sound system	√	√	√	√					
CLA-Class	118	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					
CLA-Class	118	Driver assistance system	DTR-DISTRONIC	√	√	√	√					
CLA-Class	118	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√					
CLA-Class	118	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√					
CLA-Class	118	Driver assistance system	PTS-PARKTRONIC	√	√	√	√					
CLA-Class	118	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√					
CLA-Class	118	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√					

CLA-Class	118	Chassis	ES - Electric power steering	√	√	√	√					
CLA-Class	118	Body	SCM-Steering column module	√	√	√	√					
CLA-Class	118	Drive	VG-All-wheel drive	√	√	√	√					
CLA-Class	118	Drive	VG-All-wheel drive	√	√	√	√					
CLA-Class	118	Drive	VG-All-wheel drive	√	√	√	√					
CLA-Class	118	Driver assistance system	NBR RR-Right rear short-range radar	√	√	√	√					
CLA-Class	118	Driver assistance system	NBR LR-Left rear short-range radar	√	√	√	√					
CLA-Class	118	Chassis	ESP- Electric stability program	√	√	√	√	√				
CLA-Class	118	Chassis	ESP- Electric stability program	√	√	√	√					
CLA-Class	118	Drive	FSCU-Fuel pump	√	√	√	√					
CLA-Class	118	Drive	SCR-Selective catalytic reduction	√	√	√	√					
CLA-Class	118	Drive	N127 (Drivetrain control unit)	√	√	√	√					
CLA-Class	118	Drive	N127 (Drivetrain control unit)	√	√	√	√					
CLA-Class	118	Drive	SG EM-Power electronics	√	√	√	√					
CLA-Class	118	Drive	48V on board electrical system of ISG starter generator	√	√	√						
CLA-Class	118	Body	BMS-Battery management system	√	√	√	√					
CLA-Class	118	Body	LIB-Lithium ion battery	√	√	√	√					
CLA-Class	118	Body	LIB-Lithium ion battery	√	√	√	√					
CLA-Class	118	Drive	N3/10-Motor electronics "EM71" for combustion engine "M282"	√	√	√	√	√				
CLA-Class	118	Drive	N3/10-Motor electronics "MED41" for combustion engine	√	√	√	√	√				
CLA-Class	118	Drive	N3/10-Motor electronics "MRG1AMGR4" for combustion engine "M139"	√	√	√	√					
CLA-Class	118	Body	AS-Alarm siren(H3/1)	√	√	√	√					

GLA-Class	156	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√	√	ACT0000,ACT0001,ACT0002,ACT0003,ACT0004,ACT0005,ACT0006,ACT0007,ACT0008,ACT0009,ACT0010,ACT0011,ACT0012,ACT0013,ACT0014,ACT0015,ACT0016,ACT0017,ACT0018,ACT0019,ACT0020,ACT0021,ACT0022,ACT0023,ACT0024,ACT0025,ACT0026	SP1000,SP1001,SP1002,SP1003,SP1004,SP1005,SP1006,SP1007,SP1008,SP1009,SP1010,SP1011,SP1012,SP1013,SP1014,SP1015,SP1016,SP1017,SP1018,SP1019,SP1020,SP1021,SP1022,SP1023,SP1024	CD0304, CD0305, CD0306, CD0307	√
GLA-Class	156	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√		ACT0001,ACT0004,ACT0005,ACT0002,ACT0028,ACT0008,ACT0009,ACT0010,ACT0011,ACT0022,ACT0023,ACT0024,ACT0012,ACT0015,ACT0026,	SP1025,SP1000,SP1004,SP1003,SP1005,SP1026,SP1007,SP1012,SP1013,SP1006,SP1027,SP1009,SP1017,SP1028,SP1029	CD0304, CD0305, CD0306	√
GLA-Class	156	Drive	N3/3-Motor electronics "OM607" for combustion engine "CRR1"	√	√	√	√	√	ACT0029,ACT0030,ACT0031,ACT0032,ACT0033,ACT0034,ACT0035,ACT0036,ACT0037,ACT0038,ACT0039,ACT0040,ACT0041,ACT0042,ACT0043	SP1030,SP1031,SP1032,SP1033,SP1034,SP1035,SP1036,SP1037,SP1038,SP1039,SP1040,SP1041,SP1042,SP1043,SP1044,	CD0308, CD0309, CD0310	√
GLA-Class	156	Information and communication	E call [Europe]-Emergency call system	√	√	√	√		ACT0044,ACT0045,ACT0046,ACT0047,ACT0048,ACT0049			
GLA-Class	156	Information and communication	IC-Instrument cluster	√	√	√	√		ACT0050,ACT0051,ACT0052,ACT0053,ACT0054,ACT0055,	SP1047,SP1048		√
GLA-Class	156	Information and communication	KOMO-Communication module Telematics services	√	√	√	√		ACT0057,ACT0058,ACT0059,ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065,			√
GLA-Class	156	Seats and Doors	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√		ACT0067,ACT0068,ACT0069,ACT0070,ACT0071,ACT0072,ACT0073,ACT0074	SP1049,SP1050		
GLA-Class	156	Information and communication	TS-Telematic system(N123/4)	√	√	√	√		ACT0075,ACT0076,ACT0077,ACT0078			√
GLA-Class	156	Body	EZS-Electronic ignition switch	√	√	√	√			SP1051,SP1052,SP1053	CD0320, CD0321, CD0322, CD0323, CD0324	
GLA-Class	156	Body	EZS-Electronic ignition lock	√	√	√	√				CD0325	
GLA-Class	156	Body	EZS-Electronic ignition lock (N73)	√	√	√	√					
GLA-Class	156	Body	EZS-Electronic ignition lock (N73)	√	√	√	√					
GLA-Class	156	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084			√
GLA-Class	156	Chassis	AMG DRVU-AMG DRIVE UNIT(N145)	√	√	√	√		ACT0085,ACT0086,ACT0087			√
GLA-Class	156	Chassis	ESP-Electronic stability program(N30/4)	√	√	√	√	√	ACT0088,ACT0089	SP1054,SP1055		√
GLA-Class	156	Information and communication	NAV-Navigation module(A2/30)	√	√	√	√		ACT0090,ACT0091,ACT0092,ACT0093			√
GLA-Class	156	Information and communication	Audio-Audio or COMAND	√	√	√	√					

GLA-Class	156	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
GLA-Class	156	Body	IMS-Interior motion sensor	√	√	√	√		ACT0094,ACT0095,ACT0096			√
GLA-Class	156	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0099,ACT0100	SP1056		√
GLA-Class	156	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√				√
GLA-Class	156	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√		ACT0101,ACT0102,ACT0103,ACT0104,ACT0105,ACT0106,ACT0107,ACT0108,ACT0109,ACT0110,ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,ACT0117,ACT0118,ACT0119,ACT0120,ACT0121,ACT0118,ACT0119,ACT0120,ACT0119,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0111,ACT0112,ACT0113,ACT0118,ACT0116,ACT0117,ACT0102,ACT0103,ACT0127,ACT0128,ACT0101,	SP1057,SP1058,SP1059,SP1060,SP1061		
GLA-Class	156	Information and communication	Audio-Audio or COMAND	√	√	√	√					
GLA-Class	156	Driver assistance system	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)	√	√	√	√		ACT0132	SP1062		√
GLA-Class	156	Driver assistance system	CAMERA-360 camera(N148)	√	√	√	√		ACT0542	SP1158,SP1159,SP1160,SP1161,SP1162,SP1163		√
GLA-Class	156	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					
GLA-Class	156	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					√
GLA-Class	156	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					
GLA-Class	156	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					√
GLA-Class	156	Body	Multifunction control unit-Multifunction control unit	√	√	√	√		ACT0133,ACT0134,ACT0135,ACT0136,ACT0137,ACT0138,ACT0139,ACT0140,ACT0141,ACT0142,ACT0143,ACT0144,ACT0145,ACT0146,ACT0147,ACT0148,ACT0149,ACT0150,			√
GLA-Class	156	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0156,ACT0157			√

GLA-Class	156	Information and communication	SOUND-Sound system	√	√	√	√	ACT0158,ACT0159,ACT0160,ACT0161,ACT0162,ACT0163,ACT0164,ACT0165,ACT0166,ACT0167,ACT0168,ACT0169,ACT0170,ACT0171,ACT0172,ACT0173,ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0179,ACT0180,ACT0181,		CD0348	
GLA-Class	156	Information and communication	SOUND-Bose sound system	√	√	√	√	ACT0185,ACT0186,ACT0187,ACT0188,ACT0189,ACT0190,ACT0191,ACT0192,ACT0193,ACT0194,ACT0195,ACT0196,ACT0197,ACT0198,			
GLA-Class	156	Information and communication	SOUND-Bose sound system	√	√	√	√	ACT0199,ACT0186,ACT0187,ACT0189,ACT0191,ACT0192,ACT0200,ACT0195,ACT0196,ACT0201,ACT0202,ACT0194,ACT0203,ACT0204,ACT0205,ACT0197,ACT0206,ACT0198	SP1063		
GLA-Class	156	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	ACT0207,ACT0208,ACT0209,ACT0210	SP1064	CD0349	√
GLA-Class	156	Body	HKS-Tailgate control	√	√	√	√	ACT0211,ACT0212,ACT0213	SP1065		√
GLA-Class	156	Information and communication	TV-TV tuner	√	√	√	√	ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0219,ACT0220,ACT0221,ACT0222,ACT0223		CD0350CD0351, CD0352, CD0353, CD0354, CD0355, CD0356, CD0357, CD0358, CD0359, CD0360, CD0361	
GLA-Class	156	Information and communication	TV-TV tuner	√	√	√	√	ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0230,ACT0231,ACT0232,ACT0233		CD0362CD0363, CD0364, CD0365, CD0366, CD0367, CD0368, CD0369, CD0370, CD0371, CD0372, CD0373	
GLA-Class	156	Driver assistance system	MFK-Multifunction camera	√	√	√	√	ACT0234,ACT0235	SP1066		√
GLA-Class	156	Driver assistance system	MFK-Multifunction camera(A40/11)	√	√	√	√	ACT0236,ACT0237	SP1067,SP1068		√
GLA-Class	156	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	ACT0238,ACT0239,ACT0240,ACT0241,ACT0242,ACT0243,ACT0244,ACT0245,ACT0246,ACT0247,ACT0248,ACT0249,ACT0250,ACT0251,ACT0252,	SP1069,SP1070,SP1071		√
GLA-Class	156	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√				
GLA-Class	156	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√				
GLA-Class	156	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	ACT0255,ACT0256,ACT0257,ACT0258		CD0382	
GLA-Class	156	Air conditioning	STH-Stationary heater	√	√	√	√	ACT0259,ACT0260,ACT0261,ACT0262	SP1072		√

GLA-Class	156	Information and communication	Drive Kit Plus-Drive kit for iPhone	√	√	√	√		ACT0263,ACT0264,ACT0265,ACT0266			
GLA-Class	156	Information and communication	NAVI20-Navigation(N125/2)	√	√	√	√		ACT0267,ACT0268			
GLA-Class	156	Chassis	ES-Electrical power steering(N68)	√	√	√	√			SP1073,SP1074,SP1075		√
GLA-Class	156	Body	PSD-Control module 'Panoramic sliding roof'(A98)	√	√	√	√		ACT0269,ACT0270	SP1076		√
GLA-Class	156	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√		ACT0271			√
GLA-Class	156	Information and communication	HUD-Head up display	√	√	√	√		ACT0272,ACT0273,ACT0274	SP1077,		
GLA-Class	156	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√		ACT0275			√
GLA-Class	156	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√		ACT0276,ACT0277,ACT0278,ACT0279,ACT0280,ACT0281,	SP1078,SP1079		√
GLA-Class	156	Information and communication	SDAR-Satellite radio	√	√	√	√		ACT0283,ACT0284,ACT0285,ACT0286		CD0387CD0388, CD0389, CD0389	
GLA-Class	156	Information and communication	TB5-TV tuner Tuner unit	√	√	√	√		ACT0287,ACT0288,ACT0289,ACT0290,ACT0291,ACT0292,ACT0293,ACT0294,			
GLA-Class	156	Information and communication	TV tuner (TV)	√	√	√	√		ACT0295,ACT0296,ACT0297,ACT0298,ACT0299,ACT0300,			
GLA-Class	156	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√		ACT0302,ACT0303,ACT0304,ACT0305,ACT0306,ACT0307,ACT0308	SP1080,SP1081		√
GLA-Class	156	Information and communication	MIF-Media interface	√	√	√	√					
GLA-Class	156	Information and communication	MIF-Media interface	√	√	√	√		ACT0309			
GLA-Class	156	Body	BSN-Battery sensor(B95)	√	√	√	√					
GLA-Class	156	Body	TRM-Trailer recognition module (N28/1)	√	√	√	√		ACT0310,ACT0311,ACT0312,ACT0313,ACT0314,ACT0315,ACT0316,ACT0317,ACT0318,ACT0319,ACT0320,ACT0321	SP1082,SP1083		√
GLA-Class	156	Body	Trailer recognition module-Trailer recognition	√	√	√	√		ACT0322,ACT0323,ACT0324,ACT0325,ACT0326,ACT0327,ACT0328,ACT0329,ACT0330,ACT0331,ACT0332,ACT0333,		CD0393	√

GLA-Class	156	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√	ACT0335,ACT0336,ACT0337,ACT0338,ACT0339,ACT0340,ACT0341,ACT0342,ACT0343,ACT0344,ACT0345,ACT0346,ACT0347,ACT0348,ACT0349,ACT0350,ACT0351,ACT0352,ACT0353,ACT0354,ACT0355,ACT0356,ACT0357,ACT0358,ACT0359,ACT0360,ACT0361,ACT0362,ACT0363,ACT0364,ACT0365,ACT0366,ACT0367,ACT0368,ACT0369,ACT0370,ACT0371,ACT0372,ACT0373,ACT0374,ACT0375,ACT0376,ACT0377,ACT0378,ACT0379,			√
GLA-Class	156	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√	ACT0335,ACT0336,ACT0337,ACT0338,ACT0339,ACT0340,ACT0341,ACT0342,ACT0343,ACT0344,ACT0345,ACT0346,ACT0347,ACT0348,ACT0349,ACT0350,ACT0351,ACT0352,ACT0353,ACT0354,ACT0355,ACT0356,ACT0357,ACT0358,ACT0359,ACT0360,ACT0361,ACT0362,ACT0363,ACT0364,ACT0365,ACT0366,ACT0367,ACT0368,ACT0369,ACT0370,ACT0371,ACT0372,ACT0373,ACT0374,ACT0375,ACT0376,ACT0377,ACT0378,ACT0379,			√
GLA-Class	156	Drive	FSCU05-Control unit Fuel pump	√	√	√	√	ACT0385			√
GLA-Class	156	Driver assistance system	DTR-DISTRONIC (A89)	√	√	√	√		SP1084	CD0395	√
GLA-Class	156	Chassis	DTR-DISTRONIC (A89)	√	√	√	√		SP1084	CD0395	√
GLA-Class	156	Seats and Doors	LFD-Left front door	√	√	√	√	ACT0386,ACT0387,ACT0388,ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0397,ACT0398,ACT0399,ACT0400,ACT0401,ACT0402,ACT0403,	SP1085		√
GLA-Class	156	Seats and Doors	DCU RF-Right front door	√	√	√	√	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410,ACT0411,ACT0412,ACT0413,ACT0414,ACT0415,ACT0416,ACT0417,ACT0418,ACT0419,ACT0420,ACT0421,ACT0422,	SP1086		√

GLA-Class	156	Information and communication	TV-TV tuner	√	√	√	√		ACT0424,ACT0425,ACT0426,ACT0427,ACT0222,ACT0428,ACT0219,ACT0221			
GLA-Class	156	Information and communication	TV-TV tuner	√	√	√	√		ACT0429,ACT0430,ACT0431,ACT0229,ACT0432,ACT0433,			
GLA-Class	156	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258			
GLA-Class	156	Chassis	EFB-Electronic parking brake(N128)	√	√	√	√		ACT0435,ACT0436,ACT0437,ACT0438	SP1087		√
GLA-Class	156	Driver assistance system	RFK-Backup camera	√	√	√	√		ACT0439,ACT0440	SP1088,SP1089		√
GLA-Class	156	Driver assistance system	RFK-Backup camera	√	√	√	√		ACT0439	SP1088,SP1089		√
GLA-Class	156	Body	WSS-Weight sensing system(N110)	√	√	√	√					
GLA-Class	156	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
GLA-Class	156	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
GLA-Class	156	Body	BSN-Battery sensor(B95)	√	√	√	√					
GLA-Class	156	Body	UCP-Upper control panel	√	√	√	√					
GLA-Class	156	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0442,ACT0443,ACT0444,ACT0445,ACT0446			√
GLA-Class	156	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0447,ACT0448,ACT0449,ACT0450			√
GLA-Class	156	Body	SG SW-Control unit 'Headlamp'(N71/1)	√	√	√	√		ACT0451,ACT0452,ACT0453,ACT0454,ACT0455	SP1090,SP1091,SP1092,SP1093	CD0397	√
GLA-Class	156	Body	SG SW L-Left headlamp	√	√	√	√		ACT0456,ACT0457,ACT0458,ACT0459,ACT0460,ACT0461	SP1094,SP1095,SP1096,SP1097,,SP1098,SP1099,	CD0398	√
GLA-Class	156	Body	SG SW L-Left headlamp(E1n9)	√	√	√	√		ACT0462,ACT0463,ACT0464,ACT0465,ACT0466,ACT0467	SP1101,SP1102,SP1103,SP1104,SP1105,SP1106,SP1107,SP1108	CD0399	√
GLA-Class	156	Body	SG SW R-Right headlamp	√	√	√	√		ACT0468,ACT0469,ACT0470,ACT0471,ACT0472,ACT0473	SP1109,SP1110,SP1111,SP1112,SP1113,SP1114	CD0400	√
GLA-Class	156	Body	SG SW R-Right headlamp(E1n9)	√	√	√	√		ACT0474,ACT0475,ACT0476,ACT0477,ACT0478,ACT0479	SP1115,SP1116,SP1117,SP1118,SP1119,SP1120	CD0401	√
GLA-Class	156	Body	GTO-Garage door opener(A67n2)	√	√	√	√					
GLA-Class	156	Body	OCP-Control unit 'Overhead control panel'	√	√	√	√		ACT0480,ACT0481,ACT0482,ACT0483			
GLA-Class	156	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√			SP1121		
GLA-Class	156	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√					
GLA-Class	156	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					

GLA-Class	156	Driver assistance system	PARK-Parking system (N62)	√	√	√	√		ACT0484,ACT0485		CD0411, CD0412	√
GLA-Class	156	Body	N32/2 (Front passenger seat control unit)	√			√		ACT0486			
GLA-Class	156	Body	N32/1 (Driver seat control unit)	√			√		ACT0487			
GLA-Class	156	Information and communication	DSI-DIRECT SELECT interface(N150)	√	√	√	√		ACT0488			√
GLA-Class	156	Drive	VG-All wheel drive	√	√	√	√		ACT0489	SP1122,SP1123,SP1124,SP1125		√
GLA-Class	156	Body	AS-Alarm siren(H3/1)	√	√	√			ACT0490			
GLA-Class	156	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT0490			
GLA-Class	156	Driver assistance system	KAB-Control unit Camera cover	√	√	√	√		ACT0491,ACT0492			√
GLA-Class	156	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√					
GLA-Class	156	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√					
GLA-Class	156	Drive	DKG-Electronic transmission control for double-plate clutch	√	√	√	√	√	ACT0493,ACT0494,ACT0495,ACT0496,ACT0497	SP1126,SP1127,SP1128	CD0423, CD0424, CD0425, CD0426	√
GLA-Class	156	Drive	FSCU-Fuel pump	√	√	√	√		ACT0498,ACT0499		CD0427, CD0428	√
GLA-Class	156	Drive	N127 (Drivetrain control unit)	√	√	√	√		ACT0500,ACT0501	SP1129,SP1130,SP1131	CD0429, CD0430, CD0431	√
GLA-Class	156	Drive	PTCU-Common powertrain controller(N127)	√	√	√	√		ACT0502,ACT0503,ACT0504,ACT0505,ACT0506,ACT0507	SP1132	CD0432, CD0433, CD0434	√
GLA-Class	156	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	√	√	√	√	√	ACT0508,ACT0509,ACT0510,ACT0511,ACT0512,ACT0513,ACT0514,ACT0515,ACT0516,ACT0517,ACT0518,ACT0519,ACT0520,ACT0521,ACT0522,ACT0523,ACT0524,ACT0525,SP1133,SP1134,SP1135,SP1136,SP1137,SP1138,SP1139,SP1140,SP1141,SP1142,SP1143,SP1144,SP1145,SP1146,SP1147,SP1148	CD0435, CD0436, CD0437, CD0438, CD0439, CD0440, CD0441, CD0442, CD0443	√	
GLA-Class	156	Drive	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"	√	√	√	√	√	ACT0528,ACT0529,ACT0530,ACT0531,ACT0532,ACT0533,ACT0534,ACT0535,ACT0536,ACT0537,ACT0538,ACT0539,SP1149,SP1150,SP1151,SP1152,SP1153,SP1154,SP1155,SP1156	CD0444, CD0445, CD0446, CD0447, CD0448, CD0449, CD0450, CD0451, CD0452	√	
M/GLE/GL/GLS-Class	166	Drive	N3/9-Motor electronics "CR43" for combustion engine "OM651"	√	√	√	√	√	ACT0543,ACT0544,ACT0545,ACT0546,ACT0547,ACT0548,ACT0549,ACT0550,ACT0551,ACT0552,ACT0553,ACT0554,ACT0555,ACT0556,ACT0557,ACT0558,SP1164,SP1165,SP1166,SP1167,SP1168,SP1169,SP1170,SP1171,SP1172,SP1173,SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1180,SP1181,SP1182,SP1183,SP1184,	CD0453, CD0454, CD0455, CD0456	√	

M/GLE/ GL/GLS- Class	166	Drive	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"	√	√	√	√	√	ACT0559,ACT0560,ACT0561, ACT0562,ACT0563,ACT0564, ACT0565,ACT0566,ACT0567, ACT0568,ACT0569,ACT0570,	SP1187,SP1188,SP1189, SP1190,SP1191,SP1192, SP1193,SP1194,SP1195, SP1196,SP1197,SP1198, SP1199,SP1200,SP1201, SP1202,SP1203,SP1204,	CD0457, CD0458, CD045 9, CD0460	√
M/GLE/ GL/GLS- Class	166	Drive	N3/9-Motor electronics "CDI61" for combustion engine "OM642"	√	√	√	√	√	ACT0571,ACT0572,ACT0573, ACT0574,ACT0575,ACT0576, ACT0577,ACT0578,ACT0579, ACT0580,ACT0581,ACT0582, ACT0583	SP1206,SP1207,SP1208, SP1209,SP1210,SP1211, SP1212,SP1213,SP1214, SP1215,SP1216,SP1217, SP1218,SP1219,SP1220, SP1221,SP1222,SP1223, SP1224,SP1225,SP1226,	CD0461, CD0462, CD046 3, CD0464	√
M/GLE/ GL/GLS- Class	166	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√	√	ACT0000,ACT0001,ACT0002, ACT0003,ACT0004,ACT0005, ACT0006,ACT0007,ACT0008, ACT0009,ACT0010,ACT0011, ACT0012,ACT0013,ACT0014, ACT0015,ACT0016,ACT0017, ACT0018,ACT0019,ACT0020, ACT0021,ACT0022,ACT0023 ,ACT0024,ACT0025,ACT0026	SP1000,SP1001,SP1002, SP1003,SP1004,SP1005, SP1006,SP1007,SP1008, SP1009,SP1010,SP1011, SP1012,SP1013,SP1014, SP1015,SP1016,SP1017, SP1018,SP1019,SP1020, SP1021,SP1022,SP1023, SP1024	CD0304, CD0305, CD030 6, CD0307	√
M/GLE/ GL/GLS- Class	166	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√	ACT0584,ACT0585	SP1229,SP1230,SP1231, SP1232,SP1233,SP1234, SP1235,SP1236,SP1237, SP1237,SP1238,SP1239, SP1240,SP1241,SP1242,	CD0465, CD0466, CD046 7, CD0468	√
M/GLE/ GL/GLS- Class	166	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7	√	√	√	√	√	ACT0586	SP1244,SP1245,SP1246, SP1247,SP1248,SP1249, SP1250,SP1250,SP1251, SP1252,SP1253,SP1254,	CD0469, CD0470, CD047 1, CD0472, CD0473	√
M/GLE/ GL/GLS- Class	166	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√	ACT0587,ACT0588,ACT0589	SP1256,SP1257,SP1258, SP1259,SP1260,SP1261	CD0474, CD0475, CD047 6, CD0477, CD0478	√
M/GLE/ GL/GLS- Class	166	Drive	FSCU-Fuel pump	√	√	√	√		ACT0498,ACT0499		CD0427, CD0428	√
M/GLE/ GL/GLS- Class	166	Drive	SCR-Selective Catalytic Reduction	√	√	√	√		ACT0590,ACT0591,ACT0592, ACT0593,ACT0594,ACT0595, ACT0596,ACT0597,ACT0598,	SP1262,SP1263,SP1264, SP1265,SP1266,SP1267	CD0479, CD0480, CD048 1, CD0482	√
M/GLE/ GL/GLS- Class	166	Drive	SCR-Selective catalytic reduction	√	√	√	√		ACT0600,ACT0601,ACT0602, ACT0603,ACT0604,ACT0605	SP1268,SP1269,SP1270, SP1271,SP1272,SP1273	CD0483, CD0484, CD048 5	√
M/GLE/ GL/GLS- Class	166	Drive	N127 (Drivetrain control unit)	√	√	√	√		ACT0500,ACT0501	SP1129,SP1130,SP1131	CD0429, CD0430, CD043 1	√
M/GLE/ GL/GLS- Class	166	Drive	SG EM-Power electronics	√	√	√	√			SP1274,SP1275,SP1276	CD0486, CD0487	√

M/GLE/ GL/GLS- Class	166	Body	BMS-Battery management system(N82/2)	√	√	√	√		ACT0606,ACT0607,ACT0608, ACT0609	SP1277	CD0488, CD0489	
M/GLE/ GL/GLS- Class	166	Information and communication	E call [Europe]-Emergency call system	√	√	√	√		ACT0044,ACT0045,ACT0046, ACT0047,ACT0048,ACT0049			
M/GLE/ GL/GLS- Class	166	Information and communication	AVE H-Rear audio video unit	√	√	√	√		ACT0610,ACT0611,ACT0612, ACT0613,ACT0614		CD0490, CD0491, CD0492, CD0493, CD0494	√
M/GLE/ GL/GLS- Class	166	Information and communication	TPAD-Touchpad	√	√	√	√		ACT0615,ACT0616,ACT0617			
M/GLE/ GL/GLS- Class	166	Information and communication	IC-Instrument cluster	√	√	√	√		ACT0050,ACT0051,ACT0052, ACT0053,ACT0054,ACT0055, ACT0056	SP1047,SP1048		√
M/GLE/ GL/GLS- Class	166	Information and communication	KOMO-Communication module Telematics services	√	√	√	√		ACT0057,ACT0058,ACT0059, ACT0060,ACT0061,ACT0062, ACT0063,ACT0064,ACT0065,			√
M/GLE/ GL/GLS- Class	166	Seats and Doors	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√		ACT0067,ACT0068,ACT0069, ACT0070,ACT0071,ACT0072, ACT0073,ACT0074	SP1049,SP1050		
M/GLE/ GL/GLS- Class	166	Information and communication	TS-Telematic system(N123/4)	√	√	√	√		ACT0075,ACT0076,ACT0077, ACT0078			√
M/GLE/ GL/GLS- Class	166	Body	EZS-Electronic ignition switch	√	√	√	√			SP1051,SP1052,SP1053	CD0320, CD0321, CD0322, CD0323, CD0324	
M/GLE/ GL/GLS- Class	166	Body	EZS-Electronic ignition lock	√	√	√	√				CD0325	
M/GLE/ GL/GLS- Class	166	Body	EZS-Electronic ignition lock (N73)	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Body	EZS-Electronic ignition lock (N73)	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Body	SG LG-Charger	√	√	√	√		ACT0618,ACT0619,ACT0620, ACT0621,ACT0622,ACT0623		CD0495, CD0496	√
M/GLE/ GL/GLS- Class	166	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081, ACT0082,ACT0083,ACT0084			√
M/GLE/ GL/GLS- Class	166	Chassis	ESP-Electronic stability program(N30/4)	√	√	√	√		ACT0088,ACT0089	SP1278,SP1279,SP1280, SP1281		√
M/GLE/ GL/GLS- Class	166	Chassis	ESP-Regenerative braking system(N30/6)	√	√	√	√	√	ACT0624,ACT0625,ACT0626	SP1282,SP1283,SP1284, SP1285,SP1286,SP1287	CD0499, CD0500, CD0501, CD0502	√

M/GLE/ GL/GLS- Class	166	Information and communication	NAV-Navigation module(A2/30)	√	√	√	√		ACT0090,ACT0091,ACT0092,ACT0093			√
M/GLE/ GL/GLS- Class	166	Information and communication	TPAD-Touchpad	√	√	√	√		ACT0615,ACT0616,ACT0617			√
M/GLE/ GL/GLS- Class	166	Information and communication	Audio-Audio or COMAND	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√			SP1288,SP1289,SP1290,SP1291		√
M/GLE/ GL/GLS- Class	166	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1292,SP1293,SP1294,SP1295,SP1296		√
M/GLE/ GL/GLS- Class	166	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1297,SP1293,SP1294,SP1296		√
M/GLE/ GL/GLS- Class	166	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441,ACT0627			√
M/GLE/ GL/GLS- Class	166	Body	IMS-Interior motion sensor	√	√	√	√		ACT0094,ACT0095,ACT0096			√
M/GLE/ GL/GLS- Class	166	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0099,ACT0100	SP1056		√
M/GLE/ GL/GLS- Class	166	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√				√
M/GLE/ GL/GLS- Class	166	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√		ACT0101,ACT0102,ACT0103,ACT0104,ACT0105,ACT0106,ACT0107,ACT0108,ACT0109,ACT0110,ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,ACT0117,ACT0118,ACT0119,ACT0120,ACT0121,ACT0118,ACT0119,ACT0120,ACT0119,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0111,ACT0112,ACT0113,ACT0118,ACT0116,ACT0117,ACT0102,ACT0103,ACT0127,ACT0128,ACT0101,	SP1057,SP1058,SP1059,SP1060,SP1061		

M/GLE/ GL/GLS- Class	166	Information and communication	Audio-Audio or COMAND	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Driver assistance system	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)	√	√	√	√		ACT0132	SP1062		√
M/GLE/ GL/GLS- Class	166	Seats and Doors	PPAMKS-Pneumatic pump for active multicontour seat	√	√	√	√		ACT0628,ACT0629,ACT0630			√
M/GLE/ GL/GLS- Class	166	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√		ACT0631,ACT0632,ACT0633,ACT0634,ACT0635			√
M/GLE/ GL/GLS- Class	166	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√		ACT0636,ACT0637,ACT0638,ACT0639,ACT0640,ACT0641,ACT0642,ACT0643			√
M/GLE/ GL/GLS- Class	166	Driver assistance system	CAMERA-360 camera(N148)	√	√	√	√		ACT0644	SP1298,SP1299,SP1300		√
M/GLE/ GL/GLS- Class	166	Driver assistance system	CAMERA-360 camera(N148)	√	√	√	√		ACT0542	SP1158,SP1159,SP1160,SP1161,SP1162,SP1163		√
M/GLE/ GL/GLS- Class	166	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√		ACT0645,ACT0646,ACT0647,ACT0648,ACT0649,ACT0650,ACT0651,ACT0652			√
M/GLE/ GL/GLS- Class	166	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor system(B29/5)	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Body	IRS HRA-Outer right rear intelligent radar sensor system(B29/5)	√	√	√	√					√
M/GLE/ GL/GLS- Class	166	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system (B29/4)	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Body	IRS HLA-Outer left rear intelligent radar sensor system (B29/4)	√	√	√	√					√
M/GLE/ GL/GLS- Class	166	Body	Multifunction control unit-Multifunction control unit	√	√	√	√		ACT0133,ACT0134,ACT0135,ACT0136,ACT0137,ACT0138,ACT0139,ACT0140,ACT0141,ACT0142,ACT0143,ACT0144,ACT0145,ACT0146,ACT0147,ACT0148,ACT0149,ACT0150,			√
M/GLE/ GL/GLS- Class	166	Information and communication	SG MSND-Engine sound	√	√	√	√		ACT0151,ACT0152,ACT0153,ACT0154,ACT0155			√
M/GLE/ GL/GLS- Class	166	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0156,ACT0157			√

M/GLE/ GL/GLS- Class	166	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0156,ACT0157			√
M/GLE/ GL/GLS- Class	166	Information and communication	SOUND-Sound system	√	√	√	√		ACT0158,ACT0159,ACT0160, ACT0161,ACT0162,ACT0163, ACT0164,ACT0165,ACT0166, ACT0167,ACT0168,ACT0169, ACT0170,ACT0171,ACT0172, ACT0173,ACT0174,ACT0175, ACT0176,ACT0177,ACT0178, ACT0179,ACT0180,ACT0181,		CD0348	
M/GLE/ GL/GLS- Class	166	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0185,ACT0186,ACT0187, ACT0188,ACT0189,ACT0190, ACT0191,ACT0192,ACT0193, ACT0194,ACT0195,ACT0196, ,ACT0197,ACT0198,			
M/GLE/ GL/GLS- Class	166	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0199,ACT0653,ACT0185, ACT0186,ACT0654,ACT0655, ACT0195,ACT0196,ACT0193, ACT0200,ACT0194,ACT0188, ACT0190,ACT0191,ACT0192, ACT0656,ACT0657,ACT0206,			
M/GLE/ GL/GLS- Class	166	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√		ACT0660,ACT0661,ACT0662, ACT0663,ACT0664,ACT0665, ACT0666,ACT0667,ACT0668, ACT0207,ACT0208,ACT0210, ACT0209,ACT0669,ACT0670,	SP1064,SP1301	CD0349	√
M/GLE/ GL/GLS- Class	166	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√		ACT0664,ACT0673,ACT0660, ACT0661,ACT0207,ACT0208, ACT0209,ACT0210,ACT0665, ACT0666,ACT0667,ACT0668, ACT0669,ACT0670,ACT0672,	SP1064,SP1301	CD0349	√
M/GLE/ GL/GLS- Class	166	Body	HKS-Tailgate control	√	√	√	√		ACT0211,ACT0212,ACT0213	SP1065		√
M/GLE/ GL/GLS- Class	166	Information and communication	ECS-N123/4 Emergency call system control unit	√	√	√	√		ACT0674,ACT0675,ACT0676			
M/GLE/ GL/GLS- Class	166	Information and communication	TV-TV tuner	√	√	√	√		ACT0214,ACT0215,ACT0216, ACT0217,ACT0218,ACT0219, ACT0220,ACT0221,ACT0222, ACT0223		CD0350CD0351, CD0352 , CD0353, CD0354, CD03 55, CD0356, CD0357, CD 0358, CD0359, CD0360, CD0361	
M/GLE/ GL/GLS- Class	166	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226, ACT0227,ACT0228,ACT0229, ACT0677,ACT0233			

M/GLE/ GL/GLS- Class	166	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226, ACT0227,ACT0228,ACT0229, ACT0230,ACT0231,ACT0232, ACT0233		CD0362,CD0363, CD0364 , CD0365, CD0366, CD03 67, CD0368, CD0369, CD 0370, CD0371, CD0372, CD0373	
M/GLE/ GL/GLS- Class	166	Driver assistance system	MFK-Multifunction camera	√	√	√	√		ACT0234,ACT0235	SP1066		√
M/GLE/ GL/GLS- Class	166	Driver assistance system	MFK-Multifunction camera(A40/11)	√	√	√	√		ACT0236,ACT0237	SP1067,SP1068		√
M/GLE/ GL/GLS- Class	166	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		ACT0238,ACT0241,ACT0678, ACT0243,ACT0679,ACT0680, ACT0681,ACT0682,ACT0683, ACT0684,ACT0245,ACT0685, ACT0686,ACT0687,ACT0688, ACT0689,ACT0690,ACT0253, ACT0254,ACT0691,ACT0692, ACT0251,ACT0693,ACT0694, ACT0695,ACT0696,ACT0697, ACT0698,ACT0699,ACT0700,	SP1069,SP1070,SP1071		√
M/GLE/ GL/GLS- Class	166	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257, ACT0258		CD0382	
M/GLE/ GL/GLS- Class	166	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√		ACT0704		CD0523	√
M/GLE/ GL/GLS- Class	166	Air conditioning	STH-Stationary heater	√	√	√	√		ACT0259,ACT0260,ACT0261, ACT0262	SP1072		√
M/GLE/ GL/GLS- Class	166	Information and communication	Drive Kit Plus-Drive kit for iPhone	√	√	√	√		ACT0263,ACT0264,ACT0265, ACT0266			
M/GLE/ GL/GLS- Class	166	Chassis	ES-Electric power steering(N68)	√	√	√	√			SP1302,SP1303		√
M/GLE/ GL/GLS- Class	166	Body	SD-Control module 'Sliding roof' (A98/1)	√	√	√	√		ACT0705	SP1304		√
M/GLE/ GL/GLS- Class	166	Body	PSD-Control module 'Panoramic sliding roof'(A98)	√	√	√	√		ACT0706,ACT0707	SP1305		√

M/GLE/ GL/GLS- Class	166	Body	RevETR LF-Left front reversible emergency tensioning retractor (A76)	√	√	√	√		ACT0708		CD0525	√
M/GLE/ GL/GLS- Class	166	Information and communication	HUD-Head up display	√	√	√	√		ACT0272,ACT0273,ACT0274	SP1077,		
M/GLE/ GL/GLS- Class	166	Body	RevETR RF-Right front reversible emergency tensioning retractor(A76/1)	√	√	√	√		ACT0709		CD0526	√
M/GLE/ GL/GLS- Class	166	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory function	√	√	√	√		ACT0276,ACT0277,ACT0278,ACT0279,ACT0280,ACT0281,ACT0282	SP1078,SP1079		√
M/GLE/ GL/GLS- Class	166	Information and communication	SDAR-Satellite radio	√	√	√	√		ACT0283,ACT0284,ACT0285,ACT0286		CD0387CD0388, CD0389, CD0389	
M/GLE/ GL/GLS- Class	166	Information and communication	TB5-TV tuner Tuner unit	√	√	√	√		ACT0287,ACT0288,ACT0289,ACT0290,ACT0291,ACT0292,ACT0293,ACT0294,			
M/GLE/ GL/GLS- Class	166	Information and communication	TV tuner (TV)	√	√	√	√		ACT0295,ACT0296,ACT0297,ACT0298,ACT0299,ACT0300,ACT0301			
M/GLE/ GL/GLS- Class	166	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√		ACT0302,ACT0303,ACT0304,ACT0305,ACT0306,ACT0307,ACT0308	SP1080,SP1081		√
M/GLE/ GL/GLS- Class	166	Information and communication	MIF-Media interface	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Information and communication	MIF-Media interface	√	√	√	√		ACT0309			
M/GLE/ GL/GLS- Class	166	Body	DDW-DC/DC converter(N83/1)	√	√	√	√		ACT0710	SP1306		√
M/GLE/ GL/GLS- Class	166	Body	BSN-Battery sensor(B95)	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√		ACT0711,ACT0712,ACT0713,ACT0714,ACT0715	SP1307,SP1308,SP1309,SP1310,SP1311	CD0527, CD0528, CD0529, CD0530	√
M/GLE/ GL/GLS- Class	166	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√		ACT0711,ACT0712,ACT0713,ACT0714,ACT0715	SP1307,SP1308,SP1309,SP1310,SP1311	CD0527, CD0528, CD0529, CD0530	√
M/GLE/ GL/GLS- Class	166	Seats and Doors	N32/31 (Left front seat massage function control unit)	√	√	√	√		ACT0716			
M/GLE/ GL/GLS- Class	166	Drive	ISM-Shift module	√	√	√	√		ACT0717,ACT0718,ACT0719,ACT0720,ACT0721	SP1312,SP1313,SP1314		√

M/GLE/ GL/GLS- Class	166	Body	TRM-Trailer recognition module (N28/1)	√	√	√	√		ACT0310,ACT0311,ACT0312, ACT0313,ACT0314,ACT0315, ACT0316,ACT0317,ACT0318, ACT0319,ACT0320,ACT0321	SP1082,SP1083		√
M/GLE/ GL/GLS- Class	166	Body	Trailer recognition module- Trailer recognition	√	√	√	√		ACT0322,ACT0323,ACT0324, ACT0325,ACT0326,ACT0327, ACT0328,ACT0329,ACT0330, ACT0331,ACT0332,ACT0333,		CD0393	√
M/GLE/ GL/GLS- Class	166	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√		ACT0335,ACT0336,ACT0337, ACT0338,ACT0339,ACT0340, ACT0341,ACT0342,ACT0343, ACT0344,ACT0345,ACT0346, ACT0347,ACT0348,ACT0349, ACT0350,ACT0351,ACT0352, ACT0353,ACT0354,ACT0355, ACT0356,ACT0357,ACT0358, ACT0359,ACT0360,ACT0361, ACT0362,ACT0363,ACT0364, ACT0365,ACT0366,ACT0367, ACT0368,ACT0369,ACT0370, ACT0371,ACT0372,ACT0373, ACT0374,ACT0375,ACT0376, ACT0377,ACT0378,ACT0379,			√
M/GLE/ GL/GLS- Class	166	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√		ACT0335,ACT0336,ACT0337, ACT0338,ACT0339,ACT0340, ACT0341,ACT0342,ACT0343, ACT0344,ACT0345,ACT0346, ACT0347,ACT0348,ACT0349, ACT0350,ACT0351,ACT0352, ACT0353,ACT0354,ACT0355, ACT0356,ACT0357,ACT0358, ACT0359,ACT0360,ACT0361, ACT0362,ACT0363,ACT0364, ACT0365,ACT0366,ACT0367, ACT0368,ACT0369,ACT0370, ACT0371,ACT0372,ACT0373, ACT0374,ACT0375,ACT0376, ACT0377,ACT0378,ACT0379,			√
M/GLE/ GL/GLS- Class	166	Seats and Doors	N32/32 (Right front seat massage function control unit)	√	√	√	√		ACT0722			
M/GLE/ GL/GLS- Class	166	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√		ACT0723,ACT0724,ACT0725, ACT0726,ACT0727	SP1315,SP1316,SP1317, SP1318,SP1319	CD0531, CD0532, CD053 3, CD0534	√
M/GLE/ GL/GLS- Class	166	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√		ACT0723,ACT0724,ACT0725, ACT0726,ACT0727	SP1315,SP1316,SP1317, SP1318,SP1319	CD0531, CD0532, CD053 3, CD0534	√

M/GLE/ GL/GLS- Class	166	Drive	FSCU05-Control unit Fuel pump	√	√	√	√		ACT0385			√
M/GLE/ GL/GLS- Class	166	Body	REAR-Rear control unit(N10/8)	√	√	√	√		ACT0728,ACT0729,ACT0730, ACT0731,ACT0732,ACT0733, ACT0734,ACT0735,ACT0736,			√
M/GLE/ GL/GLS- Class	166	Information and communication	N123 / 4 (emergency call system control unit) - an emergency call	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Driver assistance system	DTR-DISTRONIC	√	√	√	√					√
M/GLE/ GL/GLS- Class	166	Driver assistance system	DTR-DISTRONIC	√	√	√	√					√
M/GLE/ GL/GLS- Class	166	Driver assistance system	DTR-DISTRONIC (A89)	√	√	√	√			SP1084	CD0395	√
M/GLE/ GL/GLS- Class	166	Chassis	DTR-DISTRONIC (A89)	√	√	√	√			SP1084	CD0395	√
M/GLE/ GL/GLS- Class	166	Seats and Doors	LFD-Left front door	√	√	√	√		ACT0386,ACT0387,ACT0388, ACT0389,ACT0390,ACT0391, ACT0392,ACT0393,ACT0394, ACT0395,ACT0396,ACT0397, ACT0398,ACT0399,ACT0400, ACT0401,ACT0402,ACT0403,	SP1085		√
M/GLE/ GL/GLS- Class	166	Information and communication	N123 / 4 (emergency call system control unit) - Mercedes - Benz (MB) information / fault rescue	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Driver assistance system	NSA-Night View Assist(N101)	√	√	√	√		ACT0738,ACT0739,ACT0740	SP1320		√
M/GLE/ GL/GLS- Class	166	Seats and Doors	DCU RF-Right front door	√	√	√	√		ACT0405,ACT0406,ACT0407, ACT0408,ACT0409,ACT0410, ACT0411,ACT0412,ACT0413, ACT0414,ACT0415,ACT0416, ACT0417,ACT0418,ACT0419, ACT0420,ACT0421,ACT0422,	SP1086		√
M/GLE/ GL/GLS- Class	166	Information and communication	TV-TV tuner	√	√	√	√		ACT0424,ACT0425,ACT0426, ACT0427,ACT0222,ACT0428, ACT0219,ACT0221			
M/GLE/ GL/GLS- Class	166	Information and communication	TV-TV tuner	√	√	√	√		ACT0429,ACT0430,ACT0431, ACT0229,ACT0432,ACT0433, ACT0434			

M/GLE/ GL/GLS- Class	166	Seats and Doors	DCU LR-Left rear door(N69/3)	√	√	√	√		ACT0741,ACT0742,ACT0743, ACT0744,ACT0745,ACT0746, ACT0747,ACT0748,ACT0749, ACT0750,ACT0751,ACT0752, ACT0753,ACT0754,ACT0755, ACT0756,ACT0757,ACT0758,	SP1321		√
M/GLE/ GL/GLS- Class	166	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257, ACT0258			
M/GLE/ GL/GLS- Class	166	Seats and Doors	DCU RR-Right rear door(N69/4)	√	√	√	√		ACT0760,ACT0761,ACT0762, ACT0763,ACT0764,ACT0765, ACT0766,ACT0767,ACT0768, ACT0769,ACT0770,ACT0771, ACT0772,ACT0773,ACT0774, ACT0775,ACT0776,ACT0777,	SP1322		√
M/GLE/ GL/GLS- Class	166	Information and communication	N123 / 4 (emergency call system control unit) - the vehicle remote control unlocking / locking the vehicle remote	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Information and communication	N123 / 4 (emergency call system control unit) - anti-theft tracking	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Chassis	EFB-Electronic parking brake(N128)	√	√	√	√		ACT0435,ACT0436,ACT0437, ACT0438	SP1087		√
M/GLE/ GL/GLS- Class	166	Driver assistance system	RFK-Backup camera	√	√	√	√		ACT0439,ACT0440	SP1088,SP1089		√
M/GLE/ GL/GLS- Class	166	Driver assistance system	RFK-Backup camera	√	√	√	√		ACT0439	SP1088,SP1089		√
M/GLE/ GL/GLS- Class	166	Chassis	FGW-Chassis gateway	√	√	√	√				CD0535	√
M/GLE/ GL/GLS- Class	166	Body	WSS-Weight sensing system(N110)	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Chassis	RC-Roll control(B38/2)	√	√	√	√		ACT0779,ACT0780,ACT0781, ACT0782,ACT0783,ACT0784, ACT0785,ACT0786	SP1323		√
M/GLE/ GL/GLS- Class	166	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
M/GLE/ GL/GLS- Class	166	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441,ACT0627			√
M/GLE/ GL/GLS- Class	166	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√

M/GLE/ GL/GLS- Class	166	Air conditioning	HBF-Rear control panel(N72/2)	√	√	√	√		ACT0787,ACT0788			√
M/GLE/ GL/GLS- Class	166	Body	BSN-Battery sensor(B95)	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Body	UCP-Upper control panel	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0442,ACT0443,ACT0444, ACT0445,ACT0446			√
M/GLE/ GL/GLS- Class	166	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0447,ACT0448,ACT0449, ACT0450			√
M/GLE/ GL/GLS- Class	166	Information and communication	AVE H-Rear audio video unit	√	√	√	√		ACT0610,ACT0611,ACT0612, ACT0789,ACT0613,ACT0614		CD0490, CD0491, CD0492, CD0493, CD0494	√
M/GLE/ GL/GLS- Class	166	Body	SG SW-Control unit 'Headlamp'(N71/1)	√	√	√	√		ACT0451,ACT0452,ACT0453, ACT0454,ACT0455	SP1090,SP1091,SP1092, SP1093	CD0397	√
M/GLE/ GL/GLS- Class	166	Body	SG SW L-Left headlamp	√	√	√	√		ACT0456,ACT0457,ACT0458, ACT0459,ACT0460,ACT0461	SP1094,SP1095,SP1096, SP1097,SP1098,SP1099, SP1100	CD0398	√
M/GLE/ GL/GLS- Class	166	Body	SG SW L-Left headlamp(E1n9)	√	√	√	√		ACT0462,ACT0463,ACT0464, ACT0465,ACT0466,ACT0467	SP1101,SP1102,SP1103, SP1104,SP1105,SP1106, SP1107,SP1108	CD0399	√
M/GLE/ GL/GLS- Class	166	Body	SG SW R-Right headlamp	√	√	√	√		ACT0468,ACT0469,ACT0470, ACT0471,ACT0472,ACT0473	SP1109,SP1110,SP1111, SP1112,SP1113,SP1114	CD0400	√
M/GLE/ GL/GLS- Class	166	Body	SG SW R-Right headlamp(E1n9)	√	√	√	√		ACT0474,ACT0475,ACT0476, ACT0477,ACT0478,ACT0479	SP1115,SP1116,SP1117, SP1118,SP1119,SP1120	CD0401	√
M/GLE/ GL/GLS- Class	166	Body	GTO-Garage door opener(A67n2)	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Body	OCP-Control unit 'Overhead control panel'	√	√	√	√		ACT0480,ACT0481,ACT0482, ACT0483			
M/GLE/ GL/GLS- Class	166	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√			SP1121		
M/GLE/ GL/GLS- Class	166	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					

M/GLE/ GL/GLS- Class	166	Driver assistance system	PARK-Parking system (N62)	√	√	√	√		ACT0484,ACT0485		CD0411, CD0412	√
M/GLE/ GL/GLS- Class	166	Driver assistance system	PTS-Parktronic system	√	√	√	√		ACT0790		CD0536, CD0537, CD0538, CD0539	√
M/GLE/ GL/GLS- Class	166	Body	N32/2 (Front passenger seat control unit)	√			√		ACT0486			
M/GLE/ GL/GLS- Class	166	Body	ORBF Off-road operating panel(N72/3)	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Body	LCP-Lower operating panel with power window function	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Body	N32/1 (Driver seat control unit)	√			√		ACT0487			
M/GLE/ GL/GLS- Class	166	Drive	VG-Transfer case	√	√	√	√		ACT0791,ACT0792,ACT0793	SP1324		√
M/GLE/ GL/GLS- Class	166	Body	AS-Alarm siren(H3/1)	√	√	√			ACT0490			
M/GLE/ GL/GLS- Class	166	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT0490			
M/GLE/ GL/GLS- Class	166	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√		ACT0794,ACT0795	SP1325,SP1326,SP1327	CD0540	
M/GLE/ GL/GLS- Class	166	Body	AMLAB L 2-Actuation module 2, LED exterior lighting, left front(E1n8)	√	√	√	√		ACT0796,ACT0797	SP1328,SP1329,SP1330	CD0541	
M/GLE/ GL/GLS- Class	166	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√					
M/GLE/ GL/GLS- Class	166	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√		ACT0798,ACT0799	SP1331,SP1332	CD0542	
M/GLE/ GL/GLS- Class	166	Body	AMLAB R 2-Actuation module 2, LED exterior lighting, right front(E2n8)	√	√	√	√		ACT0800,ACT0801	SP1333,SP1334	CD0543	
M/GLE/ GL/GLS- Class	166	Information and communication	Left front short range radar	√	√	√	√					√

M/GLE/ GL/GLS- Class	166	Information and communication	Left front short range radar	√								√
M/GLE/ GL/GLS- Class	166	Drive	N3/10-Motor electronics "MED177" for combustion engine "M276"	√	√	√	√	√	ACT0802,ACT0803,ACT0804,ACT0805,ACT0806,ACT0807,ACT0808,ACT0809,ACT0810,ACT0811,ACT0812,ACT0813,ACT0814,ACT0815,ACT0816,ACT0817,ACT0818,ACT0819,	SP1335,SP1336,SP1337,SP1338,SP1339,SP1340,SP1341,SP1342,SP1343,SP1344,SP1345,SP1346,SP1347,SP1348	CD0544, CD0545, CD0546, CD0547, CD0548, CD0549, CD0550, CD0551, CD0552	√
M/GLE/ GL/GLS- Class	166	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√	ACT0821,ACT0822,ACT0823,ACT0824,ACT0825,ACT0826,ACT0827,ACT0828,ACT0829,ACT0830,ACT0831,ACT0832,ACT0833,ACT0834,ACT0835,ACT0836,ACT0837,ACT0838,	SP1349,SP1350,SP1351,SP1352,SP1353,SP1354,SP1355,SP1356,SP1357,SP1358,SP1359,SP1360,SP1361,SP1362,SP1363,SP1364	CD0553, CD0554, CD0555, CD0556, CD0557, CD0558, CD0559, CD0560, CD0561	√
GLS/GL E-Class	167	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√				
GLS/GL E-Class	167	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√				
GLS/GL E-Class	167	Seats and Doors	LFD-Left front door	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	DCU RF-Right front door	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
GLS/GL E-Class	167	Body	SRS-Supplemental restraint system	√	√	√	√	√				
GLS/GL E-Class	167	Information and communication	CTEL-Cellular telephone	√	√	√	√					
GLS/GL E-Class	167	Body	EZS-Electronic ignition switch	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
GLS/GL E-Class	167	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√					
GLS/GL E-Class	167	Information and communication	HERMES-control unit for telematics services	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	ESE_RL-Left rear electrical seat adjustment	√	√	√	√					

GLS/GL E-Class	167	Seats and Doors	Right rear ESE-Right rear electrical seat adjustment	√	√	√	√					
GLS/GL E-Class	167	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√					
GLS/GL E-Class	167	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
GLS/GL E-Class	167	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	MKS LF-Left rear multicontour seat	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	MKS LF-Left rear multicontour seat	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	MKS RF-Right rear multicontour seat	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	MKS RF-Right rear multicontour seat	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	HKS-Tailgate control	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√					
GLS/GL E-Class	167	Body	ATA-Interior motion sensor	√	√	√	√					
GLS/GL E-Class	167	Body	Trailer recognition module-Trailer recognition	√	√	√	√					
GLS/GL E-Class	167	Body	AGS-Active bell buckle	√	√	√	√					
GLS/GL E-Class	167	Body	PSD-Control module Panoramic sliding roof	√	√	√	√					
GLS/GL E-Class	167	Body	PSD-Control module Panoramic sliding roof	√	√	√	√					
GLS/GL E-Class	167	Body	PSD-Panoramic sliding roof	√	√	√	√					
GLS/GL E-Class	167	Body	AML-Ambiance light	√	√	√	√					
GLS/GL E-Class	167	Body	DC/DC-DC/DC converter	√	√	√	√					
GLS/GL E-Class	167	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√					
GLS/GL E-Class	167	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√					
GLS/GL E-Class	167	Information and communication	AVE H-Controller unit Rear entertainment system	√	√	√	√					
GLS/GL E-Class	167	Drive	SG SOGE AGA-Sound generator for exhaust system	√	√	√	√					

GLS/GL E-Class	167	Body	LRE-Steering wheel electronics	√	√	√	√				
GLS/GL E-Class	167	Information and communication	TPAD-Touchpad	√	√	√	√				
GLS/GL E-Class	167	Information and communication	Audio-Audio or COMAND	√	√	√					
GLS/GL E-Class	167	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√					
GLS/GL E-Class	167	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√					
GLS/GL E-Class	167	Information and communication	ZAN-Audio/COMAND display	√	√	√	√				
GLS/GL E-Class	167	Body	HE-Hand detection	√	√	√	√				
GLS/GL E-Class	167	Information and communication	MTAS-Mobile phone cradle	√	√	√	√				
GLS/GL E-Class	167	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√				
GLS/GL E-Class	167	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√				
GLS/GL E-Class	167	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√				
GLS/GL E-Class	167	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√				
GLS/GL E-Class	167	Information and communication	IC-Instrument cluster	√	√	√	√			SP1047,SP1048,SP1157	
GLS/GL E-Class	167	Information and communication	HUD-Head up display	√	√	√	√				
GLS/GL E-Class	167	Driver assistance system	RFK-Backup camera	√	√	√	√				
GLS/GL E-Class	167	Driver assistance system	KAR-Augmented reality camera	√	√	√	√				
GLS/GL E-Class	167	Drive	EAGGS-Electric differential lock	√	√	√	√				
GLS/GL E-Class	167	Body	AMLA-Active engine mount	√	√	√	√				
GLS/GL E-Class	167	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√				
GLS/GL E-Class	167	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√				
GLS/GL E-Class	167	Body	SG SW L-Left headlamp	√	√	√	√				
GLS/GL E-Class	167	Body	SG SW R-Right headlamp	√	√	√	√				
GLS/GL E-Class	167	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√				
GLS/GL E-Class	167	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√				

GLS/GL E-Class	167	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√					
GLS/GL E-Class	167	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
GLS/GL E-Class	167	Body	DCCU-Direct current charge connection unit	√	√	√	√					
GLS/GL E-Class	167	Body	SG LG-Charger	√	√	√	√					
GLS/GL E-Class	167	Body	GES-Hand motion sensor	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	ARB-Electric step	√	√	√						
GLS/GL E-Class	167	Seats and Doors	SIH-Seat heating of third seat row	√	√	√	√					
GLS/GL E-Class	167	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
GLS/GL E-Class	167	Body	BSN-Battery sensor(B95)	√	√	√	√					
GLS/GL E-Class	167	Body	LIB-Lithium ion battery	√	√	√	√					
GLS/GL E-Class	167	Body	LIB-Lithium ion battery	√	√	√	√					
GLS/GL E-Class	167	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
GLS/GL E-Class	167	Body	FSW-Windshield wiper	√	√	√	√					
GLS/GL E-Class	167	Body	GTO-Garage door opener(A67n2)	√	√	√	√					
GLS/GL E-Class	167	Body	OCP-Overhead control panel	√	√	√	√					
GLS/GL E-Class	167	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√					
GLS/GL E-Class	167	Body	N5 (Armrest heater control unit)	√	√	√	√					
GLS/GL E-Class	167	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	S47/2 (Driver door switch module)	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	S22 (Driver's door seat adjustment switch)	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	S51/1 (Driver seat climate control switch group)	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	S51/2 (Front passenger seat climate control switch group)	√	√	√	√					

GLS/GL E-Class	167	Seats and Doors	DCU LR-Left rear door	√	√	√						
GLS/GL E-Class	167	Seats and Doors	DCU RR-Right rear door	√	√	√						
GLS/GL E-Class	167	Seats and Doors	DCU RR-Right rear door	√	√	√						
GLS/GL E-Class	167	Body	"Driver" seat heater	√	√	√	√					
GLS/GL E-Class	167	Body	"Front passenger" seat heater	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	Seat heater in left rear passenger compartment	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	S158/11 (Left 2nd seat row seats switch group)	√	√	√						
GLS/GL E-Class	167	Seats and Doors	S158/12 (Right 2nd seat row seats switch group)	√	√	√						
GLS/GL E-Class	167	Seats and Doors	S158/13 (Seats switch group (left load compartment))	√	√	√						
GLS/GL E-Class	167	Seats and Doors	S158/14 (Seats switch group (right load compartment))	√	√	√						
GLS/GL E-Class	167	Seats and Doors	Seat heater in right rear passenger compartment	√	√	√	√					
GLS/GL E-Class	167	Body	AS-Alarm siren(H3/1)	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	MFSF-LF	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	MFSF-RF	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	Massage function in left front seat	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	Massage function in right front seat	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	Massage function in left rear seat	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	Massage function in left rear seat	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	Massage function in right rear seat	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	Massage function in right rear seat	√	√	√	√					
GLS/GL E-Class	167	Air conditioning	N61 (Windshield heater control unit)	√	√	√						
GLS/GL E-Class	167	Air conditioning	AAC-Automatic air conditioning	√	√	√						
GLS/GL E-Class	167	Air conditioning	STH-Stationary heater	√	√	√	√					
GLS/GL E-Class	167	Air conditioning	AAC-Automatic air conditioning	√	√	√						

GLS/GL E-Class	167	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
GLS/GL E-Class	167	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√					
GLS/GL E-Class	167	Information and communication	ORBF-Off-road operating panel	√	√	√						
GLS/GL E-Class	167	Body	WSS-Weight sensing system(N110)	√	√	√	√					
GLS/GL E-Class	167	Body	N38 (Rear switching module)	√	√	√	√					
GLS/GL E-Class	167	Body	LIB-Lithium ion battery	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	S51/5 (Left 3rd seat row seat heating switch)	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	S51/6 (Right 3rd seat row seat heating switch)	√	√	√	√					
GLS/GL E-Class	167	Information and communication	SOUND-Sound system	√	√	√	√					
GLS/GL E-Class	167	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					
GLS/GL E-Class	167	Driver assistance system	DTR-DISTRONIC	√	√	√	√					
GLS/GL E-Class	167	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√					
GLS/GL E-Class	167	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√					
GLS/GL E-Class	167	Driver assistance system	PTS-PARKTRONIC	√	√	√	√					
GLS/GL E-Class	167	Chassis	AIRmatic	√	√	√	√					
GLS/GL E-Class	167	Chassis	AIRmatic	√	√	√	√					
GLS/GL E-Class	167	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√					
GLS/GL E-Class	167	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√					
GLS/GL E-Class	167	Chassis	ES - Electric power steering	√	√	√	√					
GLS/GL E-Class	167	Body	SCM-Steering column module	√	√	√	√					
GLS/GL E-Class	167	Drive	VG-Transfer case	√	√	√	√					
GLS/GL E-Class	167	Driver assistance system	NBR LF-Left front short range radar	√	√	√	√					
GLS/GL E-Class	167	Driver assistance system	NBR RF-Right front short range radar	√	√	√	√					
GLS/GL E-Class	167	Driver assistance system	NBR RR-Right rear short-range radar	√	√	√	√					

GLS/GL E-Class	167	Driver assistance system	NBR LR-Left rear short-range radar	√	√	√	√					
GLS/GL E-Class	167	Chassis	Left front suspension strut	√	√	√	√					
GLS/GL E-Class	167	Chassis	Left front suspension strut	√	√	√	√					
GLS/GL E-Class	167	Chassis	Right front suspension strut	√	√	√	√					
GLS/GL E-Class	167	Chassis	Right front suspension strut	√	√	√	√					
GLS/GL E-Class	167	Chassis	Left rear suspension strut	√	√	√	√					
GLS/GL E-Class	167	Chassis	Right rear suspension strut	√	√	√	√					
GLS/GL E-Class	167	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√				
GLS/GL E-Class	167	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√				
GLS/GL E-Class	167	Drive	FSCU-Fuel pump	√	√	√	√					
GLS/GL E-Class	167	Drive	SCR-Selective catalytic reduction	√	√	√	√					
GLS/GL E-Class	167	Drive	N127 (Drivetrain control unit)	√	√	√	√					
GLS/GL E-Class	167	Drive	N127 (Drivetrain control unit)	√	√	√	√					
GLS/GL E-Class	167	Drive	SG EM-Power electronics	√	√	√	√					
GLS/GL E-Class	167	Drive	ISG-Integrated starter alternator	√	√	√	√					
GLS/GL E-Class	167	Drive	ISG-Integrated starter alternator	√	√	√						
GLS/GL E-Class	167	Body	BMS-Battery management system	√	√	√	√					
GLS/GL E-Class	167	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
GLS/GL E-Class	167	Seats and Doors	DCU LR-Left rear door	√	√	√						
GLS/GL E-Class	167	Drive	N3/10-Motor electronics "MED1775" for combustion	√	√	√	√	√				
GLS/GL E-Class	167	Drive	N3/10-Motor electronics "MED40" for combustion engine	√	√	√	√	√				
GLS/GL E-Class	167	Drive	N3/10-Motor electronics "MED41" for combustion engine	√	√	√	√	√				
GLS/GL E-Class	167	Drive	N3/10-Motor electronics "MRG1" for combustion engine "M256"	√	√	√	√	√				

SLK/SLC 172-Class	172	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√	√	ACT0000,ACT0001,ACT0002,ACT0003,ACT0004,ACT0005,ACT0006,ACT0007,ACT0008,ACT0009,ACT0010,ACT0011,ACT0012,ACT0013,ACT0014,ACT0015,ACT0016,ACT0017,ACT0018,ACT0019,ACT0020,ACT0021,ACT0022,ACT0023,ACT0024,ACT0025,ACT0026	SP1000,SP1001,SP1002,SP1003,SP1004,SP1005,SP1006,SP1007,SP1008,SP1009,SP1010,SP1011,SP1012,SP1013,SP1014,SP1015,SP1016,SP1017,SP1018,SP1019,SP1020,SP1021,SP1022,SP1023,SP1024	CD0304, CD0305, CD0306, CD0307	√
SLK/SLC 172-	172	Information and communication	Left front short range radar	√	√	√	√					√
SLK/SLC 172-	172	Information and communication	Left front short range radar	√								√
SLK/SLC 172-	172	Information and communication	E call [Europe]-Emergency call system	√	√	√	√		ACT0044,ACT0045,ACT0046,ACT0047,ACT0048,ACT0049			
SLK/SLC 172-	172	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√
SLK/SLC 172-	172	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√
SLK/SLC 172-	172	Body	CGW-Central gateway	√	√	√	√			SP1366		√
SLK/SLC 172-	172	Information and communication	IC-Instrument cluster	√	√	√	√		ACT0050,ACT0051,ACT0052,ACT0053,ACT0054,ACT0055,ACT0057,ACT0058,ACT0059,ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065,	SP1047,SP1048		√
SLK/SLC 172-Class	172	Information and communication	KOMO-Communication module Telematics services	√	√	√	√		ACT0067,ACT0068,ACT0069,ACT0070,ACT0071,ACT0072,ACT0073,ACT0074	SP1049,SP1050		√
SLK/SLC 172-Class	172	Seats and Doors	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√		ACT0075,ACT0076,ACT0077,ACT0078			√
SLK/SLC 172-	172	Information and communication	TS-Telematic system(N123/4)	√	√	√	√					√
SLK/SLC 172-	172	Body	EZS-Electronic ignition switch	√	√	√	√			SP1051,SP1052,SP1053	CD0320, CD0321, CD0322, CD0323, CD0324	
SLK/SLC 172-	172	Body	EZS-Electronic ignition switch	√	√	√	√					
SLK/SLC 172-	172	Body	EZS-Electronic ignition lock	√	√	√	√				CD0325	
SLK/SLC 172-	172	Body	EZS-Electronic ignition lock (N73)	√	√	√	√					
SLK/SLC 172-	172	Body	EZS-Electronic ignition lock (N73)	√	√	√	√					
SLK/SLC 172-	172	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084			√
SLK/SLC 172-	172	Body	SCCM-Steering column module(N80)	√	√	√	√		ACT0841,ACT0842,ACT0843,ACT0844,ACT0845			√
SLK/SLC 172-	172	Body	MSC-MAGIC SKY CONTROL(N53)	√	√	√	√		ACT0846			√
SLK/SLC 172-	172	Chassis	ESP- Electric stability program	√	√	√	√	√	ACT0847,ACT0848,ACT0849,ACT0850	SP1367,SP1368,SP1369,SP1370,SP1371		√

SLK/SLC 172-	172	Information and communication	NAV-Navigation module(A2/30)	√	√	√	√		ACT0090,ACT0091,ACT0092,ACT0093			√
SLK/SLC 172-	172	Information and communication	Audio-Audio or COMAND	√	√	√	√					
SLK/SLC 172-	172	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
SLK/SLC 172-	172	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√			SP1288,SP1289,SP1290,SP1291		√
SLK/SLC 172-	172	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1292,SP1293,SP1294,SP1295,SP1296		√
SLK/SLC 172-	172	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1297,SP1293,SP1294,SP1296		√
SLK/SLC 172-	172	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0099,ACT0100	SP1056		√
SLK/SLC 172-	172	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√				√
SLK/SLC 172-Class	172	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√		ACT0101,ACT0102,ACT0103,ACT0104,ACT0105,ACT0106,ACT0107,ACT0108,ACT0109,ACT0110,ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,ACT0117,ACT0118,ACT0119,ACT0120,ACT0121,ACT0118,ACT0119,ACT0120,ACT0119,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0111,ACT0112,ACT0113,ACT0118,ACT0116,ACT0117,ACT0102,ACT0103,ACT0127,ACT0128,ACT0101,	SP1057,SP1058,SP1059,SP1060,SP1061		
SLK/SLC 172-	172	Information and communication	Audio-Audio or COMAND	√	√	√	√					
SLK/SLC 172-	172	Driver assistance system	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)	√	√	√	√		ACT0132	SP1062		√
SLK/SLC 172-	172	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					
SLK/SLC 172-	172	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					√
SLK/SLC 172-	172	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					
SLK/SLC 172-	172	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					√
SLK/SLC 172-	172	Information and communication	SG MSND-Engine sound	√	√	√	√		ACT0151,ACT0152,ACT0153,ACT0154,ACT0155			√
SLK/SLC 172-	172	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0156,ACT0157			√
SLK/SLC 172-	172	Body	KG-KEYLESS GO	√	√	√	√		ACT0851,ACT0852,ACT0853,ACT0854			

SLK/SL C 172-	172	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0855,ACT0856,ACT0156,ACT0157,ACT0857			√
SLK/SL C 172-Class	172	Information and communication	SOUND-Sound system	√	√	√	√		ACT0158,ACT0159,ACT0160,ACT0161,ACT0162,ACT0163,ACT0164,ACT0165,ACT0166,ACT0167,ACT0168,ACT0169,ACT0170,ACT0171,ACT0172,ACT0173,ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0179,ACT0180,ACT0181,		CD0348	
SLK/SL C 172-Class	172	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0199,ACT0186,ACT0187,ACT0189,ACT0191,ACT0192,ACT0200,ACT0195,ACT0196,ACT0201,ACT0202,ACT0194,ACT0203,ACT0204,ACT0205,ACT0197,ACT0206,ACT0198	SP1063		
SLK/SL C 172-	172	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√		ACT0207,ACT0208,ACT0209,ACT0210	SP1064		√
SLK/SL C 172-	172	Chassis	ADS-Adaptive damping system	√	√	√	√		ACT0858,ACT0859,ACT0860,ACT0861	SP1372		√
SLK/SL C 172-	172	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√		ACT0207,ACT0208,ACT0209,ACT0210	SP1064	CD0349	√
SLK/SL C 172-	172	Information and communication	ECS-N123/4 Emergency call system control unit	√	√	√	√		ACT0674,ACT0675,ACT0676			
SLK/SL C 172-Class	172	Information and communication	TV-TV tuner	√	√	√	√		ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0219,ACT0220,ACT0221,ACT0222,ACT0223		CD0350CD0351, CD0352, CD0353, CD0354, CD0355, CD0356, CD0357, CD0358, CD0359, CD0360, CD0361	
SLK/SL C 172-Class	172	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0677,ACT0233			
SLK/SL C 172-Class	172	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0230,ACT0231,ACT0232,ACT0233		CD0362CD0363, CD0364, CD0365, CD0366, CD0367, CD0368, CD0369, CD0370, CD0371, CD0372, CD0373	
SLK/SL C 172-	172	Driver assistance system	MFK-Multifunction camera	√	√	√	√		ACT0234,ACT0235	SP1066		√
SLK/SL C 172-	172	Driver assistance system	MFK-Multifunction camera(A40/11)	√	√	√	√		ACT0236,ACT0237	SP1067,SP1068		√
SLK/SL C 172-Class	172	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		ACT0238,ACT0678,ACT0862,ACT0251,ACT0863,ACT0253,ACT0864,ACT0254,ACT0696,	SP1069,SP1070,SP1071		√
SLK/SL C 172-	172	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√					
SLK/SL C 172-	172	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√					
SLK/SL C 172-	172	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258		CD0382	

SLK/SL C 172-	172	Information and communication	Drive Kit Plus-Drive kit for iPhone	√	√	√	√		ACT0263,ACT0264,ACT0265,ACT0266			
SLK/SL C 172-	172	Information and communication	NAVI20-Navigation(N125/2)	√	√	√	√		ACT0267,ACT0268			
SLK/SL C 172-	172	Chassis	EHPS-Electorhydraulic power sreeting	√	√	√	√					√
SLK/SL C 172-Class	172	Body	RevETR LF-Left front reversible emergency tensioning retractor (A76)	√	√	√	√					√
SLK/SL C 172-Class	172	Body	RevETR RF-Right front reversible emergency tensioning retractor(A76/1)	√	√	√	√		ACT0709			√
SLK/SL C 172-	172	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√		ACT0865,ACT0866,ACT0867,ACT0868,ACT0869,ACT0870	SP1373,SP1374,SP1375		√
SLK/SL C 172-	172	Information and communication	SDAR-Satellite radio	√	√	√	√		ACT0283,ACT0284,ACT0285,ACT0286		CD0387CD0388, CD0389, CD0389	
SLK/SL C 172-Class	172	Information and communication	TB5-TV tuner Tuner unit	√	√	√	√		ACT0287,ACT0288,ACT0289,ACT0290,ACT0291,ACT0292,ACT0293,ACT0294,			
SLK/SL C 172-	172	Information and communication	TV tuner (TV)	√	√	√	√		ACT0295,ACT0296,ACT0297,ACT0298,ACT0299,ACT0300,			
SLK/SL C 172-	172	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√		ACT0871,ACT0872,ACT0873,ACT0874,ACT0875	SP1376,SP1377,		√
SLK/SL C 172-	172	Information and communication	MIF-Media interface	√	√	√	√					
SLK/SL C 172-	172	Information and communication	MIF-Media interface	√	√	√	√		ACT0309			
SLK/SL C 172-Class	172	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√
SLK/SL C 172-Class	172	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√		ACT0884,ACT0885,ACT0886,ACT0887,ACT0888,ACT0889,ACT0890,ACT0891			√
SLK/SL C 172-Class	172	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√
SLK/SL C 172-	172	Drive	FSCU05-Control unit Fuel pump	√	√	√	√		ACT0385			√
SLK/SL C 172-	172	Drive	FSCU-Fuel pump	√	√	√	√		ACT0499			√

SLK/SLC 172-Class	172	Body	Rear SAM-Rear signal acquisition and actuation module	√	√	√	√	ACT0892,ACT0893,ACT0894,ACT0895,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0901,ACT0902,ACT0903,ACT0904,ACT0905,ACT0906,ACT0907,ACT0908,ACT0909,ACT0910,ACT0911,ACT0912,ACT0913,ACT0914,ACT0915,ACT0916,ACT0917,ACT0918,ACT0919,ACT0920,ACT0921,ACT0922,ACT0923,ACT0924,ACT0925,ACT0926,ACT0927,ACT0928,ACT0929,ACT0892,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0892,ACT0894,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0927,ACT0928,ACT0930,ACT0927,ACT0931,ACT0928,ACT0932,,ACT0933,ACT0934			√
SLK/SLC 172-Class	172	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√

SLK/SLC 172-Class	172	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√
SLK/SLC 172-	172	Information and communication	N123 / 4 (emergency call system control unit) - an emergency call	√	√	√	√				
SLK/SLC 172-	172	Driver assistance system	DTR-DISTRONIC	√	√	√	√				√
SLK/SLC 172-	172	Driver assistance system	DTR-DISTRONIC	√	√	√	√				√
SLK/SLC 172-	172	Driver assistance system	DTR-DISTRONIC (A89)	√	√	√	√		SP1084	CD0395	√
SLK/SLC 172-	172	Chassis	DTR-DISTRONIC (A89)	√	√	√	√		SP1084	CD0395	√
SLK/SLC 172-Class	172	Seats and Doors	LFD-Left front door	√	√	√	√	ACT0386,ACT0387,ACT0388,ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0398,ACT0994,ACT0397,ACT0400,ACT0401,ACT0402,ACT0403,			√
SLK/SLC 172-Class	172	Information and communication	N123 / 4 (emergency call system control unit) - Mercedes - Benz (MB) information / fault rescue	√	√	√	√				
SLK/SLC 172-Class	172	Seats and Doors	DCU RF-Right front door	√	√	√	√	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410,ACT0411,ACT0412,ACT0413,ACT0414,ACT0415,ACT0417,ACT0996,ACT0416,ACT0419,ACT0420,ACT0421,ACT0422,			√
SLK/SLC 172-Class	172	Information and communication	TV-TV tuner	√	√	√	√	ACT0424,ACT0425,ACT0426,ACT0427,ACT0222,ACT0428,ACT0219,ACT0221			

SLK/SLC 172-	172	Information and communication	TV-TV tuner	√	√	√	√		ACT0429,ACT0430,ACT0431,ACT0229,ACT0432,ACT0433,			
SLK/SLC 172-	172	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258			
SLK/SLC 172-Class	172	Information and communication	N123 / 4 (emergency call system control unit) - the vehicle remote control unlocking / locking the vehicle remote	√	√	√	√					
SLK/SLC 172-	172	Body	STC-Soft top control(N52)	√	√	√	√		ACT0999,ACT1000,ACT1001			√
SLK/SLC 172-	172	Information and communication	N123 / 4 (emergency call system control unit) - anti-theft tracking	√	√	√	√					
SLK/SLC 172-	172	Chassis	EFB-Electronic parking brake(N128)	√	√	√	√		ACT0435,ACT0436,ACT0437,ACT0438	SP1087		√
SLK/SLC 172-	172	Driver assistance system	RFK-Backup camera	√	√	√	√		ACT0439	SP1088,SP1089		√
SLK/SLC 172-	172	Body	AIRSCARF-Neck heating system(N25/7)	√	√	√	√					√
SLK/SLC 172-	172	Body	WSS-Weight sensing system(N110)	√	√	√	√					
SLK/SLC 172-	172	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
SLK/SLC 172-	172	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
SLK/SLC 172-	172	Body	BSN-Battery sensor(B95)	√	√	√	√					
SLK/SLC 172-	172	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0442,ACT0443,ACT0444,ACT0445,ACT0446			√
SLK/SLC 172-	172	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0447,ACT0448,ACT0449,ACT0450			√
SLK/SLC 172-	172	Body	SG SW-Control unit 'Headlamp'(N71/1)	√	√	√	√		ACT0451,ACT0452,ACT0453,ACT0454,ACT0455	SP1090,SP1091,SP1092,SP1093	CD0397	√
SLK/SLC 172-	172	Body	SG SW L-Left headlamp	√	√	√	√		ACT0456,ACT0457,ACT0458,ACT0459,ACT0460,ACT0461	SP1094,SP1095,SP1096,SP1097,SP1098,SP1099,	CD0398	√
SLK/SLC 172-Class	172	Body	SG SW L-Left headlamp(E1n9)	√	√	√	√		ACT0462,ACT0463,ACT0464,ACT0465,ACT0466,ACT0467	SP1101,SP1102,SP1103,SP1104,SP1105,SP1106,SP1107,SP1108	CD0399	√
SLK/SLC 172-	172	Body	SG SW R-Right headlamp	√	√	√	√		ACT0468,ACT0469,ACT0470,ACT0471,ACT0472,ACT0473	SP1109,SP1110,SP1111,SP1112,SP1113,SP1114	CD0400	√
SLK/SLC 172-	172	Body	SG SW R-Right headlamp(E1n9)	√	√	√	√		ACT0474,ACT0475,ACT0476,ACT0477,ACT0478,ACT0479	SP1115,SP1116,SP1117,SP1118,SP1119,SP1120	CD0401	√
SLK/SLC 172-	172	Drive	N15/5 (Electronic selector lever module control unit)	√	√	√	√		ACT1002,ACT1003,ACT1004			√
SLK/SLC 172-	172	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
SLK/SLC 172-	172	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
SLK/SLC 172-	172	Body	FSW-Windshield wiper	√	√	√	√		ACT1005,			

SLK/SLC 172-	172	Body	FSW-Windshield wiper	√	√	√	√		ACT1005,			
SLK/SLC 172-	172	Body	GTO-Garage door opener(A67n2)	√	√	√	√					
SLK/SLC 172-	172	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√					
SLK/SLC 172-	172	Body	OCP-Control unit 'Overhead control panel'	√	√	√	√					
SLK/SLC 172-	172	Driver assistance system	PTS-Parktronic system	√	√	√	√		ACT1006		CD0536, CD0537, CD0538, CD0539	√
SLK/SLC 172-	172	Body	Exterior lights switch	√	√	√	√					
SLK/SLC 172-	172	Body	UCP-Upper control panel	√	√	√	√					
SLK/SLC 172-	172	Body	AU-Analog clock	√	√	√						
SLK/SLC 172-	172	Information and communication	DSI-DIRECT SELECT interface(N150)	√	√	√	√		ACT0488			√
SLK/SLC 172-	172	Body	AS-Alarm siren(H3/1)	√	√	√			ACT1007			
SLK/SLC 172-	172	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT1007			
SLK/SLC 172-	172	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√		ACT1008,ACT1009			
SLK/SLC 172-	172	Driver assistance system	KAB-Control unit Camera cover	√	√	√	√		ACT0491,ACT0492			√
SLK/SLC 172-	172	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√		ACT0794,ACT0795	SP1325,SP1326,SP1327	CD0540	
SLK/SLC 172-	172	Body	AMLAB L 2-Actuation module 2, LED exterior lighting, left	√	√	√	√		ACT0796,ACT0797	SP1328,SP1329,SP1330	CD0541	
SLK/SLC 172-	172	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√		ACT0798,ACT0799	SP1331,SP1332	CD0542	
SLK/SLC 172-Class	172	Body	AMLAB R 2-Actuation module 2, LED exterior lighting, right front(E2n8)	√	√	√	√		ACT0800,ACT0801	SP1333,SP1334	CD0543	
SLK/SLC 172-Class	172	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√	ACT0584,ACT0585	SP1229,SP1230,SP1231,SP1232,SP1233,SP1234,SP1235,SP1236,SP1237,SP1237,SP1238,SP1239,SP1240,SP1241,SP1242,	CD0465, CD0466, CD0467, CD0468	√
SLK/SLC 172-Class	172	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7	√	√	√	√	√	ACT0586	SP1244,SP1245,SP1246,SP1247,SP1248,SP1249,SP1250,SP1250,SP1251,SP1252,SP1253,SP1254,	CD0469, CD0470, CD0471, CD0472, CD0473	√
SLK/SLC 172-Class	172	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√	ACT0587,ACT0588,ACT0589	SP1256,SP1257,SP1258,SP1259,SP1260,SP1261	CD0474, CD0475, CD0476, CD0477, CD0478	√
SLK/SLC 172-	172	Drive	FSCU-Fuel pump	√	√	√	√		ACT0498,ACT0499		CD0427, CD0428	√

SLK/SLC 172-	172	Drive	SCR-Selective catalytic reduction	√	√	√	√		ACT0600,ACT0601,ACT0602,ACT0603,ACT0604,ACT0605	SP1268,SP1269,SP1270,SP1271,SP1272,SP1273	CD0483, CD0484, CD0485	√
SLK/SLC 172-Class	172	Drive	N3/10-Motor electronics "MED177" for combustion engine "M276"	√	√	√	√	√	ACT0802,ACT0803,ACT0804,ACT0805,ACT0806,ACT0807,ACT0808,ACT0809,ACT0810,ACT0811,ACT0812,ACT0813,ACT0814,ACT0815,ACT0816,ACT0817,ACT0818,ACT0819,	SP1335,SP1336,SP1337,SP1338,SP1339,SP1340,SP1341,SP1342,SP1343,SP1344,SP1345,SP1346,SP1347,SP1348	CD0544, CD0545, CD0546, CD0547, CD0548, CD0549, CD0550, CD0551, CD0552	√
SLK/SLC 172-Class	172	Drive	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'	√	√	√	√	√	ACT1010,ACT1011,ACT1012,ACT1013,ACT1014,ACT1015,ACT1016,ACT1017,ACT1018,ACT1019,ACT1020,ACT1021,	SP1378,SP1379,SP1380,SP1381	CD0578, CD0579, CD0580, CD0581, CD0582, CD0583, CD0584, CD0585, CD0586	√
SLK/SLC 172-Class	172	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√	ACT0821,ACT0822,ACT0823,ACT0824,ACT0825,ACT0826,ACT0827,ACT0828,ACT0829,ACT0830,ACT0831,ACT0832,ACT0833,ACT0834,ACT0835,ACT0836,ACT0837,ACT0838,	SP1349,SP1350,SP1351,SP1352,SP1353,SP1354,SP1355,SP1356,SP1357,SP1358,SP1359,SP1360,SP1361,SP1362,SP1363,SP1364	CD0553, CD0554, CD0555, CD0556, CD0557, CD0558, CD0559, CD0560, CD0561	√
SLK/SLC 172-Class	172	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	√	√	√	√	√	ACT0508,ACT0509,ACT0510,ACT0511,ACT0512,ACT0513,ACT0514,ACT0515,ACT0516,ACT0517,ACT0518,ACT0519,ACT0520,ACT0521,ACT0522,ACT0523,ACT0524,ACT0525,	SP1133,SP1134,SP1135,SP1136,SP1137,SP1138,SP1139,SP1140,SP1141,SP1142,SP1143,SP1144,SP1145,SP1146,SP1147,SP1148	CD0435, CD0436, CD0437, CD0438, CD0439, CD0440, CD0441, CD0442, CD0443	√
SLK/SLC 172-Class	172	Drive	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"	√	√	√	√	√	ACT1023,ACT1024,ACT1025,ACT1026,ACT1027,ACT1028,ACT1029,ACT1030,ACT1031,ACT1032,ACT1033,ACT1034,ACT1035,ACT1036,ACT1037,ACT1038,ACT1039,ACT1040,	SP1382,SP1383,SP1384,SP1385,SP1386,SP1387,SP1388,SP1389	CD0587, CD0588, CD0589, CD0590, CD0591, CD0592, CD0593, CD0594, CD0595, CD0596	√
A-Class	176	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√	√	ACT0000,ACT0001,ACT0002,ACT0003,ACT0004,ACT0005,ACT0006,ACT0007,ACT0008,ACT0009,ACT0010,ACT0011,ACT0012,ACT0013,ACT0014,ACT0015,ACT0016,ACT0017,ACT0018,ACT0019,ACT0020,ACT0021,ACT0022,ACT0023,ACT0024,ACT0025,ACT0026	SP1000,SP1001,SP1002,SP1003,SP1004,SP1005,SP1006,SP1007,SP1008,SP1009,SP1010,SP1011,SP1012,SP1013,SP1014,SP1015,SP1016,SP1017,SP1018,SP1019,SP1020,SP1021,SP1022,SP1023,SP1024	CD0304, CD0305, CD0306, CD0307	√
A-Class	176	Drive	N3/3-Motor electronics "OM607" for combustion engine "CRR1"	√	√	√	√	√	ACT0029,ACT0030,ACT0031,ACT0032,ACT0033,ACT0034,ACT0035,ACT0036,ACT0037,ACT0038,ACT0039,ACT0040,ACT0041,ACT0042,ACT0043	SP1030,SP1031,SP1032,SP1033,SP1034,SP1035,SP1036,SP1037,SP1038,SP1039,SP1040,SP1041,SP1042,SP1043,SP1044,	CD0308, CD0309, CD0310	√
A-Class	176	Information and communication	E call [Europe]-Emergency call system	√	√	√	√		ACT0044,ACT0045,ACT0046,ACT0047,ACT0048,ACT0049			
A-Class	176	Information and communication	IC-Instrument cluster	√	√	√	√		ACT0050,ACT0051,ACT0052,ACT0053,ACT0054,ACT0055,	SP1047,SP1048		√

A-Class	176	Information and communication	KOMO-Communication module Telematics services	√	√	√	√		ACT0057,ACT0058,ACT0059,ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065,			√
A-Class	176	Seats and Doors	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√		ACT0067,ACT0068,ACT0069,ACT0070,ACT0071,ACT0072,ACT0073,ACT0074	SP1049,SP1050		
A-Class	176	Information and communication	TS-Telematic system(N123/4)	√	√	√	√		ACT0075,ACT0076,ACT0077,ACT0078			√
A-Class	176	Body	EZS-Electronic ignition switch	√	√	√	√			SP1051,SP1052,SP1053	CD0320, CD0321, CD0322, CD0323, CD0324	
A-Class	176	Body	EZS-Electronic ignition lock	√	√	√	√				CD0325	
A-Class	176	Body	EZS-Electronic ignition lock	√	√	√	√					
A-Class	176	Body	EZS-Electronic ignition lock	√	√	√	√					
A-Class	176	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084			√
A-Class	176	Chassis	AMG DRVU-AMG DRIVE UNIT(N145)	√	√	√	√		ACT0085,ACT0086,ACT0087			√
A-Class	176	Chassis	ESP-Electronic stability program(N30/4)	√	√	√	√	√	ACT0088,ACT0089	SP1054,SP1055		√
A-Class	176	Information and communication	NAV-Navigation module(A2/30)	√	√	√	√		ACT0090,ACT0091,ACT0092,ACT0093			√
A-Class	176	Information and communication	Audio-Audio or COMAND	√	√	√	√					
A-Class	176	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
A-Class	176	Body	IMS-Interior motion sensor	√	√	√	√		ACT0094,ACT0095,ACT0096			√
A-Class	176	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0099,ACT0100	SP1056		√
A-Class	176	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√				√
A-Class	176	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√		ACT0101,ACT0102,ACT0103,ACT0104,ACT0105,ACT0106,ACT0107,ACT0108,ACT0109,ACT0110,ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,ACT0117,ACT0118,ACT0119,ACT0120,ACT0121,ACT0118,ACT0119,ACT0120,ACT0119,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0111,ACT0112,ACT0113,ACT0118,ACT0116,ACT0117,ACT0102,ACT0103,ACT0127,ACT0128,ACT0101,	SP1057,SP1058,SP1059,SP1060,SP1061		
A-Class	176	Information and communication	Audio-Audio or COMAND	√	√	√	√					
A-Class	176	Information and communication	AUDIO-Audio(A2)	√	√	√	√		ACT1043,ACT1044,ACT1045,ACT1046,ACT1047,ACT1048,ACT1049,ACT1050,ACT1051,			√

A-Class	176	Driver assistance system	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)	√	√	√	√		ACT0132	SP1062		√
A-Class	176	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					
A-Class	176	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					√
A-Class	176	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					
A-Class	176	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					√
A-Class	176	Body	Multifunction control unit-Multifunction control unit	√	√	√	√		ACT0133,ACT0134,ACT0135,ACT0136,ACT0137,ACT0138,ACT0139,ACT0140,ACT0141,ACT0142,ACT0143,ACT0144,ACT0145,ACT0146,ACT0147,ACT0148,ACT0149,ACT0150,			√
A-Class	176	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0156,ACT0157			√
A-Class	176	Information and communication	SOUND-Sound system	√	√	√	√		ACT0158,ACT0159,ACT0160,ACT0161,ACT0162,ACT0163,ACT0164,ACT0165,ACT0166,ACT0167,ACT0168,ACT0169,ACT0170,ACT0171,ACT0172,ACT0173,ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0179,ACT0180,ACT0181,	CD0348		
A-Class	176	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0185,ACT0186,ACT0187,ACT0188,ACT0189,ACT0190,ACT0191,ACT0192,ACT0193,ACT0194,ACT0195,ACT0196,ACT0197,ACT0198,			
A-Class	176	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0199,ACT0186,ACT0187,ACT0189,ACT0191,ACT0192,ACT0200,ACT0195,ACT0196,ACT0201,ACT0202,ACT0194,ACT0203,ACT0204,ACT0205,ACT0197,ACT0206,ACT0198	SP1063		
A-Class	176	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√		ACT0207,ACT0208,ACT0209,ACT0210	SP1064	CD0349	√
A-Class	176	Information and communication	TV-TV tuner	√	√	√	√		ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0219,ACT0220,ACT0221,ACT0222,ACT0223		CD0350CD0351, CD0352, CD0353, CD0354, CD0355, CD0356, CD0357, CD0358, CD0359, CD0360, CD0361	
A-Class	176	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0230,ACT0231,ACT0232,ACT0233		CD0362CD0363, CD0364, CD0365, CD0366, CD0367, CD0368, CD0369, CD0370, CD0371, CD0372, CD0373	
A-Class	176	Driver assistance	MFK-Multifunction camera	√	√	√	√		ACT0234,ACT0235	SP1066		√

A-Class	176	Driver assistance	MFK-Multifunction	√	√	√	√		ACT0236,ACT0237	SP1067,SP1068		√
A-Class	176	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		ACT0238,ACT0239,ACT0240,ACT0241,ACT0242,ACT0243,ACT0244,ACT0245,ACT0246,ACT0247,ACT0248,ACT0249,ACT0250,ACT0251,ACT0252,	SP1069,SP1070,SP1071		√
A-Class	176	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√					
A-Class	176	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√					
A-Class	176	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258		CD0382	
A-Class	176	Air conditioning	STH-Stationary heater	√	√	√	√		ACT0259,ACT0260,ACT0261,ACT0262	SP1072		√
A-Class	176	Information and communication	Drive Kit Plus-Drive kit for iPhone	√	√	√	√		ACT0263,ACT0264,ACT0265,ACT0266			
A-Class	176	Information and communication	NAVI20-Navigation(N125/2)	√	√	√	√		ACT0267,ACT0268			
A-Class	176	Chassis	ES-Electrical power	√	√	√	√			SP1073,SP1074,SP1075		√
A-Class	176	Body	PSD-Control module 'Panoramic sliding roof '(A98)	√	√	√	√		ACT0269,ACT0270	SP1076		√
A-Class	176	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√		ACT0271			√
A-Class	176	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√		ACT0275			√
A-Class	176	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√		ACT0276,ACT0277,ACT0278,ACT0279,ACT0280,ACT0281,	SP1078,SP1079		√
A-Class	176	Information and communication	SDAR-Satellite radio	√	√	√	√		ACT0283,ACT0284,ACT0285,ACT0286		CD0387CD0388, CD0389, CD0389	
A-Class	176	Information and communication	TB5-TV tuner Tuner unit	√	√	√	√		ACT0287,ACT0288,ACT0289,ACT0290,ACT0291,ACT0292,ACT0293,ACT0294,			
A-Class	176	Information and communication	TV tuner (TV)	√	√	√	√		ACT0295,ACT0296,ACT0297,ACT0298,ACT0299,ACT0300,			
A-Class	176	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√		ACT0302,ACT0303,ACT0304,ACT0305,ACT0306,ACT0307,ACT0308	SP1080,SP1081		√
A-Class	176	Information and communication	MIF-Media interface	√	√	√	√					
A-Class	176	Information and communication	MIF-Media interface	√	√	√	√		ACT0309			
A-Class	176	Body	BSN-Battery sensor(B95)	√	√	√	√					
A-Class	176	Body	TRM-Trailer recognition module (N28/1)	√	√	√	√		ACT0310,ACT0311,ACT0312,ACT0313,ACT0314,ACT0315,ACT0316,ACT0317,ACT0318,ACT0319,ACT0320,ACT0321	SP1082,SP1083		√

A-Class	176	Body	Trailer recognition module- Trailer recognition	√	√	√	√		ACT0322,ACT0323,ACT0324, ACT0325,ACT0326,ACT0327, ACT0328,ACT0329,ACT0330, ACT0331,ACT0332,ACT0333,		CD0393	√
A-Class	176	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√		ACT0335,ACT0336,ACT0337, ACT0338,ACT0339,ACT0340, ACT0341,ACT0342,ACT0343, ACT0344,ACT0345,ACT0346, ACT0347,ACT0348,ACT0349, ACT0350,ACT0351,ACT0352, ACT0353,ACT0354,ACT0355, ACT0356,ACT0357,ACT0358, ACT0359,ACT0360,ACT0361, ACT0362,ACT0363,ACT0364, ACT0365,ACT0366,ACT0367, ACT0368,ACT0369,ACT0370, ACT0371,ACT0372,ACT0373, ACT0374,ACT0375,ACT0376, ACT0377,ACT0378,ACT0379,			√
A-Class	176	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√		ACT0335,ACT0336,ACT0337, ACT0338,ACT0339,ACT0340, ACT0341,ACT0342,ACT0343, ACT0344,ACT0345,ACT0346, ACT0347,ACT0348,ACT0349, ACT0350,ACT0351,ACT0352, ACT0353,ACT0354,ACT0355, ACT0356,ACT0357,ACT0358, ACT0359,ACT0360,ACT0361, ACT0362,ACT0363,ACT0364, ACT0365,ACT0366,ACT0367, ACT0368,ACT0369,ACT0370, ACT0371,ACT0372,ACT0373, ACT0374,ACT0375,ACT0376, ACT0377,ACT0378,ACT0379,			√
A-Class	176	Drive	FSCU05-Control unit Fuel pump	√	√	√	√		ACT0385			√
A-Class	176	Driver assistance	DTR-DISTRONIC (A89)	√	√	√	√			SP1084	CD0395	√
A-Class	176	Chassis	DTR-DISTRONIC (A89)	√	√	√	√			SP1084	CD0395	√
A-Class	176	Seats and Doors	LFD-Left front door	√	√	√	√		ACT0386,ACT0387,ACT0388, ACT0389,ACT0390,ACT0391, ACT0392,ACT0393,ACT0394, ACT0395,ACT0396,ACT0397, ACT0398,ACT0399,ACT0400, ACT0401,ACT0402,ACT0403,	SP1085		√
A-Class	176	Seats and Doors	DCU RF-Right front door	√	√	√	√		ACT0405,ACT0406,ACT0407, ACT0408,ACT0409,ACT0410, ACT0411,ACT0412,ACT0413, ACT0414,ACT0415,ACT0416, ACT0417,ACT0418,ACT0419, ACT0420,ACT0421,ACT0422,	SP1086		√

A-Class	176	Information and communication	TV-TV tuner	√	√	√	√		ACT0424,ACT0425,ACT0426,ACT0427,ACT0222,ACT0428,ACT0219,ACT0221			
A-Class	176	Information and communication	TV-TV tuner	√	√	√	√		ACT0429,ACT0430,ACT0431,ACT0229,ACT0432,ACT0433,			
A-Class	176	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258			
A-Class	176	Chassis	EFB-Electronic parking brake(N128)	√	√	√	√		ACT0435,ACT0436,ACT0437,ACT0438	SP1087		√
A-Class	176	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439,ACT0440	SP1088,SP1089		√
A-Class	176	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439	SP1088,SP1089		√
A-Class	176	Body	WSS-Weight sensing	√	√	√	√					
A-Class	176	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
A-Class	176	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
A-Class	176	Body	BSN-Battery sensor(B95)	√	√	√	√					
A-Class	176	Body	UCP-Upper control panel	√	√	√	√					
A-Class	176	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0442,ACT0443,ACT0444,ACT0445,ACT0446			√
A-Class	176	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0447,ACT0448,ACT0449,ACT0450			√
A-Class	176	Body	SG SW-Control unit 'Headlamp'(N71/1)	√	√	√	√		ACT0451,ACT0452,ACT0453,ACT0454,ACT0455	SP1090,SP1091,SP1092,SP1093	CD0397	√
A-Class	176	Body	SG SW L-Left headlamp	√	√	√	√		ACT0456,ACT0457,ACT0458,ACT0459,ACT0460,ACT0461	SP1094,SP1095,SP1096,SP1097,,SP1098,SP1099,	CD0398	√
A-Class	176	Body	SG SW L-Left headlamp(E1n9)	√	√	√	√		ACT0462,ACT0463,ACT0464,ACT0465,ACT0466,ACT0467	SP1101,SP1102,SP1103,SP1104,SP1105,SP1106,SP1107,SP1108	CD0399	√
A-Class	176	Body	SG SW R-Right headlamp	√	√	√	√		ACT0468,ACT0469,ACT0470,ACT0471,ACT0472,ACT0473	SP1109,SP1110,SP1111,SP1112,SP1113,SP1114	CD0400	√
A-Class	176	Body	SG SW R-Right headlamp(E1n9)	√	√	√	√		ACT0474,ACT0475,ACT0476,ACT0477,ACT0478,ACT0479	SP1115,SP1116,SP1117,SP1118,SP1119,SP1120	CD0401	√
A-Class	176	Body	GTO-Garage door	√	√	√	√					
A-Class	176	Body	OCP-Control unit 'Overhead control panel'	√	√	√	√		ACT0480,ACT0481,ACT0482,ACT0483			
A-Class	176	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√			SP1121		
A-Class	176	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√					
A-Class	176	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
A-Class	176	Driver assistance	PARK-Parking system (N62)	√	√	√	√		ACT0484,ACT0485		CD0411, CD0412	√
A-Class	176	Driver assistance system	PTS-Parktronic system	√	√	√	√		ACT1053		CD0536, CD0537, CD0538, CD0539	√
A-Class	176	Body	N32/2 (Front passenger seat control unit)	√			√		ACT0486			
A-Class	176	Body	N32/1 (Driver seat control unit)	√			√		ACT0487			
A-Class	176	Information and communication	DSI-DIRECT SELECT interface(N150)	√	√	√	√		ACT0488			√

A-Class	176	Drive	VG-All wheel drive	√	√	√	√		ACT0489	SP1122,SP1123,SP1124,SP1125		√
A-Class	176	Body	AS-Alarm siren(H3/1)	√	√	√			ACT0490			
A-Class	176	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT0490			
A-Class	176	Driver assistance	KAB-Control unit Camera cover	√	√	√	√		ACT0491,ACT0492			√
A-Class	176	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√					
A-Class	176	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√					
A-Class	176	Drive	DKG-Electronic transmission control for double-plate clutch	√	√	√	√	√	ACT0493,ACT0494,ACT0495,ACT0496,ACT0497	SP1126,SP1127,SP1128	CD0423, CD0424, CD0425, CD0426	√
A-Class	176	Drive	FSCU-Fuel pump	√	√	√	√		ACT0498,ACT0499		CD0427, CD0428	√
A-Class	176	Drive	N127 (Drivetrain control unit)	√	√	√	√		ACT0500,ACT0501	SP1129,SP1130,SP1131	CD0429, CD0430, CD043	√
A-Class	176	Drive	PTCU-Common powertrain controller(N127)	√	√	√	√		ACT0502,ACT0503,ACT0504,ACT0505,ACT0506,ACT0507	SP1132	CD0432, CD0433, CD0434	√
A-Class	176	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	√	√	√	√	√	ACT0508,ACT0509,ACT0510,ACT0511,ACT0512,ACT0513,ACT0514,ACT0515,ACT0516,ACT0517,ACT0518,ACT0519,ACT0520,ACT0521,ACT0522,ACT0523,ACT0524,ACT0525,	SP1133,SP1134,SP1135,SP1136,SP1137,SP1138,SP1139,SP1140,SP1141,SP1142,SP1143,SP1144,SP1145,SP1146,SP1147,SP1148	CD0435, CD0436, CD0437, CD0438, CD0439, CD0440, CD0441, CD0442, CD0443	√
A-Class	176	Drive	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"	√	√	√	√	√	ACT0528,ACT0529,ACT0530,ACT0531,ACT0532,ACT0533,ACT0534,ACT0535,ACT0536,ACT0537,ACT0538,ACT0539,	SP1149,SP1150,SP1151,SP1152,SP1153,SP1154,SP1155,SP1156	CD0444, CD0445, CD0446, CD0447, CD0448, CD0449, CD0450, CD0451, CD0452	√
A-Class	177	Drive	CDI-Engine Electronics CRR2 for Internal Combustion Engine	√	√	√	√	√				
A-Class	177	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√				
A-Class	177	Drive	N15/13 (Double clutch transmission control unit)	√	√	√	√					
A-Class	177	Drive	Y3/14n4 (Dual clutch transmission fully integrated transmission control unit)	√	√	√						
A-Class	177	Drive	Y3/14n4 (Dual clutch transmission fully integrated transmission control unit)	√	√	√						
A-Class	177	Seats and Doors	LFD-Left front door	√	√	√	√					
A-Class	177	Seats and Doors	DCU RF-Right front door	√	√	√	√					
A-Class	177	Seats and Doors	S47/2 (Driver door switch	√	√	√	√					
A-Class	177	Seats and Doors	LFD-Left front door	√	√	√						
A-Class	177	Seats and Doors	S22 (Driver's door seat adjustment switch)	√	√	√	√					
A-Class	177	Seats and Doors	LFD-Left front door	√	√	√						
A-Class	177	Seats and Doors	S51/1 (Driver seat climate control switch group)	√	√	√	√					
A-Class	177	Seats and Doors	LFD-Left front door	√	√	√						

A-Class	177	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	√				
A-Class	177	Seats and Doors	DCU RF-Right front door	√	√	√					
A-Class	177	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	√				
A-Class	177	Seats and Doors	DCU RF-Right front door	√	√	√					
A-Class	177	Seats and Doors	S51/2 (Front passenger seat climate control switch group)	√	√	√	√				
A-Class	177	Seats and Doors	DCU RF-Right front door	√	√	√					
A-Class	177	Seats and Doors	DCU LR-Left rear door	√	√	√	√				
A-Class	177	Seats and Doors	DCU RR-Right rear door	√	√	√	√				
A-Class	177	Body	SRS-Supplemental restraint	√	√	√	√	√			
A-Class	177	Information and communication	CTEL-Cellular telephone	√	√	√	√				
A-Class	177	Body	EZS-Electronic ignition switch	√	√	√	√				
A-Class	177	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√				
A-Class	177	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√				
A-Class	177	Information and communication	HERMES-control unit for telematics services	√	√	√	√				
A-Class	177	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√				
A-Class	177	Seats and Doors	MKS LF-Left front multicontour	√	√	√	√				
A-Class	177	Seats and Doors	MKS-FS-Pilot multi-profile seat	√	√	√	√				
A-Class	177	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√				
A-Class	177	Seats and Doors	MKS-BFS-Front passenger more copy the seat	√	√	√	√				
A-Class	177	Air conditioning	AAC-Automatic air conditioning	√	√	√	√				
A-Class	177	Body	ATA-Interior motion sensor	√	√	√	√				
A-Class	177	Body	Trailer recognition module-Trailer recognition	√	√	√	√				
A-Class	177	Body	Multifunction control unit-Multifunction control unit	√	√	√	√				
A-Class	177	Body	PSD-Panoramic sliding roof	√	√	√	√				
A-Class	177	Body	AML-Ambiance light	√	√	√	√				
A-Class	177	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√				
A-Class	177	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√				
A-Class	177	Body	LRE-Steering wheel electronics	√	√	√	√				
A-Class	177	Information and communication	TPAD-Touchpad	√	√	√	√				
A-Class	177	Information and communication	Audio-Audio or COMAND	√	√	√					
A-Class	177	Information and communication	ZAN-Audio/COMAND display	√	√	√	√				

A-Class	177	Body	HE-Hand detection	√	√	√	√					
A-Class	177	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
A-Class	177	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
A-Class	177	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
A-Class	177	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
A-Class	177	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
A-Class	177	Information and communication	IC-Instrument cluster	√	√	√	√			SP1047,SP1048,SP1157		
A-Class	177	Information and communication	HUD-Head up display	√	√	√	√					
A-Class	177	Driver assistance	RFK-Backup camera	√	√	√	√					
A-Class	177	Driver assistance	KAR-Augmented reality camera	√	√	√	√					
A-Class	177	Information and communication	CSM-Windshield reader system	√	√	√	√					
A-Class	177	Chassis	AMG DRVU-AMG DRIVE	√	√	√	√					
A-Class	177	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√					
A-Class	177	Body	SG SW L-Left headlamp	√	√	√	√					
A-Class	177	Body	SG SW R-Right headlamp	√	√	√	√					
A-Class	177	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√					
A-Class	177	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√					
A-Class	177	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√					
A-Class	177	Drive	SG LML VR-LED matrix of right front lamp unit	√	√	√	√					
A-Class	177	Driver assistance	TPM-Tire pressure monitor(N88)	√	√	√	√					
A-Class	177	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
A-Class	177	Body	DCCU-Direct current charge connection unit	√	√	√	√					
A-Class	177	Body	SG LG-Charger	√	√	√	√					
A-Class	177	Body	DC/DC-DC/DC converter	√	√	√	√					
A-Class	177	Body	GES-Hand motion sensor	√	√	√	√					
A-Class	177	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
A-Class	177	Body	BSN-Battery sensor(B95)	√	√	√	√					
A-Class	177	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
A-Class	177	Body	FSW-Windshield wiper	√	√	√	√					
A-Class	177	Body	GTO-Garage door	√	√	√	√					
A-Class	177	Body	OCP-Overhead control panel	√	√	√	√					

A-Class	177	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√					
A-Class	177	Body	"Front passenger" seat heater	√	√	√	√					
A-Class	177	Body	"Driver" seat heater	√	√	√	√					
A-Class	177	Body	AS-Alarm siren(H3/1)	√	√	√	√					
A-Class	177	Air conditioning	STH-Stationary heater	√	√	√	√					
A-Class	177	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
A-Class	177	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
A-Class	177	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√					
A-Class	177	Chassis	Lower control panel(DRVU)	√	√	√	√					
A-Class	177	Body	WSS-Weight sensing	√	√	√	√					
A-Class	177	Body	N38 (Rear switching module)	√	√	√	√					
A-Class	177	Information and communication	SOUND-Sound system	√	√	√	√					
A-Class	177	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					
A-Class	177	Driver assistance	DTR-DISTRONIC	√	√	√	√					
A-Class	177	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√					
A-Class	177	Driver assistance	SGR-Radar sensors control unit	√	√	√	√					
A-Class	177	Driver assistance	DTR-DISTRONIC	√	√	√	√					
A-Class	177	Driver assistance	PTS-PARKTRONIC	√	√	√	√					
A-Class	177	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√					
A-Class	177	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√					
A-Class	177	Chassis	ES - Electric power steering	√	√	√	√					
A-Class	177	Body	SCM-Steering column module	√	√	√	√					
A-Class	177	Drive	VG-All-wheel drive	√	√	√	√					
A-Class	177	Drive	VG-All-wheel drive	√	√	√	√					
A-Class	177	Drive	VG-All-wheel drive	√	√	√	√					
A-Class	177	Body	STM-Mirror taximeter	√	√	√	√					
A-Class	177	Driver assistance	NBR RR-Right rear short-range	√	√	√	√					
A-Class	177	Driver assistance	NBR LR-Left rear short-range	√	√	√	√					
A-Class	177	Chassis	ESP- Electric stability program	√	√	√	√	√				
A-Class	177	Chassis	ESP- Electric stability program	√	√	√	√	√				
A-Class	177	Drive	FSCU-Fuel pump	√	√	√	√					
A-Class	177	Drive	SCR-Selective catalytic reduction	√	√	√	√					
A-Class	177	Drive	N127 (Drivetrain control unit)	√	√	√	√					
A-Class	177	Drive	N127 (Drivetrain control unit)	√	√	√	√					
A-Class	177	Drive	SG EM-Power electronics	√	√	√	√					
A-Class	177	Drive	48V on board electrical system of ISG starter generator	√	√	√	√					
A-Class	177	Body	BMS-Battery management system	√	√	√	√					
A-Class	177	Body	LIB-Lithium ion battery	√	√	√	√					
A-Class	177	Body	LIB-Lithium ion battery	√	√	√	√					

A-Class	177	Drive	N3/10-Motor electronics "EM71" for combustion engine "M282"	√	√	√	√	√					
A-Class	177	Drive	N3/10-Motor electronics "MED41" for combustion engine	√	√	√	√	√					
A-Class	177	Drive	N3/10-Motor electronics "MRG1AMGR4" for combustion engine "M139"	√	√	√	√						
AMG GT-Class	190	Drive	N3/10-Motor electronics "MED1775" for combustion	√	√	√	√	√					
AMG GT-Class	190	Drive	DKG-Electronic transmission control for double-plate clutch	√	√	√	√	√	ACT0493,ACT0494,ACT0495,ACT0496,ACT0497	SP1126,SP1127,SP1128	CD0423, CD0424, CD0425, CD0426	√	
AMG GT-Class	190	Information and communication	E call [Europe]-Emergency call system	√	√	√	√		ACT0044,ACT0045,ACT0046,ACT0047,ACT0048,ACT0049				
AMG GT-Class	190	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√	
AMG GT-Class	190	Information and communication	CTEL-Cellular telephone	√	√	√	√						
AMG GT-Class	190	Information and communication	KOMO-Communication module Telematics services	√	√	√	√		ACT0057,ACT0058,ACT0059,ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065,			√	
AMG GT-Class	190	Seats and Doors	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√		ACT0067,ACT0068,ACT0069,ACT0070,ACT0071,ACT0072,ACT0073,ACT0074	SP1049,SP1050			
AMG GT-Class	190	Information and communication	TS-Telematic system(N123/4)	√	√	√	√		ACT0075,ACT0076,ACT0077,ACT0078			√	
AMG GT-Class	190	Body	EZS-Electronic ignition lock (N73)	√	√	√	√						
AMG GT-Class	190	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084			√	
AMG GT-Class	190	Chassis	N93/9-AMG gateway (AMG GW)	√	√	√	√						
AMG GT-Class	190	Chassis	N3/43-AMG chassis (AMG FW)	√	√	√							
AMG GT-Class	190	Body	LRE-Steering wheel electronics	√	√	√	√						
AMG GT-Class	190	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√					
AMG GT-Class	190	Information and communication	TPAD-Touchpad	√	√	√	√		ACT0615,ACT0616,ACT0617			√	
AMG GT-Class	190	Information and communication	TPAD-Touchpad	√	√	√	√						
AMG GT-Class	190	Information and communication	Audio-Audio or COMAND	√	√	√	√						
AMG GT-Class	190	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√						
AMG GT-Class	190	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√						
AMG GT-Class	190	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√						

AMG GT-Class	190	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441,ACT0627			√
AMG GT-Class	190	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
AMG GT-Class	190	Information and communication	IC-Instrument cluster(A1)	√	√	√	√					
AMG GT-Class	190	Drive	EAGGS-Electric differential lock	√	√	√	√					
AMG GT-Class	190	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√				√
AMG GT-Class	190	Drive	Active transmission mount	√	√	√	√					
AMG GT-Class	190	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√					
AMG GT-Class	190	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√					
AMG GT-Class	190	Driver assistance system	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)	√	√	√	√		ACT0132	SP1062		√
AMG GT-Class	190	Body	AMLA-Active engine mount	√	√	√	√					
AMG GT-Class	190	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					
AMG GT-Class	190	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					√
AMG GT-Class	190	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√					
AMG GT-Class	190	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					
AMG GT-Class	190	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					√
AMG GT-Class	190	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√					
AMG GT-Class	190	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
AMG GT-Class	190	Information and communication	LCP-R	√	√	√	√					
AMG GT-Class	190	Information and communication	LCP-L	√	√	√	√					
AMG GT-Class	190	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0156,ACT0157			√
AMG GT-Class	190	Chassis	ADS-Adaptive damping system	√	√	√	√		ACT0858,ACT0859,ACT0860,ACT0861			√
AMG GT-Class	190	Driver assistance system	MFK-Multifunction camera	√	√	√	√		ACT0234,ACT0235	SP1066		√
AMG GT-Class	190	Driver assistance system	MFK-Multifunction camera(A40/11)	√	√	√	√		ACT0236,ACT0237	SP1067,SP1068		√
AMG GT-Class	190	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					

AMG GT-Class	190	Body	RevETR LF-Left front reversible emergency tensioning retractor (A76)	√	√	√	√					√
AMG GT-Class	190	Body	RevETR LF-Left front reversible emergency tensioning retractor (A76)	√	√	√	√		ACT0708			√
AMG GT-Class	190	Body	LRE-Steering wheel electronics	√	√	√	√					
AMG GT-Class	190	Body	RevETR RF-Right front reversible emergency tensioning retractor(A76/1)	√	√	√	√		ACT0709			√
AMG GT-Class	190	Body	RevETR RF-Right front reversible emergency tensioning retractor(A76/1)	√	√	√	√		ACT0709			√
AMG GT-Class	190	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√		ACT0865,ACT0866,ACT0867,ACT0868,ACT0869,ACT0870	SP1373,SP1374,SP1375		√
AMG GT-Class	190	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√		ACT0871,ACT0872,ACT0873,ACT0874,ACT0875	SP1376,SP1377,		√
AMG GT-Class	190	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√
AMG GT-Class	190	Chassis	Rear wing	√	√	√	√					
AMG GT-Class	190	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√		ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√
AMG GT-Class	190	Driver assistance system	DTR-DISTRONIC (A89)	√	√	√	√			SP1084	CD0395	√

AMG GT-Class	190	Seats and Doors	LFD-Left front door	√	√	√	√	ACT0386,ACT0387,ACT0388,ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0398,ACT0994,ACT0397,ACT0400,ACT0401,ACT0402,ACT0403,			√
AMG GT-Class	190	Seats and Doors	DCU RF-Right front door	√	√	√	√	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410,ACT0411,ACT0412,ACT0413,ACT0414,ACT0415,ACT0417,ACT0996,ACT0416,ACT0419,ACT0420,ACT0421,ACT0422,			√
AMG GT-Class	190	Information and communication	TV-TV tuner	√	√	√	√	ACT0424,ACT0425,ACT0426,ACT0427,ACT0222,ACT0428,ACT0219,ACT0221			
AMG GT-Class	190	Information and communication	TV tuner (TV)	√	√	√	√				
AMG GT-Class	190	Information and communication	TV tuner (TV)	√	√	√	√				
AMG GT-Class	190	Information and communication	TV-TV tuner	√	√	√	√	ACT0429,ACT0430,ACT0431,ACT0229,ACT0432,ACT0433,			
AMG GT-Class	190	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	ACT0255,ACT0256,ACT0257,ACT0258			
AMG GT-Class	190	Body	STC-Soft top control(N52)	√	√	√	√	ACT1054,ACT1055,ACT1056,ACT1057			√
AMG GT-Class	190	Chassis	EFB-Electronic parking brake(N128)	√	√	√	√	ACT0435,ACT0436,ACT0437,ACT0438	SP1087		√
AMG GT-Class	190	Body	AIRSCARF-Neck heating system(N25/7)	√	√	√	√				√
AMG GT-Class	190	Body	WSS-Weight sensing system(N110)	√	√	√	√				
AMG GT-Class	190	Driver assistance system	PTS-PARKTRONIC	√	√	√	√				
AMG GT-Class	190	Body	SCCM-Steering column module(N80)	√	√	√	√				
AMG GT-Class	190	Body	BSN-Battery sensor(B95)	√	√	√	√				
AMG GT-Class	190	Body	BSN-Battery sensor(B95)	√	√	√	√				
AMG GT-Class	190	Body	LIB-Lithium ion battery	√	√	√	√				
AMG GT-Class	190	Body	SG SW L-Left headlamp	√	√	√	√	ACT0456,ACT0457,ACT0458,ACT0459,ACT0460,ACT0461	SP1094,SP1095,SP1096,SP1097,SP1098,SP1099,	CD0398	√
AMG GT-Class	190	Body	SG SW L-Left headlamp(E1n9)	√	√	√	√	ACT0462,ACT0463,ACT0464,ACT0465,ACT0466,ACT0467	SP1101,SP1102,SP1103,SP1104,SP1105,SP1106,SP1107,SP1108	CD0399	√
AMG GT-Class	190	Body	SG SW R-Right headlamp	√	√	√	√	ACT0468,ACT0469,ACT0470,ACT0471,ACT0472,ACT0473	SP1109,SP1110,SP1111,SP1112,SP1113,SP1114	CD0400	√

AMG GT-Class	190	Body	SG SW R-Right headlamp(E1n9)	√	√	√	√		ACT0474,ACT0475,ACT0476,ACT0477,ACT0478,ACT0479	SP1115,SP1116,SP1117,SP1118,SP1119,SP1120	CD0401	√
AMG GT-Class	190	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
AMG GT-Class	190	Body	FSW-Windshield wiper	√	√	√	√					
AMG GT-Class	190	Body	GTO-Garage door opener(A67n2)	√	√	√	√					
AMG GT-Class	190	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√					
AMG GT-Class	190	Driver assistance system	PTS-Parktronic system	√	√	√	√		ACT1053		CD0536, CD0537, CD0538, CD0539	√
AMG GT-Class	190	Body	UCP-Upper control panel	√	√	√	√					
AMG GT-Class	190	Information and communication	DSI-DIRECT SELECT interface(N150)	√	√	√	√		ACT0488			√
AMG GT-Class	190	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT1007			
AMG GT-Class	190	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√		ACT1008,ACT1009			
AMG GT-Class	190	Body	AMLAB L 2-Actuation module 2, LED exterior lighting, left	√	√	√	√		ACT0796,ACT0797	SP1328,SP1329,SP1330	CD0541	
AMG GT-Class	190	Body	AMLAB R 2-Actuation module 2, LED exterior lighting, right front(E2n8)	√	√	√	√		ACT0800,ACT0801	SP1333,SP1334	CD0543	
AMG GT-Class	190	Drive	FSCU-Fuel pump	√	√	√	√		ACT0498,ACT0499		CD0427, CD0428	√
AMG GT-Class	190	Drive	N127 (Drivetrain control unit)	√	√	√	√		ACT0500,ACT0501	SP1129,SP1130,SP1131	CD0429, CD0430, CD0431	√
SLS-Class	197	Drive	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"	√	√	√	√	√	ACT1058,ACT1059,ACT1060,ACT1061,ACT1062,ACT1063,ACT1064,ACT1065,ACT1066,ACT1067,ACT1068,ACT1069,ACT1070,ACT1071,ACT1072,ACT1073,ACT1074,ACT1075,	SP1390,SP1391,SP1392,SP1393,SP1394,SP1395	CD0601, CD0602, CD0603, CD0604, CD0605, CD0606, CD0607, CD0608	√
SLS-Class	197	Body	BMS-H-Battery management system, rear (master)	√	√	√	√		ACT1077,ACT1078,ACT1079	SP1396,SP1397,SP1398,SP1399		√
SLS-	197	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√
SLS-	197	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√
SLS-	197	Body	CGW-Central gateway	√	√	√	√			SP1366		√
SLS-Class	197	Information and communication	IC-Instrument cluster(A1)	√	√	√	√		ACT1080,ACT1081,ACT1082,ACT1083,ACT1084,ACT1085,	SP1400,SP1401		√
SLS-	197	Body	EZS-Electronic ignition switch	√	√	√	√					
SLS-Class	197	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084			√
SLS-Class	197	Body	SCM [MRM]-Steering column module	√	√	√	√		ACT1087,ACT1088			√
SLS-Class	197	Chassis	AMG DRVU-AMG DRIVE UNIT(N145)	√	√	√	√		ACT0085,ACT0086,ACT0087			√

SLS-Class	197	Information and communication	AMG PM-AMG Performance Media(N125/2)	√	√	√	√		ACT1089			√
SLS-Class	197	Chassis	ESP-Electronic stability program(N30/4)	√	√	√	√		ACT1090,ACT0088,ACT1091	SP1402,SP1403,SP1404,SP1405		√
SLS-	197	Chassis	ESP-Electric stability	√	√	√	√			SP1406		√
SLS-Class	197	Drive	ELM-VL-Front left electrical machine	√	√	√	√		ACT1092,ACT1093,ACT1094,ACT1095,ACT1096,ACT1097,ACT1098,ACT1099,ACT1100,	SP1407,SP1408		√
SLS-Class	197	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0100,ACT0099	SP1056,SP1409		√
SLS-	197	Body	SRS-Supplemental restraint	√	√	√	√	√				√
SLS-Class	197	Information and communication	Audio-Audio or COMAND	√	√	√			ACT1102,ACT1103,ACT1104,ACT1105,ACT1106,ACT1107,ACT1108,ACT1109,ACT1110,ACT1111,ACT1112,ACT1113,ACT1114,ACT1115,ACT1116,ACT1117,ACT1118,ACT1119,ACT1120,ACT1121,ACT1112,ACT1113,ACT1114,ACT1115,ACT1117,ACT1118,ACT1122,ACT1123,ACT1124,ACT1103,ACT1104,ACT1125,ACT1126,ACT1102,ACT1105,ACT1106,ACT1107,ACT1110,ACT1119,	SP1410,SP1411,SP1412	CD0619, CD0620, CD0621, CD0622, CD0623, CD0624, CD0625, CD0626, CD0627, CD0628, CD0629, CD0630, CD0631	
SLS-Class	197	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					
SLS-Class	197	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					√
SLS-Class	197	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					
SLS-Class	197	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					√
SLS-Class	197	Body	KG-KEYLESS GO	√	√	√	√		ACT0851,ACT0852,ACT0853,ACT0854			
SLS-Class	197	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0855,ACT0856,ACT0156,ACT0157,ACT0857			√
SLS-Class	197	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0199,ACT0186,ACT0187,ACT0189,ACT0191,ACT0192,ACT0200,ACT0195,ACT0196,ACT0201,ACT0202,ACT0194,ACT0203,ACT0204,ACT0205,ACT0197,ACT0206,ACT0198	SP1063		
SLS-Class	197	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0199,ACT0653,ACT0185,ACT0186,ACT0654,ACT0655,ACT0195,ACT0196,ACT0193,ACT0200,ACT0194,ACT0188,ACT0190,ACT0191,ACT0192,ACT0656,ACT0657,ACT0206,			
SLS-	197	Body	DDW-DC/DC converter(N83/1)	√	√	√	√					√

SLS-Class	197	Chassis	ADS-Adaptive damping system	√	√	√	√		ACT0858,ACT0859,ACT0860,ACT0861			√
SLS-Class	197	Information and communication	ECS-N123/4 Emergency call system control unit	√	√	√	√		ACT0674,ACT0675,ACT0676			
SLS-Class	197	Drive	ELM-VR-Front right electrical machine	√	√	√	√		ACT1130,ACT1131,ACT1132,ACT1133,ACT1134,ACT1135,ACT1136,ACT1137,ACT1138,	SP1413		√
SLS-Class	197	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		ACT0238,ACT0678,ACT0862,ACT0253,ACT0254,ACT1140,ACT0251,ACT0695,ACT0697,ACT0696,ACT1141	SP1069,SP1070,SP1071		√
SLS-Class	197	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√					
SLS-Class	197	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√					
SLS-Class	197	Chassis	EHPS-Electorhydraulic power sreeting	√	√	√	√					√
SLS-Class	197	Drive	ELM-HL-Rear left electrical machine	√	√	√	√		ACT1142,ACT1143,ACT1144,ACT1145,ACT1146,ACT1147,ACT1148,ACT1149,ACT1150,	SP1414		√
SLS-	197	Body	WSS-Weight sensing	√	√	√	√					
SLS-Class	197	Drive	ELM-HR-Rear right electrical machine	√	√	√	√		ACT1152,ACT1153,ACT1154,ACT1155,ACT1156,ACT1157,ACT1158,ACT1159,ACT1160,	SP1415,SP1416		√
SLS-Class	197	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√		ACT0865,ACT0866,ACT0867,ACT0868,ACT0869,ACT0870	SP1373,SP1374,SP1375		√
SLS-Class	197	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√		ACT0865,ACT0866,ACT0867,ACT0868,ACT0869,ACT0870	SP1373,SP1374,SP1375		√
SLS-Class	197	Information and communication	SDAR-Satellite radio	√	√	√	√		ACT0283,ACT0284,ACT0285,ACT0286		CD0387CD0388, CD0389, CD0389	
SLS-Class	197	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√		ACT0871,ACT0872,ACT0873,ACT0874,ACT0875	SP1376,SP1377,		√
SLS-Class	197	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√		ACT0871,ACT0872,ACT0873,ACT0874,ACT0875	SP1376,SP1377,		√
SLS-Class	197	Information and communication	MIF-Media interface	√	√	√	√					
SLS-Class	197	Information and communication	MIF-Media interface	√	√	√	√		ACT0309			
SLS-Class	197	Drive	ISM-Shift module	√	√	√	√		ACT0717,ACT0718,ACT0719,ACT0720,ACT0721	SP1312,SP1313,SP1314		√
SLS-Class	197	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√
SLS-Class	197	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√		ACT0884,ACT0885,ACT0886,ACT0887,ACT0888,ACT0889,ACT0890,ACT0891			√
SLS-Class	197	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√

SLS-Class	197	Body	SG LG-Charger	√	√	√	√		ACT1162,ACT1163		CD0633, CD0634, CD0635, CD0636, CD0637	√
SLS-	197	Drive	FSCU-Fuel pump	√	√	√	√		ACT0499			√
SLS-Class	197	Body	Rear SAM-Rear signal acquisition and actuation module	√	√	√	√		ACT0892,ACT0893,ACT0894,ACT0895,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0901,ACT0902,ACT0903,ACT0904,ACT0905,ACT0906,ACT0907,ACT0908,ACT0909,ACT0910,ACT0911,ACT0912,ACT0913,ACT0914,ACT0915,ACT0916,ACT0917,ACT0918,ACT0919,ACT0920,ACT0921,ACT0922,ACT0923,ACT0924,ACT0925,ACT0926,ACT0927,ACT0928,ACT0929,ACT0892,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0892,ACT0894,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0927,ACT0928,ACT0930,ACT0927,ACT0931,ACT0928,ACT0932,,ACT0933,ACT0934			√
SLS-Class	197	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√		ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√

SLS-Class	197	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√
SLS-Class	197	Information and communication	N123 / 4 (emergency call system control unit) - an emergency call	√	√	√	√				
SLS-Class	197	Information and communication	KOMO-Communication module Telematics services	√	√	√	√	ACT0061,ACT0060,ACT0058			√
SLS-Class	197	Seats and Doors	LFD-Left front door	√	√	√	√	ACT0386,ACT0387,ACT0388,ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0398,ACT0994,ACT0397,ACT0400,ACT0401,ACT0402,ACT0403,			√
SLS-Class	197	Information and communication	N123 / 4 (emergency call system control unit) - Mercedes - Benz (MB) information / fault rescue	√	√	√	√				
SLS-Class	197	Drive	PTCU-MA-Drivetrain (master)	√	√	√	√	ACT1164,ACT1165,ACT1166,ACT1167,ACT1168,ACT1169,ACT1170,ACT1171,ACT1172,ACT1173,ACT1174	SP1417,SP1418,SP1419,SP1420		√
SLS-Class	197	Seats and Doors	DCU RF-Right front door	√	√	√	√	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410,ACT0411,ACT0412,ACT0413,ACT0414,ACT0415,ACT0417,ACT0996,ACT0416,ACT0419,ACT0420,ACT0421,ACT0422,			√
SLS-	197	Drive	PTCU-SL-Drivetrain (slave)	√	√	√	√	ACT1175			√
SLS-Class	197	Information and communication	N123 / 4 (emergency call system control unit) - the vehicle remote control unlocking / locking the vehicle remote	√	√	√	√				

SLS-Class	197	Body	STC-Soft top control(N52)	√	√	√	√		ACT1054,ACT1055,ACT1056,ACT1057			√
SLS-Class	197	Information and communication	N123 / 4 (emergency call system control unit) - anti-theft tracking	√	√	√	√					
SLS-	197	Chassis	EFB-Electric parking brake	√	√	√	√		ACT1176,ACT1177	SP1421		√
SLS-Class	197	Chassis	EFB-Electronic parking brake(N128)	√	√	√	√		ACT0435,ACT0436,ACT0437,ACT0438	SP1087		√
SLS-Class	197	Body	AIRSCARF-Neck heating system(N25/7)	√	√	√	√					√
SLS-Class	197	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
SLS-	197	Body	BSN-Battery sensor(B95)	√	√	√	√					
SLS-	197	Body	BSN-Battery sensor(B95)	√	√	√	√					
SLS-	197	Body	LIB-Lithium ion battery	√	√	√	√					
SLS-Class	197	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0442,ACT0443,ACT0444,ACT0445,ACT0446			√
SLS-Class	197	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
SLS-Class	197	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
SLS-	197	Body	FSW-Windshield wiper	√	√	√	√					
SLS-	197	Body	FSW-Windshield wiper	√	√	√	√		ACT1005,			
SLS-	197	Body	FSW-Windshield wiper	√	√	√	√		ACT1005,			
SLS-	197	Body	GTO-Garage door	√	√	√	√					
SLS-	197	Body	GTO-Garage door	√	√	√	√					
SLS-	197	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√					
SLS-Class	197	Driver assistance system	PTS-Parktronic system	√	√	√	√		ACT1006		CD0536, CD0537, CD0538, CD0539	√
SLS-	197	Body	Exterior lights switch	√	√	√	√					
SLS-	197	Body	UCP-Upper control panel	√	√	√	√					
SLS-Class	197	Information and communication	DSI-DIRECT SELECT interface(N150)	√	√	√	√		ACT0488			√
SLS-Class	197	Body	CSHVB-Crash sensor high-voltage battery	√	√	√	√					
SLS-	197	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT1007			
SLS-Class	197	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√		ACT1008,ACT1009			
SLS-Class	197	Drive	DKG-Electronic transmission control for double-plate clutch	√	√	√	√	√	ACT0493,ACT0494,ACT0495,ACT0496,ACT0497	SP1126,SP1127,SP1128	CD0423, CD0424, CD0425, CD0426	√
SLS-Class	197	Body	BMS-V-Battery management system, front (slave)	√	√	√	√		ACT1178,ACT1179,ACT1180	SP1422,SP1423,SP1424,SP1425		√
SLS-Class	197	Body	BMS-M-Battery management system, center (master)	√	√	√	√		ACT1181,ACT1182,ACT1183,ACT1184,ACT1185,ACT1186	SP1426,SP1427,SP1428,SP1429,SP1430,SP1431		√

C/GLK-Class	204	Drive	N3/9-Motor electronics "CR42" for combustion engine "OM651"	√	√	√	√	√	ACT1187,ACT1188,ACT1189,ACT1190,ACT1191,ACT1192,ACT1193,ACT1194,ACT1195,ACT1196,ACT1197,ACT1198,ACT1199,ACT1200,ACT1201,ACT1202,ACT1203,ACT1204,	SP1432,SP1433,SP1434,SP1435,SP1436,SP1437,SP1438,SP1439,SP1440,SP1441,SP1442,SP1443,SP1444,SP1445,SP1446,SP1447,SP1448,SP1449,	CD0648, CD0649, CD0650	√
C/GLK-Class	204	Drive	N3/9-Motor electronics "CDI6" for combustion engine "OM642"	√	√	√	√	√	ACT1207,ACT1208,ACT1209,ACT1210,ACT1211,ACT1212,ACT1213,ACT1214,ACT1215	SP1454,SP1455,SP1456,SP1457,SP1458,SP1459,SP1460,SP1461,SP1462,SP1463,SP1464,SP1465	CD0651, CD0652, CD0653	√
C/GLK-Class	204	Drive	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"	√	√	√	√	√	ACT0559,ACT0560,ACT0561,ACT0562,ACT0563,ACT0564,ACT0565,ACT0566,ACT0567,ACT0568,ACT0569,ACT0570,	SP1187,SP1188,SP1189,SP1190,SP1191,SP1192,SP1193,SP1194,SP1195,SP1196,SP1197,SP1198,SP1199,SP1200,SP1201,SP1202,SP1203,SP1204,	CD0457, CD0458, CD0459, CD0460	√
C/GLK-Class	204	Drive	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"	√	√	√	√	√	ACT1216,ACT1217,ACT1218,ACT1219,ACT1220,ACT1221,ACT1222,ACT1223,ACT1224,ACT1225,ACT1226	SP1466,SP1467,SP1468,SP1469,SP1470,SP1471,SP1472,SP1473,SP1474,SP1475,SP1476,SP1477,	CD0654, CD0655, CD0656	√
C/GLK-Class	204	Drive	N3/9-Motor electronics "CDI" for combustion engine "OM646"	√	√	√	√	√	ACT1227,ACT1228,ACT1229,ACT1230,ACT1231,ACT1232,ACT1233,ACT1234,ACT1235,ACT1236,ACT1237,ACT1238,ACT1239,ACT1240,ACT1241,ACT1242,ACT1243,ACT1244	SP1479,SP1480,SP1481,SP1482,SP1483,SP1484,SP1485,SP1486,SP1487,SP1488,SP1489	CD0657, CD0658	√
C/GLK-Class	204	Drive	N3/9-Motor electronics "CDID2" for combustion engine "OM651"	√	√	√	√	√	ACT1245,ACT1246,ACT1247,ACT1248,ACT1249,ACT1250,ACT1251,ACT1252,ACT1253,ACT1254,ACT1255,ACT1256,ACT1257,ACT1258,ACT1259,ACT1260,ACT1261,ACT1262,ACT1263,ACT1264,ACT1265,		CD0659, CD0660, CD0661, CD0662	√
C/GLK-Class	204	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√	√	ACT0000,ACT0001,ACT0002,ACT0003,ACT0004,ACT0005,ACT0006,ACT0007,ACT0008,ACT0009,ACT0010,ACT0011,ACT0012,ACT0013,ACT0014,ACT0015,ACT0016,ACT0017,ACT0018,ACT0019,ACT0020,ACT0021,,ACT0022,ACT0023,ACT0024,ACT0025,ACT0026	SP1000,SP1001,SP1002,SP1003,SP1004,SP1005,SP1006,SP1007,SP1008,SP1009,SP1010,SP1011,SP1012,SP1013,SP1014,SP1015,SP1016,SP1017,SP1018,SP1019,SP1020,SP1021,SP1022,SP1023,SP1024	CD0304, CD0305, CD0306, CD0307	√
C/GLK-Class	204	Information and communication	Left front short range radar	√	√	√	√					√
C/GLK-Class	204	Information and communication	Left front short range radar	√								√
C/GLK-Class	204	Information and communication	AVE H-Rear audio video unit	√	√	√	√		ACT0610,ACT0611,ACT0612,ACT0613,ACT0614		CD0490, CD0491, CD0492, CD0493, CD0494	√

C/GLK-Class	204	Drive	SG SOGE AGA-Sound generator for exhaust system	√	√	√	√		ACT1267,ACT1268			√
C/GLK-Class	204	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√
C/GLK-Class	204	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√
C/GLK-Class	204	Body	CGW-Central gateway	√	√	√	√			SP1366		√
C/GLK-Class	204	Information and communication	IC-Instrument cluster	√	√	√	√		ACT0050,ACT0051,ACT0052,ACT0053,ACT0054,ACT0055,	SP1047,SP1048		√
C/GLK-Class	204	Information and communication	KOMO-Communication module Telematics services	√	√	√	√		ACT0057,ACT0058,ACT0059,ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065,			√
C/GLK-Class	204	Information and communication	TS-Telematic system(N123/4)	√	√	√	√		ACT0075,ACT0076,ACT0077,ACT0078			√
C/GLK-Class	204	Body	EZS-Electronic ignition lock	√	√	√	√			SP1490,SP1491,SP1492		
C/GLK-Class	204	Body	EZS-Electronic ignition switch	√	√	√	√					
C/GLK-Class	204	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084			√
C/GLK-Class	204	Body	SCM [MRM]-Steering column module	√	√	√	√		ACT1087,ACT1088			√
C/GLK-Class	204	Body	SCCM-Steering column module(N80)	√	√	√	√		ACT0841,ACT0842,ACT0843,ACT0844,ACT0845			√
C/GLK-Class	204	Chassis	AMG DRVU-AMG DRIVE UNIT(N145)	√	√	√	√		ACT0085,ACT0086,ACT0087			√
C/GLK-Class	204	Information and communication	AMG PM-AMG Performance Media(N125/2)	√	√	√	√		ACT1089			√
C/GLK-Class	204	Chassis	ESP- Electric stability program	√	√	√	√	√	ACT0847,ACT0848,ACT0849,ACT0850	SP1367,SP1368,SP1369,SP1370,SP1371		√
C/GLK-Class	204	Chassis	ESP- Electric stability program	√	√	√	√	√	ACT0847,ACT0848,ACT1269,ACT0849,ACT0850	SP1493,SP1368		√
C/GLK-Class	204	Chassis	ESP- Electric stability program	√	√	√	√	√	ACT0847,ACT0848,ACT0849,ACT0850	SP1494,SP1367,SP1368,SP1369,SP1370		√
C/GLK-Class	204	Chassis	ESP-Regenerative braking system(N30/6)	√	√	√	√	√	ACT0624,ACT0625,ACT0626	SP1282,SP1283,SP1284,SP1285,SP1286,SP1287	CD0499, CD0500, CD0501, CD0502	√
C/GLK-Class	204	Information and communication	NAV-Navigation module(A2/30)	√	√	√	√		ACT0090,ACT0091,ACT0092,ACT0093			√
C/GLK-Class	204	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√			SP1288,SP1289,SP1290,SP1291		√
C/GLK-Class	204	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1292,SP1293,SP1294,SP1295,SP1296		√
C/GLK-Class	204	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1297,SP1293,SP1294,SP1296		√
C/GLK-Class	204	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0100,ACT0099	SP1056,SP1409		√
C/GLK-Class	204	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0100,ACT0099	SP1056		√

C/GLK-Class	204	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√				√
C/GLK-Class	204	Body	SRS-Supplemental restraint system	√	√	√	√	√				√
C/GLK-Class	204	Body	SRS-Supplemental restraint system	√	√	√	√	√				√
C/GLK-Class	204	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√		ACT0101,ACT0102,ACT0103,ACT0104,ACT0105,ACT0106,ACT0107,ACT0108,ACT0109,ACT0110,ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,ACT0117,ACT0118,ACT0119,ACT0120,ACT0121,ACT0118,ACT0119,ACT0120,ACT0119,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0111,ACT0112,ACT0113,ACT0118,ACT0116,ACT0117,ACT0102,ACT0103,ACT0127,ACT0128,ACT0101,	SP1057,SP1058,SP1059,SP1060,SP1061		
C/GLK-Class	204	Information and communication	Audio-Audio or COMAND	√	√	√			ACT1102,ACT1103,ACT1104,ACT1105,ACT1106,ACT1107,ACT1108,ACT1109,ACT1110,ACT1111,ACT1112,ACT1113,ACT1114,ACT1115,ACT1116,ACT1117,ACT1118,ACT1119,ACT1120,ACT1121,ACT1112,ACT1113,ACT1114,ACT1115,ACT1117,ACT1118,ACT1122,ACT1123,ACT1124,ACT1103,ACT1104,ACT1125,ACT1126,ACT1102,ACT1105,ACT1106,ACT1107,ACT1110,ACT1119,	SP1410,SP1411,SP1412	CD0619, CD0620, CD0621, CD0622, CD0623, CD0624, CD0625, CD0626, CD0627, CD0628, CD0629, CD0630, CD0631	
C/GLK-Class	204	Driver assistance system	CAMERA-360 camera(N148)	√	√	√	√		ACT0542			√
C/GLK-Class	204	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					
C/GLK-Class	204	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					√
C/GLK-Class	204	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					
C/GLK-Class	204	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					√
C/GLK-Class	204	Body	Multifunction control unit-Multifunction control unit	√	√	√	√		ACT0133,ACT0134,ACT0135,ACT0136,ACT0137,ACT0138,ACT0139,ACT0140,ACT0141,ACT0142,ACT0143,ACT0144,ACT0145,ACT0146,ACT0147,ACT0148,ACT0149,ACT0150,			√

C/GLK-Class	204	Body	Multifunction control unit- Multifunction control unit	√	√	√	√		ACT1270,ACT0137,ACT0139, ACT0148,ACT1271,ACT0142, ACT0147,ACT0145			√
C/GLK-Class	204	Body	KG-KEYLESS GO	√	√	√	√		ACT0851,ACT0852,ACT0853, ACT0854			
C/GLK-Class	204	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0855,ACT0856,ACT0156, ACT0157,ACT0857			√
C/GLK-Class	204	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0199,ACT0186,ACT0187, ACT0189,ACT0191,ACT0192, ACT0200,ACT0195,ACT0196, ACT0201,ACT0202,ACT0194, ACT0203,ACT0204,ACT0205, ACT0197,ACT0206,ACT0198	SP1063		
C/GLK-Class	204	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√		ACT0207,ACT0208,ACT0209, ACT0210	SP1064		√
C/GLK-Class	204	Chassis	ADS-Adaptive damping system	√	√	√	√		ACT0858,ACT0859,ACT0860, ACT0861	SP1372		√
C/GLK-Class	204	Body	TLC-Trunk lid control	√	√	√	√		ACT1272,ACT1273,ACT1274, ACT1275,ACT1276	SP1495,SP1496		√
C/GLK-Class	204	Information and communication	ECS-N123/4 Emergency call system control unit	√	√	√	√		ACT0674,ACT0675,ACT0676			
C/GLK-Class	204	Driver assistance system	PTS-PARKTRONIC	√	√	√	√		ACT1277			√
C/GLK-Class	204	Information and communication	TV-TV tuner	√	√	√	√		ACT0214,ACT0215,ACT0216, ACT0217,ACT0218,ACT0219, ACT0220,ACT0221,ACT0222, ACT0223		CD0350CD0351, CD0352, CD0353, CD0354, CD0355, CD0356, CD0357, CD0358, CD0359, CD0360, CD0361	
C/GLK-Class	204	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226, ACT0227,ACT0228,ACT0229, ACT0677,ACT0233			
C/GLK-Class	204	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226, ACT0227,ACT0228,ACT0229, ACT0230,ACT0231,ACT0232, ACT0233		CD0362CD0363, CD0364, CD0365, CD0366, CD0367, CD0368, CD0369, CD0370, CD0371, CD0372, CD0373	
C/GLK-Class	204	Driver assistance system	MFK-Multifunction camera	√	√	√	√		ACT0234,ACT0235	SP1066		√
C/GLK-Class	204	Driver assistance system	MFK-Multifunction camera(A40/11)	√	√	√	√		ACT0236,ACT0237	SP1067,SP1068		√
C/GLK-Class	204	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		ACT0238,ACT0241,ACT0862, ACT1278,ACT0678,ACT0245, ACT0681,ACT0687,ACT0688, ACT0253,ACT0254,ACT1279, ACT0691,ACT0692,ACT1280, ACT1140,ACT0251,ACT0863,	SP1069,SP1070,SP1071		√
C/GLK-Class	204	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√					
C/GLK-Class	204	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√					

C/GLK-Class	204	Air conditioning	STH-Stationary heater	√	√	√	√		ACT0259,ACT0260,ACT1281,ACT1282,ACT1283,ACT1284,ACT1285,ACT0262,ACT1286,			√
C/GLK-Class	204	Information and communication	Drive Kit Plus-Drive kit for iPhone	√	√	√	√		ACT0263,ACT0264,ACT0265,ACT0266			
C/GLK-Class	204	Information and communication	NAVI20-Navigation(N125/2)	√	√	√	√		ACT0267,ACT0268			
C/GLK-Class	204	Chassis	EHPS-Electorhydraulic power sreeting	√	√	√	√					√
C/GLK-Class	204	Chassis	ES-Electric power steering(N68)	√	√	√	√			SP1302		√
C/GLK-Class	204	Chassis	ES-Electric power steering(N68)	√	√	√	√			SP1302,SP1303		√
C/GLK-Class	204	Body	PSD-Control module 'Panoramic sliding roof'(A98)	√	√	√	√		ACT0706,ACT0707	SP1305		√
C/GLK-Class	204	Body	PSD-Control mdulue 'Panoramic sliding roof'(A98)	√	√	√	√		ACT1288,ACT1289	SP1497		√
C/GLK-Class	204	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√		ACT0271			√
C/GLK-Class	204	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√		ACT0275			√
C/GLK-Class	204	Body	WSS-Weight sensing system(N110)	√	√	√	√					
C/GLK-Class	204	Information and communication	HUD-Head up display	√	√	√	√		ACT0272,ACT0273,ACT0274	SP1077,		
C/GLK-Class	204	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√		ACT0865,ACT0866,ACT0867,ACT0868,ACT0869,ACT0870	SP1373,SP1374,SP1375		√
C/GLK-Class	204	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√		ACT0865,ACT0866,ACT0867,ACT0868,ACT0869,ACT0870	SP1373,SP1374,SP1375		√
C/GLK-Class	204	Information and communication	SDAR-Satellite radio	√	√	√	√		ACT0283,ACT0284,ACT0285,ACT0286		CD0387CD0388, CD0389, CD0389	
C/GLK-Class	204	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√		ACT0871,ACT0872,ACT0873,ACT0874,ACT0875	SP1376,SP1377,		√
C/GLK-Class	204	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√		ACT0871,ACT0872,ACT0873,ACT0874,ACT0875	SP1376,SP1377,		√
C/GLK-Class	204	Information and communication	MIF-Media interface	√	√	√	√					
C/GLK-Class	204	Information and communication	MIF-Media interface	√	√	√	√		ACT0309			
C/GLK-Class	204	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√		ACT0711,ACT0712,ACT0713,ACT0714,ACT0715	SP1307,SP1308,SP1309,SP1310,SP1311	CD0527, CD0528, CD0529, CD0530	√
C/GLK-Class	204	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√		ACT0711,ACT0712,ACT0713,ACT0714,ACT0715	SP1307,SP1308,SP1309,SP1310,SP1311	CD0527, CD0528, CD0529, CD0530	√
C/GLK-Class	204	Body	OCP-Overhead control panel	√	√	√	√		ACT1290,ACT1291,ACT1292,ACT1293,ACT1294	SP1498		√
C/GLK-Class	204	Drive	ISM-Shift module	√	√	√	√		ACT0717,ACT0718,ACT0719,ACT0720,ACT0721	SP1312,SP1313,SP1314		√

C/GLK-Class	204	Body	TRM-Trailer recognition module (N28/1)	√	√	√	√		ACT0311,ACT0310,ACT1295,ACT0314,ACT0316,ACT0315,ACT0312,ACT0313,ACT1296,			
C/GLK-Class	204	Body	TRM-Trailer recognition module (N28/1)	√	√	√	√		ACT0311,ACT0310,ACT0312,ACT0313,ACT1297,ACT0314,ACT0315,ACT0316,ACT1296			√
C/GLK-Class	204	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√
C/GLK-Class	204	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√		ACT0884,ACT0885,ACT0886,ACT0887,ACT0888,ACT0889,ACT0890,ACT0891			√
C/GLK-Class	204	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√
C/GLK-Class	204	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√		ACT0723,ACT0724,ACT0725,ACT0726,ACT0727	SP1315,SP1316,SP1317,SP1318,SP1319	CD0531, CD0532, CD0533, CD0534	√
C/GLK-Class	204	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√		ACT0723,ACT0724,ACT0725,ACT0726,ACT0727	SP1315,SP1316,SP1317,SP1318,SP1319	CD0531, CD0532, CD0533, CD0534	√
C/GLK-Class	204	Drive	FSCU05-Control unit Fuel pump	√	√	√	√		ACT0385			√
C/GLK-Class	204	Drive	FSCU01-Control unit Fuel pump	√	√	√	√		ACT1298			√
C/GLK-Class	204	Drive	FSCU Left-Control unit 'Left fuel pump'	√	√	√	√		ACT1299			
C/GLK-Class	204	Drive	FSCU-Fuel pump	√	√	√	√		ACT0499			√
C/GLK-Class	204	Body	Rear SAM-Rear signal acquisition and actuation module	√	√	√	√		ACT0892,ACT0893,ACT0894,ACT0895,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0901,ACT0902,ACT0903,ACT0904,ACT0905,ACT0906,ACT0907,ACT0908,ACT0909,ACT0910,ACT0911,ACT0912,ACT0913,ACT0914,ACT0915,ACT0916,ACT0917,ACT0918,ACT0919,ACT0920,ACT0921,ACT0922,ACT0923,ACT0924,ACT0925,ACT0926,ACT0927,ACT0928,ACT0929,ACT0892,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0892,ACT0894,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0927,ACT0928,ACT0930,ACT0927,ACT0931,ACT0928,ACT0932,,ACT0933,ACT0934			√

C/GLK-Class	204	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√		ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√
C/GLK-Class	204	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√		ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√
C/GLK-Class	204	Information and communication	N123 / 4 (emergency call system control unit) - an emergency call	√	√	√	√					
C/GLK-Class	204	Driver assistance system	DTR-DISTRONIC	√	√	√	√					√
C/GLK-Class	204	Driver assistance system	DTR-DISTRONIC	√	√	√	√					√

C/GLK-Class	204	Seats and Doors	DCU LF-Left front door(N69/1)	√	√	√	√		ACT1300,ACT1301,ACT1302,ACT1303,ACT1304,ACT1305,ACT1306,ACT1307,ACT1308,ACT1309,ACT1310,ACT1311,ACT1312,ACT1313,ACT1314	SP1499		√
C/GLK-Class	204	Seats and Doors	LFD-Left front door	√	√	√	√		ACT0386,ACT0387,ACT0388,ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0398,ACT0994,ACT0397,ACT0400,ACT0401,ACT0402,ACT0403,			√
C/GLK-Class	204	Information and communication	N123 / 4 (emergency call system control unit) - Mercedes - Benz (MB) information / fault rescue	√	√	√	√					
C/GLK-Class	204	Seats and Doors	DCU RF-Right front door(N69/2)	√	√	√	√		ACT1315,ACT1316,ACT1317,ACT1318,ACT1319,ACT1320,ACT1321,ACT1322,ACT1323,ACT1324,ACT1325,ACT1326,ACT1327,ACT1328,ACT1329	SP1500		√
C/GLK-Class	204	Seats and Doors	DCU RF-Right front door	√	√	√	√		ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410,ACT0411,ACT0412,ACT0413,ACT0414,ACT0415,ACT0417,ACT0996,ACT0416,ACT0419,ACT0420,ACT0421,ACT0422,			√
C/GLK-Class	204	Seats and Doors	DCU LR-Left rear door(N69/3)	√	√	√	√		ACT0741,ACT0742,ACT0743,ACT0744,ACT0745,ACT0748,ACT0747,ACT0750,ACT0751,ACT0749,ACT0755,ACT0756,ACT0757,ACT0758,ACT0759	SP1321		√
C/GLK-Class	204	Seats and Doors	DCU LR-Left rear door	√	√	√	√		ACT1330,ACT1331,ACT1332,ACT1333,ACT1334,ACT1335,ACT1336,ACT1337,ACT1338,ACT1339,ACT1340,ACT1341,ACT1342,ACT1343,ACT1344,ACT1345,ACT1346,ACT1347,			√
C/GLK-Class	204	Seats and Doors	DCU RR-Right rear door(N69/4)	√	√	√	√		ACT0760,ACT0761,ACT0762,ACT0763,ACT0764,ACT0767,ACT0766,ACT0769,ACT0770,ACT0768,ACT0774,ACT0775,ACT0776,ACT0777,ACT0778	SP1322		√
C/GLK-Class	204	Seats and Doors	DCU RR-Right rear door	√	√	√	√		ACT1351,ACT1352,ACT1353,ACT1354,ACT1355,ACT1356,ACT1357,ACT1358,ACT1359,ACT1360,ACT1361,ACT1362,ACT1363,ACT1364,ACT1365,ACT1366,ACT1367,ACT1368,			√

C/GLK-Class	204	Information and communication	N123 / 4 (emergency call system control unit) - the vehicle remote control unlocking / locking the vehicle remote	√	√	√	√					
C/GLK-Class	204	Information and communication	N123 / 4 (emergency call system control unit) - anti-theft tracking	√	√	√	√					
C/GLK-Class	204	Driver assistance system	RFK-Backup camera	√	√	√	√		ACT0439,ACT1372	SP1089,SP1088,SP1501	CD0695	√
C/GLK-Class	204	Driver assistance system	RFK-Backup camera	√	√	√	√		ACT0439,ACT0440	SP1088,SP1089		√
C/GLK-Class	204	Body	WSS-Weight sensing system(N110)	√	√	√	√					
C/GLK-Class	204	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
C/GLK-Class	204	Body	BSN-Battery sensor(B95)	√	√	√	√					
C/GLK-Class	204	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0442,ACT0443,ACT0444,ACT0445,ACT0446			√
C/GLK-Class	204	Information and communication	AVE H-Rear audio video unit	√	√	√	√		ACT0610,ACT0611,ACT0612,ACT0789,ACT0613,ACT0614		CD0490, CD0491, CD0492, CD0493, CD0494	√
C/GLK-Class	204	Body	XALWA L-Xenon headlamp, left	√	√	√	√		ACT1373,ACT1374,ACT1375,ACT1376,ACT1377	SP1502,SP1503		√
C/GLK-Class	204	Body	SG SW-Control unit 'Headlamp'(N71/1)	√	√	√	√		ACT0451,ACT0452,ACT0453,ACT0454,ACT0455	SP1090,SP1091,SP1092,SP1093	CD0397	√
C/GLK-Class	204	Body	XALWA L-Xenon headlamp, left	√	√	√	√		ACT1373,ACT1374,ACT1375,ACT1376,ACT1378,ACT1379,	SP1502		√
C/GLK-Class	204	Body	XALWA L-Xenon headlamp, left	√	√	√	√		ACT1373,ACT1374,ACT1375,ACT1376,ACT1378,ACT1380	SP1502,SP1504		√
C/GLK-Class	204	Body	XALWA R-Xenon headlamp, right	√	√	√	√		ACT1381,ACT1382	SP1505		√
C/GLK-Class	204	Body	XALWA R-Xenon headlamp, right	√	√	√	√		ACT1381,ACT1382,ACT1383			√
C/GLK-Class	204	Body	XALWA R-Xenon headlamp, right	√	√	√	√		ACT1381,ACT1382,ACT1384,ACT1385			√
C/GLK-Class	204	Information and communication	ICI-InCar Internet(N125/3)	√	√	√	√		ACT1386,ACT1387,ACT1388			
C/GLK-Class	204	Information and communication	TV-TV tuner	√	√	√	√		ACT0214,ACT0216,ACT1389			
C/GLK-Class	204	Drive	N15/5 (Electronic selector lever module control unit)	√	√	√	√		ACT1002,ACT1003,ACT1004			√
C/GLK-Class	204	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
C/GLK-Class	204	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
C/GLK-Class	204	Body	FSW-Windshield wiper	√	√	√	√		ACT1005,			
C/GLK-Class	204	Body	FSW-Windshield wiper	√	√	√	√		ACT1005,			

C/GLK-Class	204	Body	GTO-Garage door opener(A67n2)	√	√	√	√					
C/GLK-Class	204	Body	GTO-Garage door opener(A67n2)	√	√	√	√					
C/GLK-Class	204	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√					
C/GLK-Class	204	Information and communication	CTEL-Mobile phone	√	√	√	√		ACT1390,ACT1391			
C/GLK-Class	204	Driver assistance system	PTS-Parktronic system	√	√	√	√		ACT1053		CD0536, CD0537, CD0538, CD0539	√
C/GLK-Class	204	Driver assistance system	PTS-Parktronic system	√	√	√	√		ACT1006		CD0536, CD0537, CD0538, CD0539	√
C/GLK-Class	204	Body	Hazard warning light system	√	√	√	√					
C/GLK-Class	204	Body	Exterior lights switch	√	√	√	√					
C/GLK-Class	204	Body	UCP-Upper control panel	√	√	√	√					
C/GLK-Class	204	Body	UCP-Upper control panel	√	√	√	√					
C/GLK-Class	204	Body	LCP-Lower control panel	√	√	√	√					
C/GLK-Class	204	Body	LCP-Lower control panel	√	√	√	√					
C/GLK-Class	204	Body	AU-Analog clock	√	√	√						
C/GLK-Class	204	Drive	FSCU Right-Control unit 'Right fuel pump'	√	√	√	√		ACT1392			
C/GLK-Class	204	Body	AS-Alarm siren(H3/1)	√	√	√			ACT1007			
C/GLK-Class	204	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT1007			
C/GLK-Class	204	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√		ACT1008,ACT1009			
C/GLK-Class	204	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√					
C/GLK-Class	204	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√					
C/GLK-Class	204	Drive	N15/3The fault occurs when charging of the fuel injector takes too long.5	√	√	√	√	√	ACT1393,ACT1394	SP1506,SP1507,SP1508, SP1509,SP1510,SP1511, SP1512	CD0699, CD0700, CD0701	√
C/GLK-Class	204	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√	ACT0584,ACT0585	SP1229,SP1230,SP1231, SP1232,SP1233,SP1234, SP1235,SP1236,SP1237, SP1237,SP1238,SP1239, SP1240,SP1241,SP1242,	CD0465, CD0466, CD0467, CD0468	√

C/GLK-Class	204	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7	√	√	√	√	√	ACT0586	SP1244,SP1245,SP1246,SP1247,SP1248,SP1249,SP1250,SP1250,SP1251,SP1252,SP1253,SP1254,	CD0469, CD0470, CD0471, CD0472, CD0473	√
C/GLK-Class	204	Drive	FSCU-Fuel pump	√	√	√	√		ACT0498,ACT0499		CD0427, CD0428	√
C/GLK-Class	204	Drive	SCR-Selective Catalytic Reduction	√	√	√	√		ACT0590,ACT0591,ACT0592,ACT0593,ACT0594,ACT0595,ACT0596,ACT0597,ACT0598,	SP1262,SP1263,SP1264,SP1265,SP1266,SP1267	CD0479, CD0480, CD0481, CD0482	√
C/GLK-Class	204	Drive	N127 (Drivetrain control unit)	√	√	√	√		ACT0500,ACT0501	SP1129,SP1130,SP1131	CD0429, CD0430, CD0431	√
C/GLK-Class	204	Drive	N3/10-Motor electronics "ME97" for combustion engine "M272"	√	√	√	√	√	ACT1395,ACT1396,ACT1397,ACT1398,ACT1399,ACT1400,ACT1401,ACT1402,ACT1403,ACT1404,ACT1405,ACT1406,ACT1407,ACT1408,ACT1409	SP1513,SP1514,SP1515,SP1516,SP1517,SP1518,SP1519,SP1520,SP1521	CD0702, CD0703, CD0704, CD0705, CD0706, CD0707, CD0708, CD0709	√
C/GLK-Class	204	Drive	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"	√	√	√	√	√	ACT1058,ACT1059,ACT1060,ACT1061,ACT1062,ACT1063,ACT1064,ACT1065,ACT1066,ACT1067,ACT1068,ACT1069,ACT1070,ACT1071,ACT1072,ACT1073,ACT1074,ACT1075,	SP1390,SP1391,SP1392,SP1393,SP1394,SP1395	CD0601, CD0602, CD0603, CD0604, CD0605, CD0606, CD0607, CD0608	√
C/GLK-Class	204	Drive	N3/10-Motor electronics "MED177" for combustion engine "M276"	√	√	√	√	√	ACT0802,ACT0803,ACT0804,ACT0805,ACT0806,ACT0807,ACT0808,ACT0809,ACT0810,ACT0811,ACT0812,ACT0813,ACT0814,ACT0815,ACT0816,ACT0817,ACT0818,ACT0819,	SP1335,SP1336,SP1337,SP1338,SP1339,SP1340,SP1341,SP1342,SP1343,SP1344,SP1345,SP1346,SP1347,SP1348	CD0544, CD0545, CD0546, CD0547, CD0548, CD0549, CD0550, CD0551, CD0552	√
C/GLK-Class	204	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	√	√	√	√	√	ACT0508,ACT0509,ACT0510,ACT0511,ACT0512,ACT0513,ACT0514,ACT0515,ACT0516,ACT0517,ACT0518,ACT0519,ACT0520,ACT0521,ACT0522,ACT0523,ACT0524,ACT0525,	SP1133,SP1134,SP1135,SP1136,SP1137,SP1138,SP1139,SP1140,SP1141,SP1142,SP1143,SP1144,SP1145,SP1146,SP1147,SP1148	CD0435, CD0436, CD0437, CD0438, CD0439, CD0440, CD0441, CD0442, CD0443	√
C/GLK-Class	204	Drive	N3/10-Motor electronics "MED97" for combustion engine "M272"	√	√	√	√	√	ACT1410,ACT1411,ACT1412,ACT1413,ACT1414,ACT1415,ACT1416,ACT1417,ACT1418,ACT1419,ACT1420,ACT1421,ACT1422,ACT1423,ACT1424,	SP1522,SP1523,SP1524,SP1525,SP1526,SP1527	CD0710, CD0711, CD0712, CD0713, CD0714, CD0715, CD0716, , CD0717, CD0718	√
C/GLK-Class	204	Drive	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"	√	√	√	√	√	ACT1023,ACT1024,ACT1025,ACT1026,ACT1027,ACT1028,ACT1029,ACT1030,ACT1031,ACT1032,ACT1033,ACT1034,ACT1035,ACT1036,ACT1037,ACT1038,ACT1039,ACT1040,	SP1382,SP1383,SP1384,SP1385,SP1386,SP1387,SP1388,SP1389	CD0587, CD0588, CD0589, CD0590, CD0591, CD0592, CD0593, CD0594, CD0595, CD0596	√
C/GLK-Class	204	Drive	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"	√	√	√	√	√	ACT1426,ACT1427,ACT1428,ACT1429,ACT1430,ACT1431,ACT1432,ACT1433,ACT1434,ACT1435	SP1528,SP1529,SP1530,SP1531,SP1532,SP1533,SP1534,SP1535	CD0719, CD0720, CD0721, CD0722, CD0723, CD0724, CD0725, CD0726, CD0727, CD0728	√

C-Class	205	Drive	N3/9-Motor electronics "CDI41R" for combustion engine	√	√	√	√	√				
C-Class	205	Drive	N3/9-Motor electronics "CR43" for combustion engine "OM651"	√	√	√	√					
C-Class	205	Drive	N3/9-Motor electronics "CDID3S2" for combustion	√	√	√	√	√				
C-Class	205	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√				
C-Class	205	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√				
C-Class	205	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√				
C-Class	205	Body	EZS-Electronic ignition lock	√	√	√	√					
C-Class	205	Body	EZS-Electronic ignition lock	√	√	√	√					
C-Class	205	Seats and Doors	LFD-Left front door	√	√	√	√					
C-Class	205	Seats and Doors	LFD-Left front door	√	√	√	√					
C-Class	205	Seats and Doors	DCU RF-Right front door	√	√	√	√					
C-Class	205	Seats and Doors	DCU RF-Right front door	√	√	√	√					
C-Class	205	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
C-Class	205	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
C-Class	205	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
C-Class	205	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
C-Class	205	Body	SRS-Supplemental restraint	√	√	√	√	√				
C-Class	205	Body	SRS-Supplemental restraint	√	√	√	√					
C-Class	205	Information and communication	CTEL-Cellular telephone	√	√	√	√					
C-Class	205	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					
C-Class	205	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√					
C-Class	205	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
C-Class	205	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√					
C-Class	205	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√					
C-Class	205	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√					
C-Class	205	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√					
C-Class	205	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√					
C-Class	205	Information and communication	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√					

C-Class	205	Information and communication	HERMES-control unit for telematics services	√	√	√	√				
C-Class	205	Information and communication	mbrace-mbrace	√	√	√	√				
C-Class	205	Seats and Doors	MKS-FS-Pilot multi-profile seat	√	√	√	√				
C-Class	205	Seats and Doors	MKS-BFS-Front passenger more copy the seat	√	√	√	√				
C-Class	205	Air conditioning	AAC-Automatic air conditioning	√	√	√	√				
C-Class	205	Seats and Doors	HKS-Tailgate control	√	√	√	√				
C-Class	205	Seats and Doors	HKS-Tailgate control	√	√	√	√				
C-Class	205	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√				
C-Class	205	Body	Trailer recognition module-Trailer recognition	√	√	√	√				
C-Class	205	Body	Multifunction control unit-Multifunction control unit	√	√	√	√				
C-Class	205	Body	PSD-Panoramic sliding roof	√	√	√	√				
C-Class	205	Body	PSD-Panoramic sliding roof	√	√	√	√				
C-Class	205	Body	PSD-Control module Panoramic sliding roof	√	√	√	√		SP1536		
C-Class	205	Driver assistance	KAB-Control unit Camera cover	√	√	√	√				
C-Class	205	Body	AML-Ambiance light	√	√	√	√				
C-Class	205	Body	KG-Keyless Go	√	√	√	√				
C-Class	205	Body	KG-Keyless Go	√	√	√	√				
C-Class	205	Body	OCP-Overhead control panel	√	√	√	√				
C-Class	205	Body	OCP-Overhead control panel	√	√	√	√				
C-Class	205	Body	DC/DC-DC/DC converter	√	√	√	√				
C-Class	205	Information and communication	mbrace-mbrace	√	√	√	√				
C-Class	205	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	√				
C-Class	205	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√				
C-Class	205	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√				
C-Class	205	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√				
C-Class	205	Drive	SG SOGE AGA-Sound generator for exhaust system	√	√	√	√				
C-Class	205	Information and communication	SG MSND-Engine sound	√	√	√	√				
C-Class	205	Information and communication	SG MSND-Engine sound	√	√	√	√				
C-Class	205	Body	LRE-Steering wheel electronics	√	√	√	√				
C-Class	205	Information and communication	TPAD-Touchpad	√	√	√	√				
C-Class	205	Information and communication	TPAD-Touchpad	√	√	√	√				

C-Class	205	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
C-Class	205	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
C-Class	205	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
C-Class	205	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
C-Class	205	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
C-Class	205	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
C-Class	205	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√					
C-Class	205	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
C-Class	205	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
C-Class	205	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
C-Class	205	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
C-Class	205	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
C-Class	205	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
C-Class	205	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
C-Class	205	Information and communication	IC-Instrument cluster(A1)	√	√	√	√					
C-Class	205	Information and communication	IC-Instrument cluster	√	√	√	√					
C-Class	205	Information and communication	HUD-Head up display	√	√	√	√					
C-Class	205	Driver assistance	RFK-Backup camera	√	√	√	√					
C-Class	205	Driver assistance	RFK-Backup camera	√	√	√	√					
C-Class	205	Driver assistance	CAMERA-360 camera(N148)	√	√	√	√					
C-Class	205	Body	SG FOND-Rear control unit	√	√	√	√					
C-Class	205	Body	SG FOND-Rear control unit	√	√	√	√					
C-Class	205	Drive	EAGGS-Electric differential lock	√	√	√	√					
C-Class	205	Body	AMLA-Active engine mount	√	√	√	√					
C-Class	205	Chassis	AMG DRVU-AMG DRIVE	√	√	√	√					
C-Class	205	Chassis	AMG DRVU-AMG DRIVE	√	√	√	√					
C-Class	205	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√					
C-Class	205	Body	SG SW L-Left headlamp	√	√	√	√					
C-Class	205	Body	SG SW L-Left headlamp	√	√	√	√					
C-Class	205	Body	SG SW L-Left headlamp	√	√	√	√					

C-Class	205	Body	SG SW R-Right headlamp	√	√	√	√					
C-Class	205	Body	SG SW R-Right headlamp	√	√	√	√					
C-Class	205	Body	SG SW R-Right headlamp	√	√	√	√					
C-Class	205	Driver assistance	TPM-Tire pressure monitor(N88)	√	√	√	√					
C-Class	205	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
C-Class	205	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
C-Class	205	Chassis	EFB-Electric parking brake	√	√	√	√					
C-Class	205	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√					
C-Class	205	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√					
C-Class	205	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√					
C-Class	205	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√					
C-Class	205	Drive	HFPM-Haptic accelerator pedal module	√	√	√	√					
C-Class	205	Drive	ISM-Shift module	√	√	√	√					
C-Class	205	Body	SG LG-Charger	√	√	√	√					
C-Class	205	Body	SG LG-Charger	√	√	√	√					
C-Class	205	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
C-Class	205	Body	BSN-Battery sensor(B95)	√	√	√	√					
C-Class	205	Body	BSN-Battery sensor(B95)	√	√	√	√					
C-Class	205	Body	LIB-Lithium ion battery	√	√	√	√					
C-Class	205	Body	LIB-Lithium ion battery	√	√	√	√					
C-Class	205	Body	AU-Analog clock	√	√	√	√					
C-Class	205	Body	Button group, instrument panel, driver side	√	√	√	√					
C-Class	205	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
C-Class	205	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
C-Class	205	Body	FSW-Windshield wiper	√	√	√	√					
C-Class	205	Body	GTO-Garage door	√	√	√	√					
C-Class	205	Body	GTO-Garage door	√	√	√	√					
C-Class	205	Body	OCP-Overhead control panel	√	√	√	√					
C-Class	205	Body	OCP-Overhead control panel	√	√	√	√					
C-Class	205	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√					
C-Class	205	Body	Anti glare interior rearview mirror(SAM)	√	√	√	√					
C-Class	205	Body	AMLAB-R (Actuation module, LED exterior lighting, right front)	√	√	√	√					
C-Class	205	Body	AMLAB-R (Actuation module, LED exterior lighting, right front)	√	√	√	√					
C-Class	205	Body	AMLAB-L (Actuation module, LED exterior lighting, left front)	√	√	√	√					

C-Class	205	Body	AMLAB-L (Actuation module, LED exterior lighting, left front)	√	√	√	√					
C-Class	205	Body	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
C-Class	205	Body	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					
C-Class	205	Body	AIRSCARF-Neck heating system(N25/7)	√	√	√	√					
C-Class	205	Body	"Front passenger" seat heater	√	√	√	√					
C-Class	205	Body	"Driver" seat heater	√	√	√	√					
C-Class	205	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√					
C-Class	205	Seats and Doors	LFD-Left front door	√	√	√						
C-Class	205	Seats and Doors	LFD-Left front door	√	√	√						
C-Class	205	Seats and Doors	LFD-Left front door	√	√	√						
C-Class	205	Seats and Doors	DCU RF-Right front door	√	√	√						
C-Class	205	Seats and Doors	DCU RF-Right front door	√	√	√						
C-Class	205	Seats and Doors	DCU RF-Right front door	√	√	√						
C-Class	205	Seats and Doors	DCU LR-Left rear door	√	√	√						
C-Class	205	Seats and Doors	DCU RR-Right rear door	√	√	√						
C-Class	205	Body	AS-Alarm siren(H3/1)	√	√	√	√					
C-Class	205	Body	IRSS-VL-Left front interior protection sensor	√	√	√						
C-Class	205	Body	IRSS-VR-Right front interior protection sensor	√	√	√						
C-Class	205	Body	IRSS-FOR-Right rear interior protection sensor	√	√	√						
C-Class	205	Body	IRSS-FOL-Left rear interior protection sensor	√	√	√						
C-Class	205	Air conditioning	AAC-Automatic air conditioning	√	√	√						
C-Class	205	Air conditioning	STH-Stationary heater	√	√	√	√					
C-Class	205	Air conditioning	AAC-Automatic air conditioning	√	√	√						
C-Class	205	Air conditioning	AAC-Automatic air conditioning	√	√	√						
C-Class	205	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√					
C-Class	205	Information and communication	N72/1 (Upper control panel control unit)	√	√	√						
C-Class	205	Information and communication	N72/5 (Right lower control panel)	√	√	√						
C-Class	205	Information and communication	N72/4 (Left lower control panel)	√	√	√						
C-Class	205	Body	WSS-Weight sensing	√	√	√	√					
C-Class	205	Body	N38 (Rear switching module)	√	√	√	√					
C-Class	205	Body	LIB-Lithium ion battery	√	√	√	√					
C-Class	205	Information and communication	TV tuner (TV)	√	√	√	√					
C-Class	205	Information and communication	TV tuner (TV)	√	√	√	√					

C-Class	205	Information and communication	TV tuner (TV)	√	√	√	√					
C-Class	205	Information and communication	TV tuner (TV)	√	√	√	√					
C-Class	205	Information and communication	SOUND-Sound system	√	√	√	√					
C-Class	205	Information and communication	SOUND-Sound system	√	√	√	√					
C-Class	205	Information and communication	DAB-Digital radio Tuner unit	√	√	√	√					
C-Class	205	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					
C-Class	205	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					
C-Class	205	Driver assistance	DTR-DISTRONIC	√	√	√	√					
C-Class	205	Driver assistance	DTR-DISTRONIC	√	√	√	√					
C-Class	205	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√					
C-Class	205	Driver assistance	SGR-Radar sensors control unit	√	√	√	√					
C-Class	205	Driver assistance	DTR-DISTRONIC(B29)	√	√	√	√					
C-Class	205	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√					
C-Class	205	Driver assistance	PARK-Parking system (N62)	√	√	√	√					
C-Class	205	Driver assistance	PTS-PARKTRONIC	√	√	√	√					
C-Class	205	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√					
C-Class	205	Chassis	ES - Electric power steering	√	√	√	√					
C-Class	205	Chassis	ES - Electric power steering	√	√	√	√					
C-Class	205	Body	SCM-Steering column	√	√	√	√					
C-Class	205	Body	SCM-Steering column	√	√	√	√					
C-Class	205	Body	STM-Mirror taximeter	√	√	√	√					
C-Class	205	Driver assistance	NBR RR-Right rear short-range	√	√	√	√					
C-Class	205	Driver assistance	NBR LR-Left rear short-range	√	√	√	√					
C-Class	205	Chassis	ESP-Electric stability	√	√	√	√	√				
C-Class	205	Chassis	ESP-Electric stability	√	√	√	√	√				
C-Class	205	Chassis	ESP-Electric stability	√	√	√	√	√				
C-Class	205	Chassis	ESP-Electric stability	√	√	√	√	√				
C-Class	205	Chassis	ESP-Electric stability	√	√	√	√	√				
C-Class	205	Chassis	ESP-Electric stability	√	√	√	√	√				
C-Class	205	Drive	FSCU-Control unit Fuel pump	√	√	√	√					
C-Class	205	Drive	SCR-Selective catalytic reduction	√	√	√	√					
C-Class	205	Drive	SCR-Selective catalytic reduction	√	√	√	√					
C-Class	205	Drive	N127 (Drivetrain control unit)	√	√	√	√					
C-Class	205	Drive	N127 (Drivetrain control unit)	√	√	√	√					
C-Class	205	Drive	SG EM-Power electronics	√	√	√	√					
C-Class	205	Drive	ISG-Integrated starter alternator	√	√	√	√					
C-Class	205	Drive	SG EM-Power electronics	√	√	√	√					
C-Class	205	Drive	ISG-Integrated starter alternator	√	√	√	√					

C-Class	205	Body	BMS-Battery management system	√	√	√	√					
C-Class	205	Body	BMS-Battery management system	√	√	√	√					
C-Class	205	Body	BMS-Battery management system	√	√	√	√					
C-Class	205	Drive	N3/10-Motor electronics "MED177" for combustion engine	√	√	√	√	√				
C-Class	205	Drive	N3/10-Motor electronics "MED1775" for combustion	√	√	√	√	√				
C-Class	205	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√				
C-Class	205	Drive	N3/10-Motor electronics "MED40" for combustion engine	√	√	√	√	√				
C-Class	205	Drive	N3/10-Motor electronics "MED41" for combustion engine	√	√	√	√	√				
C-Class	205	Drive	N3/10-Motor electronics "MRG1" for combustion engine "M256"	√	√	√	√	√				
E-Class	207	Drive	N3/9-Motor electronics "CR42" for combustion engine "OM651"	√	√	√	√	√	ACT1187,ACT1188,ACT1189, ACT1190,ACT1191,ACT1192, ACT1193,ACT1194,ACT1195, ACT1196,ACT1197,ACT1198, ACT1199,ACT1200,ACT1201, ACT1202,ACT1203,ACT1204,	SP1432,SP1433,SP1434, SP1435,SP1436,SP1437, SP1438,SP1439,SP1440, SP1441,SP1442,SP1443, SP1444,SP1445,SP1446, SP1447,SP1448,SP1449,	CD0648, CD0649, CD0650	√
E-Class	207	Drive	N3/9-Motor electronics "CR43" for combustion engine "OM651"	√	√	√	√	√	ACT0543,ACT0544,ACT0545, ACT0546,ACT0547,ACT0548, ACT0549,ACT0550,ACT0551, ACT0552,ACT0553,ACT0554, ACT0555,ACT0556,ACT0557, ACT0558	SP1164,SP1165,SP1166, SP1167,SP1168,SP1169, SP1170,SP1171,SP1172, SP1173,SP1174,SP1175, SP1176,SP1177,SP1178, SP1179,SP1180,SP1181, SP1182,SP1183,SP1184,	CD0453, CD0454, CD0455, CD0456	√
E-Class	207	Drive	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"	√	√	√	√	√	ACT0559,ACT0560,ACT0561, ACT0562,ACT0563,ACT0564, ACT0565,ACT0566,ACT0567, ACT0568,ACT0569,ACT0570,	SP1187,SP1188,SP1189, SP1190,SP1191,SP1192, SP1193,SP1194,SP1195, SP1196,SP1197,SP1198, SP1199,SP1200,SP1201, SP1202,SP1203,SP1204,	CD0457, CD0458, CD0459, CD0460	√
E-Class	207	Drive	N3/9-Motor electronics "CDI61" for combustion engine "OM642"	√	√	√	√	√	ACT0571,ACT0572,ACT0573, ACT0574,ACT0575,ACT0576, ACT0577,ACT0578,ACT0579, ACT0580,ACT0581,ACT0582, ACT0583	SP1206,SP1207,SP1208, SP1209,SP1210,SP1211, SP1212,SP1213,SP1214, SP1215,SP1216,SP1217, SP1218,SP1219,SP1220, SP1221,SP1222,SP1223, SP1224,SP1225,SP1226,	CD0461, CD0462, CD0463, CD0464	√
E-Class	207	Drive	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"	√	√	√	√	√	ACT1216,ACT1217,ACT1218, ACT1219,ACT1220,ACT1221, ACT1222,ACT1223,ACT1224, ACT1225,ACT1226	SP1466,SP1467,SP1468, SP1469,SP1470,SP1471, SP1472,SP1473,SP1474, SP1475,SP1476,SP1477,	CD0654, CD0655, CD0656	√

E-Class	207	Drive	N3/9-Motor electronics "CDID2" for combustion engine "OM651"	√	√	√	√	√	ACT1245,ACT1246,ACT1247,ACT1248,ACT1249,ACT1250,ACT1251,ACT1252,ACT1253,ACT1254,ACT1255,ACT1256,ACT1257,ACT1258,ACT1259,ACT1260,ACT1261,ACT1262,ACT1263,ACT1264,ACT1265,		CD0659, CD0660, CD0661, CD0662	√
E-Class	207	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√	√	ACT0000,ACT0001,ACT0002,ACT0003,ACT0004,ACT0005,ACT0006,ACT0007,ACT0008,ACT0009,ACT0010,ACT0011,ACT0012,ACT0013,ACT0014,ACT0015,ACT0016,ACT0017,ACT0018,ACT0019,ACT0020,ACT0021,ACT0022,ACT0023,ACT0024,ACT0025,ACT0026	SP1000,SP1001,SP1002,SP1003,SP1004,SP1005,SP1006,SP1007,SP1008,SP1009,SP1010,SP1011,SP1012,SP1013,SP1014,SP1015,SP1016,SP1017,SP1018,SP1019,SP1020,SP1021,SP1022,SP1023,SP1024	CD0304, CD0305, CD0306, CD0307	√
E-Class	207	Drive	N15/3The fault occurs when charging of the fuel injector takes too long.5	√	√	√	√	√	ACT1393,ACT1394	SP1506,SP1507,SP1508,SP1509,SP1510,SP1511,SP1512	CD0699, CD0700, CD0701	√
E-Class	207	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√	ACT0584,ACT0585	SP1229,SP1230,SP1231,SP1232,SP1233,SP1234,SP1235,SP1236,SP1237,SP1237,SP1238,SP1239,SP1240,SP1241,SP1242,	CD0465, CD0466, CD0467, CD0468	√
E-Class	207	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7	√	√	√	√	√	ACT0586	SP1244,SP1245,SP1246,SP1247,SP1248,SP1249,SP1250,SP1250,SP1251,SP1252,SP1253,SP1254,	CD0469, CD0470, CD0471, CD0472, CD0473	√
E-Class	207	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√	ACT0587,ACT0588,ACT0589	SP1256,SP1257,SP1258,SP1259,SP1260,SP1261	CD0474, CD0475, CD0476, CD0477, CD0478	√
E-Class	207	Information and communication	Left front short range radar	√	√	√	√					√
E-Class	207	Information and communication	Left front short range radar	√								√
E-Class	207	Information and communication	E call [Europe]-Emergency call system	√	√	√	√		ACT0044,ACT0045,ACT0046,ACT0047,ACT0048,ACT0049			
E-Class	207	Information and communication	AVE H-Rear audio video unit	√	√	√	√		ACT0610,ACT0611,ACT0612,ACT0613,ACT0614		CD0490, CD0491, CD0492, CD0493, CD0494	√
E-Class	207	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√
E-Class	207	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√
E-Class	207	Body	CGW-Central gateway	√	√	√	√			SP1366		√
E-Class	207	Information and communication	IC-Instrument cluster	√	√	√	√		ACT0050,ACT0051,ACT0052,ACT0053,ACT0054,ACT0055,	SP1047,SP1048		√
E-Class	207	Information and communication	KOMO-Communication module Telematics services	√	√	√	√		ACT0057,ACT0058,ACT0059,ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065,			√

E-Class	207	Seats and Doors	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√		ACT0067,ACT0068,ACT0069,ACT0070,ACT0071,ACT0072,ACT0073,ACT0074	SP1049,SP1050		
E-Class	207	Information and communication	TS-Telematic system(N123/4)	√	√	√	√		ACT0075,ACT0076,ACT0077,ACT0078			√
E-Class	207	Body	EZS-Electronic ignition switch	√	√	√	√			SP1051,SP1052,SP1053	CD0320, CD0321, CD0322, CD0323, CD0324	
E-Class	207	Body	EZS-Electronic ignition lock	√	√	√	√			SP1490,SP1491,SP1492		
E-Class	207	Body	EZS-Electronic ignition lock	√	√	√	√				CD0325	
E-Class	207	Body	EZS-Electronic ignition lock	√	√	√	√					
E-Class	207	Body	EZS-Electronic ignition lock	√	√	√	√					
E-Class	207	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084			√
E-Class	207	Body	SCCM-Steering column module(N80)	√	√	√	√		ACT0841,ACT0842,ACT0843,ACT0844,ACT0845			√
E-Class	207	Chassis	AMG DRVU-AMG DRIVE UNIT(N145)	√	√	√	√		ACT0085,ACT0086,ACT0087			√
E-Class	207	Chassis	ESP- Electric stability program	√	√	√	√	√	ACT0847,ACT0848,ACT1269,ACT0849,ACT0850	SP1493,SP1368		√
E-Class	207	Chassis	ESP-Electronic stability program(N30/4)	√	√	√	√	√	ACT0088,ACT0089,ACT1436	SP1537,SP1280		√
E-Class	207	Information and communication	NAV-Navigation module(A2/30)	√	√	√	√		ACT0090,ACT0091,ACT0092,ACT0093			√
E-Class	207	Information and communication	Audio-Audio or COMAND	√	√	√	√					
E-Class	207	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
E-Class	207	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√			SP1288,SP1289,SP1290,SP1291		√
E-Class	207	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1292,SP1293,SP1294,SP1295,SP1296		√
E-Class	207	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1297,SP1293,SP1294,SP1296		√
E-Class	207	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0100,ACT0099	SP1056,SP1409		√
E-Class	207	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√				√
E-Class	207	Body	SRS-Supplemental restraint	√	√	√	√	√				√

E-Class	207	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√		ACT0101,ACT0102,ACT0103,ACT0104,ACT0105,ACT0106,ACT0107,ACT0108,ACT0109,ACT0110,ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,ACT0117,ACT0118,ACT0119,ACT0120,ACT0121,ACT0118,ACT0119,ACT0120,ACT0119,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0111,ACT0112,ACT0113,ACT0118,ACT0116,ACT0117,ACT0102,ACT0103,ACT0127,ACT0128,ACT0101,	SP1057,SP1058,SP1059,SP1060,SP1061		
E-Class	207	Information and communication	Audio-Audio or COMAND	√	√	√	√					
E-Class	207	Information and communication	Audio-Audio or COMAND	√	√	√			ACT1102,ACT1103,ACT1104,ACT1105,ACT1106,ACT1107,ACT1108,ACT1109,ACT1110,ACT1111,ACT1112,ACT1113,ACT1114,ACT1115,ACT1116,ACT1117,ACT1118,ACT1119,ACT1120,ACT1121,ACT1112,ACT1113,ACT1114,ACT1115,ACT1117,ACT1118,ACT1122,ACT1123,ACT1124,ACT1103,ACT1104,ACT1125,ACT1126,ACT1102,ACT1105,ACT1106,ACT1107,ACT1110,ACT1119,	SP1410,SP1411,SP1412	CD0619, CD0620, CD0621, CD0622, CD0623, CD0624, CD0625, CD0626, CD0627, CD0628, CD0629, CD0630, CD0631	
E-Class	207	Driver assistance system	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)	√	√	√	√		ACT0132	SP1062		√
E-Class	207	Driver assistance system	CAMERA-360 camera(N148)	√	√	√	√		ACT0542			√
E-Class	207	Driver assistance system	CAMERA-360 camera(N148)	√	√	√	√		ACT0542	SP1158,SP1159,SP1160,SP1161,SP1162,SP1163		√
E-Class	207	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					
E-Class	207	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					√
E-Class	207	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					
E-Class	207	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					√
E-Class	207	Body	Multifunction control unit-Multifunction control unit	√	√	√	√		ACT0133,ACT0134,ACT0135,ACT0136,ACT0137,ACT0138,ACT0139,ACT0140,ACT0141,ACT0142,ACT0143,ACT0144,ACT0145,ACT0146,ACT0147,ACT0148,ACT0149,ACT0150,			√
E-Class	207	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0156,ACT0157			√

E-Class	207	Body	KG-KEYLESS GO	√	√	√	√		ACT0851,ACT0852,ACT0853,ACT0854			
E-Class	207	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0855,ACT0856,ACT0156,ACT0157,ACT0857			√
E-Class	207	Information and communication	SOUND-Sound system	√	√	√	√		ACT0158,ACT0159,ACT0160,ACT0161,ACT0162,ACT0163,ACT0164,ACT0165,ACT0166,ACT0167,ACT0168,ACT0169,ACT0170,ACT0171,ACT0172,ACT0173,ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0179,ACT0180,ACT0181,		CD0348	
E-Class	207	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0199,ACT0186,ACT0187,ACT0189,ACT0191,ACT0192,ACT0200,ACT0195,ACT0196,ACT0201,ACT0202,ACT0194,ACT0203,ACT0204,ACT0205,ACT0197,ACT0206,ACT0198	SP1063		
E-Class	207	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0199,ACT0653,ACT0185,ACT0186,ACT0654,ACT0655,ACT0195,ACT0196,ACT0193,ACT0200,ACT0194,ACT0188,ACT0190,ACT0191,ACT0192,ACT0656,ACT0657,ACT0206,			
E-Class	207	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√		ACT0207,ACT0208,ACT0209,ACT0210	SP1064		√
E-Class	207	Chassis	ADS-Adaptive damping system	√	√	√	√		ACT0858,ACT0859,ACT0860,ACT0861	SP1372		√
E-Class	207	Body	TLC-Trunk lid control	√	√	√	√		ACT1272,ACT1273,ACT1274,ACT1275,ACT1276	SP1495,SP1496		√
E-Class	207	Information and communication	ECS-N123/4 Emergency call system control unit	√	√	√	√		ACT0674,ACT0675,ACT0676			
E-Class	207	Information and communication	TV-TV tuner	√	√	√	√		ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0219,ACT0220,ACT0221,ACT0222,ACT0223		CD0350CD0351, CD0352, CD0353, CD0354, CD0355, CD0356, CD0357, CD0358, CD0359, CD0360, CD0361	
E-Class	207	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0677,ACT0233			
E-Class	207	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0230,ACT0231,ACT0232,ACT0233		CD0362CD0363, CD0364, CD0365, CD0366, CD0367, CD0368, CD0369, CD0370, CD0371, CD0372, CD0373	
E-Class	207	Driver assistance	MFK-Multifunction camera	√	√	√	√		ACT0234,ACT0235	SP1066		√
E-Class	207	Driver assistance	MFK-Multifunction	√	√	√	√		ACT0236,ACT0237	SP1067,SP1068		√

E-Class	207	Air conditioning	AAC-Automatic air conditioning	√	√	√	√	ACT0238,ACT0241,ACT0678,ACT0862,ACT1278,ACT0245,ACT0239,ACT0240,ACT0251,ACT0253,ACT0254,ACT0685,ACT0686,ACT0687,ACT0688,ACT0691,ACT0692,ACT1280,ACT0693,ACT0694,ACT1279,	SP1069,SP1070,SP1071		√
E-Class	207	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√				
E-Class	207	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√				
E-Class	207	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	ACT0255,ACT0256,ACT0257,ACT0258		CD0382	
E-Class	207	Air conditioning	STH-Stationary heater	√	√	√	√	ACT0259,ACT0260,ACT1281,ACT1282,ACT1283,ACT1284,ACT1285,ACT0262,ACT1286,			√
E-Class	207	Information and communication	Drive Kit Plus-Drive kit for iPhone	√	√	√	√	ACT0263,ACT0264,ACT0265,ACT0266			
E-Class	207	Information and communication	NAVI20-Navigation(N125/2)	√	√	√	√	ACT0267,ACT0268			
E-Class	207	Chassis	ES-Electric power steering(N68)	√	√	√	√		SP1302		√
E-Class	207	Chassis	ES-Electric power steering(N68)	√	√	√	√		SP1302,SP1303		√
E-Class	207	Body	PSD-Control module 'Panoramic sliding roof'(A98)	√	√	√	√	ACT1288,ACT1289	SP1497		√
E-Class	207	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√	ACT0271			√
E-Class	207	Body	WSS-Weight sensing	√	√	√	√				
E-Class	207	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√	ACT0275			√
E-Class	207	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√	ACT0865,ACT0866,ACT0867,ACT0868,ACT0869,ACT0870	SP1373,SP1374,SP1375		√
E-Class	207	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√	ACT0865,ACT0866,ACT0867,ACT0868,ACT0869,ACT0870	SP1373,SP1374,SP1375		√
E-Class	207	Information and communication	SDAR-Satellite radio	√	√	√	√	ACT0283,ACT0284,ACT0285,ACT0286		CD0387CD0388, CD0389, CD0389	
E-Class	207	Information and communication	TB5-TV tuner Tuner unit	√	√	√	√	ACT0287,ACT0288,ACT0289,ACT0290,ACT0291,ACT0292,ACT0293,ACT0294,			
E-Class	207	Information and communication	TV tuner (TV)	√	√	√	√	ACT0295,ACT0296,ACT0297,ACT0298,ACT0299,ACT0300,			
E-Class	207	Air conditioning	A9/5 (Electric refrigerant compressor)	√	√	√	√	ACT1437			√
E-Class	207	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√	ACT0871,ACT0872,ACT0873,ACT0874,ACT0875	SP1376,SP1377,		√
E-Class	207	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√	ACT0871,ACT0872,ACT0873,ACT0874,ACT0875	SP1376,SP1377,		√
E-Class	207	Information and communication	MIF-Media interface	√	√	√	√				

E-Class	207	Information and communication	MIF-Media interface	√	√	√	√		ACT0309			
E-Class	207	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√		ACT0711,ACT0712,ACT0713,ACT0714,ACT0715	SP1307,SP1308,SP1309,SP1310,SP1311	CD0527, CD0528, CD0529, CD0530	√
E-Class	207	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√		ACT0711,ACT0712,ACT0713,ACT0714,ACT0715	SP1307,SP1308,SP1309,SP1310,SP1311	CD0527, CD0528, CD0529, CD0530	√
E-Class	207	Drive	ISM-Shift module	√	√	√	√		ACT0717,ACT0718,ACT0719,ACT0720,ACT0721	SP1312,SP1313,SP1314		√
E-Class	207	Body	TRM-Trailer recognition module (N28/1)	√	√	√	√		ACT0311,ACT0310,ACT0312,ACT0313,ACT1297,ACT0314,ACT0315,ACT0316,ACT1296			√
E-Class	207	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√
E-Class	207	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√		ACT0884,ACT0885,ACT0886,ACT0887,ACT0888,ACT0889,ACT0890,ACT0891			√
E-Class	207	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√
E-Class	207	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√		ACT0723,ACT0724,ACT0725,ACT0726,ACT0727	SP1315,SP1316,SP1317,SP1318,SP1319	CD0531, CD0532, CD0533, CD0534	√
E-Class	207	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√		ACT0723,ACT0724,ACT0725,ACT0726,ACT0727	SP1315,SP1316,SP1317,SP1318,SP1319	CD0531, CD0532, CD0533, CD0534	√
E-Class	207	Drive	FSCU05-Control unit Fuel pump	√	√	√	√		ACT0385			√
E-Class	207	Body	Rear SAM-Rear signal acquisition and actuation module	√	√	√	√		ACT0892,ACT0893,ACT0894,ACT0895,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0901,ACT0902,ACT0903,ACT0904,ACT0905,ACT0906,ACT0907,ACT0908,ACT0909,ACT0910,ACT0911,ACT0912,ACT0913,ACT0914,ACT0915,ACT0916,ACT0917,ACT0918,ACT0919,ACT0920,ACT0921,ACT0922,ACT0923,ACT0924,ACT0925,ACT0926,ACT0927,ACT0928,ACT0929,ACT0892,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0892,ACT0894,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0927,ACT0928,ACT0930,ACT0927,ACT0931,ACT0928,ACT0932,,ACT0933,ACT0934			√

E-Class	207	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√		ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√	
E-Class	207	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√		ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√	
E-Class	207	Information and communication	N123 / 4 (emergency call system control unit) - an emergency call	√	√	√	√						
E-Class	207	Driver assistance	DTR-DISTRONIC	√	√	√	√						√
E-Class	207	Driver assistance	DTR-DISTRONIC	√	√	√	√						√

E-Class	207	Seats and Doors	LFD-Left front door	√	√	√	√		ACT0386,ACT0387,ACT0388,ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0398,ACT0994,ACT0397,ACT0400,ACT0401,ACT0402,ACT0403,			√
E-Class	207	Information and communication	N123 / 4 (emergency call system control unit) - Mercedes - Benz (MB) information / fault rescue	√	√	√	√					
E-Class	207	Driver assistance	NSA-Night View Assist(N101)	√	√	√	√		ACT1438,ACT0740	SP1320		√
E-Class	207	Seats and Doors	DCU RF-Right front door	√	√	√	√		ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410,ACT0411,ACT0412,ACT0413,ACT0414,ACT0415,ACT0417,ACT0996,ACT0416,ACT0419,ACT0420,ACT0421,ACT0422,			√
E-Class	207	Information and communication	TV-TV tuner	√	√	√	√		ACT0424,ACT0425,ACT0426,ACT0427,ACT0222,ACT0428,ACT0219,ACT0221			
E-Class	207	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258			
E-Class	207	Information and communication	N123 / 4 (emergency call system control unit) - the vehicle remote control unlocking / locking the vehicle remote	√	√	√	√					
E-Class	207	Body	REAR-Rear control unit(N22/6)	√	√	√	√		ACT1439,ACT1440,ACT1441,ACT1442,ACT1443,ACT1444,ACT1442,ACT1443,ACT1445,ACT1446,ACT1447,ACT1448,	SP1538,SP1539		√
E-Class	207	Information and communication	N123 / 4 (emergency call system control unit) - anti-theft tracking	√	√	√	√					
E-Class	207	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439,ACT1372	SP1089,SP1088,SP1501	CD0695	√
E-Class	207	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439	SP1089		√
E-Class	207	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439	SP1088,SP1089		√
E-Class	207	Chassis	FGW-Chassis gateway	√	√	√	√				CD0535	√
E-Class	207	Body	AIRSCARF-Neck heating system(N25/7)	√	√	√	√					√
E-Class	207	Seats and Doors	N25/6 (Rear passenger compartment seat heater control	√	√	√	√		ACT1451,ACT1452			√
E-Class	207	Body	WSS-Weight sensing	√	√	√	√					
E-Class	207	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
E-Class	207	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
E-Class	207	Body	BSN-Battery sensor(B95)	√	√	√	√					
E-Class	207	Body	BSN-Battery sensor(B95)	√	√	√	√					
E-Class	207	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0442,ACT0443,ACT0444,ACT0445,ACT0446			√

E-Class	207	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0447,ACT0448,ACT0449,ACT0450			√
E-Class	207	Information and communication	AVE H-Rear audio video unit	√	√	√	√		ACT0610,ACT0611,ACT0612,ACT0789,ACT0613,ACT0614		CD0490, CD0491, CD0492, CD0493, CD0494	√
E-Class	207	Body	SG SW L-Left headlamp	√	√	√	√		ACT0456,ACT0457,ACT0458,ACT0459,ACT0460,ACT0461	SP1094,SP1095,SP1096,SP1097,SP1098,SP1099,	CD0398	√
E-Class	207	Body	SG SW L-Left headlamp(E1n9)	√	√	√	√		ACT0462,ACT0463,ACT0464,ACT0465,ACT0466,ACT0467	SP1101,SP1102,SP1103,SP1104,SP1105,SP1106,SP1107,SP1108	CD0399	√
E-Class	207	Body	XALWA L-Left xenon headlamp(E1n1)	√	√	√	√		ACT1453,ACT1454,ACT1455,ACT1456,ACT1457,ACT1458	SP1540,SP1541,SP1542		√
E-Class	207	Body	SG SW R-Right headlamp	√	√	√	√		ACT0468,ACT0469,ACT0470,ACT0471,ACT0472,ACT0473	SP1109,SP1110,SP1111,SP1112,SP1113,SP1114	CD0400	√
E-Class	207	Body	SG SW R-Right headlamp(E1n9)	√	√	√	√		ACT0474,ACT0475,ACT0476,ACT0477,ACT0478,ACT0479	SP1115,SP1116,SP1117,SP1118,SP1119,SP1120	CD0401	√
E-Class	207	Body	XALWA R-Right xenon headlamp(E2n1)	√	√	√	√		ACT1459,ACT1460,ACT1461,ACT1462,ACT1463,ACT1464	SP1543		√
E-Class	207	Information and communication	ICI-InCar Internet(N125/3)	√	√	√	√		ACT1386,ACT1387,ACT1388			
E-Class	207	Drive	N15/5 (Electronic selector lever module control unit)	√	√	√	√		ACT1002,ACT1003,ACT1004			√
E-Class	207	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
E-Class	207	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
E-Class	207	Body	FSW-Windshield wiper	√	√	√	√		ACT1005,			
E-Class	207	Body	FSW-Windshield wiper	√	√	√	√		ACT1005,			
E-Class	207	Body	GTO-Garage door	√	√	√	√					
E-Class	207	Body	GTO-Garage door	√	√	√	√					
E-Class	207	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√					
E-Class	207	Information and communication	CTEL-Mobile phone	√	√	√	√		ACT1390,ACT1391			
E-Class	207	Driver assistance	PARK-Parking system (N62)	√	√	√	√		ACT0484,ACT0485		CD0411, CD0412	√
E-Class	207	Driver assistance system	PTS-Parktronic system	√	√	√	√		ACT1006		CD0536, CD0537, CD0538, CD0539	√
E-Class	207	Body	Hazard warning light system	√	√	√	√					
E-Class	207	Body	Exterior lights switch	√	√	√	√					
E-Class	207	Body	UCP-Upper control panel	√	√	√	√					
E-Class	207	Body	UCP-Upper control panel	√	√	√	√					
E-Class	207	Body	LCP-Lower control panel	√	√	√	√					
E-Class	207	Body	LCP-Lower control panel	√	√	√	√					
E-Class	207	Body	AU-Analog clock	√	√	√	√					
E-Class	207	Information and communication	DSI-DIRECT SELECT interface(N150)	√	√	√	√		ACT0488			√
E-Class	207	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT1007			
E-Class	207	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT1007			
E-Class	207	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√		ACT1008,ACT1009			

E-Class	207	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√		ACT0794,ACT0795	SP1325,SP1326,SP1327	CD0540	
E-Class	207	Body	AMLAB L 2-Actuation module 2, LED exterior lighting, left	√	√	√	√		ACT0796,ACT0797	SP1328,SP1329,SP1330	CD0541	
E-Class	207	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√		ACT0798,ACT0799	SP1331,SP1332	CD0542	
E-Class	207	Body	AMLAB R 2-Actuation module 2, LED exterior lighting, right front(E2n8)	√	√	√	√		ACT0800,ACT0801	SP1333,SP1334	CD0543	
E-Class	207	Drive	FSCU-Fuel pump	√	√	√	√		ACT0498,ACT0499		CD0427, CD0428	√
E-Class	207	Drive	SCR-Selective Catalytic Reduction	√	√	√	√		ACT0590,ACT0591,ACT0592,ACT0593,ACT0594,ACT0595,ACT0596,ACT0597,ACT0598,	SP1262,SP1263,SP1264,SP1265,SP1266,SP1267	CD0479, CD0480, CD0481, CD0482	√
E-Class	207	Drive	SCR-Selective catalytic reduction	√	√	√	√		ACT0600,ACT0601,ACT0602,ACT0603,ACT0604,ACT0605	SP1268,SP1269,SP1270,SP1271,SP1272,SP1273	CD0483, CD0484, CD0485	√
E-Class	207	Drive	PE-Power electronics(N129/1)	√	√	√	√		ACT1465,ACT1466	SP1544,SP1545,SP1546,SP1547	CD0735, CD0736	√
E-Class	207	Body	BMS-Battery management system(N82/2)	√	√	√	√		ACT1467,ACT1468,ACT1469,ACT1470,ACT1471	SP1548	CD0737	√
E-Class	207	Drive	N3/10-Motor electronics "ME97" for combustion engine "M272"	√	√	√	√	√	ACT1395,ACT1396,ACT1397,ACT1398,ACT1399,ACT1400,ACT1401,ACT1402,ACT1403,ACT1404,ACT1405,ACT1406,ACT1407,ACT1408,ACT1409	SP1513,SP1514,SP1515,SP1516,SP1517,SP1518,SP1519,SP1520,SP1521	CD0702, CD0703, CD0704, CD0705, CD0706, CD0707, CD0708, CD0709	√
E-Class	207	Drive	N3/10-Motor electronics "MED177" for combustion engine "M276"	√	√	√	√	√	ACT0802,ACT0803,ACT0804,ACT0805,ACT0806,ACT0807,ACT0808,ACT0809,ACT0810,ACT0811,ACT0812,ACT0813,ACT0814,ACT0815,ACT0816,ACT0817,ACT0818,ACT0819,	SP1335,SP1336,SP1337,SP1338,SP1339,SP1340,SP1341,SP1342,SP1343,SP1344,SP1345,SP1346,SP1347,SP1348	CD0544, CD0545, CD0546, CD0547, CD0548, CD0549, CD0550, CD0551, CD0552	√
E-Class	207	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√	ACT0821,ACT0822,ACT0823,ACT0824,ACT0825,ACT0826,ACT0827,ACT0828,ACT0829,ACT0830,ACT0831,ACT0832,ACT0833,ACT0834,ACT0835,ACT0836,ACT0837,ACT0838,	SP1349,SP1350,SP1351,SP1352,SP1353,SP1354,SP1355,SP1356,SP1357,SP1358,SP1359,SP1360,SP1361,SP1362,SP1363,SP1364	CD0553, CD0554, CD0555, CD0556, CD0557, CD0558, CD0559, CD0560, CD0561	√
E-Class	207	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	√	√	√	√	√	ACT0508,ACT0509,ACT0510,ACT0511,ACT0512,ACT0513,ACT0514,ACT0515,ACT0516,ACT0517,ACT0518,ACT0519,ACT0520,ACT0521,ACT0522,ACT0523,ACT0524,ACT0525,	SP1133,SP1134,SP1135,SP1136,SP1137,SP1138,SP1139,SP1140,SP1141,SP1142,SP1143,SP1144,SP1145,SP1146,SP1147,SP1148	CD0435, CD0436, CD0437, CD0438, CD0439, CD0440, CD0441, CD0442, CD0443	√
E-Class	207	Drive	N3/10-Motor electronics "MED97" for combustion engine "M272"	√	√	√	√	√	ACT1410,ACT1411,ACT1412,ACT1413,ACT1414,ACT1415,ACT1416,ACT1417,ACT1418,ACT1419,ACT1420,ACT1421,ACT1422,ACT1423,ACT1424,	SP1522,SP1523,SP1524,SP1525,SP1526,SP1527	CD0710, CD0711, CD0712, CD0713, CD0714, CD0715, CD0716, , CD0717, CD0718	√

E-Class	207	Drive	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"	√	√	√	√	√	ACT1023,ACT1024,ACT1025,ACT1026,ACT1027,ACT1028,ACT1029,ACT1030,ACT1031,ACT1032,ACT1033,ACT1034,ACT1035,ACT1036,ACT1037,ACT1038,ACT1039,ACT1040,	SP1382,SP1383,SP1384,SP1385,SP1386,SP1387,SP1388,SP1389	CD0587, CD0588, CD0589, CD0590, CD0591, CD0592, CD0593, CD0594, CD0595, CD0596	√
E-Class	212	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√	√	ACT0000,ACT0001,ACT0002,ACT0003,ACT0004,ACT0005,ACT0006,ACT0007,ACT0008,ACT0009,ACT0010,ACT0011,ACT0012,ACT0013,ACT0014,ACT0015,ACT0016,ACT0017,ACT0018,ACT0019,ACT0020,ACT0021,ACT0022,ACT0023,ACT0024,ACT0025,ACT0026	SP1000,SP1001,SP1002,SP1003,SP1004,SP1005,SP1006,SP1007,SP1008,SP1009,SP1010,SP1011,SP1012,SP1013,SP1014,SP1015,SP1016,SP1017,SP1018,SP1019,SP1020,SP1021,SP1022,SP1023,SP1024	CD0304, CD0305, CD0306, CD0307	√
E-Class	212	Drive	N3/9-Motor electronics "CR43" for combustion engine "OM651"	√	√	√	√	√	ACT0543,ACT0544,ACT0545,ACT0546,ACT0547,ACT0548,ACT0549,ACT0550,ACT0551,ACT0552,ACT0553,ACT0554,ACT0555,ACT0556,ACT0557,ACT0558	SP1164,SP1165,SP1166,SP1167,SP1168,SP1169,SP1170,SP1171,SP1172,SP1173,SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1180,SP1181,SP1182,SP1183,SP1184,	CD0453, CD0454, CD0455, CD0456	√
E-Class	212	Drive	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"	√	√	√	√	√	ACT0559,ACT0560,ACT0561,ACT0562,ACT0563,ACT0564,ACT0565,ACT0566,ACT0567,ACT0568,ACT0569,ACT0570,	SP1187,SP1188,SP1189,SP1190,SP1191,SP1192,SP1193,SP1194,SP1195,SP1196,SP1197,SP1198,SP1199,SP1200,SP1201,SP1202,SP1203,SP1204,	CD0457, CD0458, CD0459, CD0460	√
E-Class	212	Drive	N3/9-Motor electronics "CDI61" for combustion engine "OM642"	√	√	√	√	√	ACT0571,ACT0572,ACT0573,ACT0574,ACT0575,ACT0576,ACT0577,ACT0578,ACT0579,ACT0580,ACT0581,ACT0582,ACT0583	SP1206,SP1207,SP1208,SP1209,SP1210,SP1211,SP1212,SP1213,SP1214,SP1215,SP1216,SP1217,SP1218,SP1219,SP1220,SP1221,SP1222,SP1223,SP1224,SP1225,SP1226,	CD0461, CD0462, CD0463, CD0464	√
E-Class	212	Drive	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"	√	√	√	√	√	ACT1472,ACT1473,ACT1474,ACT1475,ACT1476,ACT1477,ACT1478,ACT1479,ACT1480,ACT1481	SP1549,SP1550,SP1551,SP1552,SP1553,SP1554,SP1555,SP1556,SP1557,SP1558,SP1559,SP1560,SP1561,SP1562,SP1563,SP1564,SP1565,SP1566,	CD0738, CD0739, CD0740	√
E-Class	212	Drive	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"	√	√	√	√	√	ACT1216,ACT1217,ACT1218,ACT1219,ACT1220,ACT1221,ACT1222,ACT1223,ACT1224,ACT1225,ACT1226	SP1466,SP1467,SP1468,SP1469,SP1470,SP1471,SP1472,SP1473,SP1474,SP1475,SP1476,SP1477,	CD0654, CD0655, CD0656	√

E-Class	212	Drive	N3/9-Motor electronics "CDID2" for combustion engine "OM651"	√	√	√	√	√	ACT1245,ACT1246,ACT1247,ACT1248,ACT1249,ACT1250,ACT1251,ACT1252,ACT1253,ACT1254,ACT1255,ACT1256,ACT1257,ACT1258,ACT1259,ACT1260,ACT1261,ACT1262,ACT1263,ACT1264,ACT1265,		CD0659, CD0660, CD0661, CD0662	√
E-Class	212	Drive	N3/9-Motor electronics "CR42" for combustion engine "OM651"	√	√	√	√	√	ACT1187,ACT1188,ACT1189,ACT1190,ACT1191,ACT1192,ACT1193,ACT1194,ACT1195,ACT1196,ACT1197,ACT1198,ACT1199,ACT1200,ACT1201,ACT1202,ACT1203,ACT1204,	SP1432,SP1433,SP1434,SP1435,SP1436,SP1437,SP1438,SP1439,SP1440,SP1441,SP1442,SP1443,SP1444,SP1445,SP1446,SP1447,SP1448,SP1449,	CD0648, CD0649, CD0650	√
E-Class	212	Drive	N15/3The fault occurs when charging of the fuel injector takes too long.5	√	√	√	√	√	ACT1393,ACT1394	SP1506,SP1507,SP1508,SP1509,SP1510,SP1511,SP1512	CD0699, CD0700, CD0701	√
E-Class	212	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√	ACT0584,ACT0585	SP1229,SP1230,SP1231,SP1232,SP1233,SP1234,SP1235,SP1236,SP1237,SP1237,SP1238,SP1239,SP1240,SP1241,SP1242,	CD0465, CD0466, CD0467, CD0468	√
E-Class	212	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7	√	√	√	√	√	ACT0586	SP1244,SP1245,SP1246,SP1247,SP1248,SP1249,SP1250,SP1250,SP1251,SP1252,SP1253,SP1254,	CD0469, CD0470, CD0471, CD0472, CD0473	√
E-Class	212	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√	ACT0587,ACT0588,ACT0589	SP1256,SP1257,SP1258,SP1259,SP1260,SP1261	CD0474, CD0475, CD0476, CD0477, CD0478	√
E-Class	212	Information and communication	Left front short range radar	√	√	√	√					√
E-Class	212	Information and communication	Left front short range radar	√								√
E-Class	212	Information and communication	AVE H-Rear audio video unit	√	√	√	√		ACT0610,ACT0611,ACT0612,ACT0613,ACT0614		CD0490, CD0491, CD0492, CD0493, CD0494	√
E-Class	212	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√
E-Class	212	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√
E-Class	212	Body	CGW-Central gateway	√	√	√	√			SP1366		√
E-Class	212	Information and communication	IC-Instrument cluster	√	√	√	√		ACT0050,ACT0051,ACT0052,ACT0053,ACT0054,ACT0055,	SP1047,SP1048		√
E-Class	212	Information and communication	KOMO-Communication module Telematics services	√	√	√	√		ACT0057,ACT0058,ACT0059,ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065,			√
E-Class	212	Information and communication	TS-Telematic system(N123/4)	√	√	√	√		ACT0075,ACT0076,ACT0077,ACT0078			√
E-Class	212	Body	EZS-Electronic ignition switch	√	√	√	√			SP1051,SP1052,SP1053	CD0320, CD0321, CD0322, CD0323, CD0324	
E-Class	212	Body	EZS-Electronic ignition switch	√	√	√	√					
E-Class	212	Body	EZS-Electronic ignition lock	√	√	√	√				CD0325	
E-Class	212	Body	EZS-Electronic ignition lock	√	√	√	√					

E-Class	212	Body	EZS-Electronic ignition lock	√	√	√	√					
E-Class	212	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084			√
E-Class	212	Body	SCCM-Steering column module(N80)	√	√	√	√		ACT0841,ACT0842,ACT0843,ACT0844,ACT0845			√
E-Class	212	Chassis	AMG DRVU-AMG DRIVE UNIT(N145)	√	√	√	√		ACT0085,ACT0086,ACT0087			√
E-Class	212	Chassis	ESP- Electric stability program	√	√	√	√	√	ACT0847,ACT0848,ACT1269,ACT0849,ACT0850	SP1493,SP1368		√
E-Class	212	Chassis	ESP-Electronic stability program(N30/4)	√	√	√	√	√	ACT0088,ACT0089,ACT1436	SP1537,SP1280		√
E-Class	212	Chassis	ESP-Regenerative braking system(N30/6)	√	√	√	√	√	ACT0624,ACT0625,ACT0626	SP1282,SP1283,SP1284,SP1285,SP1286,SP1287	CD0499, CD0500, CD0501, CD0502	√
E-Class	212	Information and communication	NAV-Navigation module(A2/30)	√	√	√	√		ACT0090,ACT0091,ACT0092,ACT0093			√
E-Class	212	Information and communication	Audio-Audio or COMAND	√	√	√	√					
E-Class	212	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
E-Class	212	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√			SP1288,SP1289,SP1290,SP1291		√
E-Class	212	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1292,SP1293,SP1294,SP1295,SP1296		√
E-Class	212	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1297,SP1293,SP1294,SP1296		√
E-Class	212	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0100,ACT0099	SP1056,SP1409		√
E-Class	212	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√				√
E-Class	212	Body	SRS-Supplemental restraint	√	√	√	√	√				√
E-Class	212	Air conditioning	LRH-Steering wheel heater	√	√	√	√		ACT1482			√
E-Class	212	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√		ACT0101,ACT0102,ACT0103,ACT0104,ACT0105,ACT0106,ACT0107,ACT0108,ACT0109,ACT0110,ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,ACT0117,ACT0118,ACT0119,ACT0120,ACT0121,ACT0118,ACT0119,ACT0120,ACT0119,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0111,ACT0112,ACT0113,ACT0118,ACT0116,ACT0117,ACT0102,ACT0103,ACT0127,ACT0128,ACT0101,	SP1057,SP1058,SP1059,SP1060,SP1061		
E-Class	212	Information and communication	Audio-Audio or COMAND	√	√	√	√					

E-Class	212	Information and communication	Audio-Audio or COMAND	√	√	√			ACT1102,ACT1103,ACT1104,ACT1105,ACT1106,ACT1107,ACT1108,ACT1109,ACT1110,ACT1111,ACT1112,ACT1113,ACT1114,ACT1115,ACT1116,ACT1117,ACT1118,ACT1119,ACT1120,ACT1121,ACT1112,ACT1113,ACT1114,ACT1115,ACT1117,ACT1118,ACT1122,ACT1123,ACT1124,ACT1103,ACT1104,ACT1125,ACT1126,ACT1102,ACT1105,ACT1106,ACT1107,ACT1110,ACT1119,	SP1410,SP1411,SP1412	CD0619, CD0620, CD0621, CD0622, CD0623, CD0624, CD0625, CD0626, CD0627, CD0628, CD0629, CD0630, CD0631	
E-Class	212	Driver assistance system	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)	√	√	√	√		ACT0132	SP1062		√
E-Class	212	Seats and Doors	PPAMKS-Pneumatic pump for active multicontour seat	√	√	√	√		ACT0628,ACT0629,ACT0630			√
E-Class	212	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√		ACT0631,ACT0632,ACT0633,ACT0634,ACT0635			√
E-Class	212	Seats and Doors	AMKS LF-Active multicontour seat(N32/19)	√	√	√	√		ACT1483,ACT1484,ACT1485,ACT1486,ACT1487,ACT1488			√
E-Class	212	Driver assistance system	CAMERA-360 camera(N148)	√	√	√	√		ACT0644	SP1298,SP1299,SP1300		√
E-Class	212	Driver assistance system	CAMERA-360 camera(N148)	√	√	√	√		ACT0542	SP1158,SP1159,SP1160,SP1161,SP1162,SP1163		√
E-Class	212	Seats and Doors	AMKS RF-Active multicontour seat(N32/22)	√	√	√	√		ACT1489,ACT1490,ACT1491,ACT1492,ACT1493,ACT1494			√
E-Class	212	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					
E-Class	212	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					√
E-Class	212	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					
E-Class	212	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					√
E-Class	212	Body	Multifunction control unit-Multifunction control unit	√	√	√	√		ACT0133,ACT0134,ACT0135,ACT0136,ACT0137,ACT0138,ACT0139,ACT0140,ACT0141,ACT0142,ACT0143,ACT0144,ACT0145,ACT0146,ACT0147,ACT0148,ACT0149,ACT0150,			√
E-Class	212	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0156,ACT0157			√
E-Class	212	Body	KG-KEYLESS GO	√	√	√	√		ACT0851,ACT0852,ACT0853,ACT0854			
E-Class	212	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0855,ACT0856,ACT0156,ACT0157,ACT0857			√

E-Class	212	Information and communication	SOUND-Sound system	√	√	√	√	ACT0158,ACT0159,ACT0160,ACT0161,ACT0162,ACT0163,ACT0164,ACT0165,ACT0166,ACT0167,ACT0168,ACT0169,ACT0170,ACT0171,ACT0172,ACT0173,ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0179,ACT0180,ACT0181,	CD0348	
E-Class	212	Information and communication	SOUND-Bose sound system	√	√	√	√	ACT0199,ACT0186,ACT0187,ACT0189,ACT0191,ACT0192,ACT0200,ACT0195,ACT0196,ACT0201,ACT0202,ACT0194,ACT0203,ACT0204,ACT0205,ACT0197,ACT0206,ACT0198	SP1063	
E-Class	212	Information and communication	SOUND-Bose sound system	√	√	√	√	ACT0199,ACT0653,ACT0185,ACT0186,ACT0654,ACT0655,ACT0195,ACT0196,ACT0193,ACT0200,ACT0194,ACT0188,ACT0190,ACT0191,ACT0192,ACT0656,ACT0657,ACT0206,		
E-Class	212	Chassis	ELC-Electronic level control	√	√	√	√	ACT1495,ACT1496,ACT1497,ACT1498,ACT1499,ACT1500,	SP1568,SP1569	√
E-Class	212	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	ACT0207,ACT0208,ACT0209,ACT0210	SP1064	√
E-Class	212	Chassis	ADS-Adaptive damping system	√	√	√	√	ACT0858,ACT0859,ACT0860,ACT0861	SP1372	√
E-Class	212	Body	TLC-Trunk lid control	√	√	√	√	ACT1272,ACT1273,ACT1274,ACT1275,ACT1276	SP1495,SP1496	√
E-Class	212	Information and communication	ECS-N123/4 Emergency call system control unit	√	√	√	√	ACT0674,ACT0675,ACT0676		
E-Class	212	Information and communication	TV-TV tuner	√	√	√	√	ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0219,ACT0220,ACT0221,ACT0222,ACT0223		CD0350CD0351, CD0352, CD0353, CD0354, CD0355, CD0356, CD0357, CD0358, CD0359, CD0360, CD0361
E-Class	212	Information and communication	TV-TV tuner	√	√	√	√	ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0677,ACT0233		
E-Class	212	Information and communication	TV-TV tuner	√	√	√	√	ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0230,ACT0231,ACT0232,ACT0233		CD0362CD0363, CD0364, CD0365, CD0366, CD0367, CD0368, CD0369, CD0370, CD0371, CD0372, CD0373
E-Class	212	Driver assistance	MFK-Multifunction camera	√	√	√	√	ACT0234,ACT0235	SP1066	√
E-Class	212	Driver assistance	MFK-Multifunction	√	√	√	√	ACT0236,ACT0237	SP1067,SP1068	√

E-Class	212	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		ACT0238,ACT0241,ACT0678,ACT0862,ACT1278,ACT0245,ACT0239,ACT0240,ACT0251,ACT0253,ACT0254,ACT0685,ACT0686,ACT0687,ACT0688,ACT0691,ACT0692,ACT1280,ACT0693,ACT0694,ACT1279,	SP1069,SP1070,SP1071		√
E-Class	212	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√					
E-Class	212	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√					
E-Class	212	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258		CD0382	
E-Class	212	Air conditioning	STH-Stationary heater	√	√	√	√		ACT0259,ACT0260,ACT1281,ACT1282,ACT1283,ACT1284,ACT1285,ACT0262,ACT1286,			√
E-Class	212	Information and communication	Drive Kit Plus-Drive kit for iPhone	√	√	√	√		ACT0263,ACT0264,ACT0265,ACT0266			
E-Class	212	Information and communication	NAVI20-Navigation(N125/2)	√	√	√	√		ACT0267,ACT0268			
E-Class	212	Chassis	ES-Electric power steering(N68)	√	√	√	√			SP1302		√
E-Class	212	Chassis	ES-Electric power steering(N68)	√	√	√	√			SP1302,SP1303		√
E-Class	212	Body	PSD-Control module 'Panoramic sliding roof'(A98)	√	√	√	√		ACT1288,ACT1289	SP1497		√
E-Class	212	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√		ACT0271			√
E-Class	212	Body	WSS-Weight sensing	√	√	√	√					
E-Class	212	Information and communication	HUD-Head up display	√	√	√	√		ACT0272,ACT0273,ACT0274	SP1077,		
E-Class	212	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√		ACT0275			√
E-Class	212	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√		ACT0865,ACT0866,ACT0867,ACT0868,ACT0869,ACT0870	SP1373,SP1374,SP1375		√
E-Class	212	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√		ACT0865,ACT0866,ACT0867,ACT0868,ACT0869,ACT0870	SP1373,SP1374,SP1375		√
E-Class	212	Information and communication	SDAR-Satellite radio	√	√	√	√		ACT0283,ACT0284,ACT0285,ACT0286		CD0387CD0388, CD0389, CD0389	
E-Class	212	Information and communication	TB5-TV tuner Tuner unit	√	√	√	√		ACT0287,ACT0288,ACT0289,ACT0290,ACT0291,ACT0292,ACT0293,ACT0294,			
E-Class	212	Information and communication	TV tuner (TV)	√	√	√	√		ACT0295,ACT0296,ACT0297,ACT0298,ACT0299,ACT0300,			
E-Class	212	Air conditioning	A9/5 (Electric refrigerant compressor)	√	√	√	√		ACT1437			√
E-Class	212	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√		ACT0871,ACT0872,ACT0873,ACT0874,ACT0875	SP1376,SP1377,		√
E-Class	212	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√		ACT0871,ACT0872,ACT0873,ACT0874,ACT0875	SP1376,SP1377,		√

E-Class	212	Information and communication	MIF-Media interface	√	√	√	√					
E-Class	212	Information and communication	MIF-Media interface	√	√	√	√		ACT0309			
E-Class	212	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√		ACT0711,ACT0712,ACT0713,ACT0714,ACT0715	SP1307,SP1308,SP1309,SP1310,SP1311	CD0527, CD0528, CD0529, CD0530	√
E-Class	212	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√		ACT0711,ACT0712,ACT0713,ACT0714,ACT0715	SP1307,SP1308,SP1309,SP1310,SP1311	CD0527, CD0528, CD0529, CD0530	√
E-Class	212	Body	OCP-Overhead control panel	√	√	√	√		ACT1294,ACT1290,ACT1291,ACT1292	SP1498		√
E-Class	212	Drive	ISM-Shift module	√	√	√	√		ACT0717,ACT0718,ACT0719,ACT0720,ACT0721	SP1312,SP1313,SP1314		√
E-Class	212	Body	TRM-Trailer recognition module (N28/1)	√	√	√	√		ACT0311,ACT0310,ACT0312,ACT0313,ACT1297,ACT0314,ACT0315,ACT0316,ACT1296			√
E-Class	212	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√
E-Class	212	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√		ACT0884,ACT0885,ACT0886,ACT0887,ACT0888,ACT0889,ACT0890,ACT0891			√
E-Class	212	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√
E-Class	212	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√		ACT0723,ACT0724,ACT0725,ACT0726,ACT0727	SP1315,SP1316,SP1317,SP1318,SP1319	CD0531, CD0532, CD0533, CD0534	√
E-Class	212	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√		ACT0723,ACT0724,ACT0725,ACT0726,ACT0727	SP1315,SP1316,SP1317,SP1318,SP1319	CD0531, CD0532, CD0533, CD0534	√
E-Class	212	Drive	FSCU05-Control unit Fuel pump	√	√	√	√		ACT0385			√
E-Class	212	Drive	FSCU-Fuel pump	√	√	√	√		ACT0499			√

E-Class	212	Body	Rear SAM-Rear signal acquisition and actuation module	√	√	√	√	ACT0892,ACT0893,ACT0894,ACT0895,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0901,ACT0902,ACT0903,ACT0904,ACT0905,ACT0906,ACT0907,ACT0908,ACT0909,ACT0910,ACT0911,ACT0912,ACT0913,ACT0914,ACT0915,ACT0916,ACT0917,ACT0918,ACT0919,ACT0920,ACT0921,ACT0922,ACT0923,ACT0924,ACT0925,ACT0926,ACT0927,ACT0928,ACT0929,ACT0892,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0892,ACT0894,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0927,ACT0928,ACT0930,ACT0927,ACT0931,ACT0928,ACT0932,,ACT0933,ACT0934			√
E-Class	212	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√

E-Class	212	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√
E-Class	212	Information and communication	N123 / 4 (emergency call system control unit) - an emergency call	√	√	√	√				
E-Class	212	Driver assistance	DTR-DISTRONIC	√	√	√	√				√
E-Class	212	Driver assistance	DTR-DISTRONIC	√	√	√	√				√
E-Class	212	Seats and Doors	LFD-Left front door	√	√	√	√	ACT0386,ACT0387,ACT0388,ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0398,ACT0994,ACT0397,ACT0400,ACT0401,ACT0402,ACT0403,			√
E-Class	212	Information and communication	N123 / 4 (emergency call system control unit) - Mercedes - Benz (MB) information / fault rescue	√	√	√	√				
E-Class	212	Driver assistance	NSA-Night View Assist(N101)	√	√	√	√	ACT0738,ACT0739,ACT0740	SP1320		√
E-Class	212	Driver assistance	NSA-Night View Assist(N101)	√	√	√	√	ACT1438,ACT0740	SP1320		√
E-Class	212	Seats and Doors	DCU RF-Right front door	√	√	√	√	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410,ACT0411,ACT0412,ACT0413,ACT0414,ACT0415,ACT0417,ACT0996,ACT0416,ACT0419,ACT0420,ACT0421,ACT0422,			√
E-Class	212	Information and communication	TV-TV tuner	√	√	√	√	ACT0424,ACT0425,ACT0426,ACT0427,ACT0222,ACT0428,ACT0219,ACT0221			
E-Class	212	Information and communication	TV-TV tuner	√	√	√	√	ACT0429,ACT0430,ACT0431,ACT0229,ACT0432,ACT0433,			

E-Class	212	Seats and Doors	DCU LR-Left rear door	√	√	√	√		ACT1330,ACT1331,ACT1332,ACT1333,ACT1334,ACT1335,ACT1336,ACT1337,ACT1338,ACT1339,ACT1340,ACT1341,ACT1342,ACT1343,ACT1344,ACT1345,ACT1346,ACT1347,			√
E-Class	212	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258			
E-Class	212	Seats and Doors	DCU RR-Right rear door	√	√	√	√		ACT1351,ACT1352,ACT1353,ACT1354,ACT1355,ACT1356,ACT1357,ACT1358,ACT1359,ACT1360,ACT1361,ACT1362,ACT1363,ACT1364,ACT1365,ACT1366,ACT1367,ACT1368,			√
E-Class	212	Information and communication	N123 / 4 (emergency call system control unit) - the vehicle remote control unlocking / locking the vehicle remote	√	√	√	√					
E-Class	212	Information and communication	N123 / 4 (emergency call system control unit) - anti-theft tracking	√	√	√	√					
E-Class	212	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439,ACT1372	SP1089,SP1088,SP1501	CD0695	√
E-Class	212	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439	SP1089		√
E-Class	212	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439	SP1088,SP1089		√
E-Class	212	Chassis	FGW-Chassis gateway	√	√	√	√				CD0535	√
E-Class	212	Seats and Doors	N25/6 (Rear passenger compartment seat heater control	√	√	√	√		ACT1451,ACT1452			√
E-Class	212	Body	WSS-Weight sensing	√	√	√	√					
E-Class	212	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
E-Class	212	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
E-Class	212	Body	BSN-Battery sensor(B95)	√	√	√	√					
E-Class	212	Body	BSN-Battery sensor(B95)	√	√	√	√					
E-Class	212	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0442,ACT0443,ACT0444,ACT0445,ACT0446			√
E-Class	212	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0447,ACT0448,ACT0449,ACT0450			√
E-Class	212	Drive	CNG-Compressed natural gas	√			√					√
E-Class	212	Drive	N3/10-Motor electronics "CNGCM212" for combustion engine "M271CNG"	√			√		ACT1502,ACT1503,ACT1504,ACT1505,ACT1506,ACT1507,ACT1508			√
E-Class	212	Information and communication	AVE H-Rear audio video unit	√	√	√	√		ACT0610,ACT0611,ACT0612,ACT0789,ACT0613,ACT0614		CD0490, CD0491, CD0492, CD0493, CD0494	√
E-Class	212	Body	SG SW L-Left headlamp	√	√	√	√		ACT0456,ACT0457,ACT0458,ACT0459,ACT0460,ACT0461	SP1094,SP1095,SP1096,SP1097,,SP1098,SP1099,	CD0398	√
E-Class	212	Body	SG SW L-Left headlamp(E1n9)	√	√	√	√		ACT0462,ACT0463,ACT0464,ACT0465,ACT0466,ACT0467	SP1101,SP1102,SP1103,SP1104,SP1105,SP1106,SP1107,SP1108	CD0399	√

E-Class	212	Body	XALWA L-Left xenon headlamp(E1n1)	√	√	√	√		ACT1453,ACT1454,ACT1455,ACT1456,ACT1457,ACT1458	SP1540,SP1541,SP1542		√
E-Class	212	Body	SG SW R-Right headlamp	√	√	√	√		ACT0468,ACT0469,ACT0470,ACT0471,ACT0472,ACT0473	SP1109,SP1110,SP1111,SP1112,SP1113,SP1114	CD0400	√
E-Class	212	Body	SG SW R-Right headlamp(E1n9)	√	√	√	√		ACT0474,ACT0475,ACT0476,ACT0477,ACT0478,ACT0479	SP1115,SP1116,SP1117,SP1118,SP1119,SP1120	CD0401	√
E-Class	212	Body	XALWA R-Right xenon headlamp(E2n1)	√	√	√	√		ACT1459,ACT1460,ACT1461,ACT1462,ACT1463,ACT1464	SP1543		√
E-Class	212	Information and communication	ICI-InCar Internet(N125/3)	√	√	√	√		ACT1386,ACT1387,ACT1388			
E-Class	212	Drive	N15/5 (Electronic selector lever module control unit)	√	√	√	√		ACT1002,ACT1003,ACT1004			√
E-Class	212	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
E-Class	212	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
E-Class	212	Body	FSW-Windshield wiper	√	√	√	√		ACT1005,			
E-Class	212	Body	FSW-Windshield wiper	√	√	√	√		ACT1005,			
E-Class	212	Body	GTO-Garage door	√	√	√	√					
E-Class	212	Body	GTO-Garage door	√	√	√	√					
E-Class	212	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√					
E-Class	212	Information and communication	CTEL-Mobile phone	√	√	√	√		ACT1390,ACT1391			
E-Class	212	Driver assistance	PARK-Parking system (N62)	√	√	√	√		ACT0484,ACT0485		CD0411, CD0412	√
E-Class	212	Driver assistance system	PTS-Parktronic system	√	√	√	√		ACT1006		CD0536, CD0537, CD0538, CD0539	√
E-Class	212	Body	Hazard warning light system	√	√	√	√					
E-Class	212	Body	Exterior lights switch	√	√	√	√					
E-Class	212	Body	UCP-Upper control panel	√	√	√	√					
E-Class	212	Body	UCP-Upper control panel	√	√	√	√					
E-Class	212	Body	LCP-Lower control panel	√	√	√	√					
E-Class	212	Body	LCP-Lower control panel	√	√	√	√					
E-Class	212	Body	AU-Analog clock	√	√	√	√					
E-Class	212	Information and communication	DSI-DIRECT SELECT interface(N150)	√	√	√	√		ACT0488			√
E-Class	212	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT1007			
E-Class	212	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT1007			
E-Class	212	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√		ACT1008,ACT1009			
E-Class	212	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√		ACT0794,ACT0795	SP1325,SP1326,SP1327	CD0540	
E-Class	212	Body	AMLAB L 2-Actuation module 2, LED exterior lighting, left	√	√	√	√		ACT0796,ACT0797	SP1328,SP1329,SP1330	CD0541	
E-Class	212	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√		ACT0798,ACT0799	SP1331,SP1332	CD0542	
E-Class	212	Body	AMLAB R 2-Actuation module 2, LED exterior lighting, right front(E2n8)	√	√	√	√		ACT0800,ACT0801	SP1333,SP1334	CD0543	

E-Class	212	Drive	FSCU-Fuel pump	√	√	√	√		ACT0498,ACT0499		CD0427, CD0428	√
E-Class	212	Drive	SCR-Selective Catalytic Reduction	√	√	√	√		ACT0590,ACT0591,ACT0592,ACT0593,ACT0594,ACT0595,ACT0596,ACT0597,ACT0598,	SP1262,SP1263,SP1264,SP1265,SP1266,SP1267	CD0479, CD0480, CD0481, CD0482	√
E-Class	212	Drive	SCR-Selective catalytic reduction	√	√	√	√		ACT0600,ACT0601,ACT0602,ACT0603,ACT0604,ACT0605	SP1268,SP1269,SP1270,SP1271,SP1272,SP1273	CD0483, CD0484, CD0485	√
E-Class	212	Drive	PE-Power electronics(N129/1)	√	√	√	√		ACT1465,ACT1466	SP1544,SP1545,SP1546,SP1547	CD0735, CD0736	√
E-Class	212	Body	BMS-Battery management system(N82/2)	√	√	√	√		ACT1467,ACT1468,ACT1471	SP1570,SP1571		√
E-Class	212	Body	BMS-Battery management system(N82/2)	√	√	√	√		ACT1467,ACT1468,ACT1469,ACT1470,ACT1471	SP1548	CD0737	√
E-Class	212	Drive	N3/10-Motor electronics "ME97" for combustion engine "M272"	√	√	√	√	√	ACT1395,ACT1396,ACT1397,ACT1398,ACT1399,ACT1400,ACT1401,ACT1402,ACT1403,ACT1404,ACT1405,ACT1406,ACT1407,ACT1408,ACT1409	SP1513,SP1514,SP1515,SP1516,SP1517,SP1518,SP1519,SP1520,SP1521	CD0702, CD0703, CD0704, CD0705, CD0706, CD0707, CD0708, CD0709	√
E-Class	212	Drive	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"	√	√	√	√	√	ACT1058,ACT1059,ACT1060,ACT1061,ACT1062,ACT1063,ACT1064,ACT1065,ACT1066,ACT1067,ACT1068,ACT1069,ACT1070,ACT1071,ACT1072,ACT1073,ACT1074,ACT1075,	SP1390,SP1391,SP1392,SP1393,SP1394,SP1395	CD0601, CD0602, CD0603, CD0604, CD0605, CD0606, CD0607, CD0608	√
E-Class	212	Drive	N3/10-Motor electronics "MED177" for combustion engine "M276"	√	√	√	√	√	ACT0802,ACT0803,ACT0804,ACT0805,ACT0806,ACT0807,ACT0808,ACT0809,ACT0810,ACT0811,ACT0812,ACT0813,ACT0814,ACT0815,ACT0816,ACT0817,ACT0818,ACT0819,	SP1335,SP1336,SP1337,SP1338,SP1339,SP1340,SP1341,SP1342,SP1343,SP1344,SP1345,SP1346,SP1347,SP1348	CD0544, CD0545, CD0546, CD0547, CD0548, CD0549, CD0550, CD0551, CD0552	√
E-Class	212	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√	ACT0821,ACT0822,ACT0823,ACT0824,ACT0825,ACT0826,ACT0827,ACT0828,ACT0829,ACT0830,ACT0831,ACT0832,ACT0833,ACT0834,ACT0835,ACT0836,ACT0837,ACT0838,	SP1349,SP1350,SP1351,SP1352,SP1353,SP1354,SP1355,SP1356,SP1357,SP1358,SP1359,SP1360,SP1361,SP1362,SP1363,SP1364	CD0553, CD0554, CD0555, CD0556, CD0557, CD0558, CD0559, CD0560, CD0561	√
E-Class	212	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	√	√	√	√	√	ACT0508,ACT0509,ACT0510,ACT0511,ACT0512,ACT0513,ACT0514,ACT0515,ACT0516,ACT0517,ACT0518,ACT0519,ACT0520,ACT0521,ACT0522,ACT0523,ACT0524,ACT0525,	SP1133,SP1134,SP1135,SP1136,SP1137,SP1138,SP1139,SP1140,SP1141,SP1142,SP1143,SP1144,SP1145,SP1146,SP1147,SP1148	CD0435, CD0436, CD0437, CD0438, CD0439, CD0440, CD0441, CD0442, CD0443	√
E-Class	212	Drive	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"	√	√	√	√	√	ACT1509,ACT1510,ACT1511,ACT1512,ACT1513,ACT1514,ACT1515,ACT1516,ACT1517,ACT1518,ACT1519,ACT1520,ACT1521,ACT1522,ACT1523,ACT1524,ACT1525,ACT1526,ACT1527,ACT1528,ACT1529,	SP1572,SP1573,SP1574,SP1575,SP1576,SP1577,SP1578,SP1579,SP1580,SP1581,SP1582,SP1583,SP1584,SP1585	CD0741, CD0742, CD0743, CD0744, CD0745, CD0746, CD0747, CD0748, CD0749, CD0750, CD0751, CD0752	√

E-Class	212	Drive	N3/10-Motor electronics "MED97" for combustion engine "M272"	√	√	√	√	√	ACT1410,ACT1411,ACT1412,ACT1413,ACT1414,ACT1415,ACT1416,ACT1417,ACT1418,ACT1419,ACT1420,ACT1421,ACT1422,ACT1423,ACT1424,	SP1522,SP1523,SP1524,SP1525,SP1526,SP1527	CD0710, CD0711, CD0712, CD0713, CD0714, CD0715, CD0716, , CD0717, CD0718	√
E-Class	212	Drive	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"	√	√	√	√	√	ACT1023,ACT1024,ACT1025,ACT1026,ACT1027,ACT1028,ACT1029,ACT1030,ACT1031,ACT1032,ACT1033,ACT1034,ACT1035,ACT1036,ACT1037,ACT1038,ACT1039,ACT1040,	SP1382,SP1383,SP1384,SP1385,SP1386,SP1387,SP1388,SP1389	CD0587, CD0588, CD0589, CD0590, CD0591, CD0592, CD0593, CD0594, CD0595, CD0596	√
E-Class	212	Drive	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"	√	√	√	√	√	ACT1532,ACT1533,ACT1534,ACT1535,ACT1536,ACT1537,ACT1538,ACT1539,ACT1540,ACT1541,ACT1542,ACT1543,ACT1544,ACT1545,ACT1546,ACT1547,ACT1548,ACT1549	SP1586,SP1587,SP1588,SP1589,SP1590,SP1591,SP1592,SP1593,SP1594,SP1595,SP1596	CD0753, CD0754, CD0755, CD0756, CD0757, CD0758, CD0759, CD0760, CD0761, CD0762, CD0763, CD0764	√
E-Class	213	Drive	N3/9-Motor electronics "CDI61" for combustion engine "OM642"	√	√	√	√	√				
E-Class	213	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√				
E-Class	213	Drive	CDI-Motor electronics CR61 for combustion engine OM642	√	√	√	√	√				
E-Class	213	Drive	N15/15n4 (Fully integrated transmission control unit)	√	√	√	√	√				
E-Class	213	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√				
E-Class	213	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√				
E-Class	213	Seats and Doors	LFD-Left front door	√	√	√	√	√				
E-Class	213	Seats and Doors	LFD-Left front door	√	√	√	√	√				
E-Class	213	Seats and Doors	DCU RF-Right front door	√	√	√	√	√				
E-Class	213	Seats and Doors	DCU RF-Right front door	√	√	√	√	√				
E-Class	213	Seats and Doors	DCU LR-Left rear door	√	√	√	√	√				
E-Class	213	Seats and Doors	DCU LR-Left rear door	√	√	√	√	√				
E-Class	213	Seats and Doors	DCU RR-Right rear door	√	√	√	√	√				
E-Class	213	Seats and Doors	DCU RR-Right rear door	√	√	√	√	√				
E-Class	213	Body	SRS-Supplemental restraint	√	√	√	√	√				
E-Class	213	Information and communication	CTEL-Cellular telephone	√	√	√	√	√				
E-Class	213	Body	EZS-Electronic ignition lock	√	√	√	√	√				
E-Class	213	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	√				
E-Class	213	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√	√				
E-Class	213	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√	√				

E-Class	213	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
E-Class	213	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
E-Class	213	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√					
E-Class	213	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√					
E-Class	213	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√					
E-Class	213	Seats and Doors	ESE_RL-Left rear electrical seat adjustment	√	√	√	√					
E-Class	213	Seats and Doors	Right rear ESE-Right rear electrical seat adjustment	√	√	√	√					
E-Class	213	Information and communication	HERMES-control unit for telematics services	√	√	√	√					
E-Class	213	Information and communication	MTAS FO-Mobile phone cradle in rear passenger compartment	√	√	√	√					
E-Class	213	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
E-Class	213	Information and communication	MTAS FO-Mobile phone cradle in rear passenger compartment	√	√	√	√					
E-Class	213	Seats and Doors	MKS LF-Left front multicontour	√	√	√	√					
E-Class	213	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√					
E-Class	213	Seats and Doors	MKS LF-Left rear multicontour	√	√	√	√					
E-Class	213	Seats and Doors	MKS RF-Right rear multicontour	√	√	√	√					
E-Class	213	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
E-Class	213	Seats and Doors	HKS-Tailgate control	√	√	√	√					
E-Class	213	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√					
E-Class	213	Body	Trailer recognition module-Trailer recognition	√	√	√	√					
E-Class	213	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
E-Class	213	Body	PSD-Panoramic sliding roof	√	√	√	√					
E-Class	213	Body	AML-Ambiance light	√	√	√	√					
E-Class	213	Body	KG-Keyless Go	√	√	√	√					
E-Class	213	Body	OCP-Overhead control panel	√	√	√	√					
E-Class	213	Body	DC/DC-DC/DC converter	√	√	√	√					
E-Class	213	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					
E-Class	213	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	√					
E-Class	213	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√					
E-Class	213	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√					

E-Class	213	Information and communication	AVE H-Controller unit Rear entertainment system	√	√	√	√					
E-Class	213	Information and communication	SG MSND-Engine sound	√	√	√	√					
E-Class	213	Body	LRE-Steering wheel electronics	√	√	√	√					
E-Class	213	Body	LRE-Steering wheel electronics	√	√	√						
E-Class	213	Information and communication	TSC H-Touchscreen in rear passenger compartment	√	√	√	√					
E-Class	213	Information and communication	TPAD-Touchpad	√	√	√	√					
E-Class	213	Information and communication	TPAD-Touchpad	√	√	√	√					
E-Class	213	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
E-Class	213	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
E-Class	213	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
E-Class	213	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
E-Class	213	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
E-Class	213	Information and communication	Audio-Audio or COMAND	√	√	√						
E-Class	213	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
E-Class	213	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√					
E-Class	213	Body	BMS-Battery management system	√	√	√	√					
E-Class	213	Body	BMS-Battery management system	√	√	√	√					
E-Class	213	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
E-Class	213	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
E-Class	213	Information and communication	MTAS-Mobile phone cradle	√	√	√						
E-Class	213	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
E-Class	213	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
E-Class	213	Information and communication	IC-Instrument cluster	√	√	√	√			SP1047,SP1048,SP1157		
E-Class	213	Information and communication	IC-Instrument cluster(A1)	√	√	√	√					
E-Class	213	Information and communication	HUD-Head up display	√	√	√						
E-Class	213	Information and communication	HUD-Head up display	√	√	√	√					
E-Class	213	Driver assistance	RFK-Backup camera	√	√	√	√					

E-Class	213	Driver assistance	RFK-Backup camera	√	√	√	√					
E-Class	213	Driver assistance	KAR-Augmented reality camera	√	√	√	√					
E-Class	213	Drive	EAGGS-Electric differential lock	√	√	√	√					
E-Class	213	Body	AMLA-Active engine mount	√	√	√	√					
E-Class	213	Chassis	AMG DRVU-AMG DRIVE	√	√	√	√					
E-Class	213	Chassis	AMG DRVU-AMG DRIVE	√	√	√	√					
E-Class	213	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√					
E-Class	213	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√					
E-Class	213	Body	SG SW L-Left headlamp	√	√	√	√					
E-Class	213	Body	SG SW L-Left headlamp	√	√	√	√					
E-Class	213	Body	SG SW L-Left headlamp	√	√	√	√					
E-Class	213	Body	SG SW R-Right headlamp	√	√	√	√					
E-Class	213	Body	SG SW R-Right headlamp	√	√	√	√					
E-Class	213	Body	SG SW R-Right headlamp	√	√	√	√					
E-Class	213	Driver assistance	TPM-Tire pressure monitor(N88)	√	√	√	√					
E-Class	213	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
E-Class	213	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√					
E-Class	213	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√					
E-Class	213	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√					
E-Class	213	Body	DCCU-Direct current charge connection unit	√	√	√	√					
E-Class	213	Drive	HFPM-Haptic accelerator pedal module	√	√	√	√					
E-Class	213	Body	SG LG-Charger	√	√	√	√					
E-Class	213	Body	SG LG-Charger	√	√	√	√					
E-Class	213	Body	GES-Hand motion sensor	√	√	√	√					
E-Class	213	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
E-Class	213	Body	BSN-Battery sensor(B95)	√	√	√	√					
E-Class	213	Body	LIB-Lithium ion battery	√	√	√	√					
E-Class	213	Body	LIB-Lithium ion battery	√	√	√	√					
E-Class	213	Body	AU-Analog clock	√	√	√	√					
E-Class	213	Body	Button group, instrument panel, driver side	√	√	√	√					
E-Class	213	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
E-Class	213	Body	FSW-Windshield wiper	√	√	√	√					
E-Class	213	Body	GTO-Garage door	√	√	√	√					
E-Class	213	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√					
E-Class	213	Body	"Front passenger" seat heater	√	√	√	√					
E-Class	213	Body	"Driver" seat heater	√	√	√	√					
E-Class	213	Body	N5 (Armrest heater control unit)	√	√	√	√					

E-Class	213	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√					
E-Class	213	Seats and Doors	LFD-Left front door	√	√	√						
E-Class	213	Seats and Doors	LFD-Left front door	√	√	√						
E-Class	213	Seats and Doors	LFD-Left front door	√	√	√						
E-Class	213	Seats and Doors	DCU RF-Right front door	√	√	√						
E-Class	213	Seats and Doors	DCU RF-Right front door	√	√	√						
E-Class	213	Seats and Doors	DCU RF-Right front door	√	√	√						
E-Class	213	Seats and Doors	DCU LR-Left rear door	√	√	√						
E-Class	213	Seats and Doors	DCU LR-Left rear door	√	√	√						
E-Class	213	Seats and Doors	DCU LR-Left rear door	√	√	√						
E-Class	213	Seats and Doors	DCU RR-Right rear door	√	√	√						
E-Class	213	Seats and Doors	DCU RR-Right rear door	√	√	√						
E-Class	213	Seats and Doors	DCU RR-Right rear door	√	√	√						
E-Class	213	Body	"Driver" seat heater	√	√	√	√					
E-Class	213	Body	"Front passenger" seat heater	√	√	√	√					
E-Class	213	Seats and Doors	Seat heater in left rear passenger compartment	√	√	√	√					
E-Class	213	Seats and Doors	Seat heater in right rear passenger compartment	√	√	√	√					
E-Class	213	Body	AS-Alarm siren(H3/1)	√	√	√	√					
E-Class	213	Seats and Doors	Massage function in left front seat	√	√	√	√					
E-Class	213	Seats and Doors	MFSF-LF	√	√	√	√					
E-Class	213	Seats and Doors	Massage function in right front	√	√	√	√					
E-Class	213	Seats and Doors	MFSF-RF	√	√	√	√					
E-Class	213	Seats and Doors	Massage function in left rear seat	√	√	√	√					
E-Class	213	Seats and Doors	Massage function in right rear	√	√	√	√					
E-Class	213	Air conditioning	N61 (Windshield heater control	√	√	√						
E-Class	213	Air conditioning	AAC-Automatic air conditioning	√	√	√						
E-Class	213	Air conditioning	STH-Stationary heater	√	√	√	√					
E-Class	213	Air conditioning	AAC-Automatic air conditioning	√	√	√						
E-Class	213	Air conditioning	AAC-Automatic air conditioning	√	√	√						
E-Class	213	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√					
E-Class	213	Body	SCM-Steering column	√	√	√	√					
E-Class	213	Information and communication	N72/1 (Upper control panel control unit)	√	√	√						
E-Class	213	Information and communication	N72/5 (Right lower control panel)	√	√	√						
E-Class	213	Information and communication	N72/4 (Left lower control panel)	√	√	√						
E-Class	213	Body	WSS-Weight sensing	√	√	√	√					
E-Class	213	Body	N38 (Rear switching module)	√	√	√	√					
E-Class	213	Body	LIB-Lithium ion battery	√	√	√	√					
E-Class	213	Information and communication	TV tuner (TV)	√	√	√	√					

E-Class	213	Information and communication	TV tuner (TV)	√	√	√	√				
E-Class	213	Information and communication	TV tuner (TV)	√	√	√	√				
E-Class	213	Information and communication	TV tuner (TV)	√	√	√	√				
E-Class	213	Information and communication	SOUND-Sound system	√	√	√	√				
E-Class	213	Information and communication	SOUND-Sound system	√	√	√	√				
E-Class	213	Information and communication	DAB-Digital radio Tuner unit	√	√	√	√				
E-Class	213	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√				
E-Class	213	Driver assistance	DTR-DISTRONIC	√	√	√	√				
E-Class	213	Driver assistance	SGR-Radar sensors control unit	√	√	√	√				
E-Class	213	Driver assistance	DTR-DISTRONIC	√	√	√	√				
E-Class	213	Driver assistance	DTR-DISTRONIC	√	√	√	√				
E-Class	213	Driver assistance	PTS-PARKTRONIC	√	√	√	√				
E-Class	213	Chassis	ELC-Electronic level control	√	√	√	√				
E-Class	213	Chassis	ADS-Adaptive damping system	√	√	√	√				
E-Class	213	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√				
E-Class	213	Chassis	ES - Electric power steering	√	√	√	√				
E-Class	213	Chassis	ES - Electric power steering	√	√	√	√				
E-Class	213	Body	LRE-Steering wheel electronics	√	√	√	√				
E-Class	213	Chassis	AIRmatic-AIRmatic PLUS	√	√	√	√				
E-Class	213	Drive	VG-All-wheel drive	√	√	√	√				
E-Class	213	Body	STM-Mirror taximeter	√	√	√	√				
E-Class	213	Driver assistance	NBR LF-Left front short range	√	√	√	√				
E-Class	213	Driver assistance system	NBR RF-Right front short range radar	√	√	√	√				
E-Class	213	Driver assistance	NBR RR-Right rear short-range	√	√	√	√				
E-Class	213	Driver assistance	NBR LR-Left rear short-range	√	√	√	√				
E-Class	213	Chassis	ESP-Electric stability	√	√	√	√	√			
E-Class	213	Chassis	ESP-Electric stability	√	√	√	√	√			
E-Class	213	Chassis	ESP-Electric stability	√	√	√	√				
E-Class	213	Drive	FSCU-Control unit Fuel pump	√	√	√	√				
E-Class	213	Drive	SCR-Selective catalytic reduction	√	√	√	√				
E-Class	213	Drive	SCR-Selective catalytic reduction	√	√	√	√				
E-Class	213	Air conditioning	SCR-Selective catalytic reduction	√	√	√	√				
E-Class	213	Drive	N127 (Drivetrain control unit)	√	√	√	√				
E-Class	213	Drive	N127 (Drivetrain control unit)	√	√	√	√				
E-Class	213	Drive	SG EM-Power electronics	√	√	√	√				
E-Class	213	Drive	ISG-Integrated starter alternator	√	√	√	√				
E-Class	213	Drive	ISG-Integrated starter alternator	√	√	√	√				
E-Class	213	Drive	ISG-Integrated starter alternator	√	√	√	√				

E-Class	213	Information and communication	ZAN-Audio/COMAND display	√	√	√	√				
E-Class	213	Information and communication	ZAN-Audio/COMAND display	√	√	√	√				
E-Class	213	Drive	N3/10-Motor electronics "MED1775" for combustion	√	√	√	√	√			
E-Class	213	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√			
E-Class	213	Drive	N3/10-Motor electronics "MED40" for combustion engine	√	√	√	√	√			
E-Class	213	Drive	N3/10-Motor electronics "MED41" for combustion engine	√	√	√	√	√			
E-Class	213	Drive	N3/10-Motor electronics "MRG1" for combustion engine "M256"	√	√	√	√	√			
E-Class	213	Drive		√	√	√					
S-Class	217	Drive	N3/10-Motor electronics "ME1778" for combustion engine	√	√	√	√				
S-Class	217	Drive	N3/10-Motor electronics "MED177" for combustion engine	√	√	√	√	√			
S-Class	217	Drive	N3/10-Motor electronics "MED1775" for combustion	√	√	√	√	√			
S-Class	217	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√			
S-Class	217	Drive	N3/10-Motor electronics "MRG1" for combustion engine "M256"	√	√	√	√	√			
S-Class	217	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√			
S-Class	217	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√			
S-Class	217	Seats and Doors	LFD-Left front door	√	√	√	√				
S-Class	217	Seats and Doors	LFD-Left front door	√	√	√	√				
S-Class	217	Seats and Doors	DCU RF-Right front door	√	√	√	√				
S-Class	217	Seats and Doors	DCU RF-Right front door	√	√	√	√				
S-Class	217	Body	SRS-Supplemental restraint	√	√	√	√	√			
S-Class	217	Body	SRS-Supplemental restraint	√	√	√	√				
S-Class	217	Information and communication	CTEL-Cellular telephone	√	√	√	√				
S-Class	217	Body	EZS-Electronic ignition lock	√	√	√	√				
S-Class	217	Body	EZS-Electronic ignition lock	√	√	√	√				
S-Class	217	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√				
S-Class	217	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√				
S-Class	217	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√				

S-Class	217	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√				
S-Class	217	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√				
S-Class	217	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√				
S-Class	217	Information and communication	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√				
S-Class	217	Information and communication	HERMES-control unit for telematics services	√	√	√	√				
S-Class	217	Information and communication	mbrace-mbrace	√	√	√	√				
S-Class	217	Seats and Doors	MKS LF-Left front multicontour	√	√	√	√				
S-Class	217	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√				
S-Class	217	Air conditioning	AAC-Automatic air conditioning	√	√	√	√				
S-Class	217	Seats and Doors	HKS-Tailgate control	√	√	√	√				
S-Class	217	Seats and Doors	HKS-Tailgate control	√	√	√	√				
S-Class	217	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√				
S-Class	217	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√				
S-Class	217	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√				
S-Class	217	Body	PSD-Control module Panoramic sliding roof	√	√	√	√			SP1536	
S-Class	217	Driver assistance	KAB-Control unit Camera cover	√	√	√	√				
S-Class	217	Body	MSC-MAGIC SKY CONTROL	√	√	√	√				
S-Class	217	Body	AML-Ambiance light	√	√	√	√				
S-Class	217	Body	KG-Keyless Go	√	√	√	√				
S-Class	217	Body	KG-Keyless Go	√	√	√	√				
S-Class	217	Body	OCP-Overhead control panel	√	√	√	√				
S-Class	217	Body	OCP-Overhead control panel	√	√	√	√				
S-Class	217	Body	DC/DC-DC/DC converter	√	√	√	√				
S-Class	217	Information and communication	mbrace-mbrace	√	√	√	√				
S-Class	217	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√				
S-Class	217	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√				
S-Class	217	Body	LRE-Steering wheel electronics	√	√	√	√				
S-Class	217	Information and communication	TPAD-Touchpad	√	√	√	√				
S-Class	217	Information and communication	TPAD-Touchpad	√	√	√	√				
S-Class	217	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√				

S-Class	217	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√				
S-Class	217	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√				
S-Class	217	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√				
S-Class	217	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√				
S-Class	217	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√				
S-Class	217	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√				
S-Class	217	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√				
S-Class	217	Information and communication	ZAN-Audio/COMAND display	√	√	√	√				
S-Class	217	Information and communication	ZAN-Audio/COMAND display	√	√	√	√				
S-Class	217	Information and communication	MTAS-Mobile phone cradle	√	√	√	√				
S-Class	217	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√				
S-Class	217	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√				
S-Class	217	Information and communication	IC-Instrument cluster(A1)	√	√	√	√				
S-Class	217	Information and communication	IC-Instrument cluster	√	√	√	√				
S-Class	217	Information and communication	HUD-Head up display	√	√	√	√				
S-Class	217	Driver assistance	NSA-Night View Assist(N101)	√	√	√	√				
S-Class	217	Driver assistance	RFK-Backup camera	√	√	√	√				
S-Class	217	Driver assistance	RFK-Backup camera	√	√	√	√				
S-Class	217	Driver assistance	CAMERA-360 camera(N148)	√	√	√	√				
S-Class	217	Body	SG FOND-Rear control unit	√	√	√	√				
S-Class	217	Body	SG FOND-Rear control unit	√	√	√	√				
S-Class	217	Chassis	AMG DRVU-AMG DRIVE	√	√	√	√				
S-Class	217	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√				
S-Class	217	Body	SG SW L-Left headlamp	√	√	√	√				
S-Class	217	Body	SG SW L-Left headlamp	√	√	√	√				
S-Class	217	Body	SG SW L-Left headlamp	√	√	√	√				
S-Class	217	Body	SG SW R-Right headlamp	√	√	√	√				
S-Class	217	Body	SG SW R-Right headlamp	√	√	√	√				
S-Class	217	Body	SG SW R-Right headlamp	√	√	√	√				
S-Class	217	Driver assistance	TPM-Tire pressure monitor(N88)	√	√	√	√				
S-Class	217	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√				

S-Class	217	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
S-Class	217	Chassis	EFB-Electric parking brake	√	√	√	√					
S-Class	217	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√					
S-Class	217	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√					
S-Class	217	Drive	HFPM-Haptic accelerator pedal module	√	√	√	√					
S-Class	217	Drive	ISM-Shift module	√	√	√	√					
S-Class	217	Body	SG LG-Charger	√	√	√	√					
S-Class	217	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
S-Class	217	Body	BSN-Battery sensor(B95)	√	√	√	√					
S-Class	217	Body	BSN-Battery sensor(B95)	√	√	√	√					
S-Class	217	Body	LIB-Lithium ion battery	√	√	√	√					
S-Class	217	Body	LIB-Lithium ion battery	√	√	√	√					
S-Class	217	Body	Button group, instrument panel, driver side	√	√	√	√					
S-Class	217	Body	Button group, instrument panel, center	√	√	√	√					
S-Class	217	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
S-Class	217	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
S-Class	217	Body	FSW-Windshield wiper	√	√	√	√					
S-Class	217	Body	GTO-Garage door	√	√	√	√					
S-Class	217	Body	GTO-Garage door	√	√	√	√					
S-Class	217	Body	OCP-Overhead control panel	√	√	√	√					
S-Class	217	Body	OCP-Overhead control panel	√	√	√	√					
S-Class	217	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√					
S-Class	217	Body	Anti glare interior rearview mirror(SAM)	√	√	√	√					
S-Class	217	Body	AMLAB-R (Actuation module, LED exterior lighting, right front)	√	√	√	√					
S-Class	217	Body	AMLAB-R (Actuation module, LED exterior lighting, right front)	√	√	√	√					
S-Class	217	Body	AMLAB-L (Actuation module, LED exterior lighting, left front)	√	√	√	√					
S-Class	217	Body	AMLAB-L (Actuation module, LED exterior lighting, left front)	√	√	√	√					
S-Class	217	Body	AIRSCARF-Neck heating system(N25/7)	√	√	√	√					
S-Class	217	Body	N5 (Armrest heater control unit)	√	√	√	√					
S-Class	217	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√					
S-Class	217	Seats and Doors	LFD-Left front door	√	√	√						
S-Class	217	Seats and Doors	LFD-Left front door	√	√	√						
S-Class	217	Seats and Doors	DCU RF-Right front door	√	√	√						

S-Class	217	Seats and Doors	DCU RF-Right front door	√	√	√						
S-Class	217	Seats and Doors	LSE FS-N32/23 (Driver seat lumbar support adjustment	√	√	√	√					
S-Class	217	Body	"Driver" seat heater	√	√	√	√					
S-Class	217	Seats and Doors	BFS LSE-Lumbar support 'Front passenger seat'(N32/24)	√	√	√	√					
S-Class	217	Body	"Front passenger" seat heater	√	√	√	√					
S-Class	217	Seats and Doors	Seat heater in left rear passenger compartment	√	√	√	√					
S-Class	217	Seats and Doors	Seat heater in right rear passenger compartment	√	√	√	√					
S-Class	217	Body	AS-Alarm siren(H3/1)	√	√	√	√					
S-Class	217	Body	IRSS-VL-Left front interior protection sensor	√	√	√						
S-Class	217	Body	IRSS-VR-Right front interior protection sensor	√	√	√						
S-Class	217	Body	IRSS-FOR-Right rear interior protection sensor	√	√	√						
S-Class	217	Body	IRSS-FOL-Left rear interior protection sensor	√	√	√						
S-Class	217	Seats and Doors	Massage function in left front seat	√	√	√	√					
S-Class	217	Seats and Doors	Massage function in right front	√	√	√	√					
S-Class	217	Air conditioning	N61 (Windshield heater control	√	√	√						
S-Class	217	Air conditioning	AAC-Automatic air conditioning	√	√	√						
S-Class	217	Air conditioning	STH-Stationary heater	√	√	√	√					
S-Class	217	Air conditioning	AAC-Automatic air conditioning	√	√	√						
S-Class	217	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√					
S-Class	217	Information and communication	Telephone keypad	√	√	√						
S-Class	217	Information and communication	LCP-Lower control panel	√	√	√	√					
S-Class	217	Body	WSS-Weight sensing	√	√	√	√					
S-Class	217	Body	N38 (Rear switching module)	√	√	√	√					
S-Class	217	Body	LIB-Lithium ion battery	√	√	√	√					
S-Class	217	Information and communication	TV tuner (TV)	√	√	√	√					
S-Class	217	Information and communication	TV tuner (TV)	√	√	√	√					
S-Class	217	Information and communication	TV tuner (TV)	√	√	√	√					
S-Class	217	Information and communication	TV tuner (TV)	√	√	√	√					
S-Class	217	Information and communication	SOUND-Sound system	√	√	√	√					
S-Class	217	Information and communication	SOUND-Sound system	√	√	√	√					

S-Class	217	Information and communication	DAB-Digital radio Tuner unit	√	√	√	√					
S-Class	217	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					
S-Class	217	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					
S-Class	217	Driver assistance	DTR-DISTRONIC	√	√	√	√					
S-Class	217	Driver assistance	DTR-DISTRONIC	√	√	√	√					
S-Class	217	Driver assistance	SGR-Radar sensors control unit	√	√	√	√					
S-Class	217	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√					
S-Class	217	Driver assistance	PARK-Parking system (N62)	√	√	√	√					
S-Class	217	Driver assistance	PTS-PARKTRONIC	√	√	√	√					
S-Class	217	Chassis	ABC-Active body control(N51/2)	√	√	√	√					
S-Class	217	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√					
S-Class	217	Chassis	ES - Electric power steering	√	√	√	√					
S-Class	217	Chassis	ES - Electric power steering	√	√	√	√					
S-Class	217	Chassis	ES - Electric power steering	√	√	√	√					
S-Class	217	Body	SCM-Steering column	√	√	√	√					
S-Class	217	Body	SCM-Steering column	√	√	√	√					
S-Class	217	Drive	VG-All-wheel drive	√	√	√	√					
S-Class	217	Driver assistance	NBR RR-Right rear short-range	√	√	√	√					
S-Class	217	Driver assistance	NBR LR-Left rear short-range	√	√	√	√					
S-Class	217	Chassis	ESP-Electric stability	√	√	√	√	√				
S-Class	217	Chassis	ESP-Electric stability	√	√	√	√					
S-Class	217	Drive	FSCU-Control unit Fuel pump	√	√	√	√					
S-Class	217	Drive	N127 (Drivetrain control unit)	√	√	√	√					
S-Class	217	Drive	N127 (Drivetrain control unit)	√	√	√	√					
S-Class	217	Drive	SG EM-Power electronics	√	√	√	√					
S-Class	217	Drive	ISG-Integrated starter alternator	√	√	√	√					
S-Class	217	Drive	SG EM-Power electronics	√	√	√	√					
S-Class	217	Body	BMS-Battery management system	√	√	√	√					
S-Class	217	Body	BMS-Battery management system	√	√	√	√					
CLS-Class	218	Drive	N3/9-Motor electronics "CR42" for combustion engine "OM651"	√	√	√	√	√	ACT1187,ACT1188,ACT1189,ACT1190,ACT1191,ACT1192,ACT1193,ACT1194,ACT1195,ACT1196,ACT1197,ACT1198,ACT1199,ACT1200,ACT1201,ACT1202,ACT1203,ACT1204,	SP1432,SP1433,SP1434,SP1435,SP1436,SP1437,SP1438,SP1439,SP1440,SP1441,SP1442,SP1443,SP1444,SP1445,SP1446,SP1447,SP1448,SP1449,	CD0648, CD0649, CD0650	√
CLS-Class	218	Drive	N3/9-Motor electronics "CR43" for combustion engine "OM651"	√	√	√	√	√	ACT0543,ACT0544,ACT0545,ACT0546,ACT0547,ACT0548,ACT0549,ACT0550,ACT0551,ACT0552,ACT0553,ACT0554,ACT0555,ACT0556,ACT0557,ACT0558	SP1164,SP1165,SP1166,SP1167,SP1168,SP1169,SP1170,SP1171,SP1172,SP1173,SP1174,SP1175,SP1176,SP1177,SP1178,SP1179,SP1180,SP1181,SP1182,SP1183,SP1184,	CD0453, CD0454, CD0455, CD0456	√

CLS-Class	218	Drive	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"	√	√	√	√	√	ACT0559,ACT0560,ACT0561,ACT0562,ACT0563,ACT0564,ACT0565,ACT0566,ACT0567,ACT0568,ACT0569,ACT0570,	SP1187,SP1188,SP1189,SP1190,SP1191,SP1192,SP1193,SP1194,SP1195,SP1196,SP1197,SP1198,SP1199,SP1200,SP1201,SP1202,SP1203,SP1204,	CD0457, CD0458, CD0459, CD0460	√
CLS-Class	218	Drive	N3/9-Motor electronics "CDI61" for combustion engine "OM642"	√	√	√	√	√	ACT0571,ACT0572,ACT0573,ACT0574,ACT0575,ACT0576,ACT0577,ACT0578,ACT0579,ACT0580,ACT0581,ACT0582,ACT0583	SP1206,SP1207,SP1208,SP1209,SP1210,SP1211,SP1212,SP1213,SP1214,SP1215,SP1216,SP1217,SP1218,SP1219,SP1220,SP1221,SP1222,SP1223,SP1224,SP1225,SP1226,	CD0461, CD0462, CD0463, CD0464	√
CLS-Class	218	Drive	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"	√	√	√	√	√	ACT1216,ACT1217,ACT1218,ACT1219,ACT1220,ACT1221,ACT1222,ACT1223,ACT1224,ACT1225,ACT1226	SP1466,SP1467,SP1468,SP1469,SP1470,SP1471,SP1472,SP1473,SP1474,SP1475,SP1476,SP1477,	CD0654, CD0655, CD0656	√
CLS-Class	218	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√	√	ACT0000,ACT0001,ACT0002,ACT0003,ACT0004,ACT0005,ACT0006,ACT0007,ACT0008,ACT0009,ACT0010,ACT0011,ACT0012,ACT0013,ACT0014,ACT0015,ACT0016,ACT0017,ACT0018,ACT0019,ACT0020,ACT0021,ACT0022,ACT0023,ACT0024,ACT0025,ACT0026	SP1000,SP1001,SP1002,SP1003,SP1004,SP1005,SP1006,SP1007,SP1008,SP1009,SP1010,SP1011,SP1012,SP1013,SP1014,SP1015,SP1016,SP1017,SP1018,SP1019,SP1020,SP1021,SP1022,SP1023,SP1024	CD0304, CD0305, CD0306, CD0307	√
CLS-Class	218	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√	ACT0584,ACT0585	SP1229,SP1230,SP1231,SP1232,SP1233,SP1234,SP1235,SP1236,SP1237,SP1237,SP1238,SP1239,SP1240,SP1241,SP1242,	CD0465, CD0466, CD0467, CD0468	√
CLS-Class	218	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7	√	√	√	√	√	ACT0586	SP1244,SP1245,SP1246,SP1247,SP1248,SP1249,SP1250,SP1250,SP1251,SP1252,SP1253,SP1254,	CD0469, CD0470, CD0471, CD0472, CD0473	√
CLS-Class	218	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√	ACT0587,ACT0588,ACT0589	SP1256,SP1257,SP1258,SP1259,SP1260,SP1261	CD0474, CD0475, CD0476, CD0477, CD0478	√
CLS-Class	218	Information and communication	Left front short range radar	√	√	√	√					√
CLS-Class	218	Information and communication	Left front short range radar	√								√
CLS-Class	218	Information and communication	E call [Europe]-Emergency call system	√	√	√	√		ACT0044,ACT0045,ACT0046,ACT0047,ACT0048,ACT0049			
CLS-Class	218	Information and communication	AVE H-Rear audio video unit	√	√	√	√		ACT0610,ACT0611,ACT0612,ACT0613,ACT0614		CD0490, CD0491, CD0492, CD0493, CD0494	√
CLS-	218	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√
CLS-	218	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√
CLS-	218	Body	CGW-Central gateway	√	√	√	√			SP1366		√

CLS-Class	218	Information and communication	IC-Instrument cluster	√	√	√	√		ACT0050,ACT0051,ACT0052,ACT0053,ACT0054,ACT0055,	SP1047,SP1048		√
CLS-Class	218	Information and communication	KOMO-Communication module Telematics services	√	√	√	√		ACT0057,ACT0058,ACT0059,ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065,			√
CLS-Class	218	Seats and Doors	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√		ACT0067,ACT0068,ACT0069,ACT0070,ACT0071,ACT0072,ACT0073,ACT0074	SP1049,SP1050		
CLS-Class	218	Information and communication	TS-Telematic system(N123/4)	√	√	√	√		ACT0075,ACT0076,ACT0077,ACT0078			√
CLS-Class	218	Body	EZS-Electronic ignition switch	√	√	√	√			SP1051,SP1052,SP1053	CD0320, CD0321, CD0322, CD0323, CD0324	
CLS-	218	Body	EZS-Electronic ignition switch	√	√	√	√					
CLS-	218	Body	EZS-Electronic ignition lock	√	√	√	√				CD0325	
CLS-	218	Body	EZS-Electronic ignition lock	√	√	√	√					
CLS-	218	Body	EZS-Electronic ignition lock	√	√	√	√					
CLS-Class	218	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√		ACT1550,ACT1551,ACT1552,ACT1553	SP1597,SP1598	CD0765	√
CLS-Class	218	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√		ACT1554,ACT1555,ACT1556,ACT1557		CD0766	√
CLS-Class	218	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084			√
CLS-Class	218	Body	SCCM-Steering column module(N80)	√	√	√	√		ACT0841,ACT0842,ACT0843,ACT0844,ACT0845			√
CLS-Class	218	Chassis	AMG DRVU-AMG DRIVE UNIT(N145)	√	√	√	√		ACT0085,ACT0086,ACT0087			√
CLS-Class	218	Chassis	ESP- Electric stability program	√	√	√	√	√	ACT0847,ACT0848,ACT1269,ACT0849,ACT0850	SP1493,SP1368		√
CLS-Class	218	Chassis	ESP-Electronic stability program(N30/4)	√	√	√	√	√	ACT0088,ACT0089,ACT1436	SP1537,SP1280		√
CLS-Class	218	Information and communication	NAV-Navigation module(A2/30)	√	√	√	√		ACT0090,ACT0091,ACT0092,ACT0093			√
CLS-Class	218	Information and communication	Audio-Audio or COMAND	√	√	√	√					
CLS-Class	218	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
CLS-Class	218	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√			SP1288,SP1289,SP1290,SP1291		√
CLS-Class	218	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1292,SP1293,SP1294,SP1295,SP1296		√
CLS-Class	218	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1297,SP1293,SP1294,SP1296		√
CLS-Class	218	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0100,ACT0099	SP1056,SP1409		√
CLS-Class	218	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√				√
CLS-	218	Body	SRS-Supplemental restraint	√	√	√	√	√				√
CLS-	218	Air conditioning	LRH-Steering wheel heater	√	√	√	√		ACT1482			√

CLS-Class	218	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√		ACT0101,ACT0102,ACT0103,ACT0104,ACT0105,ACT0106,ACT0107,ACT0108,ACT0109,ACT0110,ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,ACT0117,ACT0118,ACT0119,ACT0120,ACT0121,ACT0118,ACT0119,ACT0120,ACT0119,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0111,ACT0112,ACT0113,ACT0118,ACT0116,ACT0117,ACT0102,ACT0103,ACT0127,ACT0128,ACT0101,	SP1057,SP1058,SP1059,SP1060,SP1061		
CLS-Class	218	Information and communication	Audio-Audio or COMAND	√	√	√	√					
CLS-Class	218	Information and communication	Audio-Audio or COMAND	√	√	√	√		ACT1102,ACT1103,ACT1104,ACT1105,ACT1106,ACT1107,ACT1108,ACT1109,ACT1110,ACT1111,ACT1112,ACT1113,ACT1114,ACT1115,ACT1116,ACT1117,ACT1118,ACT1119,ACT1120,ACT1121,ACT1112,ACT1113,ACT1114,ACT1115,ACT1117,ACT1118,ACT1122,ACT1123,ACT1124,ACT1103,ACT1104,ACT1125,ACT1126,ACT1102,ACT1105,ACT1106,ACT1107,ACT1110,ACT1119,	SP1410,SP1411,SP1412	CD0619, CD0620, CD0621, CD0622, CD0623, CD0624, CD0625, CD0626, CD0627, CD0628, CD0629, CD0630, CD0631	
CLS-Class	218	Driver assistance system	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)	√	√	√	√		ACT0132	SP1062		√
CLS-Class	218	Seats and Doors	PPAMKS-Pneumatic pump for active multicontour seat	√	√	√	√		ACT0628,ACT0629,ACT0630			√
CLS-Class	218	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√		ACT0631,ACT0632,ACT0633,ACT0634,ACT0635			√
CLS-Class	218	Seats and Doors	AMKS LF-Active multicontour seat(N32/19)	√	√	√	√		ACT1483,ACT1484,ACT1485,ACT1486,ACT1487,ACT1488			√
CLS-Class	218	Driver assistance system	CAMERA-360 camera(N148)	√	√	√	√		ACT0542	SP1158,SP1159,SP1160,SP1161,SP1162,SP1163		√
CLS-Class	218	Seats and Doors	AMKS RF-Active multicontour seat(N32/22)	√	√	√	√		ACT1489,ACT1490,ACT1491,ACT1492,ACT1493,ACT1494			√
CLS-Class	218	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					
CLS-Class	218	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					√
CLS-Class	218	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					
CLS-Class	218	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					√

CLS-Class	218	Body	Multifunction control unit-Multifunction control unit	√	√	√	√	ACT0133,ACT0134,ACT0135,ACT0136,ACT0137,ACT0138,ACT0139,ACT0140,ACT0141,ACT0142,ACT0143,ACT0144,ACT0145,ACT0146,ACT0147,ACT0148,ACT0149,ACT0150,			√
CLS-Class	218	Body	KG-KEYLESS GO(N69/5)	√	√	√	√	ACT0156,ACT0157			√
CLS-Class	218	Body	KG-KEYLESS GO	√	√	√	√	ACT0851,ACT0852,ACT0853,ACT0854			
CLS-Class	218	Body	KG-KEYLESS GO(N69/5)	√	√	√	√	ACT0855,ACT0856,ACT0156,ACT0157,ACT0857			√
CLS-Class	218	Information and communication	SOUND-Sound system	√	√	√	√	ACT0158,ACT0159,ACT0160,ACT0161,ACT0162,ACT0163,ACT0164,ACT0165,ACT0166,ACT0167,ACT0168,ACT0169,ACT0170,ACT0171,ACT0172,ACT0173,ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0179,ACT0180,ACT0181,		CD0348	
CLS-Class	218	Information and communication	SOUND-Bose sound system	√	√	√	√	ACT0199,ACT0186,ACT0187,ACT0189,ACT0191,ACT0192,ACT0200,ACT0195,ACT0196,ACT0201,ACT0202,ACT0194,ACT0203,ACT0204,ACT0205,ACT0197,ACT0206,ACT0198	SP1063		
CLS-Class	218	Information and communication	SOUND-Bose sound system	√	√	√	√	ACT0199,ACT0653,ACT0185,ACT0186,ACT0654,ACT0655,ACT0195,ACT0196,ACT0193,ACT0200,ACT0194,ACT0188,ACT0190,ACT0191,ACT0192,ACT0656,ACT0657,ACT0206,			
CLS-Class	218	Chassis	ELC-Electronic level control	√	√	√	√	ACT1495,ACT1496,ACT1497,ACT1498,ACT1499,ACT1500,	SP1568,SP1569		√
CLS-Class	218	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√	ACT0207,ACT0208,ACT0209,ACT0210	SP1064		√
CLS-Class	218	Chassis	ADS-Adaptive damping system	√	√	√	√	ACT0858,ACT0859,ACT0860,ACT0861	SP1372		√
CLS-Class	218	Body	TLC-Trunk lid control	√	√	√	√	ACT1272,ACT1273,ACT1274,ACT1275,ACT1276	SP1495,SP1496		√
CLS-Class	218	Information and communication	ECS-N123/4 Emergency call system control unit	√	√	√	√	ACT0674,ACT0675,ACT0676			
CLS-Class	218	Information and communication	TV-TV tuner	√	√	√	√	ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0219,ACT0220,ACT0221,ACT0222,ACT0223		CD0350CD0351, CD0352, CD0353, CD0354, CD0355, CD0356, CD0357, CD0358, CD0359, CD0360, CD0361	
CLS-Class	218	Information and communication	TV-TV tuner	√	√	√	√	ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0677,ACT0233			

CLS-Class	218	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0230,ACT0231,ACT0232,ACT0233		CD0362CD0363, CD0364, CD0365, CD0366, CD0367, CD0368, CD0369, CD0370, CD0371, CD0372, CD0373	
CLS-	218	Driver assistance	MFK-Multifunction camera	√	√	√	√		ACT0234,ACT0235	SP1066		√
CLS-	218	Driver assistance	MFK-Multifunction	√	√	√	√		ACT0236,ACT0237	SP1067,SP1068		√
CLS-Class	218	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		ACT0238,ACT0241,ACT0862,ACT1278,ACT0678,ACT0245,ACT0681,ACT0687,ACT0688,ACT0253,ACT0254,ACT1279,ACT0691,ACT0692,ACT1280,ACT1140,ACT0251,ACT0863,	SP1069,SP1070,SP1071		√
CLS-Class	218	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√					
CLS-Class	218	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√					
CLS-Class	218	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258		CD0382	
CLS-Class	218	Air conditioning	STH-Stationary heater	√	√	√	√		ACT0259,ACT0260,ACT1281,ACT1282,ACT1283,ACT1284,ACT1285,ACT0262,ACT1286,			√
CLS-Class	218	Information and communication	Drive Kit Plus-Drive kit for iPhone	√	√	√	√		ACT0263,ACT0264,ACT0265,ACT0266			
CLS-Class	218	Information and communication	NAVI20-Navigation(N125/2)	√	√	√	√		ACT0267,ACT0268			
CLS-	218	Chassis	ES-Electric power steering(N68)	√	√	√	√			SP1302		√
CLS-	218	Chassis	ES-Electric power steering(N68)	√	√	√	√			SP1302,SP1303		√
CLS-Class	218	Body	PSD-Control module 'Panoramic sliding roof'(A98)	√	√	√	√		ACT1288,ACT1289	SP1497		√
CLS-Class	218	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√		ACT0271			√
CLS-	218	Body	WSS-Weight sensing	√	√	√	√					
CLS-Class	218	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√		ACT0275			√
CLS-Class	218	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√		ACT0865,ACT0866,ACT0867,ACT0868,ACT0869,ACT0870	SP1373,SP1374,SP1375		√
CLS-Class	218	Seats and Doors	N32/1 (Driver seat control unit)	√	√	√	√		ACT0865,ACT0866,ACT0867,ACT0868,ACT0869,ACT0870	SP1373,SP1374,SP1375		√
CLS-Class	218	Information and communication	SDAR-Satellite radio	√	√	√	√		ACT0283,ACT0284,ACT0285,ACT0286		CD0387CD0388, CD0389, CD0389	
CLS-Class	218	Information and communication	TB5-TV tuner Tuner unit	√	√	√	√		ACT0287,ACT0288,ACT0289,ACT0290,ACT0291,ACT0292,ACT0293,ACT0294,			
CLS-Class	218	Information and communication	TV tuner (TV)	√	√	√	√		ACT0295,ACT0296,ACT0297,ACT0298,ACT0299,ACT0300,			
CLS-Class	218	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√		ACT0871,ACT0872,ACT0873,ACT0874,ACT0875	SP1376,SP1377,		√

CLS-Class	218	Seats and Doors	N32/2 (Front passenger seat control unit)	√	√	√	√		ACT0871,ACT0872,ACT0873,ACT0874,ACT0875	SP1376,SP1377,		√
CLS-Class	218	Information and communication	MIF-Media interface	√	√	√	√					
CLS-Class	218	Information and communication	MIF-Media interface	√	√	√	√		ACT0309			
CLS-Class	218	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√		ACT0711,ACT0712,ACT0713,ACT0714,ACT0715	SP1307,SP1308,SP1309,SP1310,SP1311	CD0527, CD0528, CD0529, CD0530	√
CLS-Class	218	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√		ACT0711,ACT0712,ACT0713,ACT0714,ACT0715	SP1307,SP1308,SP1309,SP1310,SP1311	CD0527, CD0528, CD0529, CD0530	√
CLS-Class	218	Body	OCP-Overhead control panel	√	√	√	√		ACT1294,ACT1290,ACT1291,ACT1292	SP1498		√
CLS-Class	218	Drive	ISM-Shift module	√	√	√	√		ACT0717,ACT0718,ACT0719,ACT0720,ACT0721	SP1312,SP1313,SP1314		√
CLS-Class	218	Body	TRM-Trailer recognition module (N28/1)	√	√	√	√		ACT0311,ACT0310,ACT0312,ACT0313,ACT1297,ACT0314,ACT0315,ACT0316,ACT1296			√
CLS-Class	218	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√
CLS-Class	218	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√		ACT0884,ACT0885,ACT0886,ACT0887,ACT0888,ACT0889,ACT0890,ACT0891			√
CLS-Class	218	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√
CLS-Class	218	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√		ACT0723,ACT0724,ACT0725,ACT0726,ACT0727	SP1315,SP1316,SP1317,SP1318,SP1319	CD0531, CD0532, CD0533, CD0534	√
CLS-Class	218	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√		ACT0723,ACT0724,ACT0725,ACT0726,ACT0727	SP1315,SP1316,SP1317,SP1318,SP1319	CD0531, CD0532, CD0533, CD0534	√
CLS-	218	Drive	FSCU05-Control unit Fuel pump	√	√	√	√		ACT0385			√
CLS-	218	Drive	FSCU-Fuel pump	√	√	√	√		ACT0499			√

CLS-Class	218	Body	Rear SAM-Rear signal acquisition and actuation module	√	√	√	√	ACT0892,ACT0893,ACT0894,ACT0895,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0901,ACT0902,ACT0903,ACT0904,ACT0905,ACT0906,ACT0907,ACT0908,ACT0909,ACT0910,ACT0911,ACT0912,ACT0913,ACT0914,ACT0915,ACT0916,ACT0917,ACT0918,ACT0919,ACT0920,ACT0921,ACT0922,ACT0923,ACT0924,ACT0925,ACT0926,ACT0927,ACT0928,ACT0929,ACT0892,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0892,ACT0894,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0927,ACT0928,ACT0930,ACT0927,ACT0931,ACT0928,ACT0932,,ACT0933,ACT0934			√
CLS-Class	218	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√

CLS-Class	218	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√
CLS-Class	218	Information and communication	N123 / 4 (emergency call system control unit) - an emergency call	√	√	√	√				
CLS-	218	Driver assistance	DTR-DISTRONIC	√	√	√	√				√
CLS-	218	Driver assistance	DTR-DISTRONIC	√	√	√	√				√
CLS-Class	218	Seats and Doors	LFD-Left front door	√	√	√	√	ACT0386,ACT0387,ACT0388,ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0398,ACT0994,ACT0397,ACT0400,ACT0401,ACT0402,ACT0403,			√
CLS-Class	218	Information and communication	N123 / 4 (emergency call system control unit) - Mercedes - Benz (MB) information / fault rescue	√	√	√	√				
CLS-	218	Driver assistance	NSA-Night View Assist(N101)	√	√	√	√	ACT0738,ACT0739,ACT0740	SP1320		√
CLS-	218	Driver assistance	NSA-Night View Assist(N101)	√	√	√	√	ACT1438,ACT0740	SP1320		√
CLS-Class	218	Seats and Doors	DCU RF-Right front door	√	√	√	√	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410,ACT0411,ACT0412,ACT0413,ACT0414,ACT0415,ACT0417,ACT0996,ACT0416,ACT0419,ACT0420,ACT0421,ACT0422,			√
CLS-Class	218	Information and communication	TV-TV tuner	√	√	√	√	ACT0424,ACT0425,ACT0426,ACT0427,ACT0222,ACT0428,ACT0219,ACT0221			
CLS-Class	218	Information and communication	TV-TV tuner	√	√	√	√	ACT0429,ACT0430,ACT0431,ACT0229,ACT0432,ACT0433,			

CLS-Class	218	Seats and Doors	DCU LR-Left rear door	√	√	√	√		ACT1330,ACT1331,ACT1332,ACT1333,ACT1334,ACT1335,ACT1336,ACT1337,ACT1338,ACT1339,ACT1340,ACT1341,ACT1342,ACT1343,ACT1344,ACT1345,ACT1346,ACT1347,			√
CLS-Class	218	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258			
CLS-Class	218	Seats and Doors	DCU RR-Right rear door	√	√	√	√		ACT1351,ACT1352,ACT1353,ACT1354,ACT1355,ACT1356,ACT1357,ACT1358,ACT1359,ACT1360,ACT1361,ACT1362,ACT1363,ACT1364,ACT1365,ACT1366,ACT1367,ACT1368,			√
CLS-Class	218	Information and communication	N123 / 4 (emergency call system control unit) - the vehicle remote control unlocking / locking the vehicle remote	√	√	√	√					
CLS-Class	218	Information and communication	N123 / 4 (emergency call system control unit) - anti-theft tracking	√	√	√	√					
CLS-	218	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439,ACT1372	SP1089,SP1088,SP1501	CD0695	√
CLS-	218	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439,ACT0440	SP1088,SP1089		√
CLS-	218	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439	SP1089		√
CLS-	218	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439	SP1088,SP1089		√
CLS-	218	Chassis	FGW-Chassis gateway	√	√	√	√				CD0535	√
CLS-Class	218	Seats and Doors	N25/6 (Rear passenger compartment seat heater control	√	√	√	√		ACT1451,ACT1452			√
CLS-	218	Body	WSS-Weight sensing	√	√	√	√					
CLS-Class	218	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
CLS-Class	218	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
CLS-	218	Body	BSN-Battery sensor(B95)	√	√	√	√					
CLS-	218	Body	BSN-Battery sensor(B95)	√	√	√	√					
CLS-Class	218	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0442,ACT0443,ACT0444,ACT0445,ACT0446			√
CLS-Class	218	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0447,ACT0448,ACT0449,ACT0450			√
CLS-Class	218	Information and communication	AVE H-Rear audio video unit	√	√	√	√		ACT0610,ACT0611,ACT0612,ACT0789,ACT0613,ACT0614		CD0490, CD0491, CD0492, CD0493, CD0494	√
CLS-Class	218	Body	XALWA L-Left xenon headlamp(E1n1)	√	√	√	√		ACT1453,ACT1454,ACT1558,ACT1559,ACT1457	SP1540,SP1541,SP1542,SP1599,SP1600		√
CLS-Class	218	Body	SG SW L-Left headlamp	√	√	√	√		ACT0456,ACT0457,ACT0458,ACT0459,ACT0460,ACT0461	SP1094,SP1095,SP1096,SP1097,SP1098,SP1099,	CD0398	√
CLS-Class	218	Body	SG SW L-Left headlamp(E1n9)	√	√	√	√		ACT0462,ACT0463,ACT0464,ACT0465,ACT0466,ACT0467	SP1101,SP1102,SP1103,SP1104,SP1105,SP1106,SP1107,SP1108	CD0399	√
CLS-Class	218	Body	XALWA R-Right xenon headlamp(E2n1)	√	√	√	√		ACT1459,ACT1460,ACT1463	SP1543,SP1601,SP1602		√

CLS-Class	218	Body	SG SW R-Right headlamp	√	√	√	√		ACT0468,ACT0469,ACT0470,ACT0471,ACT0472,ACT0473	SP1109,SP1110,SP1111,SP1112,SP1113,SP1114	CD0400	√
CLS-Class	218	Body	SG SW R-Right headlamp(E1n9)	√	√	√	√		ACT0474,ACT0475,ACT0476,ACT0477,ACT0478,ACT0479	SP1115,SP1116,SP1117,SP1118,SP1119,SP1120	CD0401	√
CLS-Class	218	Information and communication	ICI-InCar Internet(N125/3)	√	√	√	√		ACT1386,ACT1387,ACT1388			
CLS-Class	218	Drive	N15/5 (Electronic selector lever module control unit)	√	√	√	√		ACT1002,ACT1003,ACT1004			√
CLS-Class	218	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
CLS-Class	218	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
CLS-	218	Body	FSW-Windshield wiper	√	√	√	√		ACT1005,			
CLS-	218	Body	FSW-Windshield wiper	√	√	√	√		ACT1005,			
CLS-	218	Body	GTO-Garage door	√	√	√	√					
CLS-	218	Body	GTO-Garage door	√	√	√	√					
CLS-	218	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√					
CLS-Class	218	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
CLS-Class	218	Information and communication	CTEL-Mobile phone	√	√	√	√		ACT1390,ACT1391			
CLS-	218	Driver assistance	PARK-Parking system (N62)	√	√	√	√		ACT0484,ACT0485		CD0411, CD0412	√
CLS-Class	218	Driver assistance system	PTS-Parktronic system	√	√	√	√		ACT0790		CD0536, CD0537, CD0538, CD0539	√
CLS-	218	Body	Exterior lights switch	√	√	√	√					
CLS-	218	Body	UCP-Upper control panel	√	√	√	√					
CLS-	218	Body	LCP-Lower control panel	√	√	√	√					
CLS-	218	Body	LCP-Lower control panel	√	√	√	√					
CLS-	218	Body	AU-Analog clock	√	√	√	√					
CLS-Class	218	Information and communication	DSI-DIRECT SELECT interface(N150)	√	√	√	√		ACT0488			√
CLS-	218	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT1007			
CLS-	218	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT1007			
CLS-Class	218	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√		ACT1008,ACT1009			
CLS-Class	218	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√					
CLS-Class	218	Body	E1n8 (Actuation module 2, LED exterior lighting, left front)	√	√	√	√					
CLS-Class	218	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√		ACT0794,ACT0795	SP1325,SP1326,SP1327	CD0540	
CLS-Class	218	Body	AMLAB L 2-Actuation module 2, LED exterior lighting, left	√	√	√	√		ACT0796,ACT0797	SP1328,SP1329,SP1330	CD0541	
CLS-Class	218	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√					
CLS-Class	218	Body	E2n8 (Actuation module 2, LED exterior lighting, right front)	√	√	√	√					

CLS-Class	218	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√		ACT0798,ACT0799	SP1331,SP1332	CD0542	
CLS-Class	218	Body	AMLAB R 2-Actuation module 2, LED exterior lighting, right front(E2n8)	√	√	√	√		ACT0800,ACT0801	SP1333,SP1334	CD0543	
CLS-	218	Drive	FSCU-Fuel pump	√	√	√	√		ACT0498,ACT0499		CD0427, CD0428	√
CLS-Class	218	Drive	SCR-Selective Catalytic Reduction	√	√	√	√		ACT0590,ACT0591,ACT0592,ACT0593,ACT0594,ACT0595,ACT0596,ACT0597,ACT0598,	SP1262,SP1263,SP1264,SP1265,SP1266,SP1267	CD0479, CD0480, CD0481, CD0482	√
CLS-Class	218	Drive	SCR-Selective catalytic reduction	√	√	√	√		ACT0600,ACT0601,ACT0602,ACT0603,ACT0604,ACT0605	SP1268,SP1269,SP1270,SP1271,SP1272,SP1273	CD0483, CD0484, CD0485	√
CLS-Class	218	Drive	N3/10-Motor electronics "ME97" for combustion engine "M272"	√	√	√	√	√	ACT1395,ACT1396,ACT1397,ACT1398,ACT1399,ACT1400,ACT1401,ACT1402,ACT1403,ACT1404,ACT1405,ACT1406,ACT1407,ACT1408,ACT1409	SP1513,SP1514,SP1515,SP1516,SP1517,SP1518,SP1519,SP1520,SP1521	CD0702, CD0703, CD0704, CD0705, CD0706, CD0707, CD0708, CD0709	√
CLS-Class	218	Drive	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"	√	√	√	√	√	ACT1058,ACT1059,ACT1060,ACT1061,ACT1062,ACT1063,ACT1064,ACT1065,ACT1066,ACT1067,ACT1068,ACT1069,ACT1070,ACT1071,ACT1072,ACT1073,ACT1074,ACT1075,	SP1390,SP1391,SP1392,SP1393,SP1394,SP1395	CD0601, CD0602, CD0603, CD0604, CD0605, CD0606, CD0607, CD0608	√
CLS-Class	218	Drive	N3/10-Motor electronics "MED177" for combustion engine "M276"	√	√	√	√	√	ACT0802,ACT0803,ACT0804,ACT0805,ACT0806,ACT0807,ACT0808,ACT0809,ACT0810,ACT0811,ACT0812,ACT0813,ACT0814,ACT0815,ACT0816,ACT0817,ACT0818,ACT0819,	SP1335,SP1336,SP1337,SP1338,SP1339,SP1340,SP1341,SP1342,SP1343,SP1344,SP1345,SP1346,SP1347,SP1348	CD0544, CD0545, CD0546, CD0547, CD0548, CD0549, CD0550, CD0551, CD0552	√
CLS-Class	218	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√	ACT0821,ACT0822,ACT0823,ACT0824,ACT0825,ACT0826,ACT0827,ACT0828,ACT0829,ACT0830,ACT0831,ACT0832,ACT0833,ACT0834,ACT0835,ACT0836,ACT0837,ACT0838,	SP1349,SP1350,SP1351,SP1352,SP1353,SP1354,SP1355,SP1356,SP1357,SP1358,SP1359,SP1360,SP1361,SP1362,SP1363,SP1364	CD0553, CD0554, CD0555, CD0556, CD0557, CD0558, CD0559, CD0560, CD0561	√
CLS-Class	218	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	√	√	√	√	√	ACT0508,ACT0509,ACT0510,ACT0511,ACT0512,ACT0513,ACT0514,ACT0515,ACT0516,ACT0517,ACT0518,ACT0519,ACT0520,ACT0521,ACT0522,ACT0523,ACT0524,ACT0525,	SP1133,SP1134,SP1135,SP1136,SP1137,SP1138,SP1139,SP1140,SP1141,SP1142,SP1143,SP1144,SP1145,SP1146,SP1147,SP1148	CD0435, CD0436, CD0437, CD0438, CD0439, CD0440, CD0441, CD0442, CD0443	√
CLS-Class	218	Drive	N3/10-Motor electronics "MED97" for combustion engine "M272"	√	√	√	√	√	ACT1410,ACT1411,ACT1412,ACT1413,ACT1414,ACT1415,ACT1416,ACT1417,ACT1418,ACT1419,ACT1420,ACT1421,ACT1422,ACT1423,ACT1424,	SP1522,SP1523,SP1524,SP1525,SP1526,SP1527	CD0710, CD0711, CD0712, CD0713, CD0714, CD0715, CD0716, , CD0717, CD0718	√

CLS-Class	218	Drive	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"	√	√	√	√	√	ACT1023,ACT1024,ACT1025,ACT1026,ACT1027,ACT1028,ACT1029,ACT1030,ACT1031,ACT1032,ACT1033,ACT1034,ACT1035,ACT1036,ACT1037,ACT1038,ACT1039,ACT1040,	SP1382,SP1383,SP1384,SP1385,SP1386,SP1387,SP1388,SP1389	CD0587, CD0588, CD0589, CD0590, CD0591, CD0592, CD0593, CD0594, CD0595, CD0596	√
S-Class	222	Drive	N3/9-Motor electronics "CR43" for combustion engine "OM651"	√	√	√	√					
S-Class	222	Drive	N3/9-Motor electronics "CDI61" for combustion engine "OM642"	√	√	√	√	√				
S-Class	222	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√				
S-Class	222	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√				
S-Class	222	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√				
S-Class	222	Seats and Doors	LFD-Left front door	√	√	√	√					
S-Class	222	Seats and Doors	LFD-Left front door	√	√	√	√					
S-Class	222	Seats and Doors	LFD-Left front door	√	√	√	√					
S-Class	222	Seats and Doors	DCU RF-Right front door	√	√	√	√					
S-Class	222	Seats and Doors	DCU RF-Right front door	√	√	√	√					
S-Class	222	Seats and Doors	DCU RF-Right front door	√	√	√	√					
S-Class	222	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
S-Class	222	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
S-Class	222	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
S-Class	222	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
S-Class	222	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
S-Class	222	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
S-Class	222	Body	SRS-Supplemental restraint	√	√	√	√	√				
S-Class	222	Body	SRS-Supplemental restraint	√	√	√	√	√				
S-Class	222	Body	EZS-Electronic ignition lock	√	√	√	√	√				
S-Class	222	Body	EZS-Electronic ignition lock	√	√	√	√	√				
S-Class	222	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√					
S-Class	222	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√					
S-Class	222	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√					
S-Class	222	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√					
S-Class	222	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√					
S-Class	222	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√					
S-Class	222	Seats and Doors	ESE_RL-Left rear electrical seat adjustment	√	√	√	√					

S-Class	222	Seats and Doors	Right rear ESE-Right rear electrical seat adjustment	√	√	√	√					
S-Class	222	Information and communication	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√					
S-Class	222	Information and communication	HERMES-control unit for telematics services	√	√	√	√					
S-Class	222	Information and communication	mbrace-mbrace	√	√	√	√					
S-Class	222	Information and communication	MTAS FO-Mobile phone cradle in rear passenger compartment	√	√	√	√					
S-Class	222	Seats and Doors	MKS LF-Left front multicontour	√	√	√	√					
S-Class	222	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√					
S-Class	222	Seats and Doors	MKS LF-Left rear multicontour	√	√	√	√					
S-Class	222	Seats and Doors	MKS RF-Right rear multicontour	√	√	√	√					
S-Class	222	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
S-Class	222	Air conditioning	STH-Stationary heater	√	√	√	√					
S-Class	222	Seats and Doors	HKS-Tailgate control	√	√	√	√					
S-Class	222	Seats and Doors	HKS-Tailgate control	√	√	√	√					
S-Class	222	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√					
S-Class	222	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√					
S-Class	222	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√					
S-Class	222	Body	Trailer recognition module-Trailer recognition	√	√	√	√					
S-Class	222	Body	Trailer recognition module-Trailer recognition	√	√	√	√					
S-Class	222	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
S-Class	222	Body	AGS-Active bell buckle	√	√	√	√					
S-Class	222	Body	PSD-Control module Panoramic sliding roof	√	√	√	√			SP1536		
S-Class	222	Driver assistance	KAB-Control unit Camera cover	√	√	√	√					
S-Class	222	Body	MSC-MAGIC SKY CONTROL	√	√	√	√					
S-Class	222	Body	AML-Ambiance light	√	√	√	√					
S-Class	222	Body	KG-Keyless Go	√	√	√	√					
S-Class	222	Body	KG-Keyless Go	√	√	√	√					
S-Class	222	Body	OCP-Overhead control panel	√	√	√	√					
S-Class	222	Body	DC/DC-DC/DC converter	√	√	√	√					
S-Class	222	Information and communication	mbrace-mbrace	√	√	√	√					
S-Class	222	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√					
S-Class	222	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√					

S-Class	222	Body	LRE-Steering wheel electronics	√	√	√	√					
S-Class	222	Information and communication	TPAD-Touchpad	√	√	√	√					
S-Class	222	Information and communication	TPAD-Touchpad	√	√	√	√					
S-Class	222	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
S-Class	222	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
S-Class	222	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
S-Class	222	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
S-Class	222	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
S-Class	222	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
S-Class	222	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√					
S-Class	222	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√					
S-Class	222	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
S-Class	222	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
S-Class	222	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√					
S-Class	222	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√					
S-Class	222	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
S-Class	222	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
S-Class	222	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
S-Class	222	Information and communication	IC-Instrument cluster(A1)	√	√	√	√					
S-Class	222	Information and communication	IC-Instrument cluster	√	√	√	√					
S-Class	222	Information and communication	HUD-Head up display	√	√	√	√					
S-Class	222	Driver assistance	NSA-Night View Assist(N101)	√	√	√	√					
S-Class	222	Driver assistance	RFK-Backup camera	√	√	√	√					
S-Class	222	Driver assistance	RFK-Backup camera	√	√	√	√					
S-Class	222	Driver assistance	CAMERA-360 camera(N148)	√	√	√	√					
S-Class	222	Body	SG FOND-Rear control unit	√	√	√	√					
S-Class	222	Information and communication	CTEL-Cellular telephone	√	√	√	√					
S-Class	222	Chassis	AMG DRVU-AMG DRIVE	√	√	√	√					

S-Class	222	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√					
S-Class	222	Body	SG SW L-Left headlamp	√	√	√	√					
S-Class	222	Body	SG SW L-Left headlamp	√	√	√	√					
S-Class	222	Body	SG SW R-Right headlamp	√	√	√	√					
S-Class	222	Body	SG SW R-Right headlamp	√	√	√	√					
S-Class	222	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√					
S-Class	222	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√					
S-Class	222	Driver assistance	TPM-Tire pressure monitor(N88)	√	√	√	√					
S-Class	222	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
S-Class	222	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
S-Class	222	Chassis	EFB-Electric parking brake	√	√	√	√					
S-Class	222	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√					
S-Class	222	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√					
S-Class	222	Drive	HFBM-Haptic accelerator pedal module	√	√	√	√					
S-Class	222	Drive	ISM-Shift module	√	√	√	√					
S-Class	222	Body	SG LG-Charger	√	√	√	√					
S-Class	222	Body	SG LG-Charger	√	√	√	√					
S-Class	222	Body	DC/DC-DC/DC converter	√	√	√	√					
S-Class	222	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
S-Class	222	Body	BSN-Battery sensor(B95)	√	√	√	√					
S-Class	222	Body	BSN-Battery sensor(B95)	√	√	√	√					
S-Class	222	Body	LIB-Lithium ion battery	√	√	√	√					
S-Class	222	Body	LIB-Lithium ion battery	√	√	√	√					
S-Class	222	Body	AU-Analog clock	√	√	√	√					
S-Class	222	Body	Button group, instrument panel, driver side	√	√	√	√					
S-Class	222	Body	Button group, instrument panel, center	√	√	√	√					
S-Class	222	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
S-Class	222	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
S-Class	222	Body	FSW-Windshield wiper	√	√	√	√					
S-Class	222	Body	GTO-Garage door	√	√	√	√					
S-Class	222	Body	GTO-Garage door	√	√	√	√					
S-Class	222	Body	OCP-Overhead control panel	√	√	√	√					
S-Class	222	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√					
S-Class	222	Body	Anti glare interior rearview mirror(SAM)	√	√	√	√					

S-Class	222	Body	AMLAB-R (Actuation module, LED exterior lighting, right front)	√	√	√	√					
S-Class	222	Body	AMLAB-R (Actuation module, LED exterior lighting, right front)	√	√	√	√					
S-Class	222	Body	AMLAB-L (Actuation module, LED exterior lighting, left front)	√	√	√	√					
S-Class	222	Body	AMLAB-L (Actuation module, LED exterior lighting, left front)	√	√	√	√					
S-Class	222	Body	AIRSCARF-Neck heating system(N25/7)	√	√	√	√					
S-Class	222	Body	N5 (Armrest heater control unit)	√	√	√	√					
S-Class	222	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√					
S-Class	222	Seats and Doors	LFD-Left front door	√	√	√						
S-Class	222	Seats and Doors	LFD-Left front door	√	√	√						
S-Class	222	Seats and Doors	LFD-Left front door	√	√	√						
S-Class	222	Seats and Doors	DCU RF-Right front door	√	√	√						
S-Class	222	Seats and Doors	DCU RF-Right front door	√	√	√						
S-Class	222	Seats and Doors	DCU RF-Right front door	√	√	√						
S-Class	222	Seats and Doors	DCU LR-Left rear door	√	√	√						
S-Class	222	Seats and Doors	DCU LR-Left rear door	√	√	√						
S-Class	222	Seats and Doors	DCU LR-Left rear door	√	√	√						
S-Class	222	Seats and Doors	DCU RR-Right rear door	√	√	√						
S-Class	222	Seats and Doors	DCU RR-Right rear door	√	√	√						
S-Class	222	Seats and Doors	DCU RR-Right rear door	√	√	√						
S-Class	222	Seats and Doors	LSE FS-N32/23 (Driver seat lumbar support adjustment	√	√	√	√					
S-Class	222	Body	"Driver" seat heater	√	√	√	√					
S-Class	222	Seats and Doors	BFS LSE-Lumbar support 'Front passenger seat'(N32/24)	√	√	√	√					
S-Class	222	Body	"Front passenger" seat heater	√	√	√	√					
S-Class	222	Seats and Doors	Seat heater in left rear passenger compartment	√	√	√	√					
S-Class	222	Seats and Doors	Seat heater in right rear passenger compartment	√	√	√	√					
S-Class	222	Body	AS-Alarm siren(H3/1)	√	√	√	√					
S-Class	222	Body	IRSS-VL-Left front interior protection sensor	√	√	√						
S-Class	222	Body	IRSS-VR-Right front interior protection sensor	√	√	√						
S-Class	222	Body	IRSS-FOR-Right rear interior protection sensor	√	√	√						
S-Class	222	Body	IRSS-FOL-Left rear interior protection sensor	√	√	√						
S-Class	222	Seats and Doors	Massage function in left front seat	√	√	√	√					
S-Class	222	Seats and Doors	Massage function in right front	√	√	√	√					
S-Class	222	Seats and Doors	Massage function in left rear seat	√	√	√	√					
S-Class	222	Seats and Doors	Massage function in right rear	√	√	√	√					

S-Class	222	Air conditioning	N61 (Windshield heater control	√	√	√						
S-Class	222	Air conditioning	AAC-Automatic air conditioning	√	√	√						
S-Class	222	Air conditioning	STH-Stationary heater	√	√	√	√					
S-Class	222	Air conditioning	AAC-Automatic air conditioning	√	√	√						
S-Class	222	Air conditioning	AAC-Automatic air conditioning	√	√	√						
S-Class	222	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√					
S-Class	222	Information and communication	Telephone keypad	√	√	√						
S-Class	222	Information and communication	LCP-Lower control panel	√	√	√	√					
S-Class	222	Body	WSS-Weight sensing	√	√	√	√					
S-Class	222	Body	N38 (Rear switching module)	√	√	√	√					
S-Class	222	Body	LIB-Lithium ion battery	√	√	√	√					
S-Class	222	Information and communication	TV tuner (TV)	√	√	√	√					
S-Class	222	Information and communication	TV tuner (TV)	√	√	√	√					
S-Class	222	Information and communication	TV tuner (TV)	√	√	√	√					
S-Class	222	Information and communication	TV tuner (TV)	√	√	√	√					
S-Class	222	Information and communication	SOUND-Sound system	√	√	√	√					
S-Class	222	Information and communication	SOUND-Sound system	√	√	√	√					
S-Class	222	Information and communication	AVE H-Controller unit Rear entertainment system	√	√	√	√					
S-Class	222	Information and communication	AVE H-Controller unit Rear entertainment system	√	√	√	√					
S-Class	222	Information and communication	DAB-Digital radio Tuner unit	√	√	√	√					
S-Class	222	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					
S-Class	222	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					
S-Class	222	Driver assistance	DTR-DISTRONIC	√	√	√	√					
S-Class	222	Driver assistance	DTR-DISTRONIC	√	√	√	√					
S-Class	222	Driver assistance	SGR-Radar sensors control unit	√	√	√	√					
S-Class	222	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√					
S-Class	222	Driver assistance	DTR-DISTRONIC	√	√	√	√					
S-Class	222	Driver assistance	PARK-Parking system (N62)	√	√	√	√					
S-Class	222	Driver assistance	PTS-PARKTRONIC	√	√	√	√					
S-Class	222	Chassis	ABC-Active body control(N51/2)	√	√	√	√					
S-Class	222	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√					
S-Class	222	Chassis	ES - Electric power steering	√	√	√	√					

S-Class	222	Chassis	ES - Electric power steering	√	√	√	√						
S-Class	222	Chassis	ES - Electric power steering	√	√	√	√						
S-Class	222	Body	SCM-Steering column	√	√	√	√						
S-Class	222	Body	SCM-Steering column	√	√	√	√						
S-Class	222	Drive	VG-All-wheel drive	√	√	√	√						
S-Class	222	Body	FLANFS-Fire extinguishing system and emergency fresh air	√	√	√	√						
S-Class	222	Body	STM-Mirror taximeter	√	√	√	√						
S-Class	222	Driver assistance	NBR RR-Right rear short-range	√	√	√	√						
S-Class	222	Driver assistance	NBR LR-Left rear short-range	√	√	√	√						
S-Class	222	Chassis	ESP-Electric stability	√	√	√	√	√					
S-Class	222	Chassis	ESP-Electric stability	√	√	√	√						
S-Class	222	Drive	FSCU-Control unit Fuel pump	√	√	√	√						
S-Class	222	Drive	SCR-Selective catalytic reduction	√	√	√	√						
S-Class	222	Drive	SCR-Selective catalytic reduction	√	√	√	√						
S-Class	222	Drive	N127 (Drivetrain control unit)	√	√	√	√						
S-Class	222	Drive	N127 (Drivetrain control unit)	√	√	√	√						
S-Class	222	Drive	SG EM-Power electronics	√	√	√	√						
S-Class	222	Drive	SG EM-Power electronics	√	√	√	√						
S-Class	222	Drive	ISG-Integrated starter alternator	√	√	√	√						
S-Class	222	Drive	SG EM-Power electronics	√	√	√	√						
S-Class	222	Drive	ISG-Integrated starter alternator	√	√	√	√						
S-Class	222	Body	BMS-Battery management system	√	√	√	√						
S-Class	222	Body	BMS-Battery management system	√	√	√	√						
S-Class	222	Body	BMS-Battery management system	√	√	√	√						
S-Class	222	Drive	N3/10-Motor electronics "ME1778" for combustion engine	√	√	√	√						
S-Class	222	Drive	N3/10-Motor electronics "MED177" for combustion engine	√	√	√	√	√					
S-Class	222	Drive	N3/10-Motor electronics "MED1775" for combustion	√	√	√	√	√					
S-Class	222	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√					
S-Class	222	Drive	N3/10-Motor electronics "MED41" for combustion engine	√	√	√	√	√					
S-Class	222	Drive	N3/10-Motor electronics "MRG1" for combustion engine "M256"	√	√	√	√	√					
SL-Class	231	Drive	N3/10-Motor electronics "ME1778" for combustion engine "M279"	√	√	√	√		ACT1560,ACT1561,ACT1562,ACT1563,ACT1564,ACT1565,ACT1566,ACT1567,ACT1568,ACT1569,ACT1570,ACT1571	SP1603,SP1604,SP1605,SP1606	CD0769, CD0770, CD0771, CD0772, CD0773, CD0774, CD0775	√	
SL-Class	231	Drive	N3/10-Motor electronics "MED177" for combustion engine "M276"	√	√	√	√	√	ACT0802,ACT0803,ACT0804,ACT0805,ACT0806,ACT0807,ACT0808,ACT0809,ACT0810,ACT0811,ACT0812,ACT0813,ACT0814,ACT0815,ACT0816,ACT0817,ACT0818,ACT0819,	SP1335,SP1336,SP1337,SP1338,SP1339,SP1340,SP1341,SP1342,SP1343,SP1344,SP1345,SP1346,SP1347,SP1348	CD0544, CD0545, CD0546, CD0547, CD0548, CD0549, CD0550, CD0551, CD0552	√	

SL-Class	231	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√	ACT0821,ACT0822,ACT0823,ACT0824,ACT0825,ACT0826,ACT0827,ACT0828,ACT0829,ACT0830,ACT0831,ACT0832,ACT0833,ACT0834,ACT0835,ACT0836,ACT0837,ACT0838,	SP1349,SP1350,SP1351,SP1352,SP1353,SP1354,SP1355,SP1356,SP1357,SP1358,SP1359,SP1360,SP1361,SP1362,SP1363,SP1364	CD0553, CD0554, CD0555, CD0556, CD0557, CD0558, CD0559, CD0560, CD0561	√
SL-Class	231	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√	ACT0584,ACT0585	SP1229,SP1230,SP1231,SP1232,SP1233,SP1234,SP1235,SP1236,SP1237,SP1237,SP1238,SP1239,SP1240,SP1241,SP1242,	CD0465, CD0466, CD0467, CD0468	√
SL-Class	231	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√	ACT0587,ACT0588,ACT0589	SP1256,SP1257,SP1258,SP1259,SP1260,SP1261	CD0474, CD0475, CD0476, CD0477, CD0478	√
SL-Class	231	Information and communication	Left front short range radar	√	√	√	√					√
SL-Class	231	Information and communication	Left front short range radar	√								√
SL-Class	231	Information and communication	E call [Europe]-Emergency call system	√	√	√	√		ACT0044,ACT0045,ACT0046,ACT0047,ACT0048,ACT0049			
SL-Class	231	Drive	SG SOGE AGA-Sound generator for exhaust system	√	√	√	√		ACT1267,ACT1572			√
SL-Class	231	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√
SL-Class	231	Body	CGW[ZGW]-Central gateway	√	√	√	√			SP1365	CD0562	√
SL-Class	231	Body	CGW-Central gateway	√	√	√	√			SP1366		√
SL-Class	231	Information and communication	IC-Instrument cluster	√	√	√	√		ACT0050,ACT0051,ACT0052,ACT0053,ACT0054,ACT0055,	SP1047,SP1048		√
SL-Class	231	Information and communication	KOMO-Communication module Telematics services	√	√	√	√		ACT0057,ACT0058,ACT0059,ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065,			√
SL-Class	231	Seats and Doors	KOMO/mbrace-Communication module "Telematics services"/Notrufsystem	√	√	√	√		ACT0067,ACT0068,ACT0069,ACT0070,ACT0071,ACT0072,ACT0073,ACT0074	SP1049,SP1050		
SL-Class	231	Information and communication	TS-Telematic system(N123/4)	√	√	√	√		ACT0075,ACT0076,ACT0077,ACT0078			√
SL-Class	231	Body	EZS-Electronic ignition switch	√	√	√	√			SP1051,SP1052,SP1053	CD0320, CD0321, CD0322, CD0323, CD0324	
SL-Class	231	Body	EZS-Electronic ignition lock	√	√	√	√				CD0325	
SL-Class	231	Body	EZS-Electronic ignition lock	√	√	√	√					
SL-Class	231	Body	EZS-Electronic ignition lock	√	√	√	√					
SL-Class	231	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084			√
SL-Class	231	Body	MSC-MAGIC SKY	√	√	√	√		ACT0846			√
SL-Class	231	Chassis	AMG DRVU-AMG DRIVE UNIT(N145)	√	√	√	√		ACT0085,ACT0086,ACT0087			√
SL-Class	231	Information and communication	AMG PM-AMG Performance Media(N125/2)	√	√	√	√		ACT1089			√
SL-Class	231	Chassis	ESP-Electronic stability program(N30/4)	√	√	√	√	√	ACT0088,ACT0089	SP1054,SP1055		√

SL-Class	231	Information and communication	Audio-Audio or COMAND	√	√	√	√					
SL-Class	231	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
SL-Class	231	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√			SP1288,SP1289,SP1290,SP1291		√
SL-Class	231	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1292,SP1293,SP1294,SP1295,SP1296		√
SL-Class	231	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1297,SP1293,SP1294,SP1296		√
SL-Class	231	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0099,ACT0100	SP1056		√
SL-Class	231	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√				√
SL-Class	231	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√		ACT0101,ACT0102,ACT0103,ACT0104,ACT0105,ACT0106,ACT0107,ACT0108,ACT0109,ACT0110,ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,ACT0117,ACT0118,ACT0119,ACT0120,ACT0121,ACT0118,ACT0119,ACT0120,ACT0119,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0111,ACT0112,ACT0113,ACT0118,ACT0116,ACT0117,ACT0102,ACT0103,ACT0127,ACT0128,ACT0101,	SP1057,SP1058,SP1059,SP1060,SP1061		
SL-Class	231	Information and communication	Audio-Audio or COMAND	√	√	√	√					
SL-Class	231	Driver assistance system	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)	√	√	√	√		ACT0132	SP1062		√
SL-Class	231	Seats and Doors	PPAMKS-Pneumatic pump for active multicontour seat	√	√	√	√		ACT0628,ACT0629,ACT0630			√
SL-Class	231	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√		ACT0631,ACT0632,ACT0633,ACT0634,ACT0635			√
SL-Class	231	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√		ACT0636,ACT1573,ACT0637,ACT1574,ACT1575,ACT0643			√
SL-Class	231	Seats and Doors	AMKS RF-Active multicontour seat(N32/22)	√	√	√	√		ACT1576,ACT1577,ACT1578,ACT1579,ACT1580,ACT1494			√
SL-Class	231	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0156,ACT0157			√
SL-Class	231	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0156,ACT0157			√

SL-Class	231	Information and communication	SOUND-Sound system	√	√	√	√		ACT0158,ACT0159,ACT0160,ACT0161,ACT0162,ACT0163,ACT0164,ACT0165,ACT0166,ACT0167,ACT0168,ACT0169,ACT0170,ACT0171,ACT0172,ACT0173,ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0179,ACT0180,ACT0181,		CD0348	
SL-Class	231	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0185,ACT0186,ACT0187,ACT0188,ACT0189,ACT0190,ACT0191,ACT0192,ACT0193,ACT0194,ACT0195,ACT0196,ACT0197,ACT0198,			
SL-Class	231	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0199,ACT0653,ACT0185,ACT0186,ACT0654,ACT0655,ACT0195,ACT0196,ACT0193,ACT0200,ACT0194,ACT0188,ACT0190,ACT0191,ACT0192,ACT0656,ACT0657,ACT0206,			
SL-Class	231	Chassis	ABC-Active body control(N51/2)	√	√	√	√		ACT1581,ACT1582,ACT1583,ACT1584,ACT1585,ACT1586,ACT1587,ACT1588,ACT1589,ACT1590,ACT1591,ACT1592,	SP1607,SP1608,SP1609,SP1610,SP1611,SP1612		√
SL-Class	231	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√		ACT0207,ACT0208,ACT0209,ACT0210	SP1064		√
SL-Class	231	Chassis	ADS-Adaptive damping system	√	√	√	√		ACT0858,ACT0859,ACT0860,ACT0861	SP1372		√
SL-Class	231	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√		ACT0207,ACT0208,ACT0209,ACT0210	SP1064	CD0349	√
SL-Class	231	Information and communication	TV-TV tuner	√	√	√	√		ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0219,ACT0220,ACT0221,ACT0222,ACT0223		CD0350CD0351, CD0352, CD0353, CD0354, CD0355, CD0356, CD0357, CD0358, CD0359, CD0360, CD0361	
SL-Class	231	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0677,ACT0233			
SL-Class	231	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0230,ACT0231,ACT0232,ACT0233		CD0362CD0363, CD0364, CD0365, CD0366, CD0367, CD0368, CD0369, CD0370, CD0371, CD0372, CD0373	
SL-Class	231	Driver assistance	MFK-Multifunction camera	√	√	√	√		ACT0234,ACT0235	SP1066		√
SL-Class	231	Driver assistance	MFK-Multifunction	√	√	√	√		ACT0236,ACT0237	SP1067,SP1068		√
SL-Class	231	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		ACT0238,ACT0241,ACT0678,ACT0244,ACT0243,ACT0681,ACT1280,ACT0253,ACT0254,ACT0691,ACT0692,ACT0685,ACT0686,ACT0687,ACT0688,	SP1069,SP1070,SP1071		√

SL-Class	231	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√					
SL-Class	231	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√					
SL-Class	231	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258		CD0382	
SL-Class	231	Information and communication	Drive Kit Plus-Drive kit for iPhone	√	√	√	√		ACT0263,ACT0264,ACT0265,ACT0266			
SL-Class	231	Chassis	ES-Electric power steering(N68)	√	√	√	√			SP1302		√
SL-Class	231	Body	RevETR LF-Left front reversible emergency tensioning retractor (A76)	√	√	√	√		ACT0708			√
SL-Class	231	Body	RevETR RF-Right front reversible emergency tensioning retractor(A76/1)	√	√	√	√		ACT0709			√
SL-Class	231	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√		ACT0276,ACT0277,ACT0278,ACT0279,ACT0280,ACT0281,	SP1078,SP1079		√
SL-Class	231	Information and communication	SDAR-Satellite radio	√	√	√	√		ACT0283,ACT0284,ACT0285,ACT0286		CD0387CD0388, CD0389, CD0389	
SL-Class	231	Information and communication	TB5-TV tuner Tuner unit	√	√	√	√		ACT0287,ACT0288,ACT0289,ACT0290,ACT0291,ACT0292,ACT0293,ACT0294,			
SL-Class	231	Information and communication	TV tuner (TV)	√	√	√	√		ACT0295,ACT0296,ACT0297,ACT0298,ACT0299,ACT0300,			
SL-Class	231	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√		ACT0302,ACT0303,ACT0304,ACT0305,ACT0306,ACT0307,ACT0308	SP1080,SP1081		√
SL-Class	231	Information and communication	MIF-Media interface	√	√	√	√					
SL-Class	231	Information and communication	MIF-Media interface	√	√	√	√		ACT0309			
SL-Class	231	Drive	ISM-Shift module	√	√	√	√		ACT0717,ACT0718,ACT0719,ACT0720,ACT0721	SP1312,SP1313,SP1314		√
SL-Class	231	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√
SL-Class	231	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√		ACT0884,ACT0885,ACT0886,ACT0887,ACT0888,ACT0889,ACT0890,ACT0891			√
SL-Class	231	Body	Driver side SAM-Driver signal acquisition and actuation module	√	√	√	√		ACT0876,ACT0877,ACT0878,ACT0879,ACT0880,ACT0881,ACT0882,ACT0883			√

SL-Class	231	Body	Rear SAM-Rear signal acquisition and actuation module	√	√	√	√	ACT0892,ACT0893,ACT0894,ACT0895,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0901,ACT0902,ACT0903,ACT0904,ACT0905,ACT0906,ACT0907,ACT0908,ACT0909,ACT0910,ACT0911,ACT0912,ACT0913,ACT0914,ACT0915,ACT0916,ACT0917,ACT0918,ACT0919,ACT0920,ACT0921,ACT0922,ACT0923,ACT0924,ACT0925,ACT0926,ACT0927,ACT0928,ACT0929,ACT0892,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0892,ACT0894,ACT0896,ACT0897,ACT0898,ACT0899,ACT0900,ACT0927,ACT0928,ACT0930,ACT0927,ACT0931,ACT0928,ACT0932,,ACT0933,ACT0934			√
SL-Class	231	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√

SL-Class	231	Body	REAR SAM-Rear signal acquisition and actuation module	√	√	√	√	ACT0943,ACT0944,ACT0945,ACT0946,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0952,ACT0953,ACT0954,ACT0955,ACT0956,ACT0957,ACT0958,ACT0959,ACT0960,ACT0961,ACT0962,ACT0963,ACT0964,ACT0965,ACT0966,ACT0967,ACT0968,ACT0969,ACT0970,ACT0971,ACT0972,ACT0973,ACT0974,ACT0975,ACT0976,ACT0977,ACT0978,ACT0979,ACT0980,ACT0943,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0943,ACT0945,ACT0947,ACT0948,ACT0949,ACT0950,ACT0951,ACT0978,ACT0979,ACT0981,ACT0978,ACT0982,ACT0979,ACT0983,,ACT0984,ACT0985			√	
SL-Class	231	Driver assistance	DTR-DISTRONIC	√	√	√	√					√
SL-Class	231	Driver assistance	DTR-DISTRONIC	√	√	√	√					√
SL-Class	231	Driver assistance	DTR-DISTRONIC (A89)	√	√	√	√			SP1084	CD0395	√
SL-Class	231	Chassis	DTR-DISTRONIC (A89)	√	√	√	√			SP1084	CD0395	√
SL-Class	231	Seats and Doors	LFD-Left front door	√	√	√	√	ACT0386,ACT0387,ACT0388,ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0397,ACT0398,ACT0399,ACT0400,ACT0401,ACT0402,ACT0403,	SP1085			√
SL-Class	231	Driver assistance	NSA-Night View Assist(N101)	√	√	√	√	ACT1438,ACT0740	SP1320			√
SL-Class	231	Seats and Doors	DCU RF-Right front door	√	√	√	√	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410,ACT0411,ACT0412,ACT0413,ACT0414,ACT0415,ACT0416,ACT0417,ACT0418,ACT0419,ACT0420,ACT0421,ACT0422,	SP1086			√
SL-Class	231	Information and communication	TV-TV tuner	√	√	√	√	ACT0424,ACT0425,ACT0426,ACT0427,ACT0222,ACT0428,ACT0219,ACT0221				
SL-Class	231	Information and communication	TV-TV tuner	√	√	√	√	ACT0429,ACT0430,ACT0431,ACT0229,ACT0432,ACT0433,				
SL-Class	231	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	ACT0255,ACT0256,ACT0257,ACT0258				
SL-Class	231	Seats and Doors	BFS LSE-Lumbar support 'Front passenger seat'(N32/24)	√	√	√	√	ACT1595,ACT1596				
SL-Class	231	Body	STC-Soft top control(N52)	√	√	√	√	ACT0999,ACT1597,ACT1000,ACT1597,ACT1001,ACT1598,ACT1599,ACT1600,ACT1601,	SP1613,SP1614,SP1615			√

SL-Class	231	Seats and Doors	LSE FS-N32/23 (Driver seat lumbar support adjustment)	√	√	√	√		ACT1603,ACT1604			
SL-Class	231	Chassis	EFB-Electronic parking brake(N128)	√	√	√	√		ACT0435,ACT0436,ACT0437,ACT0438	SP1087		√
SL-Class	231	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439,ACT0440	SP1088,SP1089		√
SL-Class	231	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439	SP1088,SP1089		√
SL-Class	231	Chassis	FGW-Chassis gateway	√	√	√	√				CD0535	√
SL-Class	231	Body	AIRSCARF-Neck heating system(N25/7)	√	√	√	√					√
SL-Class	231	Body	WSS-Weight sensing	√	√	√	√					
SL-Class	231	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
SL-Class	231	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
SL-Class	231	Body	BSN-Battery sensor(B95)	√	√	√	√					
SL-Class	231	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0442,ACT0443,ACT0444,ACT0445,ACT0446			√
SL-Class	231	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0447,ACT0448,ACT0449,ACT0450			√
SL-Class	231	Body	SG SW-Control unit 'Headlamp'(N71/1)	√	√	√	√		ACT0451,ACT0452,ACT0453,ACT0454,ACT0455	SP1090,SP1091,SP1092,SP1093	CD0397	√
SL-Class	231	Body	SG SW L-Left headlamp	√	√	√	√		ACT0456,ACT0457,ACT0458,ACT0459,ACT0460,ACT0461	SP1094,SP1095,SP1096,SP1097,SP1098,SP1099,	CD0398	√
SL-Class	231	Body	SG SW L-Left headlamp(E1n9)	√	√	√	√		ACT0462,ACT0463,ACT0464,ACT0465,ACT0466,ACT0467	SP1101,SP1102,SP1103,SP1104,SP1105,SP1106,SP1107,SP1108	CD0399	√
SL-Class	231	Body	SG SW R-Right headlamp	√	√	√	√		ACT0468,ACT0469,ACT0470,ACT0471,ACT0472,ACT0473	SP1109,SP1110,SP1111,SP1112,SP1113,SP1114	CD0400	√
SL-Class	231	Body	SG SW R-Right headlamp(E1n9)	√	√	√	√		ACT0474,ACT0475,ACT0476,ACT0477,ACT0478,ACT0479	SP1115,SP1116,SP1117,SP1118,SP1119,SP1120	CD0401	√
SL-Class	231	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
SL-Class	231	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
SL-Class	231	Body	FSW-Windshield wiper	√	√	√	√		ACT1005,			
SL-Class	231	Body	FSW-Windshield wiper	√	√	√	√		ACT1005,			
SL-Class	231	Body	GTO-Garage door	√	√	√	√					
SL-Class	231	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√					
SL-Class	231	Body	OCP-Control unit 'Overhead control panel'	√	√	√	√					
SL-Class	231	Driver assistance	PARK-Parking system (N62)	√	√	√	√		ACT0484,ACT0485		CD0411, CD0412	√
SL-Class	231	Driver assistance system	PTS-Parktronic system	√	√	√	√		ACT1053		CD0536, CD0537, CD0538, CD0539	√
SL-Class	231	Body	Exterior lights switch	√	√	√	√					
SL-Class	231	Body	UCP-Upper control panel	√	√	√	√					
SL-Class	231	Body	LCP-Lower control panel	√	√	√	√					
SL-Class	231	Body	AU-Analog clock	√	√	√	√					

SL-Class	231	Information and communication	DSI-DIRECT SELECT interface(N150)	√	√	√	√		ACT0488				√
SL-Class	231	Body	AS-Alarm siren(H3/1)	√	√	√			ACT1007				
SL-Class	231	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT1007				
SL-Class	231	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√		ACT1008,ACT1009				
SL-Class	231	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√						
SL-Class	231	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√		ACT0794,ACT0795	SP1325,SP1326,SP1327	CD0540		
SL-Class	231	Body	AMLAB L 2-Actuation module 2, LED exterior lighting, left	√	√	√	√		ACT0796,ACT0797	SP1328,SP1329,SP1330	CD0541		
SL-Class	231	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√						
SL-Class	231	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√		ACT0798,ACT0799	SP1331,SP1332	CD0542		
SL-Class	231	Body	AMLAB R 2-Actuation module 2, LED exterior lighting, right front(E2n8)	√	√	√	√		ACT0800,ACT0801	SP1333,SP1334	CD0543		
SL-Class	231	Drive	FSCU-Fuel pump	√	√	√	√		ACT0498,ACT0499		CD0427, CD0428		√
E-Class	238	Drive	N3/9-Motor electronics "CDI61" for combustion engine "OM642"	√	√	√	√	√					
E-Class	238	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√					
E-Class	238	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√					
E-Class	238	Seats and Doors	LFD-Left front door	√	√	√	√						
E-Class	238	Seats and Doors	LFD-Left front door	√	√	√	√						
E-Class	238	Seats and Doors	DCU RF-Right front door	√	√	√	√						
E-Class	238	Seats and Doors	DCU RF-Right front door	√	√	√	√						
E-Class	238	Body	SG FOND-Rear control unit	√	√	√	√						
E-Class	238	Body	SRS-Supplemental restraint	√	√	√	√	√					
E-Class	238	Body	EZS-Electronic ignition lock	√	√	√	√						
E-Class	238	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√						
E-Class	238	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√						
E-Class	238	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√						
E-Class	238	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√						
E-Class	238	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√						
E-Class	238	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√						
E-Class	238	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√						

E-Class	238	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√				
E-Class	238	Seats and Doors	ESE_RL-Left rear electrical seat adjustment	√	√	√	√				
E-Class	238	Seats and Doors	Right rear ESE-Right rear electrical seat adjustment	√	√	√	√				
E-Class	238	Information and communication	HERMES-control unit for telematics services	√	√	√	√				
E-Class	238	Information and communication	MTAS-Mobile phone cradle	√	√	√	√				
E-Class	238	Seats and Doors	MKS LF-Left front multicontour	√	√	√	√				
E-Class	238	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√				
E-Class	238	Seats and Doors	MKS LF-Left rear multicontour	√	√	√	√				
E-Class	238	Seats and Doors	MKS RF-Right rear multicontour	√	√	√	√				
E-Class	238	Air conditioning	AAC-Automatic air conditioning	√	√	√	√				
E-Class	238	Seats and Doors	HKS-Tailgate control	√	√	√	√				
E-Class	238	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√				
E-Class	238	Body	Trailer recognition module-Trailer recognition	√	√	√	√				
E-Class	238	Body	Multifunction control unit-Multifunction control unit	√	√	√	√				
E-Class	238	Body	PSD-Panoramic sliding roof	√	√	√	√				
E-Class	238	Body	PSD-Control module Panoramic sliding roof	√	√	√	√			SP1536	
E-Class	238	Body	AML-Ambiance light	√	√	√	√				
E-Class	238	Body	KG-Keyless Go	√	√	√	√				
E-Class	238	Body	OCP-Overhead control panel	√	√	√	√				
E-Class	238	Body	OCP-Overhead control panel	√	√	√	√				
E-Class	238	Body	DC/DC-DC/DC converter	√	√	√	√				
E-Class	238	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√				
E-Class	238	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√				
E-Class	238	Information and communication	SG MSND-Engine sound	√	√	√	√				
E-Class	238	Body	LRE-Steering wheel electronics	√	√	√	√				
E-Class	238	Body	LRE-Steering wheel electronics	√	√	√	√				
E-Class	238	Information and communication	TSC H-Touchscreen in rear passenger compartment	√	√	√	√				
E-Class	238	Information and communication	TPAD-Touchpad	√	√	√	√				
E-Class	238	Information and communication	TPAD-Touchpad	√	√	√	√				
E-Class	238	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√				

E-Class	238	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
E-Class	238	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
E-Class	238	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
E-Class	238	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
E-Class	238	Information and communication	Audio-Audio or COMAND	√	√	√						
E-Class	238	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
E-Class	238	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√					
E-Class	238	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
E-Class	238	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
E-Class	238	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
E-Class	238	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
E-Class	238	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
E-Class	238	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
E-Class	238	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
E-Class	238	Information and communication	IC-Instrument cluster	√	√	√	√			SP1047,SP1048,SP1157		
E-Class	238	Information and communication	IC-Instrument cluster(A1)	√	√	√	√					
E-Class	238	Information and communication	HUD-Head up display	√	√	√						
E-Class	238	Information and communication	HUD-Head up display	√	√	√	√					
E-Class	238	Driver assistance	RFK-Backup camera	√	√	√	√					
E-Class	238	Driver assistance	RFK-Backup camera	√	√	√	√					
E-Class	238	Driver assistance	KAR-Augmented reality camera	√	√	√	√					
E-Class	238	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
E-Class	238	Chassis	AMG DRVU-AMG DRIVE	√	√	√						
E-Class	238	Chassis	AMG DRVU-AMG DRIVE	√	√	√	√					
E-Class	238	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√					
E-Class	238	Body	SG SW L-Left headlamp	√	√	√	√					
E-Class	238	Body	SG SW L-Left headlamp	√	√	√	√					
E-Class	238	Body	SG SW L-Left headlamp	√	√	√	√					
E-Class	238	Body	SG SW R-Right headlamp	√	√	√	√					

E-Class	238	Body	SG SW R-Right headlamp	√	√	√	√					
E-Class	238	Body	SG SW R-Right headlamp	√	√	√	√					
E-Class	238	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√					
E-Class	238	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√					
E-Class	238	Driver assistance	TPM-Tire pressure monitor(N88)	√	√	√	√					
E-Class	238	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
E-Class	238	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√					
E-Class	238	Drive	HFPM-Haptic accelerator pedal module	√	√	√	√					
E-Class	238	Body	SG LG-Charger	√	√	√	√					
E-Class	238	Body	GES-Hand motion sensor	√	√	√	√					
E-Class	238	Body	BSN-Battery sensor(B95)	√	√	√	√					
E-Class	238	Body	LIB-Lithium ion battery	√	√	√	√					
E-Class	238	Body	LIB-Lithium ion battery	√	√	√	√					
E-Class	238	Body	AU-Analog clock	√	√	√	√					
E-Class	238	Body	Button group, instrument panel, driver side	√	√	√	√					
E-Class	238	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
E-Class	238	Body	FSW-Windshield wiper	√	√	√	√					
E-Class	238	Body	FSW-Windshield wiper	√	√	√	√					
E-Class	238	Body	GTO-Garage door	√	√	√	√					
E-Class	238	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√					
E-Class	238	Body	AIRSCARF-Neck heating system(N25/7)	√	√	√	√					
E-Class	238	Body	"Front passenger" seat heater	√	√	√	√					
E-Class	238	Body	"Driver" seat heater	√	√	√	√					
E-Class	238	Body	N5 (Armrest heater control unit)	√	√	√	√					
E-Class	238	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√					
E-Class	238	Seats and Doors	LFD-Left front door	√	√	√	√					
E-Class	238	Seats and Doors	LFD-Left front door	√	√	√	√					
E-Class	238	Seats and Doors	LFD-Left front door	√	√	√	√					
E-Class	238	Seats and Doors	DCU RF-Right front door	√	√	√	√					
E-Class	238	Seats and Doors	DCU RF-Right front door	√	√	√	√					
E-Class	238	Body	"Driver" seat heater	√	√	√	√					
E-Class	238	Body	"Front passenger" seat heater	√	√	√	√					
E-Class	238	Seats and Doors	Seat heater in left rear passenger compartment	√	√	√	√					
E-Class	238	Seats and Doors	Seat heater in right rear passenger compartment	√	√	√	√					
E-Class	238	Body	AS-Alarm siren(H3/1)	√	√	√	√					

E-Class	238	Body	IRSS-VL-Left front interior protection sensor	√	√	√						
E-Class	238	Body	IRSS-VR-Right front interior protection sensor	√	√	√						
E-Class	238	Body	IRSS-FOR-Right rear interior protection sensor	√	√	√						
E-Class	238	Body	IRSS-FOL-Left rear interior protection sensor	√	√	√						
E-Class	238	Seats and Doors	Massage function in left front seat	√	√	√	√					
E-Class	238	Seats and Doors	MFSF-LF	√	√	√	√					
E-Class	238	Seats and Doors	Massage function in right front	√	√	√	√					
E-Class	238	Seats and Doors	MFSF-RF	√	√	√	√					
E-Class	238	Seats and Doors	Massage function in left rear seat	√	√	√	√					
E-Class	238	Seats and Doors	Massage function in right rear	√	√	√	√					
E-Class	238	Air conditioning	N61 (Windshield heater control	√	√	√						
E-Class	238	Air conditioning	AAC-Automatic air conditioning	√	√	√						
E-Class	238	Air conditioning	STH-Stationary heater	√	√	√	√					
E-Class	238	Air conditioning	AAC-Automatic air conditioning	√	√	√						
E-Class	238	Air conditioning	AAC-Automatic air conditioning	√	√	√						
E-Class	238	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√					
E-Class	238	Body	SCM-Steering column	√	√	√	√					
E-Class	238	Information and communication	N72/1 (Upper control panel control unit)	√	√	√						
E-Class	238	Information and communication	N72/5 (Right lower control panel)	√	√	√						
E-Class	238	Information and communication	N72/4 (Left lower control panel)	√	√	√						
E-Class	238	Body	WSS-Weight sensing	√	√	√	√					
E-Class	238	Body	N38 (Rear switching module)	√	√	√	√					
E-Class	238	Body	LIB-Lithium ion battery	√	√	√	√					
E-Class	238	Information and communication	TV tuner (TV)	√	√	√	√					
E-Class	238	Information and communication	TV tuner (TV)	√	√	√	√					
E-Class	238	Information and communication	TV tuner (TV)	√	√	√	√					
E-Class	238	Information and communication	TV tuner (TV)	√	√	√	√					
E-Class	238	Information and communication	SOUND-Sound system	√	√	√	√					
E-Class	238	Information and communication	SOUND-Sound system	√	√	√	√					
E-Class	238	Information and communication	DAB-Digital radio Tuner unit	√	√	√	√					
E-Class	238	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					
E-Class	238	Driver assistance	DTR-DISTRONIC	√	√	√	√					

E-Class	238	Driver assistance	SGR-Radar sensors control unit	√	√	√	√					
E-Class	238	Driver assistance	DTR-DISTRONIC	√	√	√	√					
E-Class	238	Driver assistance	PTS-PARKTRONIC	√	√	√	√					
E-Class	238	Chassis	ELC-Electronic level control	√	√	√	√					
E-Class	238	Chassis	ADS-Adaptive damping system	√	√	√	√					
E-Class	238	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√					
E-Class	238	Chassis	ES - Electric power steering	√	√	√	√					
E-Class	238	Chassis	ES - Electric power steering	√	√	√	√					
E-Class	238	Body	LRE-Steering wheel electronics	√	√	√	√					
E-Class	238	Chassis	AIRmatic-AIRmatic PLUS	√	√	√	√					
E-Class	238	Drive	VG-All-wheel drive	√	√	√	√					
E-Class	238	Body	STM-Mirror taximeter	√	√	√	√					
E-Class	238	Driver assistance	NBR LF-Left front short range	√	√	√	√					
E-Class	238	Driver assistance system	NBR RF-Right front short range radar	√	√	√	√					
E-Class	238	Driver assistance	NBR RR-Right rear short-range	√	√	√	√					
E-Class	238	Driver assistance	NBR LR-Left rear short-range	√	√	√	√					
E-Class	238	Chassis	ESP-Electric stability	√	√	√	√	√				
E-Class	238	Chassis	ESP-Electric stability	√	√	√	√	√				
E-Class	238	Chassis	ESP-Electric stability	√	√	√	√					
E-Class	238	Drive	FSCU-Control unit Fuel pump	√	√	√	√					
E-Class	238	Drive	SCR-Selective catalytic reduction	√	√	√	√					
E-Class	238	Drive	SCR-Selective catalytic reduction	√	√	√	√					
E-Class	238	Drive	N127 (Drivetrain control unit)	√	√	√						
E-Class	238	Drive	N127 (Drivetrain control unit)	√	√	√	√					
E-Class	238	Drive	SG EM-Power electronics	√	√	√	√					
E-Class	238	Drive	ISG-Integrated starter alternator	√	√	√	√					
E-Class	238	Drive	ISG-Integrated starter alternator	√	√	√						
E-Class	238	Drive	ISG-Integrated starter alternator	√	√	√	√					
E-Class	238	Body	BMS-Battery management system	√	√	√	√					
E-Class	238	Body	BMS-Battery management system	√	√	√	√					
E-Class	238	Drive	N3/10-Motor electronics "MED1775" for combustion	√	√	√	√	√				
E-Class	238	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√				
E-Class	238	Drive	N3/10-Motor electronics "MED40" for combustion engine	√	√	√	√	√				
E-Class	238	Drive	N3/10-Motor electronics "MED41" for combustion engine	√	√	√	√	√				
E-Class	238	Drive	N3/10-Motor electronics "MRG1" for combustion engine "M256"	√	√	√	√	√				
ED-Class	243	Seats and Doors	LFD-Left front door	√	√	√	√					
ED-Class	243	Seats and Doors	DCU RF-Right front door	√	√	√	√					
ED-Class	243	Body	SRS-Supplemental restraint	√	√	√	√	√				

ED-Class	243	Information and communication	CTEL-Cellular telephone	√	√	√	√					
ED-Class	243	Body	EZS-Electronic ignition switch	√	√	√	√					
ED-Class	243	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					
ED-Class	243	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√					
ED-Class	243	Information and communication	HERMES-control unit for telematics services	√	√	√	√					
ED-Class	243	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
ED-Class	243	Seats and Doors	MKS-FS-Pilot multi-profile seat	√	√	√	√					
ED-Class	243	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
ED-Class	243	Seats and Doors	MKS-BFS-Front passenger more copy the seat	√	√	√	√					
ED-Class	243	Seats and Doors	HKS-Tailgate control	√	√	√	√					
ED-Class	243	Body	ATA-Interior motion sensor	√	√	√	√					
ED-Class	243	Body	Trailer recognition module-Trailer recognition	√	√	√	√					
ED-Class	243	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
ED-Class	243	Body	PSD-Control module Panoramic sliding roof	√	√	√	√					
ED-Class	243	Body	PSD-Panoramic sliding roof	√	√	√	√					
ED-Class	243	Body	AML-Ambiance light	√	√	√	√					
ED-Class	243	Drive	SG EM-Power electronics	√	√	√	√					
ED-Class	243	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√					
ED-Class	243	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√					
ED-Class	243	Body	LRE-Steering wheel electronics	√	√	√	√					
ED-Class	243	Information and communication	TPAD-Touchpad	√	√	√	√					
ED-Class	243	Information and communication	Audio-Audio or COMAND	√	√	√						
ED-Class	243	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
ED-Class	243	Body	HE-Hand detection	√	√	√	√					
ED-Class	243	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
ED-Class	243	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
ED-Class	243	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
ED-Class	243	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
ED-Class	243	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					

ED-Class	243	Information and communication	IC-Instrument cluster	√	√	√	√			SP1047,SP1048,SP1157		
ED-Class	243	Information and communication	HUD-Head up display	√	√	√	√					
ED-Class	243	Driver assistance	RFK-Backup camera	√	√	√	√					
ED-Class	243	Driver assistance	KAR-Augmented reality camera	√	√	√	√					
ED-Class	243	Information and communication	CSM-Windshield reader system	√	√	√	√					
ED-Class	243	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√					
ED-Class	243	Body	SG SW L-Left headlamp	√	√	√	√					
ED-Class	243	Body	SG SW R-Right headlamp	√	√	√	√					
ED-Class	243	Driver assistance	TPM-Tire pressure monitor(N88)	√	√	√	√					
ED-Class	243	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
ED-Class	243	Body	DCCU-Direct current charge connection unit	√	√	√	√					
ED-Class	243	Drive	SG EM-Power electronics	√	√	√	√					
ED-Class	243	Body	SG LG-Charger	√	√	√	√					
ED-Class	243	Body	DC/DC-DC converter	√	√	√	√					
ED-Class	243	Body	SG LG-Charger	√	√	√	√					
ED-Class	243	Body	BSN-Battery sensor(B95)	√	√	√	√					
ED-Class	243	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
ED-Class	243	Body	FSW-Windshield wiper	√	√	√	√					
ED-Class	243	Body	GTO-Garage door	√	√	√	√					
ED-Class	243	Body	OCP-Overhead control panel	√	√	√	√					
ED-Class	243	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√					
ED-Class	243	Body	"Front passenger" seat heater	√	√	√	√					
ED-Class	243	Body	"Driver" seat heater	√	√	√	√					
ED-Class	243	Seats and Doors	S47/2 (Driver door switch	√	√	√	√					
ED-Class	243	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	√					
ED-Class	243	Seats and Doors	S22 (Driver"s door seat adjustment switch)	√	√	√	√					
ED-Class	243	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	√					
ED-Class	243	Seats and Doors	S51/1 (Driver seat climate control switch group)	√	√	√	√					
ED-Class	243	Seats and Doors	S51/2 (Front passenger seat climate control switch group)	√	√	√	√					
ED-Class	243	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
ED-Class	243	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
ED-Class	243	Body	AS-Alarm siren(H3/1)	√	√	√	√					
ED-Class	243	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
ED-Class	243	Body	WSS-Weight sensing	√	√	√	√					
ED-Class	243	Body	N38 (Rear switching module)	√	√	√	√					

ED-Class	243	Information and communication	SOUND-Sound system	√	√	√	√					
ED-Class	243	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					
ED-Class	243	Driver assistance	DTR-DISTRONIC	√	√	√	√					
ED-Class	243	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√					
ED-Class	243	Driver assistance	SGR-Radar sensors control unit	√	√	√	√					
ED-Class	243	Driver assistance	PTS-PARKTRONIC	√	√	√	√					
ED-Class	243	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√					
ED-Class	243	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√					
ED-Class	243	Chassis	ES - Electric power steering	√	√	√	√					
ED-Class	243	Body	SCM-Steering column module	√	√	√	√					
ED-Class	243	Body	STM-Mirror taximeter	√	√	√	√					
ED-Class	243	Driver assistance	NBR RR-Right rear short-range	√	√	√	√					
ED-Class	243	Driver assistance	NBR LR-Left rear short-range	√	√	√	√					
ED-Class	243	Chassis	ESP- Electric stability program	√	√	√	√	√				
ED-Class	243	Body	BMS-Battery management system	√	√	√	√					
ED-Class	243	Body	BMS-Battery management system	√	√	√	√					
ED-Class	243	Drive	N127 (Drivetrain control unit)	√	√	√	√					
B-Class	246	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√	√	ACT0000,ACT0001,ACT0002,ACT0003,ACT0004,ACT0005,ACT0006,ACT0007,ACT0008,ACT0009,ACT0010,ACT0011,ACT0012,ACT0013,ACT0014,ACT0015,ACT0016,ACT0017,ACT0018,ACT0019,ACT0020,ACT0021,,ACT0022,ACT0023,ACT0024,ACT0025,ACT0026	SP1000,SP1001,SP1002,SP1003,SP1004,SP1005,SP1006,SP1007,SP1008,SP1009,SP1010,SP1011,SP1012,SP1013,SP1014,SP1015,SP1016,SP1017,SP1018,SP1019,SP1020,SP1021,SP1022,SP1023,SP1024	CD0304, CD0305, CD0306, CD0307	√
B-Class	246	Drive	N3/9-Motor electronics "CDID3" for combustion engine "OM651"	√	√	√	√		ACT0001,ACT0004,ACT0005,ACT0002,ACT0028,ACT0008,ACT0009,ACT0010,ACT0011,ACT0022,ACT0023,ACT0024,ACT0012,ACT0015,ACT0026,	SP1025,SP1000,SP1004,SP1003,SP1005,SP1026,SP1007,SP1012,SP1013,SP1006,SP1027,SP1009,SP1017,SP1028,SP1029	CD0304, CD0305, CD0306	√
B-Class	246	Drive	N3/3-Motor electronics "OM607" for combustion engine "CRR1"	√	√	√	√	√	ACT0029,ACT0030,ACT0031,ACT0032,ACT0033,ACT0034,ACT0035,ACT0036,ACT0037,ACT0038,ACT0039,ACT0040,ACT0041,ACT0042,ACT0043	SP1030,SP1031,SP1032,SP1033,SP1034,SP1035,SP1036,SP1037,SP1038,SP1039,SP1040,SP1041,SP1042,SP1043,SP1044,	CD0308, CD0309, CD0310	√
B-Class	246	Drive	DKG-Electronic transmission control for double-plate clutch	√	√	√	√	√	ACT0493,ACT0494,ACT0495,ACT0496,ACT0497	SP1126,SP1127,SP1128	CD0423, CD0424, CD0425, CD0426	√
B-Class	246	Chassis	Powertrain control unit gateway	√	√	√	√					√
B-Class	246	Information and communication	E call [Europe]-Emergency call system	√	√	√	√		ACT0044,ACT0045,ACT0046,ACT0047,ACT0048,ACT0049			
B-Class	246	Information and communication	IC-Instrument cluster	√	√	√	√		ACT0050,ACT0051,ACT0052,ACT0053,ACT0054,ACT0055,	SP1047,SP1048		√

B-Class	246	Information and communication	KOMO-Communication module Telematics services	√	√	√	√		ACT0057,ACT0058,ACT0059,ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065,			√
B-Class	246	Seats and Doors	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√		ACT0067,ACT0068,ACT0069,ACT0070,ACT0071,ACT0072,ACT0073,ACT0074	SP1049,SP1050		
B-Class	246	Information and communication	TS-Telematic system(N123/4)	√	√	√	√		ACT0075,ACT0076,ACT0077,ACT0078			√
B-Class	246	Body	EZS-Electronic ignition switch	√	√	√	√			SP1051,SP1052,SP1053	CD0320, CD0321, CD0322, CD0323, CD0324	
B-Class	246	Body	EZS-Electronic ignition lock	√	√	√	√				CD0325	
B-Class	246	Body	EZS-Electronic ignition lock	√	√	√	√					
B-Class	246	Body	EZS-Electronic ignition lock	√	√	√	√					
B-Class	246	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084			√
B-Class	246	Chassis	AMG DRVU-AMG DRIVE UNIT(N145)	√	√	√	√		ACT0085,ACT0086,ACT0087			√
B-Class	246	Chassis	ESP-Electronic stability program(N30/4)	√	√	√	√	√	ACT0088,ACT0089	SP1054,SP1055		√
B-Class	246	Body	RBS-Regenerative braking system	√	√	√	√		ACT1605,ACT1606	SP1616,SP1617,SP1618,SP1619,SP1620,SP1621	CD0778, CD0779, CD0780, CD0781,	√
B-Class	246	Information and communication	NAV-Navigation module(A2/30)	√	√	√	√		ACT0090,ACT0091,ACT0092,ACT0093			√
B-Class	246	Information and communication	Audio-Audio or COMAND	√	√	√	√					
B-Class	246	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
B-Class	246	Body	IMS-Interior motion sensor	√	√	√	√		ACT0094,ACT0095,ACT0096			√
B-Class	246	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0099,ACT0100	SP1056		√
B-Class	246	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√				√
B-Class	246	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√		ACT0101,ACT0102,ACT0103,ACT0104,ACT0105,ACT0106,ACT0107,ACT0108,ACT0109,ACT0110,ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,ACT0117,ACT0118,ACT0119,ACT0120,ACT0121,ACT0118,ACT0119,ACT0120,ACT0119,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0111,ACT0112,ACT0113,ACT0118,ACT0116,ACT0117,ACT0102,ACT0103,ACT0127,ACT0128,ACT0101,	SP1057,SP1058,SP1059,SP1060,SP1061		
B-Class	246	Information and communication	Audio-Audio or COMAND	√	√	√	√					

B-Class	246	Driver assistance system	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)	√	√	√	√		ACT0132	SP1062		√
B-Class	246	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					
B-Class	246	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					√
B-Class	246	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					
B-Class	246	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					√
B-Class	246	Body	Multifunction control unit-Multifunction control unit	√	√	√	√		ACT0133,ACT0134,ACT0135,ACT0136,ACT0137,ACT0138,ACT0139,ACT0140,ACT0141,ACT0142,ACT0143,ACT0144,ACT0145,ACT0146,ACT0147,ACT0148,ACT0149,ACT0150,			√
B-Class	246	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0156,ACT0157			√
B-Class	246	Information and communication	SOUND-Sound system	√	√	√	√		ACT0158,ACT0159,ACT0160,ACT0161,ACT0162,ACT0163,ACT0164,ACT0165,ACT0166,ACT0167,ACT0168,ACT0169,ACT0170,ACT0171,ACT0172,ACT0173,ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0179,ACT0180,ACT0181,		CD0348	
B-Class	246	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0199,ACT0186,ACT0187,ACT0189,ACT0191,ACT0192,ACT0200,ACT0195,ACT0196,ACT0201,ACT0202,ACT0194,ACT0203,ACT0204,ACT0205,ACT0197,ACT0206,ACT0198	SP1063		
B-Class	246	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√		ACT0207,ACT0208,ACT0209,ACT0210	SP1064	CD0349	√
B-Class	246	Information and communication	TV-TV tuner	√	√	√	√		ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0219,ACT0220,ACT0221,ACT0222,ACT0223		CD0350CD0351, CD0352, CD0353, CD0354, CD0355, CD0356, CD0357, CD0358, CD0359, CD0360, CD0361	
B-Class	246	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0677,ACT0233			
B-Class	246	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0230,ACT0231,ACT0232,ACT0233		CD0362CD0363, CD0364, CD0365, CD0366, CD0367, CD0368, CD0369, CD0370, CD0371, CD0372, CD0373	
B-Class	246	Driver assistance	MFK-Multifunction camera	√	√	√	√		ACT0234,ACT0235	SP1066		√
B-Class	246	Driver assistance	MFK-Multifunction	√	√	√	√		ACT0236,ACT0237	SP1067,SP1068		√

B-Class	246	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		ACT0238,ACT0239,ACT0240,ACT0241,ACT0242,ACT0243,ACT0244,ACT0245,ACT0246,ACT0247,ACT0248,ACT0249,ACT0250,ACT0251,ACT0252,	SP1069,SP1070,SP1071		√
B-Class	246	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√					
B-Class	246	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√					
B-Class	246	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258		CD0382	
B-Class	246	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√		ACT0704		CD0523	√
B-Class	246	Air conditioning	STH-Stationary heater	√	√	√	√		ACT0259,ACT0260,ACT0261,ACT0262	SP1072		√
B-Class	246	Information and communication	Drive Kit Plus-Drive kit for iPhone	√	√	√	√		ACT0263,ACT0264,ACT0265,ACT0266			
B-Class	246	Information and communication	NAVI20-Navigation(N125/2)	√	√	√	√		ACT0267,ACT0268			
B-Class	246	Chassis	ES-Electrical power	√	√	√	√			SP1073,SP1074,SP1075		√
B-Class	246	Body	PSD-Control module 'Panoramic sliding roof '(A98)	√	√	√	√		ACT0270,ACT0269	SP1076		√
B-Class	246	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√		ACT0271			√
B-Class	246	Information and communication	HUD-Head up display	√	√	√	√		ACT0272,ACT0273,ACT0274	SP1077,		
B-Class	246	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√		ACT0275			√
B-Class	246	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√		ACT0276,ACT0277,ACT0278,ACT0279,ACT0280,ACT0281,	SP1078,SP1079		√
B-Class	246	Information and communication	SDAR-Satellite radio	√	√	√	√		ACT0283,ACT0284,ACT0285,ACT0286		CD0387CD0388, CD0389, CD0389	
B-Class	246	Information and communication	TB5-TV tuner Tuner unit	√	√	√	√		ACT0287,ACT0288,ACT0289,ACT0290,ACT0291,ACT0292,ACT0293,ACT0294,			
B-Class	246	Information and communication	TV tuner (TV)	√	√	√	√		ACT0295,ACT0296,ACT0297,ACT0298,ACT0299,ACT0300,			
B-Class	246	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√		ACT0302,ACT0303,ACT0304,ACT0305,ACT0306,ACT0307,ACT0308	SP1080,SP1081		√
B-Class	246	Information and communication	MIF-Media interface	√	√	√	√					
B-Class	246	Information and communication	MIF-Media interface	√	√	√	√		ACT0309			
B-Class	246	Body	BSN-Battery sensor(B95)	√	√	√	√					
B-Class	246	Body	TRM-Trailer recognition module (N28/1)	√	√	√	√		ACT0310,ACT0311,ACT0312,ACT0313,ACT0314,ACT0315,ACT0316,ACT0317,ACT0318,ACT0319,ACT0320,ACT0321	SP1082,SP1083		√

B-Class	246	Body	Trailer recognition module- Trailer recognition	√	√	√	√		ACT0322,ACT0323,ACT0324, ACT0325,ACT0326,ACT0327, ACT0328,ACT0329,ACT0330, ACT0331,ACT0332,ACT0333,		CD0393	√
B-Class	246	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√		ACT0335,ACT0336,ACT0337, ACT0338,ACT0339,ACT0340, ACT0341,ACT0342,ACT0343, ACT0344,ACT0345,ACT0346, ACT0347,ACT0348,ACT0349, ACT0350,ACT0351,ACT0352, ACT0353,ACT0354,ACT0355, ACT0356,ACT0357,ACT0358, ACT0359,ACT0360,ACT0361, ACT0362,ACT0363,ACT0364, ACT0365,ACT0366,ACT0367, ACT0368,ACT0369,ACT0370, ACT0371,ACT0372,ACT0373, ACT0374,ACT0375,ACT0376, ACT0377,ACT0378,ACT0379,			√
B-Class	246	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√		ACT0335,ACT0336,ACT0337, ACT0338,ACT0339,ACT0340, ACT0341,ACT0342,ACT0343, ACT0344,ACT0345,ACT0346, ACT0347,ACT0348,ACT0349, ACT0350,ACT0351,ACT0352, ACT0353,ACT0354,ACT0355, ACT0356,ACT0357,ACT0358, ACT0359,ACT0360,ACT0361, ACT0362,ACT0363,ACT0364, ACT0365,ACT0366,ACT0367, ACT0368,ACT0369,ACT0370, ACT0371,ACT0372,ACT0373, ACT0374,ACT0375,ACT0376, ACT0377,ACT0378,ACT0379,			√
B-Class	246	Drive	FSCU05-Control unit Fuel pump	√	√	√	√		ACT0385			√
B-Class	246	Driver assistance	DTR-DISTRONIC (A89)	√	√	√	√			SP1084	CD0395	√
B-Class	246	Chassis	DTR-DISTRONIC (A89)	√	√	√	√			SP1084	CD0395	√
B-Class	246	Seats and Doors	LFD-Left front door	√	√	√	√		ACT0386,ACT0387,ACT0388, ACT0389,ACT0390,ACT0391, ACT0392,ACT0393,ACT0394, ACT0395,ACT0396,ACT0397, ACT0398,ACT0399,ACT0400, ACT0401,ACT0402,ACT0403,	SP1085		√
B-Class	246	Seats and Doors	DCU RF-Right front door	√	√	√	√		ACT0405,ACT0406,ACT0407, ACT0408,ACT0409,ACT0410, ACT0411,ACT0412,ACT0413, ACT0414,ACT0415,ACT0416, ACT0417,ACT0418,ACT0419, ACT0420,ACT0421,ACT0422,	SP1086		√

B-Class	246	Information and communication	TV-TV tuner	√	√	√	√		ACT0424,ACT0425,ACT0426,ACT0427,ACT0222,ACT0428,ACT0219,ACT0221			
B-Class	246	Information and communication	TV-TV tuner	√	√	√	√		ACT0429,ACT0430,ACT0431,ACT0229,ACT0432,ACT0433,			
B-Class	246	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258			
B-Class	246	Chassis	EFB-Electronic parking brake(N128)	√	√	√	√		ACT0435,ACT0436,ACT0437,ACT0438	SP1087		√
B-Class	246	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439,ACT0440	SP1088,SP1089		√
B-Class	246	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439	SP1088,SP1089		√
B-Class	246	Body	WSS-Weight sensing	√	√	√	√					
B-Class	246	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
B-Class	246	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441			√
B-Class	246	Body	BSN-Battery sensor(B95)	√	√	√	√					
B-Class	246	Body	UCP-Upper control panel	√	√	√	√					
B-Class	246	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0442,ACT0443,ACT0444,ACT0445,ACT0446			√
B-Class	246	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0447,ACT0448,ACT0449,ACT0450			√
B-Class	246	Drive	CNG-Compressed natural gas	√			√					√
B-Class	246	Body	SG SW-Control unit 'Headlamp'(N71/1)	√	√	√	√		ACT0451,ACT0452,ACT0453,ACT0454,ACT0455	SP1090,SP1091,SP1092,SP1093	CD0397	√
B-Class	246	Body	SG SW L-Left headlamp	√	√	√	√		ACT0456,ACT0457,ACT0458,ACT0459,ACT0460,ACT0461	SP1094,SP1095,SP1096,SP1097,,SP1098,SP1099,	CD0398	√
B-Class	246	Body	SG SW L-Left headlamp(E1n9)	√	√	√	√		ACT0462,ACT0463,ACT0464,ACT0465,ACT0466,ACT0467	SP1101,SP1102,SP1103,SP1104,SP1105,SP1106,SP1107,SP1108	CD0399	√
B-Class	246	Body	SG SW R-Right headlamp	√	√	√	√		ACT0468,ACT0469,ACT0470,ACT0471,ACT0472,ACT0473	SP1109,SP1110,SP1111,SP1112,SP1113,SP1114	CD0400	√
B-Class	246	Body	SG SW R-Right headlamp(E1n9)	√	√	√	√		ACT0474,ACT0475,ACT0476,ACT0477,ACT0478,ACT0479	SP1115,SP1116,SP1117,SP1118,SP1119,SP1120	CD0401	√
B-Class	246	Body	GTO-Garage door	√	√	√	√					
B-Class	246	Body	OCP-Control unit 'Overhead control panel'	√	√	√	√		ACT0480,ACT0481,ACT0482,ACT0483			
B-Class	246	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√			SP1121		
B-Class	246	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√					
B-Class	246	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
B-Class	246	Driver assistance	PARK-Parking system (N62)	√	√	√	√		ACT0484,ACT0485		CD0411, CD0412	√
B-Class	246	Driver assistance system	PTS-Parktronic system	√	√	√	√		ACT1053		CD0536, CD0537, CD0538, CD0539	√
B-Class	246	Body	N32/2 (Front passenger seat control unit)	√			√		ACT0486			
B-Class	246	Body	N32/1 (Driver seat control unit)	√			√		ACT0487			
B-Class	246	Drive	VG-All wheel drive	√	√	√	√		ACT0489	SP1122,SP1123,SP1124,SP1125		√

B-Class	246	Body	AS-Alarm siren(H3/1)	√	√	√			ACT0490			
B-Class	246	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT0490			
B-Class	246	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√					
B-Class	246	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√					
B-Class	246	Drive	FSCU-Fuel pump	√	√	√	√		ACT0498,ACT0499		CD0427, CD0428	√
B-Class	246	Drive	N127 (Drivetrain control unit)	√	√	√	√		ACT0500,ACT0501	SP1129,SP1130,SP1131	CD0429, CD0430, CD043	√
B-Class	246	Drive	PTCU-Common powertrain controller(N127)	√	√	√	√		ACT1607,ACT0504,ACT1608, ACT1609,ACT1610,ACT1611, ACT1612,ACT1613	SP1622,SP1623		√
B-Class	246	Drive	PTCU-Common powertrain controller(N127)	√	√	√	√		ACT0502,ACT0503,ACT0504, ACT0505,ACT0506,ACT0507	SP1132	CD0432, CD0433, CD0434	√
B-Class	246	Drive	N3/10-Motor electronics "MED40" for combustion engine "M274"	√	√	√	√	√	ACT0508,ACT0509,ACT0510, ACT0511,ACT0512,ACT0513, ACT0514,ACT0515,ACT0516, ACT0517,ACT0518,ACT0519, ACT0520,ACT0521,ACT0522, ACT0523,ACT0524,ACT0525, SP1148	SP1133,SP1134,SP1135, SP1136,SP1137,SP1138, SP1139,SP1140,SP1141, SP1142,SP1143,SP1144, SP1145,SP1146,SP1147, SP1148	CD0435, CD0436, CD0437, CD0438, CD0439, CD0440, CD0441, CD0442, CD0443	√
B-Class	246	Drive	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"	√	√	√	√	√	ACT1509,ACT1510,ACT1511, ACT1512,ACT1513,ACT1514, ACT1515,ACT1516,ACT1517, ACT1518,ACT1519,ACT1520, ACT1521,ACT1522,ACT1523, ACT1524,ACT1525,ACT1526, ACT1527,ACT1528,ACT1529,	SP1572,SP1573,SP1574, SP1575,SP1576,SP1577, SP1578,SP1579,SP1580, SP1581,SP1582,SP1583, SP1584,SP1585	CD0741, CD0742, CD0743, CD0744, CD0745, CD0746, CD0747, CD0748, CD0749, CD0750, CD0751, CD0752	√
GLB/B/ GLA-	247	Drive	CDI-Engine Electronics CRR2 for Internal Combustion Engine	√	√	√	√	√				
GLB/B/ GLA-	247	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√				
GLB/B/ GLA-	247	Drive	N15/13 (Double clutch transmission control unit)	√	√	√	√					
GLB/B/ GLA- Class	247	Drive	Y3/14n4 (Dual clutch transmission fully integrated transmission control unit)	√	√	√						
GLB/B/ GLA- Class	247	Drive	Y3/14n4 (Dual clutch transmission fully integrated transmission control unit)	√	√	√						
GLB/B/ GLA-	247	Seats and Doors	LFD-Left front door	√	√	√	√					
GLB/B/ GLA-	247	Seats and Doors	DCU RF-Right front door	√	√	√	√					
GLB/B/ GLA-	247	Body	SRS-Supplemental restraint system	√	√	√	√	√				
GLB/B/ GLA-	247	Body	EZS-Electronic ignition switch	√	√	√	√					
GLB/B/ GLA-	247	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					

GLB/B/ GLA-	247	Body	Driver side SAM-Front signal acquisition and actuation module	√	√	√	√					
GLB/B/ GLA-	247	Information and communication	HERMES-control unit for telematics services	√	√	√	√					
GLB/B/ GLA-	247	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
GLB/B/ GLA-	247	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√					
GLB/B/ GLA-	247	Seats and Doors	MKS-FS-Pilot multi-profile seat	√	√	√	√					
GLB/B/ GLA-	247	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√					
GLB/B/ GLA-	247	Seats and Doors	MKS-BFS-Front passenger more copy the seat	√	√	√	√					
GLB/B/ GLA-	247	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
GLB/B/ GLA-	247	Seats and Doors	HKS-Tailgate control	√	√	√	√					
GLB/B/ GLA-	247	Body	ATA-Interior motion sensor	√	√	√	√					
GLB/B/ GLA-	247	Body	Trailer recognition module-Trailer recognition	√	√	√	√					
GLB/B/ GLA-	247	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
GLB/B/ GLA-	247	Body	PSD-Control module Panoramic sliding roof	√	√	√	√					
GLB/B/ GLA-	247	Body	PSD-Panoramic sliding roof	√	√	√	√					
GLB/B/ GLA-	247	Body	AML-Ambiance light	√	√	√	√					
GLB/B/ GLA-	247	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√					
GLB/B/ GLA-	247	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√					
GLB/B/ GLA-	247	Body	LRE-Steering wheel electronics	√	√	√	√					
GLB/B/ GLA-	247	Information and communication	TPAD-Touchpad	√	√	√	√					
GLB/B/ GLA-	247	Information and communication	Audio-Audio or COMAND	√	√	√	√					
GLB/B/ GLA-	247	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
GLB/B/ GLA-	247	Body	HE-Hand detection	√	√	√	√					
GLB/B/ GLA-	247	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
GLB/B/ GLA-	247	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					

GLB/B/ GLA-	247	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√				
GLB/B/ GLA-	247	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√				
GLB/B/ GLA-	247	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√				
GLB/B/ GLA-	247	Information and communication	IC-Instrument cluster	√	√	√	√			SP1047,SP1048,SP1157	
GLB/B/ GLA-	247	Information and communication	HUD-Head up display	√	√	√	√				
GLB/B/ GLA-	247	Driver assistance system	RFK-Backup camera	√	√	√	√				
GLB/B/ GLA-	247	Driver assistance system	KAR-Augmented reality camera	√	√	√	√				
GLB/B/ GLA-	247	Information and communication	CSM-Windshield reader system	√	√	√	√				
GLB/B/ GLA-	247	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√				
GLB/B/ GLA-	247	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√				
GLB/B/ GLA-	247	Body	SG SW L-Left headlamp	√	√	√	√				
GLB/B/ GLA-	247	Body	SG SW R-Right headlamp	√	√	√	√				
GLB/B/ GLA-	247	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√				
GLB/B/ GLA-	247	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√				
GLB/B/ GLA-	247	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√				
GLB/B/ GLA-	247	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√				
GLB/B/ GLA-	247	Body	DCCU-Direct current charge connection unit	√	√	√	√				
GLB/B/ GLA-	247	Body	SG LG-Charger	√	√	√	√				
GLB/B/ GLA-	247	Body	DC/DC-DC/DC converter	√	√	√	√				
GLB/B/ GLA-	247	Body	GES-Hand motion sensor	√	√	√	√				
GLB/B/ GLA-	247	Body	Multifunction control unit-Multifunction control unit	√	√	√	√				
GLB/B/ GLA-	247	Body	BSN-Battery sensor(B95)	√	√	√	√				
GLB/B/ GLA-	247	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√				
GLB/B/ GLA-	247	Body	FSW-Windshield wiper	√	√	√	√				

GLB/B/ GLA-	247	Body	GTO-Garage door opener(A67n2)	√	√	√	√				
GLB/B/ GLA-	247	Body	OCP-Overhead control panel	√	√	√	√				
GLB/B/ GLA-	247	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√				
GLB/B/ GLA-	247	Body	"Front passenger" seat heater	√	√	√	√				
GLB/B/ GLA-	247	Body	"Driver" seat heater	√	√	√	√				
GLB/B/ GLA-	247	Seats and Doors	S47/2 (Driver door switch module)	√	√	√	√				
GLB/B/ GLA-	247	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	√				
GLB/B/ GLA-	247	Seats and Doors	S22 (Driver"s door seat adjustment switch)	√	√	√	√				
GLB/B/ GLA-	247	Seats and Doors	S23 (Front passenger door seat adjustment switch)	√	√	√	√				
GLB/B/ GLA-	247	Seats and Doors	S51/1 (Driver seat climate control switch group)	√	√	√	√				
GLB/B/ GLA-	247	Seats and Doors	S51/2 (Front passenger seat climate control switch group)	√	√	√	√				
GLB/B/ GLA-	247	Seats and Doors	DCU LR-Left rear door	√	√	√	√				
GLB/B/ GLA-	247	Seats and Doors	DCU RR-Right rear door	√	√	√	√				
GLB/B/ GLA-	247	Body	AS-Alarm siren(H3/1)	√	√	√	√				
GLB/B/ GLA-	247	Air conditioning	STH-Stationary heater	√	√	√	√				
GLB/B/ GLA-	247	Air conditioning	AAC-Automatic air conditioning	√	√	√	√				
GLB/B/ GLA-	247	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√				
GLB/B/ GLA-	247	Chassis	Lower control panel(DRVU)	√	√	√					
GLB/B/ GLA-	247	Body	WSS-Weight sensing system(N110)	√	√	√	√				
GLB/B/ GLA-	247	Body	N38 (Rear switching module)	√	√	√	√				
GLB/B/ GLA-	247	Information and communication	SOUND-Sound system	√	√	√	√				
GLB/B/ GLA-	247	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√				
GLB/B/ GLA-	247	Driver assistance system	DTR-DISTRONIC	√	√	√	√				
GLB/B/ GLA-	247	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√				

GLB/B/ GLA-	247	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√				
GLB/B/ GLA-	247	Driver assistance system	PTS-PARKTRONIC	√	√	√	√				
GLB/B/ GLA-	247	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√				
GLB/B/ GLA-	247	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√				
GLB/B/ GLA-	247	Chassis	ES - Electric power steering	√	√	√	√				
GLB/B/ GLA-	247	Body	SCM-Steering column module	√	√	√	√				
GLB/B/ GLA-	247	Drive	VG-All-wheel drive	√	√	√	√				
GLB/B/ GLA-	247	Drive	VG-All-wheel drive	√	√	√	√				
GLB/B/ GLA-	247	Drive	VG-All-wheel drive	√	√	√	√				
GLB/B/ GLA-	247	Body	STM-Mirror taximeter	√	√	√	√				
GLB/B/ GLA-	247	Driver assistance system	NBR RR-Right rear short-range radar	√	√	√	√				
GLB/B/ GLA-	247	Driver assistance system	NBR LR-Left rear short-range radar	√	√	√	√				
GLB/B/ GLA-	247	Chassis	ESP- Electric stability program	√	√	√	√	√			
GLB/B/ GLA-	247	Drive	FSCU-Fuel pump	√	√	√	√				
GLB/B/ GLA-	247	Drive	SCR-Selective catalytic reduction	√	√	√	√				
GLB/B/ GLA-	247	Drive	N127 (Drivetrain control unit)	√	√	√					
GLB/B/ GLA-	247	Drive	N127 (Drivetrain control unit)	√	√	√	√				
GLB/B/ GLA-	247	Drive	SG EM-Power electronics	√	√	√	√				
GLB/B/ GLA-	247	Drive	48V on board electrical system of ISG starter generator	√	√	√					
GLB/B/ GLA-	247	Body	BMS-Battery management system	√	√	√	√				
GLB/B/ GLA-	247	Body	LIB-Lithium ion battery	√	√	√	√				
GLB/B/ GLA-	247	Body	LIB-Lithium ion battery	√	√	√	√				
GLB/B/ GLA-	247	Drive	N3/10-Motor electronics "EM71" for combustion engine "M282"	√	√	√	√	√			
GLB/B/ GLA-	247	Drive	N3/10-Motor electronics "MED41" for combustion engine	√	√	√	√	√			

GLB/B/ GLA- Class	247	Drive	N3/10-Motor electronics "MRG1AMGR4" for combustion engine "M139"	√	√	√	√					
GLC- Class	253	Drive	N3/9-Motor electronics "CR43" for combustion engine "OM651"	√	√	√	√					
GLC- Class	253	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√				
GLC- Class	253	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√				
GLC-	253	Seats and Doors	LFD-Left front door	√	√	√	√					
GLC-	253	Seats and Doors	LFD-Left front door	√	√	√	√					
GLC-	253	Seats and Doors	DCU RF-Right front door	√	√	√	√					
GLC-	253	Seats and Doors	DCU RF-Right front door	√	√	√	√					
GLC-	253	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
GLC-	253	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
GLC-	253	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
GLC-	253	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
GLC-	253	Body	SG FOND-Rear control unit	√	√	√	√					
GLC-	253	Body	SRS-Supplemental restraint	√	√	√	√	√				
GLC-	253	Body	SRS-Supplemental restraint	√	√	√	√	√				
GLC-	253	Body	EZS-Electronic ignition lock	√	√	√	√					
GLC-	253	Body	EZS-Electronic ignition lock	√	√	√	√					
GLC- Class	253	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					
GLC- Class	253	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√					
GLC- Class	253	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
GLC- Class	253	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√					
GLC- Class	253	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√					
GLC- Class	253	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√					
GLC- Class	253	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√					
GLC- Class	253	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√					
GLC- Class	253	Information and communication	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√					
GLC- Class	253	Information and communication	HERMES-control unit for telematics services	√	√	√	√					
GLC- Class	253	Information and communication	mbrace-mbrace	√	√	√	√					
GLC-	253	Seats and Doors	MKS-FS-Pilot multi-profile seat	√	√	√	√					

GLC-	253	Air conditioning	AAC-Automatic air conditioning	√	√	√	√				
GLC-Class	253	Seats and Doors	MKS-BFS-Front passenger more copy the seat	√	√	√	√				
GLC-	253	Seats and Doors	HKS-Tailgate control	√	√	√	√				
GLC-	253	Seats and Doors	HKS-Tailgate control	√	√	√	√				
GLC-Class	253	Body	ATA-ATA[EDW]/tow-away protection/interior protection	√	√	√	√				
GLC-Class	253	Body	Trailer recognition module-Trailer recognition	√	√	√	√				
GLC-Class	253	Body	Multifunction control unit-Multifunction control unit	√	√	√	√				
GLC-	253	Body	PSD-Panoramic sliding roof	√	√	√	√				
GLC-	253	Body	PSD-Panoramic sliding roof	√	√	√	√				
GLC-Class	253	Body	PSD-Control module Panoramic sliding roof	√	√	√	√			SP1536	
GLC-	253	Driver assistance	KAB-Control unit Camera cover	√	√	√	√				
GLC-	253	Body	AML-Ambiance light	√	√	√	√				
GLC-	253	Body	KG-Keyless Go	√	√	√	√				
GLC-	253	Body	KG-Keyless Go	√	√	√	√				
GLC-	253	Body	OCP-Overhead control panel	√	√	√	√				
GLC-	253	Body	DC/DC-DC/DC converter	√	√	√	√				
GLC-Class	253	Information and communication	mbrace-mbrace	√	√	√	√				
GLC-Class	253	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor system	√	√	√	√				
GLC-Class	253	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√				
GLC-Class	253	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√				
GLC-Class	253	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√				
GLC-Class	253	Information and communication	SG MSND-Engine sound	√	√	√	√				
GLC-	253	Body	LRE-Steering wheel electronics	√	√	√	√				
GLC-	253	Drive	Voltage converter of fuel cell	√	√	√	√				
GLC-	253	Drive	Fuel cell management system	√	√	√	√				
GLC-	253	Drive	Exhaust air turbocharger	√	√	√	√				
GLC-	253	Drive	Fuel cell stack	√	√	√	√				
GLC-Class	253	Information and communication	TPAD-Touchpad	√	√	√	√				
GLC-Class	253	Information and communication	TPAD-Touchpad	√	√	√	√				
GLC-Class	253	Information and communication	TPAD-Touchpad	√	√	√	√				
GLC-Class	253	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√				
GLC-Class	253	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√				

GLC-Class	253	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
GLC-Class	253	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
GLC-Class	253	Information and communication	Audio-Audio or COMAND	√	√	√						
GLC-Class	253	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
GLC-Class	253	Driver assistance	KAR-Augmented reality camera	√	√	√	√					
GLC-Class	253	Information and communication	CTEL-Cellular telephone	√	√	√	√					
GLC-Class	253	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√					
GLC-Class	253	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
GLC-Class	253	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
GLC-Class	253	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
GLC-Class	253	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
GLC-Class	253	Information and communication	IC-Instrument cluster(A1)	√	√	√	√					
GLC-Class	253	Information and communication	IC-Instrument cluster	√	√	√	√					
GLC-Class	253	Information and communication	HUD-Head up display	√	√	√	√					
GLC-Class	253	Driver assistance	RFK-Backup camera	√	√	√	√					
GLC-Class	253	Driver assistance	RFK-Backup camera	√	√	√	√					
GLC-Class	253	Driver assistance	CAMERA-360 camera(N148)	√	√	√	√					
GLC-Class	253	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
GLC-Class	253	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
GLC-Class	253	Drive	Fuel tank	√	√	√	√					
GLC-Class	253	Information and communication	CSM-Windshield reader system	√	√	√	√					
GLC-Class	253	Drive	EAGGS-Electric differential lock	√	√	√	√					
GLC-Class	253	Body	AMLA-Active engine mount	√	√	√	√					
GLC-Class	253	Chassis	AMG DRVU-AMG DRIVE	√	√	√	√					
GLC-Class	253	Chassis	AMG DRVU-AMG DRIVE	√	√	√	√					
GLC-Class	253	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√					
GLC-Class	253	Body	SG SW L-Left headlamp	√	√	√	√					
GLC-Class	253	Body	SG SW L-Left headlamp	√	√	√	√					
GLC-Class	253	Body	SG SW L-Left headlamp	√	√	√	√					
GLC-Class	253	Body	SG SW R-Right headlamp	√	√	√	√					
GLC-Class	253	Body	SG SW R-Right headlamp	√	√	√	√					

GLC-	253	Body	SG SW R-Right headlamp	√	√	√	√					
GLC-Class	253	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√					
GLC-Class	253	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√					
GLC-	253	Driver assistance	TPM-Tire pressure monitor(N88)	√	√	√	√					
GLC-Class	253	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
GLC-Class	253	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
GLC-	253	Chassis	EFB-Electric parking brake	√	√	√	√					
GLC-Class	253	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√					
GLC-Class	253	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√					
GLC-Class	253	Drive	HFBM-Haptic accelerator pedal module	√	√	√	√					
GLC-	253	Drive	ISM-Shift module	√	√	√	√					
GLC-	253	Drive	SG EM-Power electronics	√	√	√	√					
GLC-	253	Body	SG LG-Charger	√	√	√	√					
GLC-	253	Body	SG LG-Charger	√	√	√	√					
GLC-Class	253	Body	CSHVB-Crash sensor high-voltage battery	√	√	√	√					
GLC-	253	Body	DC/DC-DC/DC converter	√	√	√	√					
GLC-	253	Body	GES-Hand motion sensor	√	√	√	√					
GLC-Class	253	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
GLC-	253	Body	BSN-Battery sensor(B95)	√	√	√	√					
GLC-	253	Body	BSN-Battery sensor(B95)	√	√	√	√					
GLC-	253	Body	LIB-Lithium ion battery	√	√	√	√					
GLC-	253	Body	LIB-Lithium ion battery	√	√	√	√					
GLC-Class	253	Body	Button group, instrument panel, driver side	√	√	√	√					
GLC-	253	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
GLC-	253	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
GLC-	253	Body	FSW-Windshield wiper	√	√	√	√					
GLC-	253	Body	GTO-Garage door	√	√	√	√					
GLC-	253	Body	GTO-Garage door	√	√	√	√					
GLC-	253	Body	OCP-Overhead control panel	√	√	√	√					
GLC-Class	253	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√					
GLC-Class	253	Body	Anti glare interior rearview mirror(SAM)	√	√	√	√					
GLC-Class	253	Body	AMLAB-R (Actuation module, LED exterior lighting, right front)	√	√	√	√					
GLC-Class	253	Body	AMLAB-R (Actuation module, LED exterior lighting, right front)	√	√	√	√					

GLC-Class	253	Body	AMLAB-L (Actuation module, LED exterior lighting, left front)	√	√	√	√					
GLC-Class	253	Body	AMLAB-L (Actuation module, LED exterior lighting, left front)	√	√	√	√					
GLC-Class	253	Body	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
GLC-Class	253	Body	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					
GLC-	253	Body	"Front passenger" seat heater	√	√	√	√					
GLC-	253	Body	"Driver" seat heater	√	√	√	√					
GLC-Class	253	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√					
GLC-	253	Seats and Doors	LFD-Left front door	√	√	√						
GLC-	253	Seats and Doors	LFD-Left front door	√	√	√						
GLC-	253	Seats and Doors	LFD-Left front door	√	√	√						
GLC-	253	Seats and Doors	DCU RF-Right front door	√	√	√						
GLC-	253	Seats and Doors	DCU RF-Right front door	√	√	√						
GLC-	253	Seats and Doors	DCU RF-Right front door	√	√	√						
GLC-	253	Seats and Doors	DCU LR-Left rear door	√	√	√						
GLC-	253	Seats and Doors	DCU RR-Right rear door	√	√	√						
GLC-	253	Body	AS-Alarm siren(H3/1)	√	√	√	√					
GLC-	253	Air conditioning	AAC-Automatic air conditioning	√	√	√						
GLC-	253	Air conditioning	STH-Stationary heater	√	√	√	√					
GLC-	253	Air conditioning	STH-Stationary heater	√	√	√	√					
GLC-	253	Air conditioning	AAC-Automatic air conditioning	√	√	√						
GLC-	253	Air conditioning	AAC-Automatic air conditioning	√	√	√						
GLC-Class	253	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√					
GLC-Class	253	Information and communication	N72/1 (Upper control panel control unit)	√	√	√						
GLC-Class	253	Information and communication	LCP-Lower control panel	√	√	√	√					
GLC-Class	253	Information and communication	N72/5 (Right lower control panel)	√	√	√						
GLC-Class	253	Information and communication	N72/4 (Left lower control panel)	√	√	√						
GLC-	253	Body	WSS-Weight sensing	√	√	√	√					
GLC-	253	Body	N38 (Rear switching module)	√	√	√	√					
GLC-	253	Body	LIB-Lithium ion battery	√	√	√	√					
GLC-Class	253	Information and communication	TV tuner (TV)	√	√	√	√					
GLC-Class	253	Information and communication	TV tuner (TV)	√	√	√	√					
GLC-Class	253	Information and communication	TV tuner (TV)	√	√	√	√					
GLC-Class	253	Information and communication	TV tuner (TV)	√	√	√	√					

GLC-Class	253	Information and communication	SOUND-Sound system	√	√	√	√				
GLC-Class	253	Information and communication	SOUND-Sound system	√	√	√	√				
GLC-Class	253	Information and communication	SOUND-Sound system	√	√	√	√				
GLC-Class	253	Information and communication	DAB-Digital radio Tuner unit	√	√	√	√				
GLC-Class	253	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√				
GLC-Class	253	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√				
GLC-	253	Driver assistance	DTR-DISTRONIC	√	√	√	√				
GLC-	253	Driver assistance	DTR-DISTRONIC	√	√	√	√				
GLC-Class	253	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√				
GLC-	253	Driver assistance	SGR-Radar sensors control unit	√	√	√	√				
GLC-	253	Driver assistance	DTR-DISTRONIC(B29)	√	√	√	√				
GLC-Class	253	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√				
GLC-	253	Driver assistance	PARK-Parking system (N62)	√	√	√	√				
GLC-	253	Driver assistance	PTS-PARKTRONIC	√	√	√	√				
GLC-	253	Chassis	ELC-Electronic level control	√	√	√	√				
GLC-	253	Chassis	ADS-Adaptive damping system	√	√	√	√				
GLC-Class	253	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√				
GLC-	253	Chassis	ES - Electric power steering	√	√	√	√				
GLC-	253	Chassis	ES - Electric power steering	√	√	√	√				
GLC-	253	Body	SCM-Steering column	√	√	√	√				
GLC-	253	Body	SCM-Steering column	√	√	√	√				
GLC-	253	Chassis	AIRmatic-AIRmatic PLUS	√	√	√	√				
GLC-	253	Drive	VG-All-wheel drive	√	√	√	√				
GLC-	253	Body	STM-Mirror taximeter	√	√	√	√				
GLC-	253	Driver assistance	NBR RR-Right rear short-range	√	√	√	√				
GLC-	253	Driver assistance	NBR LR-Left rear short-range	√	√	√	√				
GLC-	253	Chassis	ESP-Electric stability	√	√	√	√	√			
GLC-	253	Chassis	ESP-Electric stability	√	√	√	√	√			
GLC-	253	Chassis	ESP-Electric stability	√	√	√	√	√			
GLC-	253	Chassis	ESP-Electric stability	√	√	√	√	√			
GLC-	253	Drive	FSCU-Control unit Fuel pump	√	√	√	√				
GLC-	253	Drive	SCR-Selective catalytic reduction	√	√	√	√				
GLC-	253	Drive	SCR-Selective catalytic reduction	√	√	√	√				
GLC-	253	Drive	N127 (Drivetrain control unit)	√	√	√	√				
GLC-	253	Drive	N127 (Drivetrain control unit)	√	√	√	√				
GLC-	253	Drive	N127 (Drivetrain control unit)	√	√	√	√				
GLC-	253	Drive	SG EM-Power electronics	√	√	√	√				
GLC-	253	Drive	SG EM-Power electronics	√	√	√	√				

GLC-	253	Drive	ISG-Integrated starter alternator	√	√	√	√					
GLC-	253	Drive	ISG-Integrated starter alternator	√	√	√	√					
GLC-	253	Body	BMS-Battery management system	√	√	√	√					
GLC-	253	Body	BMS-Battery management system	√	√	√	√					
GLC-	253	Body	BMS-Battery management system	√	√	√	√					
GLC-Class	253	Drive	N3/10-Motor electronics "MED177" for combustion engine	√	√	√	√	√				
GLC-Class	253	Drive	N3/10-Motor electronics "MED1775" for combustion	√	√	√	√	√				
GLC-Class	253	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√				
GLC-Class	253	Drive	N3/10-Motor electronics "MED40" for combustion engine	√	√	√	√	√				
GLC-Class	253	Drive	N3/10-Motor electronics "MED41" for combustion engine	√	√	√	√	√				
CLS-Class	257	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√				
CLS-Class	257	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√				
CLS-	257	Seats and Doors	LFD-Left front door	√	√	√	√					
CLS-	257	Seats and Doors	DCU RF-Right front door	√	√	√	√					
CLS-	257	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
CLS-	257	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
CLS-	257	Body	EZS-Electronic ignition lock	√	√	√	√					
CLS-Class	257	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					
CLS-Class	257	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					
CLS-Class	257	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√					
CLS-Class	257	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
CLS-Class	257	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
CLS-Class	257	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√					
CLS-	257	Body	SRS-Supplemental restraint	√	√	√	√	√				
CLS-Class	257	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√					
CLS-Class	257	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√					
CLS-Class	257	Information and communication	MTAS FO-Mobile phone cradle in rear passenger compartment	√	√	√	√					
CLS-	257	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
CLS-	257	Seats and Doors	MKS LF-Left front multicontour	√	√	√	√					

CLS-Class	257	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√					
CLS-	257	Seats and Doors	HKS-Tailgate control	√	√	√	√					
CLS-Class	257	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√					
CLS-Class	257	Body	Trailer recognition module-Trailer recognition	√	√	√	√					
CLS-	257	Body	PSD-Panoramic sliding roof	√	√	√	√					
CLS-	257	Body	AML-Ambiance light	√	√	√	√					
CLS-	257	Body	KG-Keyless Go	√	√	√	√					
CLS-	257	Body	OCP-Overhead control panel	√	√	√	√					
CLS-	257	Body	DC/DC-DC/DC converter	√	√	√	√					
CLS-Class	257	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√					
CLS-Class	257	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√					
CLS-Class	257	Information and communication	SG MSND-Engine sound	√	√	√	√					
CLS-	257	Body	LRE-Steering wheel electronics	√	√	√	√					
CLS-Class	257	Information and communication	TPAD-Touchpad	√	√	√	√					
CLS-Class	257	Information and communication	TPAD-Touchpad	√	√	√	√					
CLS-Class	257	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
CLS-Class	257	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
CLS-Class	257	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
CLS-Class	257	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√					
CLS-Class	257	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
CLS-Class	257	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
CLS-Class	257	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
CLS-Class	257	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√					
CLS-Class	257	Information and communication	IC-Instrument cluster(A1)	√	√	√	√					
CLS-Class	257	Information and communication	HUD-Head up display	√	√	√	√					
CLS-	257	Driver assistance	RFK-Backup camera	√	√	√	√					
CLS-	257	Driver assistance	RFK-Backup camera	√	√	√	√					
CLS-Class	257	Information and communication	HERMES-control unit for telematics services	√	√	√	√					
CLS-	257	Chassis	AMG DRVU-AMG DRIVE	√	√	√	√					
CLS-	257	Body	SG SW L-Left headlamp	√	√	√	√					

CLS-	257	Body	SG SW L-Left headlamp	√	√	√	√					
CLS-Class	257	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√					
CLS-Class	257	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√					
CLS-	257	Driver assistance	TPM-Tire pressure monitor(N88)	√	√	√	√					
CLS-Class	257	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
CLS-Class	257	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION	√	√	√	√					
CLS-	257	Body	SG SW R-Right headlamp	√	√	√	√					
CLS-	257	Body	SG SW R-Right headlamp	√	√	√	√					
CLS-Class	257	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
CLS-	257	Body	BSN-Battery sensor(B95)	√	√	√	√					
CLS-	257	Body	LIB-Lithium ion battery	√	√	√	√					
CLS-	257	Body	LIB-Lithium ion battery	√	√	√	√					
CLS-	257	Body	AU-Analog clock	√	√	√	√					
CLS-Class	257	Body	Button group, instrument panel, driver side	√	√	√	√					
CLS-	257	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
CLS-	257	Body	FSW-Windshield wiper	√	√	√	√					
CLS-	257	Body	GTO-Garage door	√	√	√	√					
CLS-Class	257	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√					
CLS-	257	Body	"Front passenger" seat heater	√	√	√	√					
CLS-	257	Body	"Driver" seat heater	√	√	√	√					
CLS-	257	Body	N5 (Armrest heater control unit)	√	√	√	√					
CLS-Class	257	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√					
CLS-	257	Seats and Doors	LFD-Left front door	√	√	√	√					
CLS-	257	Seats and Doors	LFD-Left front door	√	√	√	√					
CLS-	257	Seats and Doors	LFD-Left front door	√	√	√	√					
CLS-	257	Seats and Doors	DCU RF-Right front door	√	√	√	√					
CLS-	257	Seats and Doors	DCU RF-Right front door	√	√	√	√					
CLS-	257	Seats and Doors	DCU RF-Right front door	√	√	√	√					
CLS-	257	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
CLS-	257	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
CLS-	257	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
CLS-	257	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
CLS-	257	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
CLS-	257	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
CLS-	257	Body	"Driver" seat heater	√	√	√	√					
CLS-	257	Body	"Front passenger" seat heater	√	√	√	√					
CLS-Class	257	Seats and Doors	Seat heater in left rear passenger compartment	√	√	√	√					
CLS-Class	257	Seats and Doors	Seat heater in right rear passenger compartment	√	√	√	√					

CLS-	257	Body	AS-Alarm siren(H3/1)	√	√	√	√					
CLS-	257	Seats and Doors	Massage function in left front seat	√	√	√	√					
CLS-	257	Seats and Doors	Massage function in right front	√	√	√	√					
CLS-	257	Seats and Doors	MFSF-LF	√	√	√	√					
CLS-	257	Seats and Doors	MFSF-RF	√	√	√	√					
CLS-	257	Air conditioning	N61 (Windshield heater control	√	√	√						
CLS-	257	Air conditioning	STH-Stationary heater	√	√	√	√					
CLS-	257	Air conditioning	AAC-Automatic air conditioning	√	√	√						
CLS-	257	Air conditioning	AAC-Automatic air conditioning	√	√	√						
CLS- Class	257	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√					
CLS- Class	257	Information and communication	N72/1 (Upper control panel control unit)	√	√	√						
CLS- Class	257	Information and communication	N72/5 (Right lower control panel)	√	√	√						
CLS- Class	257	Information and communication	N72/4 (Left lower control panel)	√	√	√						
CLS-	257	Body	WSS-Weight sensing	√	√	√	√					
CLS-	257	Body	N38 (Rear switching module)	√	√	√	√					
CLS-	257	Body	LIB-Lithium ion battery	√	√	√	√					
CLS- Class	257	Information and communication	TV tuner (TV)	√	√	√	√					
CLS- Class	257	Information and communication	TV tuner (TV)	√	√	√	√					
CLS- Class	257	Information and communication	TV tuner (TV)	√	√	√	√					
CLS- Class	257	Information and communication	TV tuner (TV)	√	√	√	√					
CLS- Class	257	Information and communication	SOUND-Sound system	√	√	√	√					
CLS- Class	257	Information and communication	DAB-Digital radio Tuner unit	√	√	√	√					
CLS- Class	257	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					
CLS-	257	Driver assistance	DTR-DISTRONIC	√	√	√	√					
CLS-	257	Driver assistance	SGR-Radar sensors control unit	√	√	√	√					
CLS-	257	Driver assistance	DTR-DISTRONIC	√	√	√	√					
CLS-	257	Driver assistance	PTS-PARKTRONIC	√	√	√	√					
CLS-	257	Chassis	ADS-Adaptive damping system	√	√	√	√					
CLS- Class	257	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√					
CLS-	257	Chassis	ES - Electric power steering	√	√	√	√					
CLS-	257	Chassis	ES - Electric power steering	√	√	√	√					
CLS-	257	Body	SCM-Steering column	√	√	√	√					
CLS-	257	Chassis	AIRmatic-AIRmatic PLUS	√	√	√	√					
CLS-	257	Drive	VG-All-wheel drive	√	√	√	√					
CLS-	257	Driver assistance	NBR LF-Left front short range	√	√	√	√					

CLS-Class	257	Driver assistance system	NBR RF-Right front short range radar	√	√	√	√					
CLS-	257	Driver assistance	NBR RR-Right rear short-range	√	√	√	√					
CLS-	257	Driver assistance	NBR LR-Left rear short-range	√	√	√	√					
CLS-	257	Chassis	ESP-Electric stability	√	√	√	√	√				
CLS-	257	Drive	FSCU-Control unit Fuel pump	√	√	√	√					
CLS-	257	Drive	SCR-Selective catalytic reduction	√	√	√	√					
CLS-	257	Drive	N127 (Drivetrain control unit)	√	√	√	√					
CLS-	257	Drive	ISG-Integrated starter alternator	√	√	√	√					
CLS-	257	Drive	ISG-Integrated starter alternator	√	√	√	√					
CLS-Class	257	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√				
CLS-Class	257	Drive	N3/10-Motor electronics "MED40" for combustion engine	√	√	√	√	√				
CLS-Class	257	Drive	N3/10-Motor electronics "MED41" for combustion engine	√	√	√	√	√				
CLS-Class	257	Drive	N3/10-Motor electronics "MRG1" for combustion engine "M256"	√	√	√	√	√				
X 290 AMG-Class	290	Drive	N3/10-Motor electronics "MED1775" for combustion engine "M178"	√	√	√	√	√				
X 290 AMG-Class	290	Drive	N3/10-Motor electronics "MRG1" for combustion engine "M256"	√	√	√	√	√				
X 290 AMG-Class	290	Drive	N15/15n4 (Fully integrated transmission control unit)	√	√	√	√					
X 290 AMG-Class	290	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√				
X 290 AMG-Class	290	Seats and Doors	LFD-Left front door	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	DCU RF-Right front door	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
X 290 AMG-Class	290	Body	SRS-Supplemental restraint system	√	√	√	√	√				

X 290 AMG-Class	290	Body	EZS-Electronic ignition lock	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory function	√	√	√	√					
X 290 AMG-Class	290	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√					
X 290 AMG-Class	290	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√					
X 290 AMG-Class	290	Information and communication	HERMES-control unit for telematics services	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√					
X 290 AMG-Class	290	Information and communication	MTAS FO-Mobile phone cradle in rear passenger comparrtment	√	√	√	√					
X 290 AMG-Class	290	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√					
X 290 AMG-Class	290	Body	Trailer recognition module-Trailer recognition	√	√	√	√					

X 290 AMG-Class	290	Body	PSD-Panoramic sliding roof	√	√	√	√					
X 290 AMG-Class	290	Body	AML-Ambiance light	√	√	√	√					
X 290 AMG-Class	290	Body	KG-Keyless Go	√	√	√	√					
X 290 AMG-Class	290	Body	OCP-Overhead control panel	√	√	√	√					
X 290 AMG-Class	290	Body	DC/DC-DC/DC converter	√	√	√	√					
X 290 AMG-Class	290	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√					
X 290 AMG-Class	290	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√					
X 290 AMG-Class	290	Information and communication	SG MSND-Engine sound	√	√	√	√					
X 290 AMG-Class	290	Body	LRE-Steering wheel electronics	√	√	√	√					
X 290 AMG-Class	290	Information and communication	TSC H-Touchscreen in rear passenger compartment	√	√	√	√					
X 290 AMG-Class	290	Information and communication	TPAD-Touchpad	√	√	√	√					
X 290 AMG-Class	290	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
X 290 AMG-Class	290	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
X 290 AMG-Class	290	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√					
X 290 AMG-Class	290	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
X 290 AMG-Class	290	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					

X 290 AMG-Class	290	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
X 290 AMG-Class	290	Information and communication	MTAS-Mobile phone cradle	√	√	√	√					
X 290 AMG-Class	290	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√					
X 290 AMG-Class	290	Body	RevETR RF-Right front reversible emergency tensioning retractor	√	√	√	√					
X 290 AMG-Class	290	Information and communication	IC-Instrument cluster	√	√	√	√			SP1047,SP1048,SP1157		
X 290 AMG-Class	290	Information and communication	IC-Instrument cluster(A1)	√	√	√	√					
X 290 AMG-Class	290	Information and communication	HUD-Head up display	√	√	√	√					
X 290 AMG-Class	290	Driver assistance system	RFK-Backup camera	√	√	√	√					
X 290 AMG-Class	290	Information and communication	CTEL-Cellular telephone	√	√	√	√					
X 290 AMG-Class	290	Drive	EAGGS-Electric differential lock	√	√	√	√					
X 290 AMG-Class	290	Body	AMLA-Active engine mount	√	√	√	√					
X 290 AMG-Class	290	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√					
X 290 AMG-Class	290	Body	SG SW L-Left headlamp	√	√	√	√					
X 290 AMG-Class	290	Body	SG SW R-Right headlamp	√	√	√	√					
X 290 AMG-Class	290	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√					
X 290 AMG-Class	290	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√					

X 290 AMG-Class	290	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√					
X 290 AMG-Class	290	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√					
X 290 AMG-Class	290	Driver assistance system	SG AWF-Control unit COLLISION PREVENTION ASSIST	√	√	√	√					
X 290 AMG-Class	290	Drive	HFBM-Haptic accelerator pedal module	√	√	√	√					
X 290 AMG-Class	290	Body	SG LG-Charger	√	√	√	√					
X 290 AMG-Class	290	Body	DC/DC-DC/DC converter	√	√	√						
X 290 AMG-Class	290	Body	GES-Hand motion sensor	√	√	√	√					
X 290 AMG-Class	290	Air conditioning	SG EM-Power electronics	√	√	√	√					
X 290 AMG-Class	290	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
X 290 AMG-Class	290	Body	BSN-Battery sensor(B95)	√	√	√	√					
X 290 AMG-Class	290	Body	LIB-Lithium ion battery	√	√	√	√					
X 290 AMG-Class	290	Body	LIB-Lithium ion battery	√	√	√	√					
X 290 AMG-Class	290	Body	Button group, instrument panel, driver side	√	√	√	√					
X 290 AMG-Class	290	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
X 290 AMG-Class	290	Body	FSW-Windshield wiper	√	√	√	√					
X 290 AMG-Class	290	Body	FSW-Windshield wiper	√	√	√	√					

X 290 AMG-Class	290	Body	GTO-Garage door opener(A67n2)	√	√	√	√					
X 290 AMG-Class	290	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√					
X 290 AMG-Class	290	Body	"Front passenger" seat heater	√	√	√	√					
X 290 AMG-Class	290	Body	"Driver" seat heater	√	√	√	√					
X 290 AMG-Class	290	Body	N5 (Armrest heater control unit)	√	√	√	√					
X 290 AMG-Class	290	Body	N25/6 (Rear passenger compartment seat heater control unit)	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	LFD-Left front door	√	√	√						
X 290 AMG-Class	290	Seats and Doors	LFD-Left front door	√	√	√						
X 290 AMG-Class	290	Seats and Doors	LFD-Left front door	√	√	√						
X 290 AMG-Class	290	Seats and Doors	DCU RF-Right front door	√	√	√						
X 290 AMG-Class	290	Seats and Doors	DCU RF-Right front door	√	√	√						
X 290 AMG-Class	290	Seats and Doors	DCU RF-Right front door	√	√	√						
X 290 AMG-Class	290	Seats and Doors	DCU LR-Left rear door	√	√	√						
X 290 AMG-Class	290	Seats and Doors	DCU LR-Left rear door	√	√	√						
X 290 AMG-Class	290	Seats and Doors	DCU RR-Right rear door	√	√	√						
X 290 AMG-Class	290	Seats and Doors	DCU RR-Right rear door	√	√	√						

X 290 AMG-Class	290	Body	"Driver" seat heater	√	√	√	√					
X 290 AMG-Class	290	Body	"Front passenger" seat heater	√	√	√	√					
X 290 AMG-Class	290	Body	AS-Alarm siren(H3/1)	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	Massage function in left front seat	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	Massage function in right front seat	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	MFSF-LF	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	MFSF-RF	√	√	√	√					
X 290 AMG-Class	290	Air conditioning	N61 (Windshield heater control unit)	√	√	√	√					
X 290 AMG-Class	290	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
X 290 AMG-Class	290	Air conditioning	STH-Stationary heater	√	√	√	√					
X 290 AMG-Class	290	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
X 290 AMG-Class	290	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
X 290 AMG-Class	290	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√					
X 290 AMG-Class	290	Body	SCM-Steering column module(N80)	√	√	√	√					
X 290 AMG-Class	290	Information and communication	OCP-Overhead control panel	√	√	√	√					
X 290 AMG-Class	290	Body	WSS-Weight sensing system(N110)	√	√	√	√					

X 290 AMG-Class	290	Body	N38 (Rear switching module)	√	√	√	√					
X 290 AMG-Class	290	Body	LIB-Lithium ion battery	√	√	√	√					
X 290 AMG-Class	290	Information and communication	TV tuner (TV)	√	√	√	√					
X 290 AMG-Class	290	Information and communication	SOUND-Sound system	√	√	√	√					
X 290 AMG-Class	290	Information and communication	SOUND-Sound system	√	√	√	√					
X 290 AMG-Class	290	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					
X 290 AMG-Class	290	Driver assistance system	DTR-DISTRONIC	√	√	√	√					
X 290 AMG-Class	290	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√					
X 290 AMG-Class	290	Driver assistance system	DTR-DISTRONIC	√	√	√	√					
X 290 AMG-Class	290	Driver assistance system	PTS-PARKTRONIC	√	√	√	√					
X 290 AMG-Class	290	Chassis	ADS-Adaptive damping system	√	√	√	√					
X 290 AMG-Class	290	Chassis	ES - Electric power steering	√	√	√	√					
X 290 AMG-Class	290	Chassis	AIRmatic-AIRmatic PLUS	√	√	√	√					
X 290 AMG-Class	290	Drive	VG-All-wheel drive	√	√	√	√					
X 290 AMG-Class	290	Driver assistance system	NBR LF-Left front short range radar	√	√	√	√					
X 290 AMG-Class	290	Driver assistance system	NBR RF-Right front short range radar	√	√	√	√					

X 290 AMG-Class	290	Driver assistance system	NBR RR-Right rear short-range radar	√	√	√	√					
X 290 AMG-Class	290	Driver assistance system	NBR LR-Left rear short-range radar	√	√	√	√					
X 290 AMG-Class	290	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√				
X 290 AMG-Class	290	Drive	FSCU-Control unit Fuel pump	√	√	√	√					
X 290 AMG-Class	290	Drive	N127 (Drivetrain control unit)	√	√	√						
X 290 AMG-Class	290	Drive	N127 (Drivetrain control unit)	√	√	√	√					
X 290 AMG-Class	290	Drive	ISG-Integrated starter alternator	√	√	√	√					
X 290 AMG-Class	290	Drive	ISG-Integrated starter alternator	√	√	√	√					
X 290 AMG-Class	290	Body	BMS-Battery management system	√	√	√	√					
X 290 AMG-Class	290	Chassis	Rear wing	√	√	√	√					
X 290 AMG-Class	290	Information and communication	LCP-L	√	√	√	√					
X 290 AMG-Class	290	Information and communication	LCP-R	√	√	√	√					
X 290 AMG-Class	290	Drive	ISM-Shift module	√	√	√	√					
X 290 AMG-Class	290	Chassis	Left rear axle steering	√	√	√	√					
X 290 AMG-Class	290	Chassis	Right rear axle steering	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√					

X 290 AMG-Class	290	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√					
X 290 AMG-Class	290	Seats and Doors	HKS-Tailgate control	√	√	√	√					
X 290 AMG-Class	290	Drive	Active transmission mount	√	√	√	√					
GLE-Class	292	Drive	N3/9-Motor electronics "CDI61" for combustion engine "OM642"	√	√	√	√	√	ACT0571,ACT0572,ACT0573,ACT0574,ACT0575,ACT0576,ACT0577,ACT0578,ACT0579,ACT0580,ACT0581,ACT0582,ACT0583	SP1206,SP1207,SP1208,SP1209,SP1210,SP1211,SP1212,SP1213,SP1214,SP1215,SP1216,SP1217,SP1218,SP1219,SP1220,SP1221,SP1222,SP1223,SP1224,SP1225,SP1226,	CD0461, CD0462, CD0463, CD0464	√
GLE-Class	292	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√	ACT0584,ACT0585	SP1229,SP1230,SP1231,SP1232,SP1233,SP1234,SP1235,SP1236,SP1237,SP1237,SP1238,SP1239,SP1240,SP1241,SP1242,	CD0465, CD0466, CD0467, CD0468	√
GLE-Class	292	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7	√	√	√	√	√	ACT0586	SP1244,SP1245,SP1246,SP1247,SP1248,SP1249,SP1250,SP1250,SP1251,SP1252,SP1253,SP1254,	CD0469, CD0470, CD0471, CD0472, CD0473	√
GLE-Class	292	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√	ACT0587,ACT0588,ACT0589	SP1256,SP1257,SP1258,SP1259,SP1260,SP1261	CD0474, CD0475, CD0476, CD0477, CD0478	√
GLE-Class	292	Information and communication	Left front short range radar	√	√	√	√					√
GLE-Class	292	Information and communication	Left front short range radar	√								√
GLE-Class	292	Information and communication	E call [Europe]-Emergency call system	√	√	√	√		ACT0044,ACT0045,ACT0046,ACT0047,ACT0048,ACT0049			
GLE-Class	292	Information and communication	AVE H-Rear audio video unit	√	√	√	√		ACT0610,ACT0611,ACT0612,ACT0613,ACT0614		CD0490, CD0491, CD0492, CD0493, CD0494	√
GLE-Class	292	Information and communication	TPAD-Touchpad	√	√	√	√		ACT0615,ACT0616,ACT0617			
GLE-Class	292	Information and communication	IC-Instrument cluster	√	√	√	√		ACT0050,ACT0051,ACT0052,ACT0053,ACT0054,ACT0055,	SP1047,SP1048		√
GLE-Class	292	Information and communication	KOMO-Communication module Telematics services	√	√	√	√		ACT0057,ACT0058,ACT0059,ACT0060,ACT0061,ACT0062,ACT0063,ACT0064,ACT0065,			√
GLE-Class	292	Seats and Doors	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√		ACT0067,ACT0068,ACT0069,ACT0070,ACT0071,ACT0072,ACT0073,ACT0074	SP1049,SP1050		
GLE-Class	292	Information and communication	TS-Telematic system(N123/4)	√	√	√	√		ACT0075,ACT0076,ACT0077,ACT0078			√

GLE-Class	292	Body	EZS-Electronic ignition switch	√	√	√	√			SP1051,SP1052,SP1053	CD0320, CD0321, CD0322, CD0323, CD0324	
GLE-	292	Body	EZS-Electronic ignition lock	√	√	√	√				CD0325	
GLE-	292	Body	EZS-Electronic ignition lock	√	√	√	√					
GLE-	292	Body	EZS-Electronic ignition lock	√	√	√	√					
GLE-Class	292	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084			√
GLE-Class	292	Chassis	ESP-Electronic stability program(N30/4)	√	√	√	√		ACT0088,ACT0089	SP1278,SP1279,SP1280,SP1281		√
GLE-Class	292	Chassis	ESP-Regenerative braking system(N30/6)	√	√	√	√	√	ACT0624,ACT0625,ACT0626	SP1282,SP1283,SP1284,SP1285,SP1286,SP1287	CD0499, CD0500, CD0501, CD0502	√
GLE-Class	292	Information and communication	TPAD-Touchpad	√	√	√	√		ACT0615,ACT0616,ACT0617			√
GLE-Class	292	Information and communication	Audio-Audio or COMAND	√	√	√	√					
GLE-Class	292	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
GLE-Class	292	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√			SP1288,SP1289,SP1290,SP1291		√
GLE-Class	292	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1292,SP1293,SP1294,SP1295,SP1296		√
GLE-Class	292	Driver assistance system	SGR-Radar sensors control unit(N62/1)	√	√	√	√			SP1297,SP1293,SP1294,SP1296		√
GLE-Class	292	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441,ACT0627			√
GLE-	292	Body	IMS-Interior motion sensor	√	√	√	√		ACT0094,ACT0095,ACT0096			√
GLE-Class	292	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0099,ACT0100	SP1056		√
GLE-Class	292	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√				√
GLE-Class	292	Information and communication	Audio-Audio or COMAND	√	√	√	√					
GLE-Class	292	Driver assistance system	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)	√	√	√	√		ACT0132	SP1062		√
GLE-Class	292	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√		ACT0636,ACT0637,ACT0638,ACT0639,ACT0640,ACT0641,ACT0642,ACT0643			√
GLE-Class	292	Driver assistance system	CAMERA-360 camera(N148)	√	√	√	√		ACT0542	SP1158,SP1159,SP1160,SP1161,SP1162,SP1163		√
GLE-Class	292	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√		ACT0645,ACT0646,ACT0647,ACT0648,ACT0649,ACT0650,ACT0651,ACT0652			√
GLE-Class	292	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					
GLE-Class	292	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					√
GLE-Class	292	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					

GLE-Class	292	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					√
GLE-Class	292	Body	Multifunction control unit-Multifunction control unit	√	√	√	√		ACT0133,ACT0134,ACT0135,ACT0136,ACT0137,ACT0138,ACT0139,ACT0140,ACT0141,ACT0142,ACT0143,ACT0144,ACT0145,ACT0146,ACT0147,ACT0148,ACT0149,ACT0150,			√
GLE-Class	292	Information and communication	SG MSND-Engine sound	√	√	√	√		ACT0151,ACT0152,ACT0153,ACT0154,ACT0155			√
GLE-	292	Body	KG-KEYLESS GO(N69/5)	√	√	√	√		ACT0156,ACT0157			√
GLE-Class	292	Information and communication	SOUND-Sound system	√	√	√	√		ACT0158,ACT0159,ACT0160,ACT0161,ACT0162,ACT0163,ACT0164,ACT0165,ACT0166,ACT0167,ACT0168,ACT0169,ACT0170,ACT0171,ACT0172,ACT0173,ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0179,ACT0180,ACT0181,		CD0348	
GLE-Class	292	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√		ACT0664,ACT0673,ACT0660,ACT0661,ACT0207,ACT0208,ACT0209,ACT0210,ACT0665,ACT0666,ACT0667,ACT0668,ACT0669,ACT0670,ACT0672,ACT1614,ACT0212,ACT0213	SP1064,SP1301	CD0349	√
GLE-	292	Body	HKS-Tailgate control	√	√	√	√		ACT0234,ACT0235	SP1065		√
GLE-	292	Driver assistance	MFK-Multifunction camera	√	√	√	√		ACT0236,ACT0237	SP1066		√
GLE-	292	Driver assistance	MFK-Multifunction	√	√	√	√		ACT0238,ACT0241,ACT0678,ACT0243,ACT0679,ACT0680,ACT0681,ACT0682,ACT0683,ACT0684,ACT0245,ACT0685,ACT0686,ACT0687,ACT0688,ACT0689,ACT0690,ACT0253,ACT0254,ACT0691,ACT0692,ACT0251,ACT0693,ACT0694,ACT0695,ACT0696,ACT0697,ACT0698,ACT0699,ACT0700,	SP1067,SP1068		√
GLE-Class	292	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258	SP1069,SP1070,SP1071		√
GLE-Class	292	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0259,ACT0260,ACT0261,ACT0262		CD0382	
GLE-Class	292	Air conditioning	STH-Stationary heater	√	√	√	√			SP1072		√
GLE-	292	Chassis	ES-Electric power steering(N68)	√	√	√	√			SP1302,SP1303		√
GLE-Class	292	Body	SD-Control module 'Sliding roof' (A98/1)	√	√	√	√		ACT0705	SP1304		√
GLE-Class	292	Body	PSD-Control module 'Panoramic sliding roof' (A98)	√	√	√	√		ACT0269,ACT0270	SP1076		√
GLE-Class	292	Body	RevETR LF-Left front reversible emergency tensioning retractor (A76)	√	√	√	√		ACT0708		CD0525	√

GLE-Class	292	Information and communication	HUD-Head up display	√	√	√	√		ACT0272,ACT0273,ACT0274	SP1077,		
GLE-Class	292	Body	RevETR RF-Right front reversible emergency tensioning retractor(A76/1)	√	√	√	√		ACT0709		CD0526	√
GLE-Class	292	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√		ACT0276,ACT0277,ACT0278,ACT0279,ACT0280,ACT0281,	SP1078,SP1079		√
GLE-Class	292	Information and communication	TB5-TV tuner Tuner unit	√	√	√	√		ACT0287,ACT0288,ACT0289,ACT0290,ACT0291,ACT0292,ACT0293,ACT0294,			
GLE-Class	292	Information and communication	TV tuner (TV)	√	√	√	√		ACT0295,ACT0296,ACT0297,ACT0298,ACT0299,ACT0300,			
GLE-Class	292	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√		ACT0302,ACT0303,ACT0304,ACT0305,ACT0306,ACT0307,ACT0308	SP1080,SP1081		√
GLE-	292	Body	BSN-Battery sensor(B95)	√	√	√	√					
GLE-Class	292	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√		ACT0711,ACT0712,ACT0713,ACT0714,ACT0715	SP1307,SP1308,SP1309,SP1310,SP1311	CD0527, CD0528, CD0529, CD0530	√
GLE-Class	292	Information and communication	D FOL-Display in left rear passenger compartment	√	√	√	√		ACT0711,ACT0712,ACT0713,ACT0714,ACT0715	SP1307,SP1308,SP1309,SP1310,SP1311	CD0527, CD0528, CD0529, CD0530	√
GLE-Class	292	Seats and Doors	N32/31 (Left front seat massage function control unit)	√	√	√	√		ACT0716			
GLE-Class	292	Drive	ISM-Shift module	√	√	√	√		ACT0717,ACT0718,ACT0719,ACT0720,ACT0721	SP1312,SP1313,SP1314		√
GLE-Class	292	Body	Trailer recognition module-Trailer recognition	√	√	√	√		ACT0322,ACT0323,ACT0324,ACT0325,ACT0326,ACT0327,ACT0328,ACT0329,ACT0330,ACT0331,ACT0332,ACT0333,		CD0393	√
GLE-Class	292	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√		ACT0335,ACT0336,ACT0337,ACT0338,ACT0339,ACT0340,ACT0341,ACT0342,ACT0343,ACT0344,ACT0345,ACT0346,ACT0347,ACT0348,ACT0349,ACT0350,ACT0351,ACT0352,ACT0353,ACT0354,ACT0355,ACT0356,ACT0357,ACT0358,ACT0359,ACT0360,ACT0361,ACT0362,ACT0363,ACT0364,ACT0365,ACT0366,ACT0367,ACT0368,ACT0369,ACT0370,ACT0371,ACT0372,ACT0373,ACT0374,ACT0375,ACT0376,ACT0377,ACT0378,ACT0379,			√

GLE-Class	292	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√	ACT0335,ACT0336,ACT0337,ACT0338,ACT0339,ACT0340,ACT0341,ACT0342,ACT0343,ACT0344,ACT0345,ACT0346,ACT0347,ACT0348,ACT0349,ACT0350,ACT0351,ACT0352,ACT0353,ACT0354,ACT0355,ACT0356,ACT0357,ACT0358,ACT0359,ACT0360,ACT0361,ACT0362,ACT0363,ACT0364,ACT0365,ACT0366,ACT0367,ACT0368,ACT0369,ACT0370,ACT0371,ACT0372,ACT0373,ACT0374,ACT0375,ACT0376,ACT0377,ACT0378,ACT0379,			√
GLE-Class	292	Seats and Doors	N32/32 (Right front seat massage function control unit)	√	√	√	√	ACT0722			
GLE-Class	292	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√	ACT0723,ACT0724,ACT0725,ACT0726,ACT0727	SP1315,SP1316,SP1317,SP1318,SP1319	CD0531, CD0532, CD0533, CD0534	√
GLE-Class	292	Information and communication	D FOR-Display in right rear passenger compartment	√	√	√	√	ACT0723,ACT0724,ACT0725,ACT0726,ACT0727	SP1315,SP1316,SP1317,SP1318,SP1319	CD0531, CD0532, CD0533, CD0534	√
GLE-	292	Drive	FSCU05-Control unit Fuel pump	√	√	√	√	ACT0385			√
GLE-Class	292	Body	REAR-Rear control unit(N10/8)	√	√	√	√	ACT0728,ACT0729,ACT0730,ACT0731,ACT0732,ACT0733,ACT0734,ACT0735,ACT0736,			√
GLE-	292	Driver assistance	DTR-DISTRONIC	√	√	√	√				√
GLE-	292	Driver assistance	DTR-DISTRONIC	√	√	√	√				√
GLE-	292	Driver assistance	DTR-DISTRONIC (A89)	√	√	√	√		SP1084	CD0395	√
GLE-	292	Chassis	DTR-DISTRONIC (A89)	√	√	√	√		SP1084	CD0395	√
GLE-Class	292	Seats and Doors	LFD-Left front door	√	√	√	√	ACT0386,ACT0387,ACT0388,ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0397,ACT0398,ACT0399,ACT0400,ACT0401,ACT0402,ACT0403,	SP1085		√
GLE-Class	292	Seats and Doors	DCU RF-Right front door	√	√	√	√	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410,ACT0411,ACT0412,ACT0413,ACT0414,ACT0415,ACT0416,ACT0417,ACT0418,ACT0419,ACT0420,ACT0421,ACT0422,	SP1086		√
GLE-Class	292	Information and communication	TV-TV tuner	√	√	√	√	ACT0424,ACT0425,ACT0426,ACT0427,ACT0222,ACT0428,ACT0219,ACT0221			
GLE-Class	292	Information and communication	TV-TV tuner	√	√	√	√	ACT0429,ACT0430,ACT0431,ACT0229,ACT0432,ACT0433,			

GLE-Class	292	Seats and Doors	DCU LR-Left rear door(N69/3)	√	√	√	√	ACT0741,ACT0742,ACT0743,ACT0744,ACT0745,ACT0746,ACT0747,ACT0748,ACT0749,ACT0750,ACT0751,ACT0752,ACT0753,ACT0754,ACT0755,ACT0756,ACT0757,ACT0758,	SP1321		√
GLE-Class	292	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√	ACT0255,ACT0256,ACT0257,ACT0258			
GLE-Class	292	Seats and Doors	DCU RR-Right rear door(N69/4)	√	√	√	√	ACT0760,ACT0761,ACT0762,ACT0763,ACT0764,ACT0765,ACT0766,ACT0767,ACT0768,ACT0769,ACT0770,ACT0771,ACT0772,ACT0773,ACT0774,ACT0775,ACT0776,ACT0777,	SP1322		√
GLE-Class	292	Chassis	EFB-Electronic parking brake(N128)	√	√	√	√	ACT0435,ACT0436,ACT0437,ACT0438	SP1087		√
GLE-	292	Driver assistance	RFK-Backup camera	√	√	√	√	ACT0439	SP1088,SP1089		√
GLE-	292	Chassis	FGW-Chassis gateway	√	√	√	√			CD0535	√
GLE-	292	Body	WSS-Weight sensing	√	√	√	√				
GLE-Class	292	Chassis	RC-Roll control(B38/2)	√	√	√	√	ACT0779,ACT0780,ACT0781,ACT0782,ACT0783,ACT0784,ACT0785,ACT0786	SP1323		√
GLE-Class	292	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√	ACT0441			√
GLE-Class	292	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√	ACT0441,ACT0627			√
GLE-	292	Air conditioning	HBF-Rear control panel(N72/2)	√	√	√	√	ACT0787,ACT0788			√
GLE-	292	Body	UCP-Upper control panel	√	√	√	√				
GLE-Class	292	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	ACT0447,ACT0448,ACT0449,ACT0450			√
GLE-Class	292	Information and communication	AVE H-Rear audio video unit	√	√	√	√	ACT0610,ACT0611,ACT0612,ACT0789,ACT0613,ACT0614		CD0490, CD0491, CD0492, CD0493, CD0494	√
GLE-Class	292	Body	SG SW L-Left headlamp	√	√	√	√	ACT0456,ACT0457,ACT0458,ACT0459,ACT0460,ACT0461	SP1094,SP1095,SP1096,SP1097,,SP1098,SP1099,	CD0398	√
GLE-Class	292	Body	SG SW L-Left headlamp(E1n9)	√	√	√	√	ACT0462,ACT0463,ACT0464,ACT0465,ACT0466,ACT0467	SP1101,SP1102,SP1103,SP1104,SP1105,SP1106,SP1107,SP1108	CD0399	√
GLE-Class	292	Body	SG SW R-Right headlamp	√	√	√	√	ACT0468,ACT0469,ACT0470,ACT0471,ACT0472,ACT0473	SP1109,SP1110,SP1111,SP1112,SP1113,SP1114	CD0400	√
GLE-Class	292	Body	SG SW R-Right headlamp(E1n9)	√	√	√	√	ACT0474,ACT0475,ACT0476,ACT0477,ACT0478,ACT0479	SP1115,SP1116,SP1117,SP1118,SP1119,SP1120	CD0401	√
GLE-	292	Body	GTO-Garage door	√	√	√	√				
GLE-Class	292	Body	OCP-Control unit 'Overhead control panel'	√	√	√	√	ACT0480,ACT0481,ACT0482,ACT0483			
GLE-	292	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√				
GLE-Class	292	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√				
GLE-	292	Driver assistance	PARK-Parking system (N62)	√	√	√	√	ACT0484,ACT0485		CD0411, CD0412	√

GLE-Class	292	Body	N32/2 (Front passenger seat control unit)	√			√		ACT0486			
GLE-Class	292	Body	ORBF Off-road operating panel(N72/3)	√	√	√	√					
GLE-Class	292	Body	LCP-Lower operating panel with power window function	√	√	√	√					
GLE-Class	292	Body	N32/1 (Driver seat control unit)	√			√		ACT0487			
GLE-Class	292	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT0490			
GLE-Class	292	Body	E1n7 (Actuation module, LED exterior lighting, left front)	√	√	√	√		ACT0794,ACT0795	SP1325,SP1326,SP1327	CD0540	
GLE-Class	292	Body	AMLAB L 2-Actuation module 2, LED exterior lighting, left	√	√	√	√		ACT0796,ACT0797	SP1328,SP1329,SP1330	CD0541	
GLE-Class	292	Body	E2n7 (Actuation module, LED exterior lighting, right front)	√	√	√	√		ACT0798,ACT0799	SP1331,SP1332	CD0542	
GLE-Class	292	Body	AMLAB R 2-Actuation module 2, LED exterior lighting, right front(E2n8)	√	√	√	√		ACT0800,ACT0801	SP1333,SP1334	CD0543	
GLE-Class	292	Drive	FSCU-Fuel pump	√	√	√	√		ACT0498,ACT0499		CD0427, CD0428	√
GLE-Class	292	Drive	SCR-Selective catalytic reduction	√	√	√	√		ACT0600,ACT0601,ACT0602,ACT0603,ACT0604,ACT0605	SP1268,SP1269,SP1270,SP1271,SP1272,SP1273	CD0483, CD0484, CD0485	√
GLE-Class	292	Drive	N3/10-Motor electronics "MED177" for combustion engine "M276"	√	√	√	√	√	ACT0802,ACT0803,ACT0804,ACT0805,ACT0806,ACT0807,ACT0808,ACT0809,ACT0810,ACT0811,ACT0812,ACT0813,ACT0814,ACT0815,ACT0816,ACT0817,ACT0818,ACT0819,	SP1335,SP1336,SP1337,SP1338,SP1339,SP1340,SP1341,SP1342,SP1343,SP1344,SP1345,SP1346,SP1347,SP1348	CD0544, CD0545, CD0546, CD0547, CD0548, CD0549, CD0550, CD0551, CD0552	√
GLE-Class	292	Drive	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"	√	√	√	√	√	ACT0821,ACT0822,ACT0823,ACT0824,ACT0825,ACT0826,ACT0827,ACT0828,ACT0829,ACT0830,ACT0831,ACT0832,ACT0833,ACT0834,ACT0835,ACT0836,ACT0837,ACT0838,	SP1349,SP1350,SP1351,SP1352,SP1353,SP1354,SP1355,SP1356,SP1357,SP1358,SP1359,SP1360,SP1361,SP1362,SP1363,SP1364	CD0553, CD0554, CD0555, CD0556, CD0557, CD0558, CD0559, CD0560, CD0561	√
EQC-Class	293	Seats and Doors	LFD-Left front door	√	√	√	√					
EQC-Class	293	Seats and Doors	DCU RF-Right front door	√	√	√	√					
EQC-Class	293	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
EQC-Class	293	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
EQC-Class	293	Body	SRS-Supplemental restraint system	√	√	√	√	√				
EQC-Class	293	Body	EZS-Electronic ignition lock	√	√	√	√					
EQC-Class	293	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					
EQC-Class	293	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√					

EQC-Class	293	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√				
EQC-Class	293	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√				
EQC-Class	293	Information and communication	HERMES-control unit for telematics services	√	√	√	√				
EQC-Class	293	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√				
EQC-Class	293	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√				
EQC-Class	293	Seats and Doors	MKS-FS-Pilot multi-profile seat	√	√	√	√				
EQC-Class	293	Seats and Doors	MKS-BFS-Front passenger more copy the seat	√	√	√	√				
EQC-Class	293	Air conditioning	AAC-Automatic air conditioning	√	√	√	√				
EQC-Class	293	Seats and Doors	HKS-Tailgate control	√	√	√	√				
EQC-Class	293	Body	Trailer recognition module-Trailer recognition	√	√	√	√				
EQC-Class	293	Body	PSD-Panoramic sliding roof	√	√	√	√				
EQC-Class	293	Body	AML-Ambiance light	√	√	√	√				
EQC-Class	293	Body	KG-Keyless Go	√	√	√	√				
EQC-Class	293	Body	OCP-Overhead control panel	√	√	√	√				
EQC-Class	293	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√				
EQC-Class	293	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√				
EQC-Class	293	Body	LRE-Steering wheel electronics	√	√	√	√				
EQC-Class	293	Information and communication	TPAD-Touchpad	√	√	√	√				
EQC-Class	293	Information and communication	TPAD-Touchpad	√	√	√	√				
EQC-Class	293	Information and communication	Audio-Audio or COMAND	√	√	√	√				
EQC-Class	293	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√				
EQC-Class	293	Information and communication	ZAN-Audio/COMAND display	√	√	√	√				
EQC-Class	293	Information and communication	MTAS-Mobile phone cradle	√	√	√	√				
EQC-Class	293	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√				

EQC-Class	293	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√				
EQC-Class	293	Information and communication	IC-Instrument cluster(A1)	√	√	√	√				
EQC-Class	293	Information and communication	HUD-Head up display	√	√	√	√				
EQC-Class	293	Driver assistance system	RFK-Backup camera	√	√	√	√				
EQC-Class	293	Driver assistance system	KAR-Augmented reality camera	√	√	√	√				
EQC-Class	293	Information and communication	CSM-Windshield reader system	√	√	√	√				
EQC-Class	293	Body	SOGESTAR2-Sound generator for electric vehicle	√	√	√	√				
EQC-Class	293	Body	SG SW L-Left headlamp	√	√	√	√				
EQC-Class	293	Body	SG SW R-Right headlamp	√	√	√	√				
EQC-Class	293	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√				
EQC-Class	293	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√				
EQC-Class	293	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√				
EQC-Class	293	Driver assistance system	MFK-Multifunction camera(mono)(A40/11)	√	√	√	√				
EQC-Class	293	Body	DCCU-Direct current charge connection unit	√	√	√	√				
EQC-Class	293	Drive	SG EM-Power electronics	√	√	√	√				
EQC-Class	293	Drive	SG EM-Power electronics 1	√	√	√	√				
EQC-Class	293	Body	SG LG-Charger	√	√	√	√				
EQC-Class	293	Body	DC/DC-DC/DC converter	√	√	√	√				
EQC-Class	293	Body	GES-Hand motion sensor	√	√	√	√				
EQC-Class	293	Body	BSN-Battery sensor(B95)	√	√	√	√				
EQC-Class	293	Body	Button group, instrument panel, driver side	√	√	√	√				
EQC-Class	293	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√				
EQC-Class	293	Body	FSW-Windshield wiper	√	√	√	√				
EQC-Class	293	Body	GTO-Garage door opener(A67n2)	√	√	√	√				

EQC-Class	293	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√					
EQC-Class	293	Body	"Front passenger" seat heater	√	√	√	√					
EQC-Class	293	Body	"Driver" seat heater	√	√	√	√					
EQC-Class	293	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√					
EQC-Class	293	Seats and Doors	LFD-Left front door	√	√	√						
EQC-Class	293	Seats and Doors	LFD-Left front door	√	√	√						
EQC-Class	293	Seats and Doors	LFD-Left front door	√	√	√						
EQC-Class	293	Seats and Doors	DCU RF-Right front door	√	√	√						
EQC-Class	293	Seats and Doors	DCU RF-Right front door	√	√	√						
EQC-Class	293	Seats and Doors	DCU RF-Right front door	√	√	√						
EQC-Class	293	Seats and Doors	DCU LR-Left rear door	√	√	√						
EQC-Class	293	Seats and Doors	DCU RR-Right rear door	√	√	√						
EQC-Class	293	Body	AS-Alarm siren(H3/1)	√	√	√	√					
EQC-Class	293	Air conditioning	AAC-Automatic air conditioning	√	√	√						
EQC-Class	293	Air conditioning	AAC-Automatic air conditioning	√	√	√						
EQC-Class	293	Air conditioning	AAC-Automatic air conditioning	√	√	√						
EQC-Class	293	Information and communication	N72/1 (Upper control panel control unit)	√	√	√						
EQC-Class	293	Information and communication	LCP-Lower control panel	√	√	√	√					
EQC-Class	293	Information and communication	N72/5 (Right lower control panel)	√	√	√						
EQC-Class	293	Information and communication	N72/4 (Left lower control panel)	√	√	√						
EQC-Class	293	Body	WSS-Weight sensing system(N110)	√	√	√	√					
EQC-Class	293	Body	N38 (Rear switching module)	√	√	√	√					
EQC-Class	293	Information and communication	SOUND-Sound system	√	√	√	√					
EQC-Class	293	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					

EQC-Class	293	Driver assistance system	DTR-DISTRONIC	√	√	√	√				
EQC-Class	293	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√				
EQC-Class	293	Driver assistance system	SGR-Radar sensors control unit	√	√	√	√				
EQC-Class	293	Driver assistance system	PTS-PARKTRONIC	√	√	√	√				
EQC-Class	293	Chassis	ELC-Electronic level control	√	√	√	√				
EQC-Class	293	Chassis	ES - Electric power steering	√	√	√	√				
EQC-Class	293	Body	SCM-Steering column module(N80)	√	√	√	√				
EQC-Class	293	Driver assistance system	NBR RR-Right rear short-range radar	√	√	√	√				
EQC-Class	293	Driver assistance system	NBR LR-Left rear short-range radar	√	√	√	√				
EQC-Class	293	Body	BMS-Battery management system	√	√	√	√				
EQC-Class	293	Body	BMS-Battery management system 1	√	√	√	√				
EQC-Class	293	Body	BMS-Battery management system 2	√	√	√	√				
EQC-Class	293	Chassis	ESP-Electric stability program(N30/4)	√	√	√	√	√			
EQC-Class	293	Drive	N127 (Drivetrain control unit)	√	√	√	√				
EQC-Class	293	Drive	EAGGS-Electric differential lock	√	√	√	√				
EQC-Class	293	Drive	HPPM-Haptic accelerator pedal module	√	√	√	√				
EQC-Class	293	Drive	FSCU-Control unit Fuel pump	√	√	√	√				
EQC-Class	293	Drive	ISM-Shift module	√	√	√	√				
EQC-Class	293	Drive	ISG-Integrated starter alternator	√	√	√	√				
EQC-Class	293	Drive	ISG-Integrated starter alternator	√	√	√	√				
EQC-Class	293	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√				
EQC-Class	293	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√					
EQC-Class	293	Chassis	EFB-Electric parking brake	√	√	√	√				
EQC-Class	293	Chassis	AIRmatic-AIRmatic PLUS	√	√	√	√				

EQC-Class	293	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√					
AMG-Class	298	Drive	ME-Motro electronics CNGCM246 for combustion	√	√	√	√					
AMG-Class	298	Drive	VGS-Transmission control	√	√	√	√					
AMG-Class	298	Drive	N127 (Drivetrain control unit)	√	√	√						
AMG-Class	298	Seats and Doors	LFD-Left front door	√	√	√	√					
AMG-Class	298	Seats and Doors	DCU RF-Right front door	√	√	√	√					
AMG-Class	298	Body	EZS-Electronic ignition lock	√	√	√	√					
AMG-Class	298	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					
AMG-Class	298	Information and communication	HERMES-control unit for telematics services	√	√	√	√					
AMG-Class	298	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√					
AMG-Class	298	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√					
AMG-Class	298	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					
AMG-Class	298	Body	KG-Keyless Go	√	√	√	√					
AMG-Class	298	Body	LRE-Steering wheel electronics	√	√	√	√					
AMG-Class	298	Information and communication	Audio-Audio or COMAND	√	√	√						
AMG-Class	298	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
AMG-Class	298	Information and communication	IC-Instrument cluster(A1)	√	√	√	√					
AMG-Class	298	Body	SRS-Supplemental restraint system	√	√	√	√	√				
AMG-Class	298	Chassis	AMG DRVU-AMG DRIVE UNIT	√	√	√	√					
AMG-Class	298	Body	SG SW L-Left headlamp	√	√	√	√					
AMG-Class	298	Body	SG SW R-Right headlamp	√	√	√	√					
AMG-Class	298	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√					
AMG-Class	298	Body	SG LG-Charger	√	√	√						
AMG-Class	298	Body	DC/DC-DC/DC converter	√	√	√	√					

AMG-Class	298	Drive	SG EM-Power electronics	√	√	√						
AMG-Class	298	Drive	SG EM-Power electronics	√	√	√						
AMG-Class	298	Drive	SG EM-Power electronics	√	√	√						
AMG-Class	298	Information and communication	ZAN-Audio/COMAND display	√	√	√	√					
AMG-Class	298	Body	Multifunction control unit-Multifunction control unit	√	√	√	√					
AMG-Class	298	Body	BSN-Battery sensor(B95)	√	√	√	√					
AMG-Class	298	Body	LIB-Lithium ion battery	√	√	√	√					
AMG-Class	298	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
AMG-Class	298	Body	FSW-Windshield wiper	√	√	√	√					
AMG-Class	298	Seats and Doors	S47/2 (Driver door switch module)	√	√	√	√					
AMG-Class	298	Information and communication	OCP-Overhead control panel	√	√	√						
AMG-Class	298	Body	WSS-Weight sensing system(N110)	√	√	√	√					
AMG-Class	298	Driver assistance system	PTS-PARKTRONIC	√	√	√	√					
AMG-Class	298	Chassis	ES - Electric power steering	√	√	√	√					
AMG-Class	298	Body	SCM-Steering column module(N80)	√	√	√	√					
AMG-Class	298	Chassis	ESP- Electric stability program	√	√	√						
AMG-Class	298	Drive	FSCU-Control unit Fuel pump	√	√	√	√					
AMG-Class	298	Drive	N127 (Drivetrain control unit)	√	√	√						
AMG-Class	298	Drive	SG EM-Power electronics	√	√	√						
AMG-Class	298	Body	BMS-Battery management system	√	√	√	√					
G-Class	461	Drive	N3/30-Motor electronics "CDI6" for combustion engine "OM642"	√	√	√	√					
G-Class	461	Drive	N15/3The fault occurs when charging of the fuel injector takes too long.5	√	√	√	√					
G-Class	461	Body	CGW-Central gateway	√	√	√	√					
G-Class	461	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
G-Class	461	Body	EZS-Electronic ignition switch	√	√	√	√					

G-Class	461	Driver assistance	TPM-Tire pressure monitor(N88)	√	√	√	√					
G-Class	461	Body	SRS-Supplemental restraint	√	√	√	√					
G-Class	461	Air conditioning	STH-Stationary heater	√	√	√	√					
G-Class	461	Chassis	ESP- Electric stability program	√	√	√	√					
G-Class	461	Drive	ESM [EWM]	√	√	√	√					
G-Class	461	Information and communication	IC-Instrument cluster	√	√	√	√					
G-Class	461	Drive	VG-Transfer case	√	√	√	√					
G-Class	463	Drive	N3/9-Motor electronics "CDI61" for combustion engine "OM642"	√	√	√	√	√	ACT0571,ACT0572,ACT0573,ACT0574,ACT0575,ACT0576,ACT0577,ACT0578,ACT0579,ACT0580,ACT0581,ACT0582,ACT0583	SP1206,SP1207,SP1208,SP1209,SP1210,SP1211,SP1212,SP1213,SP1214,SP1215,SP1216,SP1217,SP1218,SP1219,SP1220,SP1221,SP1222,SP1223,SP1224,SP1225,SP1226,	CD0461, CD0462, CD0463, CD0464	√
G-Class	463	Drive	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"	√	√	√	√		ACT1472,ACT1473,ACT1474,ACT1475,ACT1476,ACT1477,ACT1478,ACT1479,ACT1480,ACT1481	SP1549,SP1550,SP1551,SP1552,SP1553,SP1554,SP1555,SP1556,SP1557,SP1558,SP1559,SP1560,SP1561,SP1562,SP1563,SP1564,SP1565,SP1566,	CD0738, CD0739, CD0740	√
G-Class	463	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√		ACT0335,ACT0336,ACT0337,ACT0338,ACT0339,ACT0340,ACT0341,ACT0342,ACT0343,ACT0344,ACT0345,ACT0346,ACT0347,ACT0348,ACT0349,ACT0350,ACT0351,ACT0352,ACT0353,ACT0354,ACT0355,ACT0356,ACT0357,ACT0358,ACT0359,ACT0360,ACT0361,ACT0362,ACT0363,ACT0364,ACT0365,ACT0366,ACT0367,ACT0368,ACT0369,ACT0370,ACT0371,ACT0372,ACT0373,ACT0374,ACT0375,ACT0376,ACT0377,ACT0378,ACT0379,		√	

G-Class	463	Body	SAM-Signal acquisition and actuation module(N10)	√	√	√	√	ACT0335,ACT0336,ACT0337,ACT0338,ACT0339,ACT0340,ACT0341,ACT0342,ACT0343,ACT0344,ACT0345,ACT0346,ACT0347,ACT0348,ACT0349,ACT0350,ACT0351,ACT0352,ACT0353,ACT0354,ACT0355,ACT0356,ACT0357,ACT0358,ACT0359,ACT0360,ACT0361,ACT0362,ACT0363,ACT0364,ACT0365,ACT0366,ACT0367,ACT0368,ACT0369,ACT0370,ACT0371,ACT0372,ACT0373,ACT0374,ACT0375,ACT0376,ACT0377,ACT0378,ACT0379,			√
G-Class	463	Drive	N127 (Drivetrain control unit)	√	√	√	√	ACT0500,ACT0501	SP1129,SP1130,SP1131	CD0429, CD0430, CD043	√
G-Class	463	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√	ACT0441			√
G-Class	463	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√	ACT0441,ACT0627			√
G-Class	463	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√	ACT0441			√
G-Class	463	Information and communication	DAB-Digital Audio Broadcasting(N87/3)	√	√	√	√				
G-Class	463	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√				
G-Class	463	Information and communication	ZAN-Audio/COMAND display	√	√	√	√	ACT0442,ACT0443,ACT0444,ACT0445,ACT0446			√
G-Class	463	Seats and Doors	LFD-Left front door	√	√	√	√	ACT0386,ACT0387,ACT0388,ACT0389,ACT0390,ACT0391,ACT0392,ACT0393,ACT0394,ACT0395,ACT0396,ACT0397,ACT0398,ACT0399,ACT0400,ACT0401,ACT0402,ACT0403,	SP1085		√
G-Class	463	Seats and Doors	DCU RF-Right front door	√	√	√	√	ACT0405,ACT0406,ACT0407,ACT0408,ACT0409,ACT0410,ACT0411,ACT0412,ACT0413,ACT0414,ACT0415,ACT0416,ACT0417,ACT0418,ACT0419,ACT0420,ACT0421,ACT0422,	SP1086		√
G-Class	463	Seats and Doors	DCU LR-Left rear door(N69/3)	√	√	√	√	ACT0741,ACT0742,ACT0743,ACT0744,ACT0745,ACT0746,ACT0747,ACT0748,ACT0749,ACT0750,ACT0751,ACT0752,ACT0753,ACT0754,ACT0755,ACT0756,ACT0757,ACT0758,	SP1321		√

G-Class	463	Seats and Doors	DCU RR-Right rear door(N69/4)	√	√	√	√		ACT0760,ACT0761,ACT0762,ACT0763,ACT0764,ACT0765,ACT0766,ACT0767,ACT0768,ACT0769,ACT0770,ACT0771,ACT0772,ACT0773,ACT0774,ACT0775,ACT0776,ACT0777,	SP1322		√
G-Class	463	Information and communication	DSI-DIRECT SELECT interface(N150)	√	√	√	√		ACT0488			√
G-Class	463	Drive	ISM-Shift module	√	√	√	√		ACT0717,ACT0718,ACT0719,ACT0720,ACT0721	SP1312,SP1313,SP1314		√
G-Class	463	Information and communication	ZAN-Audio/COMAND display	√	√	√	√		ACT0447,ACT0448,ACT0449,ACT0450			√
G-Class	463	Body	AISP-Dimming inside rearview mirror(A67)	√	√	√	√					
G-Class	463	Information and communication	E call [Europe]-Emergency call system	√	√	√	√		ACT0044,ACT0045,ACT0046,ACT0047,ACT0048,ACT0049			
G-Class	463	Body	EZS-Electronic ignition switch	√	√	√	√			SP1051,SP1052,SP1053	CD0320, CD0321, CD0322, CD0323, CD0324	
G-Class	463	Chassis	ESP-Electric stability	√	√	√	√		ACT1615,ACT1616	SP1624,SP1625		√
G-Class	463	Chassis	ESP-Electric stability	√	√	√	√		ACT1615,ACT1616	SP1624,SP1625		√
G-Class	463	Body	EZS-Electronic ignition lock	√	√	√	√				CD0325	
G-Class	463	Body	EZS-Electronic ignition lock	√	√	√	√					
G-Class	463	Body	EZS-Electronic ignition lock	√	√	√	√					
G-Class	463	Body	FLANFS-Fire extinguishing system and emergency fresh air	√	√	√	√		ACT1617,ACT1618,ACT1619,ACT1620			
G-Class	463	Drive	FSCU-Fuel pump	√	√	√	√		ACT0498,ACT0499		CD0427, CD0428	√
G-Class	463	Body	GTO-Garage door	√	√	√	√					
G-Class	463	Seats and Doors	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem	√	√	√	√		ACT0067,ACT0068,ACT0069,ACT0070,ACT0071,ACT0072,ACT0073,ACT0074	SP1049,SP1050		
G-Class	463	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√		ACT0101,ACT0102,ACT0103,ACT0104,ACT0105,ACT0106,ACT0107,ACT0108,ACT0109,ACT0110,ACT0111,ACT0112,ACT0113,ACT0114,ACT0115,ACT0116,ACT0117,ACT0118,ACT0119,ACT0120,ACT0121,ACT0118,ACT0119,ACT0120,ACT0119,ACT0121,ACT0122,ACT0123,ACT0124,ACT0125,ACT0126,ACT0111,ACT0112,ACT0113,ACT0118,ACT0116,ACT0117,ACT0102,ACT0103,ACT0127,ACT0128,ACT0101,	SP1057,SP1058,SP1059,SP1060,SP1061		
G-Class	463	Information and communication	Audio-Audio or COMAND	√	√	√	√					
G-Class	463	Information and communication	Audio-Audio or COMAND	√	√	√	√					

G-Class	463	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√					
G-Class	463	Air conditioning	AAC-Automatic air conditioning	√	√	√	√		ACT0238,ACT0241,ACT0678,ACT0243,ACT0679,ACT0680,ACT0681,ACT0682,ACT0683,ACT0684,ACT0245,ACT0685,ACT0686,ACT0687,ACT0688,ACT0689,ACT0690,ACT0253,ACT0254,ACT0691,ACT0692,ACT0251,ACT0693,ACT0694,ACT0695,ACT0696,ACT0697,ACT0698,ACT0699,ACT0700,	SP1069,SP1070,SP1071		√
G-Class	463	Body	BSN-Battery sensor(B95)	√	√	√	√					
G-Class	463	Driver assistance system	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					
G-Class	463	Driver assistance system	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					
G-Class	463	Body	IRS HRA-Outer right rear intelligent radar sensor	√	√	√	√					√
G-Class	463	Body	IRS HLA-Outer left rear intelligent radar sensor system	√	√	√	√					√
G-Class	463	Information and communication	IC-Instrument cluster	√	√	√	√		ACT0050,ACT0051,ACT0052,ACT0053,ACT0054,ACT0055,	SP1047,SP1048		√
G-Class	463	Information and communication	IC-Instrument cluster(A1)	√	√	√	√		ACT1080,ACT1081,ACT1082,ACT1083,ACT1084,ACT1085,	SP1400,SP1401		√
G-Class	463	Information and communication	IC-Instrument cluster	√	√	√	√		ACT0050,ACT0051,ACT0052,ACT0053,ACT0054,ACT0055,	SP1047,SP1048		√
G-Class	463	Air conditioning	STH-Stationary heater	√	√	√	√		ACT0259,ACT0260,ACT0261,ACT0262	SP1072		√
G-Class	463	Driver assistance	DTR-DISTRONIC (A89)	√	√	√	√			SP1084	CD0395	√
G-Class	463	Chassis	DTR-DISTRONIC (A89)	√	√	√	√			SP1084	CD0395	√
G-Class	463	Body	B38/2-Rain/light sensor(RGLS)	√	√	√	√			SP1121		
G-Class	463	Body	LCP-Lower operating panel with power window function	√	√	√	√					
G-Class	463	Body	UCP-Upper control panel	√	√	√	√					
G-Class	463	Body	Multifunction control unit-Multifunction control unit	√	√	√	√		ACT0133,ACT0134,ACT0135,ACT0136,ACT0137,ACT0138,ACT0139,ACT0140,ACT0141,ACT0142,ACT0143,ACT0144,ACT0145,ACT0146,ACT0147,ACT0148,ACT0149,ACT0150,			√
G-Class	463	Body	WSS-Weight sensing	√	√	√	√					
G-Class	463	Body	OCP-Control unit 'Overhead control panel'	√	√	√	√		ACT0480,ACT0481,ACT0482,ACT0483			
G-Class	463	Body	SRS-Supplemental restraint system (N2/10)	√	√	√	√	√				√
G-Class	463	Information and communication	TS-Telematic system(N123/4)	√	√	√	√		ACT0075,ACT0076,ACT0077,ACT0078			√

G-Class	463	Driver assistance system	PTS-Parktronic system	√	√	√	√		ACT1006		CD0536, CD0537, CD0538, CD0539	√
G-Class	463	Body	N10/8 (Rear passenger compartment control unit)	√	√	√	√		ACT1621,ACT1622,ACT1623,ACT1624,ACT1625,ACT1626,ACT1627,ACT1628,ACT1629,			√
G-Class	463	Driver assistance	RFK-Backup camera	√	√	√	√		ACT0439	SP1088,SP1089		√
G-Class	463	Body	SCM-Steering column module(N80)	√	√	√	√		ACT0079,ACT0080,ACT0081,ACT0082,ACT0083,ACT0084			√
G-Class	463	Drive	SCR-Selective Catalytic Reduction	√	√	√	√		ACT0590,ACT0591,ACT0592,ACT0593,ACT0594,ACT0595,ACT0596,ACT0597,ACT0598,	SP1262,SP1263,SP1264,SP1265,SP1266,SP1267	CD0479, CD0480, CD0481, CD0482	√
G-Class	463	Information and communication	SDAR-Satellite radio	√	√	√	√		ACT0283,ACT0284,ACT0285,ACT0286		CD0387CD0388, CD0389, CD0389	
G-Class	463	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√		ACT0276,ACT0277,ACT0278,ACT0279,ACT0280,ACT0281,	SP1078,SP1079		√
G-Class	463	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√		ACT0302,ACT0303,ACT0304,ACT0305,ACT0306,ACT0307,ACT0308	SP1080,SP1081		√
G-Class	463	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT0490			
G-Class	463	Body	AS-Alarm siren(H3/1)	√	√	√	√		ACT0490			
G-Class	463	Information and communication	SOUND-Sound system	√	√	√	√		ACT0158,ACT0159,ACT0160,ACT0161,ACT0162,ACT0163,ACT0164,ACT0165,ACT0166,ACT0167,ACT0168,ACT0169,ACT0170,ACT0171,ACT0172,ACT0173,ACT0174,ACT0175,ACT0176,ACT0177,ACT0178,ACT0179,ACT0180,ACT0181,		CD0348	
G-Class	463	Information and communication	SOUND-Bose sound system	√	√	√	√		ACT0199,ACT0186,ACT0187,ACT0189,ACT0191,ACT0192,ACT0200,ACT0195,ACT0196,ACT0201,ACT0202,ACT0194,ACT0203,ACT0204,ACT0205,ACT0197,ACT0206,ACT0198	SP1063		
G-Class	463	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√		ACT0207,ACT0208,ACT0209,ACT1631			√
G-Class	463	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258		CD0382	
G-Class	463	Information and communication	TB5-TV tuner Tuner unit	√	√	√	√		ACT0287,ACT0288,ACT0289,ACT0290,ACT0291,ACT0292,ACT0293,ACT0294,			
G-Class	463	Information and communication	DAB-Digital Audio Broadcasting	√	√	√	√		ACT0255,ACT0256,ACT0257,ACT0258			
G-Class	463	Information and communication	TV-TV tuner	√	√	√	√		ACT0424,ACT0425,ACT0426,ACT0427,ACT0222,ACT0428,ACT0219,ACT0221			
G-Class	463	Drive	VG-Transfer case	√	√	√	√		ACT0791	SP1324	CD0792	√

G-Class	463	Body	TRM-Trailer recognition module (N28/1)	√	√	√	√		ACT0310,ACT0311,ACT0312,ACT0313,ACT0314,ACT0315,ACT0316,ACT0317,ACT0318,ACT0319,ACT0320,ACT0321	SP1082,SP1083		√
G-Class	463	Driver assistance system	TPM-Tire pressure monitor(N88)	√	√	√	√		ACT0097,ACT0098,ACT0099,ACT0100	SP1056		√
G-Class	463	Information and communication	TV-TV tuner	√	√	√	√		ACT0214,ACT0215,ACT0216,ACT0217,ACT0218,ACT0219,ACT0220,ACT0221,ACT0222,ACT0223		CD0350CD0351, CD0352, CD0353, CD0354, CD0355, CD0356, CD0357, CD0358, CD0359, CD0360, CD0361	
G-Class	463	Information and communication	TV-TV tuner	√	√	√	√		ACT0224,ACT0225,ACT0226,ACT0227,ACT0228,ACT0229,ACT0230,ACT0231,ACT0232,ACT0233		CD0362CD0363, CD0364, CD0365, CD0366, CD0367, CD0368, CD0369, CD0370, CD0371, CD0372, CD0373	
G-Class	463	Information and communication	TV-TV tuner	√	√	√	√		ACT0429,ACT0430,ACT0431,ACT0229,ACT0432,ACT0433,			
G-Class	463	Information and communication	TV tuner (TV)	√	√	√	√		ACT0295,ACT0296,ACT0297,ACT0298,ACT0299,ACT0300,			
G-Class	463	Information and communication	MIF-Media interface	√	√	√	√					
G-Class	463	Information and communication	MIF-Media interface	√	√	√	√		ACT0309			
G-Class	463	Drive	Y3/8n4-Fully integrated transmission control	√	√	√	√	√	ACT0584,ACT0585	SP1229,SP1230,SP1231,SP1232,SP1233,SP1234,SP1235,SP1236,SP1237,SP1237,SP1238,SP1239,SP1240,SP1241,SP1242,	CD0465, CD0466, CD0467, CD0468	√
G-Class	463	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7	√	√	√	√	√	ACT0586	SP1244,SP1245,SP1246,SP1247,SP1248,SP1249,SP1250,SP1250,SP1251,SP1252,SP1253,SP1254,	CD0469, CD0470, CD0471, CD0472, CD0473	√
G-Class	463	Body	SG SW-Control unit 'Headlamp'(N71/1)	√	√	√	√		ACT1632	SP1090		
G-Class	463	Body	SG SW-Control unit 'Headlamp'(N71/1)	√	√	√	√		ACT1632	SP1090		
G-Class	463	Body	IMS-Interior motion sensor	√	√	√	√		ACT0094,ACT0095,ACT0096			√
G-Class	463	Information and communication	COU-Audio/COMAND operating unit (A40/9)	√	√	√	√		ACT0441,ACT0627			√
G-Class	463	Drive	N3/10-Motor electronics "ME1778" for combustion engine "M279"	√	√	√	√		ACT1560,ACT1561,ACT1562,ACT1563,ACT1564,ACT1565,ACT1566,ACT1567,ACT1568,ACT1569,ACT1570,ACT1571	SP1603,SP1604,SP1605,SP1606	CD0769, CD0770, CD0771, CD0772, CD0773, CD0774, CD0775	√
G-Class	463	Drive	N3/10-Motor electronics "ME97" for combustion engine "M272"	√	√	√	√	√	ACT1395,ACT1396,ACT1397,ACT1398,ACT1399,ACT1400,ACT1401,ACT1402,ACT1403,ACT1404,ACT1405,ACT1406,ACT1407,ACT1408,ACT1409	SP1513,SP1514,SP1515,SP1516,SP1517,SP1518,SP1519,SP1520,SP1521	CD0702, CD0703, CD0704, CD0705, CD0706, CD0707, CD0708, CD0709	√

G-Class	463	Drive	N3/10-Motor electronics "MED177" for combustion engine "M276"	√	√	√	√	√	ACT0802,ACT0803,ACT0804,ACT0805,ACT0806,ACT0807,ACT0808,ACT0809,ACT0810,ACT0811,ACT0812,ACT0813,ACT0814,ACT0815,ACT0816,ACT0817,ACT0818,ACT0819,	SP1335,SP1336,SP1337,SP1338,SP1339,SP1340,SP1341,SP1342,SP1343,SP1344,SP1345,SP1346,SP1347,SP1348	CD0544, CD0545, CD0546, CD0547, CD0548, CD0549, CD0550, CD0551, CD0552	√
G-Class	463	Drive	N3/10-Motor electronics "MED1775" for combustion engine "M178"	√	√	√	√		ACT1633,ACT1634,ACT1635,ACT1636,ACT1637,ACT1638,ACT1639,ACT1640,ACT1641,ACT1642,ACT1643,ACT1644,ACT1645,ACT1646,ACT1647,ACT1648,ACT1649,ACT1650,	SP1626,SP1627,SP1628,SP1629,SP1630,SP1631,SP1632,SP1633,SP1634	CD0793, CD0794, CD0795, CD0796, CD0797, CD0798, CD0799, CD0800	√
G-Class	463	Drive	N3/40-Motor electronics "MRD1" for combustion engine "OM654"	√	√	√	√	√				
G-Class	463	Drive	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9	√	√	√	√	√				
G-Class	463	Chassis	ESP-Electric stability	√	√	√	√					
G-Class	463	Drive	FSCU-Control unit Fuel pump	√	√	√	√					
G-Class	463	Drive	SCR-Selective catalytic reduction	√	√	√	√					
G-Class	463	Drive	N127 (Drivetrain control unit)	√	√	√	√					
G-Class	463	Body	SRS-Supplemental restraint	√	√	√	√	√				
G-Class	463	Seats and Doors	LFD-Left front door	√	√	√	√					
G-Class	463	Seats and Doors	DCU RF-Right front door	√	√	√	√					
G-Class	463	Seats and Doors	DCU LR-Left rear door	√	√	√	√					
G-Class	463	Seats and Doors	DCU RR-Right rear door	√	√	√	√					
G-Class	463	Information and communication	CTEL-Cellular telephone	√	√	√	√					
G-Class	463	Body	EZS-Electronic ignition lock	√	√	√	√					
G-Class	463	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver	√	√	√	√					
G-Class	463	Seats and Doors	ESV Driver-Electric seat adjustmnet Driver with memory	√	√	√	√					
G-Class	463	Seats and Doors	ESA Front passenger-Electric seat adjustment Front passenger	√	√	√	√					
G-Class	463	Seats and Doors	ESV Front passenger-Electric seat adjustment Front passenger with memory function	√	√	√	√					
G-Class	463	Body	SAMF-Front signal acquisition and actuation module(N10/6)	√	√	√	√					
G-Class	463	Body	SAMR-Rear signal acquisition and actuation module(N10/8)	√	√	√	√					
G-Class	463	Information and communication	HERMES-control unit for telematics services	√	√	√	√					
G-Class	463	Seats and Doors	MKS LF-Left front multicontour seat	√	√	√	√					
G-Class	463	Seats and Doors	MKS RF-Right front multicontour seat	√	√	√	√					
G-Class	463	Air conditioning	AAC-Automatic air conditioning	√	√	√	√					

G-Class	463	Seats and Doors	PPAMKS-Pneumatic pump for multicontour seat	√	√	√	√				
G-Class	463	Body	Trailer recognition module- Trailer recognition	√	√	√	√				
G-Class	463	Body	PSD-Panoramic sliding roof	√	√	√	√				
G-Class	463	Body	AML-Ambiance light	√	√	√	√				
G-Class	463	Body	KG-Keyless Go	√	√	√	√				
G-Class	463	Body	OCP-Overhead control panel	√	√	√	√				
G-Class	463	Driver assistance system	IRS HRA-Outer right rear integrated radar sensor (B92/6)	√	√	√	√				
G-Class	463	Driver assistance system	IRS HLA-Outer left rear integrated radar sensor (B92/11)	√	√	√	√				
G-Class	463	Body	LRE-Steering wheel electronics	√	√	√	√				
G-Class	463	Information and communication	TPAD-Touchpad	√	√	√	√				
G-Class	463	Information and communication	AUDIO-Audio or COMAND(A2-A40/3)	√	√	√	√				
G-Class	463	Information and communication	IC-Instrument cluster(A1)	√	√	√	√				
G-Class	463	Information and communication	mbrace-mbrace	√	√	√	√				
G-Class	463	Information and communication	MTAS-Mobile phone cradle	√	√	√	√				
G-Class	463	Information and communication	MTAS-Mobile phone cradle	√	√	√	√				
G-Class	463	Body	RevETR LF-Left front reversible emergency tensioning retractor	√	√	√	√				
G-Class	463	Body	RevETR RF-Right front reversible emergency tensioning	√	√	√	√				
G-Class	463	Information and communication	COU[ZBE]-Audio/COMAND operating unit	√	√	√	√				
G-Class	463	Information and communication	ZAN-Audio/COMAND display	√	√	√	√				
G-Class	463	Chassis	AMG DRVU-AMG DRIVE	√	√	√	√				
G-Class	463	Chassis	AMG DRVU-AMG DRIVE	√	√	√	√				
G-Class	463	Body	SG SW L-Left headlamp	√	√	√	√				
G-Class	463	Body	SG SW R-Right headlamp	√	√	√	√				
G-Class	463	Driver assistance	TPM-Tire pressure monitor(N88)	√	√	√	√				
G-Class	463	Body	SG LML VL-LED matrix of left front lamp unit	√	√	√	√				
G-Class	463	Body	SG-LML-VR-LED matrix of right front lamp unit	√	√	√	√				
G-Class	463	Body	BSN-Battery sensor(B95)	√	√	√	√				
G-Class	463	Body	AU-Analog clock	√	√	√	√				
G-Class	463	Body	Button group, instrument panel, driver side	√	√	√	√				
G-Class	463	Body	Button group, instrument panel, center	√	√	√	√				

G-Class	463	Body	RGLS-Rain/light sensor(B38/2)	√	√	√	√					
G-Class	463	Body	FSW-Windshield wiper	√	√	√	√					
G-Class	463	Body	GTO-Garage door	√	√	√	√					
G-Class	463	Body	Anti glare interior rearview mirror(DBE)	√	√	√	√					
G-Class	463	Body	N25/6 (Rear passenger compartment seat heater control	√	√	√	√					
G-Class	463	Seats and Doors	S47/2 (Driver door switch	√	√	√	√					
G-Class	463	Seats and Doors	LFD-Left front door	√	√	√						
G-Class	463	Seats and Doors	LFD-Left front door	√	√	√						
G-Class	463	Seats and Doors	S47/3 (Front passenger door switch module)	√	√	√	√					
G-Class	463	Seats and Doors	DCU RF-Right front door	√	√	√						
G-Class	463	Seats and Doors	DCU RF-Right front door	√	√	√						
G-Class	463	Seats and Doors	DCU LR-Left rear door	√	√	√						
G-Class	463	Seats and Doors	DCU RR-Right rear door	√	√	√						
G-Class	463	Body	"Driver" seat heater	√	√	√	√					
G-Class	463	Body	"Front passenger" seat heater	√	√	√	√					
G-Class	463	Body	AS-Alarm siren(H3/1)	√	√	√	√					
G-Class	463	Seats and Doors	Massage function in left front seat	√	√	√	√					
G-Class	463	Seats and Doors	MFSF-LF	√	√	√	√					
G-Class	463	Seats and Doors	Massage function in right front	√	√	√	√					
G-Class	463	Seats and Doors	MFSF-RF	√	√	√	√					
G-Class	463	Air conditioning	N61 (Windshield heater control	√	√	√						
G-Class	463	Air conditioning	STH-Stationary heater	√	√	√	√					
G-Class	463	Air conditioning	AAC-Automatic air conditioning	√	√	√						
G-Class	463	Air conditioning	AAC-Automatic air conditioning	√	√	√						
G-Class	463	Air conditioning	TSTH-Radio remote control of stationary heater	√	√	√	√					
G-Class	463	Body	SCM-Steering column	√	√	√	√					
G-Class	463	Information and communication	N72/1 (Upper control panel control unit)	√	√	√						
G-Class	463	Information and communication	N72/5 (Right lower control panel)	√	√	√						
G-Class	463	Information and communication	N72/4 (Left lower control panel)	√	√	√						
G-Class	463	Body	WSS-Weight sensing	√	√	√	√					
G-Class	463	Information and communication	TV tuner (TV)	√	√	√	√					
G-Class	463	Information and communication	SOUND-Sound system	√	√	√	√					
G-Class	463	Driver assistance system	MFK-Multifunction camera(stereo)(A40/13)	√	√	√	√					
G-Class	463	Driver assistance system	SG AWF-COLLISION PREVENTION ASSIST	√	√	√	√					
G-Class	463	Driver assistance	PTS-PARKTRONIC	√	√	√	√					
G-Class	463	Chassis	ADS-Adaptive damping system	√	√	√	√					
G-Class	463	Chassis	ES - Electric power steering	√	√	√	√					

G-Class	463	Body	LRE-Steering wheel electronics	√	√	√	√					
G-Class	463	Drive	VG-Transfer case	√	√	√	√					
G-Class	463	Drive	EAGGS-Electric differential lock	√	√	√	√					
G-Class	463	Chassis	ADS-Adaptive damping system(N51/5)	√	√	√	√					
G-Class	463	Drive	N3/10-Motor electronics "MED1775" for combustion	√	√	√	√	√				
G-Class	463	Drive	N3/10-Motor electronics "MED41" for combustion engine	√	√	√	√	√				

XTOOL

Coding Functions List

No.	Functions Name	System Name
CD0001	All codes	AAC-Automatic air conditioning
CD0002	All coding settings	AAC-Automatic air conditioning
CD0003	Read coding and change if necessary.	AAC-Automatic air conditioning
CD0004	Special settings	AAC-Automatic air conditioning
CD0005	This setting should only be changed if requested by customer.	AAC-Automatic air conditioning
CD0006	Workshop coding	AAC-Automatic air conditioning
CD0007	Workshop coding1	AAC-Automatic air conditioning
CD0008	Workshop coding2	AAC-Automatic air conditioning
CD0009	Automatic child seat recognition(AKSE)/Seat occupied recognition	AB-Airbag
CD0010	Buckle emergency tensioning retractor	AB-Airbag
CD0011	Disposal detonation	AB-Airbag
CD0012	Emergency tensioning retractor	AB-Airbag
CD0013	Emergency tensioning retractor(FRONT)	AB-Airbag
CD0014	Kneebags	AB-Airbag
CD0015	NECK-PRO head restraint	AB-Airbag
CD0016	Passenger airbag	AB-Airbag
CD0017	Pyrofuse	AB-Airbag
CD0018	Read coding and change if necessary.	AB-Airbag
CD0019	Rear seat belts	AB-Airbag
CD0020	Seat belt buckle switch(FRONT)	AB-Airbag
CD0021	Seat belt buckles	AB-Airbag
CD0022	Seat belt reminder warning for front passenger	AB-Airbag
CD0023	Seat fittings	AB-Airbag
CD0024	Seat mat type 'Passenger'	AB-Airbag
CD0025	Settings	AB-Airbag
CD0026	Side airbag deactivation [USA]	AB-Airbag
CD0027	Side airbags	AB-Airbag
CD0028	Side airbags[FRONT PASSENGER]	AB-Airbag
CD0029	Special protection	AB-Airbag
CD0030	Steering variant	AB-Airbag
CD0031	Vehicle equipment	AB-Airbag
CD0032	Vehicle model	AB-Airbag
CD0033	Window airbags	AB-Airbag

CD0034	Additional settings	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)
CD0035	Installation state	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)
CD0036	Radio parameters	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)
CD0037	Specified configuration of MOST components	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)
CD0038	Read coding and change if necessary.	AHE-Trailer recognition
CD0039	Variant coding	AHE-Trailer recognition
CD0040	Brake data	ASSYST PLUS-PLUS Active Service System
CD0041	Current brake lining thickness	ASSYST PLUS-PLUS Active Service System
CD0042	Internal ASSYST PLUS data	ASSYST PLUS-PLUS Active Service System
CD0043	Service work sequence	ASSYST PLUS-PLUS Active Service System
CD0044	ATA alarm signal siren	ATA-Anti theft alarm system
CD0045	ATA basic function	ATA-Anti theft alarm system
CD0046	Installation state	AUDIO
CD0047	Navigation	AUDIO
CD0048	Navigation parameters	AUDIO
CD0049	Radio parameters	AUDIO
CD0050	Rear screen	AUDIO
CD0051	TV parameters(Shut off criteria)	AUDIO
CD0052	All codes	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater
CD0053	Special settings	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater
CD0054	This setting should only be changed if requested by customer.	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater
CD0055	Workshop coding	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater
CD0056	Coding	CDI 3-Common Rail Diesel Injection3
CD0057	Read coding and change if necessary.	CDI 3-Common Rail Diesel Injection3
CD0058	SCN(Software Calibration Number)	CDI 3-Common Rail Diesel Injection3
CD0059	Variant coding according to factory data	CDI 3-Common Rail Diesel Injection3
CD0060	All codes	CGW-Central gateway
CD0061	Factory settings	COMAND
CD0062	Language settings	COMAND
CD0063	Menu settings	COMAND
CD0064	Menu settings()	COMAND

CD0065	AUX input	COMAND or AUDIO
CD0066	Language settings	COMAND or AUDIO
CD0067	Navigation data	COMAND or AUDIO
CD0068	Read coding and change if necessary.	DCM FL-Door control module front left
CD0069	Read coding and change if necessary.	DCM FR-Door control module front right
CD0070	Read coding and change if necessary.	DCM RL-Door control module rear left
CD0071	Read coding and change if necessary.	DCM RR-Door control module rear right
CD0072	Refrigerant' pressure sensor	Dr side SAM-Driver signal acquisition and actuation module
CD0073	Air conditioning	Dr side SAM-Driver signal acquisition and actuation module
CD0074	Auxiliary fan Coolant	Dr side SAM-Driver signal acquisition and actuation module
CD0075	Blower motor in control module box	Dr side SAM-Driver signal acquisition and actuation module
CD0076	Coding of model series	Dr side SAM-Driver signal acquisition and actuation module
CD0077	Curve illumination	Dr side SAM-Driver signal acquisition and actuation module
CD0078	Engine version	Dr side SAM-Driver signal acquisition and actuation module
CD0079	Equipment	Dr side SAM-Driver signal acquisition and actuation module
CD0080	Exterior lighting	Dr side SAM-Driver signal acquisition and actuation module
CD0081	Footwell lighting	Dr side SAM-Driver signal acquisition and actuation module
CD0082	Gear display	Dr side SAM-Driver signal acquisition and actuation module
CD0083	Headlamp cleaning system	Dr side SAM-Driver signal acquisition and actuation module
CD0084	Heated steering wheel	Dr side SAM-Driver signal acquisition and actuation module
CD0085	Model designation(Only with code 336)	Dr side SAM-Driver signal acquisition and actuation module
CD0086	Oil cooler relay	Dr side SAM-Driver signal acquisition and actuation module
CD0087	Signal Terminal 61	Dr side SAM-Driver signal acquisition and actuation module
CD0088	Steering column module	Dr side SAM-Driver signal acquisition and actuation module
CD0089	Turning lamps	Dr side SAM-Driver signal acquisition and actuation module
CD0090	Washer nozzle heater	Dr side SAM-Driver signal acquisition and actuation module
CD0091	Windshield wiper	Dr side SAM-Driver signal acquisition and actuation module
CD0092	Wiper rest heater	Dr side SAM-Driver signal acquisition and actuation module
CD0093	Wiper system	Dr side SAM-Driver signal acquisition and actuation module
CD0094	Read coding and change if necessary.	EPB-Electric parking brake
CD0095	Variant coding	ESA FL-Electric seat adjustment front left
CD0096	Variant coding	ESA FR-Electric seat adjustment front right
CD0097	Read coding and change if necessary.	ESA R-Electric seat adjustment rear
CD0098	Variant coding	ESA R-Electric seat adjustment rear
CD0099	Read coding and change if necessary.	ESA driver-Electric seat adjustment driver (with memory)
CD0100	Read coding and change if necessary.	ESA passenger-Electric seat adjustment passenger

CD0101	Read coding and change if necessary.	ESM-Electronic selector module
CD0102	Distronic	ESP-Electronic stability program
CD0103	ESP-Trailer stabilization	ESP-Electronic stability program
CD0104	Speed-sensitive power steering	ESP-Electronic stability program
CD0105	AIRmatic/ABC active body control	EZS-Electronic ignition switch
CD0106	ATA interior motion / towing sensor	EZS-Electronic ignition switch
CD0107	ATA interior motion sensor	EZS-Electronic ignition switch
CD0108	ATA towing sensor	EZS-Electronic ignition switch
CD0109	All codes	EZS-Electronic ignition switch
CD0110	Automatic closing of front windows	EZS-Electronic ignition switch
CD0111	Automatic closing of rear windows	EZS-Electronic ignition switch
CD0112	Automatic dimming mirror	EZS-Electronic ignition switch
CD0113	Automatic driving lights on	EZS-Electronic ignition switch
CD0114	COMAND or AUDIO	EZS-Electronic ignition switch
CD0115	Cellular telephone	EZS-Electronic ignition switch
CD0116	Central gateway functionality	EZS-Electronic ignition switch
CD0117	Climate control	EZS-Electronic ignition switch
CD0118	Convenience systems	EZS-Electronic ignition switch
CD0119	Distronic	EZS-Electronic ignition switch
CD0120	Driving lights	EZS-Electronic ignition switch
CD0121	Engine cooling	EZS-Electronic ignition switch
CD0122	Fuel cell or electric drive	EZS-Electronic ignition switch
CD0123	Headlamp cleaning system	EZS-Electronic ignition switch
CD0124	Headlamp range adjustment	EZS-Electronic ignition switch
CD0125	Keyless Go	EZS-Electronic ignition switch
CD0126	Lane recognition	EZS-Electronic ignition switch
CD0127	Manual recirculated air control	EZS-Electronic ignition switch
CD0128	Multifunction steering wheel	EZS-Electronic ignition switch
CD0129	National version	EZS-Electronic ignition switch
CD0130	Parktronic	EZS-Electronic ignition switch
CD0131	Power locking	EZS-Electronic ignition switch
CD0132	Rear air conditioning	EZS-Electronic ignition switch
CD0133	Rear window screen	EZS-Electronic ignition switch
CD0134	Relocking/Vehicle speed threshold for automatic locking	EZS-Electronic ignition switch
CD0135	Seat adjustment	EZS-Electronic ignition switch
CD0136	Series and engine version	EZS-Electronic ignition switch

CD0137	Set status CAN bus	EZS-Electronic ignition switch
CD0138	Sound system	EZS-Electronic ignition switch
CD0139	Special vehicle multifunction control module (SVMCM)	EZS-Electronic ignition switch
CD0140	Special vehicles	EZS-Electronic ignition switch
CD0141	Standard setting: Climate control	EZS-Electronic ignition switch
CD0142	Stationary heater or Telestart	EZS-Electronic ignition switch
CD0143	Sun sensor	EZS-Electronic ignition switch
CD0144	Telecommunications	EZS-Electronic ignition switch
CD0145	Telematic service 'Remote door unlocking' (TELE AID)	EZS-Electronic ignition switch
CD0146	Tire pressure monitor	EZS-Electronic ignition switch
CD0147	Trailer	EZS-Electronic ignition switch
CD0148	Trailer lighting	EZS-Electronic ignition switch
CD0149	Trailer recognition	EZS-Electronic ignition switch
CD0150	Trailer recognition/Trailer lighting	EZS-Electronic ignition switch
CD0151	Transmission	EZS-Electronic ignition switch
CD0152	Turn signal confirmation for opening and closing via transmitter key	EZS-Electronic ignition switch
CD0153	Vehicle speed signal threshold for automatic locking	EZS-Electronic ignition switch
CD0154	Voice control system	EZS-Electronic ignition switch
CD0155	Washer system	EZS-Electronic ignition switch
CD0156	Windscreen heater	EZS-Electronic ignition switch
CD0157	Wiper system	EZS-Electronic ignition switch
CD0158	Wipers	EZS-Electronic ignition switch
CD0159	Read coding.	FSCU-Fuel pump
CD0160	Read coding and change if necessary.	FSCU-Fuel pump AMG
CD0161	Read coding and change if necessary.	HRA-Automatic headlamp range adjustment and headlamp control
CD0162	Configuration for key 1	IC-Instrument cluster
CD0163	Configuration for key 2	IC-Instrument cluster
CD0164	Configuration for key 3	IC-Instrument cluster
CD0165	Current menu setting	IC-Instrument cluster
CD0166	Customer-specific settings	IC-Instrument cluster
CD0167	Trip computer settings	IC-Instrument cluster
CD0168	Codings specific for instrument cluster	ICM-Instrument cluster with maintenance interval display
CD0169	Configuration for key 1	ICM-Instrument cluster with maintenance interval display
CD0170	Configuration for key 2	ICM-Instrument cluster with maintenance interval display
CD0171	Configuration for key 3	ICM-Instrument cluster with maintenance interval display
CD0172	Display coding	ICM-Instrument cluster with maintenance interval display

CD0173	Factory settings	ICM-Instrument cluster with maintenance interval display
CD0174	RDK tire pressure control	ICM-Instrument cluster with maintenance interval display
CD0175	Special equipment	ICM-Instrument cluster with maintenance interval display
CD0176	Read coding and change if necessary.	KG-KEYLESS GO
CD0177	Read coding and change if necessary.	KG-Keyless Go
CD0178	Coding	ME 9.7-Motor electronics 9.7
CD0179	Coding	ME SF 17.7-Motor electronics 17.7
CD0180	Read coding and change if necessary.	ME SFI 2.0-Motor electronics 2.0
CD0181	Special vehicle special protection(B4):Read coding and change if necessary	ME SFI 2.0-Motor electronics 2.0
CD0182	Special vehicle special protection(B6/B7):Read coding and change if necessary	ME SFI 2.0-Motor electronics 2.0
CD0183	CVN(Calibration verification number)	ME SFI 2.8-Motor electronics 2.8
CD0184	Coding	ME SFI 2.8-Motor electronics 2.8
CD0185	Read coding and change if necessary.	ME SFI 2.8-Motor electronics 2.8
CD0186	Read coding.	ME SFI 2.8-Motor electronics 2.8
CD0187	SCN(Software Calibration Number)	ME SFI 2.8-Motor electronics 2.8
CD0188	Special vehicle special protection:Read coding and change if necessary.	ME SFI 2.8-Motor electronics 2.8
CD0189	CVN(Calibration verification number)	ME SFI-CNG compressed natural gas
CD0190	Coding	ME SFI-CNG compressed natural gas
CD0191	SCN(Software Calibration Number)	ME SFI-CNG compressed natural gas
CD0192	Variant coding according to factory data	ME SFI-CNG compressed natural gas
CD0193	CVN(Calibration verification number)	ME SFI-Gasoline engine control
CD0194	Coding	ME SFI-Gasoline engine control
CD0195	Coding according to plant data	ME SFI-Gasoline engine control
CD0196	SCN(Software Calibration Number)	ME SFI-Gasoline engine control
CD0197	Coding	ME SFI-Motor electronics
CD0198	Read coding and change if necessary.	ME SFI-Motor electronics
CD0199	Read coding.	ME SFI-Motor electronics
CD0200	CVN(Calibration verification number)	MED 17.7-Motor electronics for direct injection 17.7
CD0201	Coding	MED 17.7-Motor electronics for direct injection 17.7
CD0202	SCN(Software Calibration Number)	MED 17.7-Motor electronics for direct injection 17.7
CD0203	Type approval number	MED 17.7-Motor electronics for direct injection 17.7
CD0204	Coding	MED 9.7-Motor electronics for direct injection 9.7
CD0205	Additional equipment	MSS-Special vehicle multifunction control module
CD0206	Advanced options	MSS-Special vehicle multifunction control module
CD0207	Full alarm	MSS-Special vehicle multifunction control module
CD0208	Higher-priority alarm options	MSS-Special vehicle multifunction control module

CD0209	Odometer	MSS-Special vehicle multifunction control module
CD0210	Options	MSS-Special vehicle multifunction control module
CD0211	Radio help call	MSS-Special vehicle multifunction control module
CD0212	Read the coding of control module ZGW.	MSS-Special vehicle multifunction control module
CD0213	Run-on times	MSS-Special vehicle multifunction control module
CD0214	Silent alarm	MSS-Special vehicle multifunction control module
CD0215	Undervoltage value	MSS-Special vehicle multifunction control module
CD0216	Anti-pinch protection	OCP-Overhead control panel
CD0217	Automatic interior mirror dimming	OCP-Overhead control panel
CD0218	Close-via-tilt function	OCP-Overhead control panel
CD0219	Closing of tilting/sliding roof when it rains	OCP-Overhead control panel
CD0220	Coding of sliding/tilting roof function of 'automatic operation'	OCP-Overhead control panel
CD0221	Interior lamp-Actuation	OCP-Overhead control panel
CD0222	Light sensor	OCP-Overhead control panel
CD0223	Panoramic sliding roof	OCP-Overhead control panel
CD0224	Parameterization and windshield adaptation	OCP-Overhead control panel
CD0225	Presafe	OCP-Overhead control panel
CD0226	Read coding and change if necessary.	OCP-Overhead control panel
CD0227	Read coding and change if necessary.(Panoramic sliding roof)	OCP-Overhead control panel
CD0228	Read coding and change if necessary.(Sliding/tilting roof)	OCP-Overhead control panel
CD0229	Roller sun blind	OCP-Overhead control panel
CD0230	Sliding/tilting roof	OCP-Overhead control panel
CD0231	Tilting/sliding roof memory feature	OCP-Overhead control panel
CD0232	Central locking	PSE-Pneumatic system equipment
CD0233	Childproof locks	PSE-Pneumatic system equipment
CD0234	Emergency opening	PSE-Pneumatic system equipment
CD0235	Factory settings Trunk lid remote closing	PSE-Pneumatic system equipment
CD0236	Head restraint adjustment	PSE-Pneumatic system equipment
CD0237	Multicontour backrests	PSE-Pneumatic system equipment
CD0238	Power locking	PSE-Pneumatic system equipment
CD0239	Trunk interior button(1)	PSE-Pneumatic system equipment
CD0240	Trunk interior button(2)	PSE-Pneumatic system equipment
CD0241	Trunk lid remote closing	PSE-Pneumatic system equipment
CD0242	Trunk lid remote release	PSE-Pneumatic system equipment
CD0243	License plate bracket	PTS-PARKTRONIC
CD0244	Steering version	PTS-PARKTRONIC

CD0245	Trailer coupling	PTS-PARKTRONIC
CD0246	Warning signal-Configuration	PTS-PARKTRONIC
CD0247	License plate bracket	PTS-Parktronic system
CD0248	PTS switch	PTS-Parktronic system
CD0249	ROELight Configuration	PTS-Parktronic system
CD0250	Rear warning elements	PTS-Parktronic system
CD0251	Trailer coupling	PTS-Parktronic system
CD0252	Vehicle version	PTS-Parktronic system
CD0253	Warning signal-Configuration	PTS-Parktronic system
CD0254	Front seat heater	Pass side SAM-Passenger-side signal acquisition and actuation module
CD0255	Radiator blind	Pass side SAM-Passenger-side signal acquisition and actuation module
CD0256	Side lamp Version	Pass side SAM-Passenger-side signal acquisition and actuation module
CD0257	Turning lamps	Pass side SAM-Passenger-side signal acquisition and actuation module
CD0258	ATA National variant coding	REAR SAM-Rear signal acquisition and actuation module
CD0259	ATA Volume control:Warning buzzer(USA)	REAR SAM-Rear signal acquisition and actuation module
CD0260	Ambiance lighting(Code 877)	REAR SAM-Rear signal acquisition and actuation module
CD0261	Battery sensor	REAR SAM-Rear signal acquisition and actuation module
CD0262	Battery sensor LIN bus	REAR SAM-Rear signal acquisition and actuation module
CD0263	Cigarette lighter	REAR SAM-Rear signal acquisition and actuation module
CD0264	Diesel particulate filter	REAR SAM-Rear signal acquisition and actuation module
CD0265	EDW anti-theft alarm	REAR SAM-Rear signal acquisition and actuation module
CD0266	Easy Entry	REAR SAM-Rear signal acquisition and actuation module
CD0267	Easy Entry/Rear seat belt buckle switch(Code U01)	REAR SAM-Rear signal acquisition and actuation module
CD0268	Electric rear window curtain	REAR SAM-Rear signal acquisition and actuation module
CD0269	Equipment version	REAR SAM-Rear signal acquisition and actuation module
CD0270	Flashing stop lamp	REAR SAM-Rear signal acquisition and actuation module
CD0271	LED'Trailer lighting'	REAR SAM-Rear signal acquisition and actuation module
CD0272	Light	REAR SAM-Rear signal acquisition and actuation module
CD0273	Miscellaneous	REAR SAM-Rear signal acquisition and actuation module
CD0274	Model series	REAR SAM-Rear signal acquisition and actuation module
CD0275	Rear foglight	REAR SAM-Rear signal acquisition and actuation module
CD0276	Rear head restraint lowering	REAR SAM-Rear signal acquisition and actuation module
CD0277	Rear screen	REAR SAM-Rear signal acquisition and actuation module
CD0278	Rear-end door lock	REAR SAM-Rear signal acquisition and actuation module
CD0279	Relays Seat adjustment	REAR SAM-Rear signal acquisition and actuation module
CD0280	Assignment of control unit to model series	REDC-Rear end door closing control module

CD0281	Read coding and change if necessary.	REDC-Rear end door closing control module
CD0282	Special equipment 'Spare wheel carrier'	REDC-Rear end door closing control module
CD0283	Read coding and change if necessary.	RWT-Rear end door control module
CD0284	Read coding and change if necessary.	RevETR LF-Left front reversible emergency tensioning retractor
CD0285	Vehicle equipment	RevETR LF-Left front reversible emergency tensioning retractor
CD0286	Read coding and change if necessary.	RevETR RF-Right front reversible emergency tensioning retractor
CD0287	Vehicle equipment	RevETR RF-Right front reversible emergency tensioning retractor
CD0288	Read coding and change if necessary.(Only for special protection vehicles)	SAM F-Signal acquisition and actuation module front
CD0289	Basic setting(N10 (SAM control unit))	SAM-Signal acquisition and actuation module
CD0290	Light sensor	SAM-Signal acquisition and actuation module
CD0291	Rear foglight(National version)	SAM-Signal acquisition and actuation module
CD0292	CVN(Calibration verification number)	SCR-Selective Catalytic Reduction
CD0293	Coding according to plant data	SCR-Selective Catalytic Reduction
CD0294	SCN(Software Calibration Number)	SCR-Selective Catalytic Reduction
CD0295	Type approval number	SCR-Selective Catalytic Reduction
CD0296	Read coding and change if necessary.	TLC-Trunk lid control
CD0297	Read coding and change if necessary.	TPM-Tire pressure monitor
CD0298	National variant coding	TV-TV tuner(AGW)
CD0299	PAL/NTSC	TV-TV tuner(AGW)
CD0300	Read coding and change if necessary.	UCP-Upper control panel
CD0301	Coding according to plant data:Read coding and change if necessary.	XALWA L-Xenon headlamp, left
CD0302	Display of coding data	XALWA L-Xenon headlamp, left
CD0303	Read coding and change if necessary.	XALWA L-Xenon headlamp, left
CD0304	Display of SCN	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
CD0305	Display of CVN	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
CD0306	Display of model check number	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
CD0307	Writing of the VIN	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
CD0308	Display of SCN	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
CD0309	Display of CVN	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
CD0310	Display of model check number	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
CD0311	Initial startup	E call [Europe]-Emergency call system
CD0312	Current menu settings	IC-Instrument cluster
CD0313	Transfer of manufacturer default settings	IC-Instrument cluster
CD0314	Oil grade factor	IC-Instrument cluster
CD0315	Customer-specific settings	IC-Instrument cluster
CD0316	Subsequent adjustment of resistance of GSM antenna	KOMO-Communication module Telematics services

CD0317	Language setting	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
CD0318	Check configuration.	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
CD0319	Data logger	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
CD0320	Display of coding data	EZS-Electronic ignition switch
CD0321	Disabling of key or key track with workshop key	EZS-Electronic ignition switch
CD0322	Disabling of key or key track	EZS-Electronic ignition switch
CD0323	Re-enabling of key or key track	EZS-Electronic ignition switch
CD0324	Writing of vehicle identification number	EZS-Electronic ignition switch
CD0325	Display of coding data	EZS-Electronic ignition lock
CD0326	Vehicle model	AMG DRVU-AMG DRIVE UNIT(N145)
CD0327	Events	ESP-Electronic stability program(N30/4)
CD0328	Check coding "Hill Start Assist".	ESP-Electronic stability program(N30/4)
CD0329	Special function FIN	ESP-Electronic stability program(N30/4)
CD0330	Check of control unit software	SRS-Supplemental restraint system (N2/10)
CD0331	Unlocking of control unit	SRS-Supplemental restraint system (N2/10)
CD0332	Setting language	AUDIO-Audio or COMAND(A2-A40/3)
CD0333	Video AUX jack	AUDIO-Audio or COMAND(A2-A40/3)
CD0334	Mercedes-Benz Contact	AUDIO-Audio or COMAND(A2-A40/3)
CD0335	Run-on time after switching off ignition	AUDIO-Audio or COMAND(A2-A40/3)
CD0336	SPLITVIEW	AUDIO-Audio or COMAND(A2-A40/3)
CD0337	Restart MOST ring.	AUDIO-Audio or COMAND(A2-A40/3)
CD0338	Run-on times	Multifunction control unit-Multifunction control unit
CD0339	Roof sign	Multifunction control unit-Multifunction control unit
CD0340	Muting of audio sources	Multifunction control unit-Multifunction control unit
CD0341	Radio help call	Multifunction control unit-Multifunction control unit
CD0342	Emergency alarm	Multifunction control unit-Multifunction control unit
CD0343	Other options	Multifunction control unit-Multifunction control unit
CD0344	Customer request	Multifunction control unit-Multifunction control unit
CD0345	Reset of coding	Multifunction control unit-Multifunction control unit
CD0346	Restoration of communication with the control unit	Multifunction control unit-Multifunction control unit
CD0347	Control unit reset	Multifunction control unit-Multifunction control unit
CD0348	Display of coding data	SOUND-Sound system
CD0349	Control unit replacement with initial startup of new control unit	TV-TV tuner
CD0350	Initial startup of already installed control unit	TV-TV tuner
CD0351	National version	TV-TV tuner
CD0352	Control line of component "Antenna amplifier"	TV-TV tuner

CD0353	Type of antennas	TV-TV tuner
CD0354	Type of video signal	TV-TV tuner
CD0355	PAL / NTSC	TV-TV tuner
CD0356	Configuration of AUX jacks	TV-TV tuner
CD0357	Special function	TV-TV tuner
CD0358	Fan	TV-TV tuner
CD0359	All codings	TV-TV tuner
CD0360	Reset	TV-TV tuner
CD0361	Control unit replacement with initial startup of new control unit	TV-TV tuner
CD0362	Initial startup of already installed control unit	TV-TV tuner
CD0363	National version	TV-TV tuner
CD0364	Control line of component "Antenna amplifier"	TV-TV tuner
CD0365	Type of antennas	TV-TV tuner
CD0366	Type of video signal	TV-TV tuner
CD0367	PAL / NTSC	TV-TV tuner
CD0368	Configuration of AUX jacks	TV-TV tuner
CD0369	Special function	TV-TV tuner
CD0370	Fan	TV-TV tuner
CD0371	All codings	TV-TV tuner
CD0372	Reset	TV-TV tuner
CD0373	Customer request	AAC-Automatic air conditioning
CD0374	Workshop coding	AAC-Automatic air conditioning
CD0375	Special settings	AAC-Automatic air conditioning
CD0376	No-load current	AAC-Automatic air conditioning
CD0377	Parameters of DAB tuner	DAB-Digital Audio Broadcasting(N87/3)
CD0378	Restart MOST ring.	DAB-Digital Audio Broadcasting(N87/3)
CD0379	Parameters of DAB tuner	DAB-Digital Audio Broadcasting
CD0380	Restart MOST ring.	DAB-Digital Audio Broadcasting
CD0381	Display of coding data	DAB-Digital Audio Broadcasting
CD0382	Variant coding	STH-Stationary heater
CD0383	Customer request	STH-Stationary heater
CD0384	Data record	STH-Stationary heater
CD0385	Initial startup	ES-Electrical power steering(N68)
CD0386	Control unit replacement with initial startup of new control unit	SDAR-Satellite radio
CD0387	Initial startup of already installed control unit	SDAR-Satellite radio
CD0388	National version	SDAR-Satellite radio

CD0389	Model of trailer hitch	TRM-Trailer recognition module (N28/1)
CD0390	Reset of coding	TRM-Trailer recognition module (N28/1)
CD0391	Initial startup	Trailer recognition module-Trailer recognition
CD0392	Erasing of initialization values	Trailer recognition module-Trailer recognition
CD0393	Display of coding data	FSCU05-Control unit Fuel pump
CD0394	Display of coding data	DTR-DISTRONIC (A89)
CD0395	Teach-in process	WSS-Weight sensing system(N110)
CD0396	Display of coding data	SG SW-Control unit 'Headlamp'(N71/1)
CD0397	Display of coding data	SG SW L-Left headlamp
CD0398	Display of coding data	SG SW L-Left headlamp(E1n9)
CD0399	Display of coding data	SG SW R-Right headlamp
CD0400	Display of coding data	SG SW R-Right headlamp(E1n9)
CD0401	Security code	GTO-Garage door opener(A67n2)
CD0402	Country code	GTO-Garage door opener(A67n2)
CD0403	Initialization	GTO-Garage door opener(A67n2)
CD0404	Version of switch group	OCP-Control unit 'Overhead control panel'
CD0405	Location of interior lamp	OCP-Control unit 'Overhead control panel'
CD0406	E15/3 (Rear dome lamp)	OCP-Control unit 'Overhead control panel'
CD0407	Initial startup	OCP-Control unit 'Overhead control panel'
CD0408	Initial startup	B38/2-Rain/light sensor(RGLS)
CD0409	Initial startup	AISP-Dimming inside rearview mirror(A67)
CD0410	Display of coding data	PARK-Parking system (N62)
CD0411	Volume and frequency	PARK-Parking system (N62)
CD0412	Initial startup	N32/2 (Front passenger seat control unit)
CD0413	Initial startup	N32/1 (Driver seat control unit)
CD0414	Function illumination	DSI-DIRECT SELECT interface(N150)
CD0415	Manual initial startup	VG-All wheel drive
CD0416	National version	AS-Alarm siren(H3/1)
CD0417	Volume of acoustic locking feedback	AS-Alarm siren(H3/1)
CD0418	Important note	AS-Alarm siren(H3/1)
CD0419	Initial startup	AS-Alarm siren(H3/1)
CD0420	Commissioning of control unit "E1n7 (Actuation module, LED exterior light	E1n7 (Actuation module, LED exterior lighting, left front)
CD0421	Commissioning of control unit "E2n7 (Actuation module, LED exterior light	E2n7 (Actuation module, LED exterior lighting, right front)
CD0422	Display of coding data	DKG-Electronic transmission control for double-plate clutch transmission
CD0423	Display of SCN	DKG-Electronic transmission control for double-plate clutch transmission
CD0424	Display of CVN	DKG-Electronic transmission control for double-plate clutch transmission

CD0425	Display of model check number	DKG-Electronic transmission control for double-plate clutch transmission
CD0426	Display of coding data	FSCU-Fuel pump
CD0427	Display of SCN	FSCU-Fuel pump
CD0428	Display of coding data	N127 (Drivetrain control unit)
CD0429	Display of SCN	N127 (Drivetrain control unit)
CD0430	Display of CVN	N127 (Drivetrain control unit)
CD0431	Display of coding data	PTCU-Common powertrain controller(N127)
CD0432	Display of SCN	PTCU-Common powertrain controller(N127)
CD0433	Display of CVN	PTCU-Common powertrain controller(N127)
CD0434	Display of coding data	N3/10-Motor electronics "MED40" for combustion engine "M274"
CD0435	Display of SCN	N3/10-Motor electronics "MED40" for combustion engine "M274"
CD0436	Display of CVN	N3/10-Motor electronics "MED40" for combustion engine "M274"
CD0437	Display of model check number	N3/10-Motor electronics "MED40" for combustion engine "M274"
CD0438	Correction programming of ignition	N3/10-Motor electronics "MED40" for combustion engine "M274"
CD0439	Correction programming of fuel quantity	N3/10-Motor electronics "MED40" for combustion engine "M274"
CD0440	Correction programming of specified idle speed	N3/10-Motor electronics "MED40" for combustion engine "M274"
CD0441	Correction programming of specified idle speed with gear range engaged	N3/10-Motor electronics "MED40" for combustion engine "M274"
CD0442	Injector injection quantity adjustment	N3/10-Motor electronics "MED40" for combustion engine "M274"
CD0443	Display of coding data	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
CD0444	Display of SCN	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
CD0445	Display of CVN	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
CD0446	Display of model check number	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
CD0447	Correction programming of ignition	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
CD0448	Correction programming of fuel quantity	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
CD0449	Correction programming of specified idle speed in selector lever position "P"	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
CD0450	Correction programming of specified idle speed with gear range engaged	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
CD0451	Injector injection quantity adjustment	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
CD0452	Display of SCN	N3/9-Motor electronics "CR43" for combustion engine "OM651"
CD0453	Display of CVN	N3/9-Motor electronics "CR43" for combustion engine "OM651"
CD0454	Display of model check number	N3/9-Motor electronics "CR43" for combustion engine "OM651"
CD0455	Writing of the VIN	N3/9-Motor electronics "CR43" for combustion engine "OM651"
CD0456	Display of SCN	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
CD0457	Display of CVN	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
CD0458	Display of model check number	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
CD0459	Writing of the VIN	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
CD0460	Display of SCN	N3/9-Motor electronics "CDI61" for combustion engine "OM642"

CD0461	Display of CVN	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
CD0462	Display of model check number	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
CD0463	Writing of the VIN	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
CD0464	Display of coding data	Y3/8n4-Fully integrated transmission control
CD0465	Display of SCN	Y3/8n4-Fully integrated transmission control
CD0466	Display of CVN	Y3/8n4-Fully integrated transmission control
CD0467	Writing of the VIN	Y3/8n4-Fully integrated transmission control
CD0468	Display of coding data	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
CD0469	Display of SCN	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
CD0470	Display of CVN	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
CD0471	Writing of the VIN	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
CD0472	Correction programming of electrohydraulic actuator part number	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
CD0473	Display of coding data	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9
CD0474	Display of SCN	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9
CD0475	Display of CVN	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9
CD0476	Display of model check number	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9
CD0477	Writing of the VIN	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9
CD0478	Display of SCN	SCR-Selective Catalytic Reduction
CD0479	Display of CVN	SCR-Selective Catalytic Reduction
CD0480	Display of model check number	SCR-Selective Catalytic Reduction
CD0481	Writing of the VIN	SCR-Selective Catalytic Reduction
CD0482	Display of SCN	SCR-Selective catalytic reduction
CD0483	Display of CVN	SCR-Selective catalytic reduction
CD0484	Display of model check number	SCR-Selective catalytic reduction
CD0485	Display of SCN	SG EM-Power electronics
CD0486	Display of CVN	SG EM-Power electronics
CD0487	Display of SCN	BMS-Battery management system(N82/2)
CD0488	Display of CVN	BMS-Battery management system(N82/2)
CD0489	Display of coding data	AVE H-Rear audio video unit
CD0490	Automatic function:Transfer of coding into control unit "Display in rear pass	AVE H-Rear audio video unit
CD0491	Connected control units	AVE H-Rear audio video unit
CD0492	Region code	AVE H-Rear audio video unit
CD0493	Reset	AVE H-Rear audio video unit
CD0494	Display of SCN	SG LG-Charger
CD0495	Display of CVN	SG LG-Charger
CD0496	Special functionFIN	ESP-Electronic stability program(N30/4)

CD0497	Calibration of component "A7/3 (Traction system hydraulic unit)"	ESP-Electronic stability program(N30/4)
CD0498	Display of SCN	ESP-Regenerative braking system(N30/6)
CD0499	Display of CVN	ESP-Regenerative braking system(N30/6)
CD0500	Perform coding of control unit "N30/6 (Regenerative braking system contro	ESP-Regenerative braking system(N30/6)
CD0501	Special functionVIN	ESP-Regenerative braking system(N30/6)
CD0502	M40Pneumatic pump for multicontour seat	PPAMKS-Pneumatic pump for active multicontour seat
CD0503	M40/1Pneumatic pump for active multicontour seat	PPAMKS-Pneumatic pump for active multicontour seat
CD0504	Control unit reset	PPAMKS-Pneumatic pump for active multicontour seat
CD0505	M40 (Multicontour seat pneumatic pump)	PPAMKS-Pneumatic pump for multicontour seat
CD0506	M40/1 (Dynamic multicontour seat pneumatic pump)	PPAMKS-Pneumatic pump for multicontour seat
CD0507	M40/1 (Active multicontour seat pneumatic pump)	PPAMKS-Pneumatic pump for multicontour seat
CD0508	Control unit reset	PPAMKS-Pneumatic pump for multicontour seat
CD0509	Activation of component "Rear switching module"	KG-KEYLESS GO(N69/5)
CD0510	Parameters of sound system	SOUND-Bose sound system
CD0511	Display of coding data	ADS-Adaptive damping system(N51/5)
CD0512	Antenna monitoring	ECS-N123/4 Emergency call system control unit
CD0513	Waking control unit by pressing a button	ECS-N123/4 Emergency call system control unit
CD0514	NavigationParameter	ECS-N123/4 Emergency call system control unit
CD0515	Model series	ECS-N123/4 Emergency call system control unit
CD0516	Vehicle configuration	ECS-N123/4 Emergency call system control unit
CD0517	Messages in multifunction display	ECS-N123/4 Emergency call system control unit
CD0518	Antenna resistance values	ECS-N123/4 Emergency call system control unit
CD0519	Antenna resistance values(alternative)	ECS-N123/4 Emergency call system control unit
CD0520	EXTENDEDSet	ECS-N123/4 Emergency call system control unit
CD0521	AirbagCode	ECS-N123/4 Emergency call system control unit
CD0522	Special functions	TV-TV tuner
CD0523	Display of coding data	SOGESTAR2-Sound generator for electric vehicle
CD0524	Initial startup	ES-Electric power steering(N68)
CD0525	Initial startup of already installed control unit	RevETR LF-Left front reversible emergency tensioning retractor (A76)
CD0526	Initial startup of already installed control unit	RevETR RF-Right front reversible emergency tensioning retractor(A76/1)
CD0527	Display of coding data	D FOL-Display in left rear passenger compartment
CD0528	Automatic function:Transfer of coding into control unit "Display in rear pas	D FOL-Display in left rear passenger compartment
CD0529	Connected control units	D FOL-Display in left rear passenger compartment
CD0530	Reset	D FOL-Display in left rear passenger compartment
CD0531	Display of coding data	D FOR-Display in right rear passenger compartment
CD0532	Automatic function:Transfer of coding into control unit "Display in rear pas	D FOR-Display in right rear passenger compartment

CD0533	Connected control units	D FOR-Display in right rear passenger compartment
CD0534	Reset	D FOR-Display in right rear passenger compartment
CD0535	Display of coding data	FGW-Chassis gateway
CD0536	Display of coding data	PTS-Parktronic system
CD0537	Volume and frequency	PTS-Parktronic system
CD0538	Width of license plate bracket	PTS-Parktronic system
CD0539	Trailer hitch	PTS-Parktronic system
CD0540	Display of coding data	E1n7 (Actuation module, LED exterior lighting, left front)
CD0541	Display of coding data	AMLAB L 2-Actuation module 2, LED exterior lighting, left front(E1n8)
CD0542	Display of coding data	E2n7 (Actuation module, LED exterior lighting, right front)
CD0543	Display of coding data	AMLAB R 2-Actuation module 2, LED exterior lighting, right front(E2n8)
CD0544	Display of coding data	N3/10-Motor electronics "MED177" for combustion engine "M276"
CD0545	Display of SCN	N3/10-Motor electronics "MED177" for combustion engine "M276"
CD0546	Display of CVN	N3/10-Motor electronics "MED177" for combustion engine "M276"
CD0547	Display of model check number	N3/10-Motor electronics "MED177" for combustion engine "M276"
CD0548	Correction programming of ignition	N3/10-Motor electronics "MED177" for combustion engine "M276"
CD0549	Correction programming of fuel quantity	N3/10-Motor electronics "MED177" for combustion engine "M276"
CD0550	Correction programming of specified idle speed in selector lever position "P	N3/10-Motor electronics "MED177" for combustion engine "M276"
CD0551	Correction programming of specified idle speed with gear range engaged	N3/10-Motor electronics "MED177" for combustion engine "M276"
CD0552	Injector injection quantity adjustment	N3/10-Motor electronics "MED177" for combustion engine "M276"
CD0553	Display of coding data	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
CD0554	Display of SCN	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
CD0555	Display of CVN	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
CD0556	Display of model check number	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
CD0557	Correction programming of ignition	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
CD0558	Correction programming of fuel quantity	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
CD0559	Correction programming of specified idle speed in selector lever position "P	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
CD0560	Correction programming of specified idle speed with gear range engaged	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
CD0561	Injector injection quantity adjustment	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
CD0562	Display of coding data	CGW[ZGW]-Central gateway
CD0563	Display of coding data	CGW-Central gateway
CD0564	Delay period for turn signals after closing of trunk lid	EZS-Electronic ignition switch
CD0565	Initial startup	EZS-Electronic ignition switch
CD0566	Reset offset value of signal "Longitudinal acceleration".	ESP- Electric stability program
CD0567	Perform coding of control unit "N30/4 (Electronic Stability Program control	ESP- Electric stability program
CD0568	Special functions VIN	ESP- Electric stability program

CD0569	Action 067 2015 395	SRS-Supplemental restraint system (N2/10)
CD0570	Action 050 2017 275 / 050 2017 156	SRS-Supplemental restraint system (N2/10)
CD0571	Locking of control unit	SRS-Supplemental restraint system (N2/10)
CD0572	Initial startup	KG-KEYLESS GO
CD0573	Initial startup	EHPS-Electorhydraulic power sreeting
CD0574	Seat adjustment	N32/1 (Driver seat control unit)
CD0575	Seat adjustment	N32/2 (Front passenger seat control unit)
CD0576	Exit lamp "A-pillar"	OCP-Control unit 'Overhead control panel'
CD0577	Switch group	OCP-Control unit 'Overhead control panel'
CD0578	Interior lamp in rear compartment	OCP-Control unit 'Overhead control panel'
CD0579	Display of coding data	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
CD0580	Display of SCN	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
CD0581	Display of CVN	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
CD0582	Display of model check number	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
CD0583	Correction programming of ignition	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
CD0584	Correction programming of fuel quantity	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
CD0585	Correction programming of specified idle speed in selector lever position "P"	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
CD0586	Correction programming of specified idle speed with gear range engaged	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
CD0587	Injector injection quantity adjustment	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
CD0588	Display of coding data	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
CD0589	Display of SCN	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
CD0590	Display of CVN	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
CD0591	Display of model check number	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
CD0592	Correction programming of ignition	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
CD0593	Correction programming of fuel quantity	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
CD0594	Correction programming of electric fan for combustion engine or air conditi	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
CD0595	Correction programming of specified idle speed	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
CD0596	Correction programming of specified idle speed with gear range engaged	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
CD0597	Default initialization	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
CD0598	Language setting	AUDIO-Audio(A2)
CD0599	Frequency readout	AUDIO-Audio(A2)
CD0600	Perform control unit reset.	AUDIO-Audio(A2)
CD0601	The production run is active.	STC-Soft top control(N52)
CD0602	Display of coding data	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
CD0603	Display of SCN	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
CD0604	Display of CVN	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"

CD0605	Display of model check number	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
CD0606	Correction programming of ignition	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
CD0607	Correction programming of fuel quantity	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
CD0608	Correction programming of specified idle speed in selector lever position "P"	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
CD0609	Correction programming of specified idle speed with gear range engaged	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
CD0610	Current menu settings	IC-Instrument cluster(A1)
CD0611	Transfer of manufacturer default settings	IC-Instrument cluster(A1)
CD0612	Oil grade factor	IC-Instrument cluster(A1)
CD0613	Customer-specific settings	IC-Instrument cluster(A1)
CD0614	Adjusting the parameters	AMG PM-AMG Performance Media(N125/2)
CD0615	Road test	ESP-Electronic stability program(N30/4)
CD0616	Reset offset value of signal "Longitudinal acceleration".	ESP-Electronic stability program(N30/4)
CD0617	Special function VIN	ESP-Electronic stability program(N30/4)
CD0618	Special functionVIN	ESP-Electric stability program(N30/4)
CD0619	Unlocking of control unit	SRS-Supplemental restraint system
CD0620	Display of coding data	Audio-Audio or COMAND
CD0621	Check codings in control unit "Audio or COMAND" and change if necessary	Audio-Audio or COMAND
CD0622	Setting language	Audio-Audio or COMAND
CD0623	Language for the voice control system	Audio-Audio or COMAND
CD0624	Video AUX jack	Audio-Audio or COMAND
CD0625	Mercedes-Benz Contact	Audio-Audio or COMAND
CD0626	Navigation data	Audio-Audio or COMAND
CD0627	Special equipment	Audio-Audio or COMAND
CD0628	Frequency readout	Audio-Audio or COMAND
CD0629	Run-on time after switching off ignition	Audio-Audio or COMAND
CD0630	Deactivation of MOST communication	Audio-Audio or COMAND
CD0631	Activation of MOST communication	Audio-Audio or COMAND
CD0632	Restart MOST ring.	Audio-Audio or COMAND
CD0633	Initial startup	WSS-Weight sensing system(N110)
CD0634	Initial startup of already installed control unit	SG LG-Charger
CD0635	Check codings in control unit "22 KW".	SG LG-Charger
CD0636	Automatische Codierung	SG LG-Charger
CD0637	Lock high-voltage component lock.	SG LG-Charger
CD0638	Unlock high-voltage component lock.	SG LG-Charger
CD0639	Set type of antenna.	KOMO-Communication module Telematics services
CD0640	Reading of parameter data from control unit	PTCU-MA-Drivetrain (master)

CD0641	Writing of parameter data to control unit	PTCU-MA-Drivetrain (master)
CD0642	Display currently set codings.	PTCU-MA-Drivetrain (master)
CD0643	Coding of control unit	PTCU-MA-Drivetrain (master)
CD0644	Reading of parameter data from control unit	PTCU-SL-Drivetrain (slave)
CD0645	Writing of parameter data to control unit	PTCU-SL-Drivetrain (slave)
CD0646	Display currently set codings.	PTCU-SL-Drivetrain (slave)
CD0647	Coding of control unit	PTCU-SL-Drivetrain (slave)
CD0648	Writing of the VIN	PTCU-SL-Drivetrain (slave)
CD0649	Display of SCN	N3/9-Motor electronics "CR42" for combustion engine "OM651"
CD0650	Display of CVN	N3/9-Motor electronics "CR42" for combustion engine "OM651"
CD0651	Display of model check number	N3/9-Motor electronics "CR42" for combustion engine "OM651"
CD0652	Display of SCN	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
CD0653	Display of CVN	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
CD0654	Display of model check number	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
CD0655	Display of SCN	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
CD0656	Display of CVN	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
CD0657	Display of model check number	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
CD0658	Display of SCN	N3/9-Motor electronics "CDI" for combustion engine "OM646"
CD0659	Display of model check number	N3/9-Motor electronics "CDI" for combustion engine "OM646"
CD0660	Display of coding data	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
CD0661	Display of SCN	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
CD0662	Display of CVN	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
CD0663	Display of model check number	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
CD0664	Disabling of key or key track with workshop key	EZS-Electronic ignition lock
CD0665	Disabling of key or key track	EZS-Electronic ignition lock
CD0666	Re-enabling of key or key track	EZS-Electronic ignition lock
CD0667	Writing of vehicle identification number	EZS-Electronic ignition lock
CD0668	Initial startup:EZS	EZS-Electronic ignition lock
CD0669	Initial startup:ESL [ELV]	EZS-Electronic ignition lock
CD0670	Events	ESP- Electric stability program
CD0671	Special functionFIN	ESP- Electric stability program
CD0672	Read out fault memory.	ESP- Electric stability program
CD0673	Abort road test.	ESP- Electric stability program
CD0674	Control unit programming	ESP- Electric stability program
CD0675	Special functionVIN	ESP- Electric stability program
CD0676	Roof sign lamp	Multifunction control unit-Multifunction control unit

CD0677	Silent alarm	Multifunction control unit-Multifunction control unit
CD0678	Active alarm	Multifunction control unit-Multifunction control unit
CD0679	Initialization	Multifunction control unit-Multifunction control unit
CD0680	Variant coding	TLC-Trunk lid control
CD0681	Increase in the opening angle of the liftgate	TLC-Trunk lid control
CD0682	Special settings	STH-Stationary heater
CD0683	Panoramic sliding sunroof	PSD-Control module 'Panoramic sliding roof'(A98)
CD0684	Panoramic sliding sunroof	PSD-Control mudule 'Panoramic sliding roof'(A98)
CD0685	A67 (Inside rearview mirror)	OCP-Overhead control panel
CD0686	Tilting/sliding sunroof	OCP-Overhead control panel
CD0687	OFF time of interior lamp in dimmed state	OCP-Overhead control panel
CD0688	ON time of interior lamp in dimmed state	OCP-Overhead control panel
CD0689	Type of trailer hitch and national version	TRM-Trailer recognition module (N28/1)
CD0690	Display of coding data	FSCU01-Control unit Fuel pump
CD0691	Read out coding and modify if necessary.	FSCU01-Control unit Fuel pump
CD0692	Manual coding	FSCU Left-Control unit 'Left fuel pump'
CD0693	Read out coding and modify if necessary.	FSCU Left-Control unit 'Left fuel pump'
CD0694	Folding in/out of outside mirrors	DCU LF-Left front door(N69/1)
CD0695	Folding in/out of outside mirrors	DCU RF-Right front door(N69/2)
CD0696	Display of coding data	RFK-Backup camera
CD0697	Variant coding	XALWA R-Xenon headlamp, right
CD0698	Manual coding	FSCU Right-Control unit 'Right fuel pump'
CD0699	Read out coding and modify if necessary.	FSCU Right-Control unit 'Right fuel pump'
CD0700	Display of coding data	N15/3The fault occurs when charging of the fuel injector takes too long.5
CD0701	Display of SCN	N15/3The fault occurs when charging of the fuel injector takes too long.5
CD0702	Display of CVN	N15/3The fault occurs when charging of the fuel injector takes too long.5
CD0703	Display of coding data	N3/10-Motor electronics "ME97" for combustion engine "M272"
CD0704	Display of SCN	N3/10-Motor electronics "ME97" for combustion engine "M272"
CD0705	Display of CVN	N3/10-Motor electronics "ME97" for combustion engine "M272"
CD0706	Display of model check number	N3/10-Motor electronics "ME97" for combustion engine "M272"
CD0707	Correction programming of ignition	N3/10-Motor electronics "ME97" for combustion engine "M272"
CD0708	Correction programming of fuel quantity	N3/10-Motor electronics "ME97" for combustion engine "M272"
CD0709	Correction programming of specified idle speed in selector lever position "P"	N3/10-Motor electronics "ME97" for combustion engine "M272"
CD0710	Correction programming of specified idle speed with gear range engaged	N3/10-Motor electronics "ME97" for combustion engine "M272"
CD0711	Display of coding data	N3/10-Motor electronics "MED97" for combustion engine "M272"
CD0712	Display of SCN	N3/10-Motor electronics "MED97" for combustion engine "M272"

CD0713	Display of CVN	N3/10-Motor electronics "MED97" for combustion engine "M272"
CD0714	Display of model check number	N3/10-Motor electronics "MED97" for combustion engine "M272"
CD0715	Correction programming of ignition	N3/10-Motor electronics "MED97" for combustion engine "M272"
CD0716	Correction programming of fuel quantity	N3/10-Motor electronics "MED97" for combustion engine "M272"
CD0717	Correction programming of specified idle speed in selector lever position "P"	N3/10-Motor electronics "MED97" for combustion engine "M272"
CD0718	Correction programming of specified idle speed with gear range engaged	N3/10-Motor electronics "MED97" for combustion engine "M272"
CD0719	Injector injection quantity adjustment	N3/10-Motor electronics "MED97" for combustion engine "M272"
CD0720	Display of coding data	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
CD0721	Display of SCN	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
CD0722	Display of CVN	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
CD0723	Display of model check number	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
CD0724	Correction programming of ignition	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
CD0725	Correction programming of fuel quantity	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
CD0726	Correction programming of electric fan for combustion engine or air conditioning	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
CD0727	Correction programming of specified idle speed in selector lever position "P"	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
CD0728	Correction programming of specified idle speed with gear range engaged	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
CD0729	Default initialization	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
CD0730	Variant coding	AAC-Automatic air conditioning
CD0731	Position of fresh air/recirculated air flap at ignition OFF	AAC-Automatic air conditioning
CD0732	Special equipment "AIRCAP"	REAR-Rear control unit(N22/6)
CD0733	Coding of component "Belt extender"	REAR-Rear control unit(N22/6)
CD0734	Set functionality of wind deflector to state prior to facelift.	REAR-Rear control unit(N22/6)
CD0735	Set functionality of wind deflector to state after facelift.	REAR-Rear control unit(N22/6)
CD0736	Display of SCN	PE-Power electronics(N129/1)
CD0737	Display of CVN	PE-Power electronics(N129/1)
CD0738	Display of SCN	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
CD0739	Display of CVN	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
CD0740	Display of model check number	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
CD0741	Display of coding data	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
CD0742	Display of SCN	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
CD0743	Display of CVN	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
CD0744	Display of model check number	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
CD0745	Correction programming of ignition	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
CD0746	Correction programming of fuel quantity	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
CD0747	Injector injection quantity adjustment	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
CD0748	Block natural gas operation.	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"

CD0749	Enable natural gas operation	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
CD0750	Enable natural gas operation after crash event.	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
CD0751	Correction programming of specified idle speed	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
CD0752	Correction programming of specified idle speed with gear range engaged	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
CD0753	Display of coding data	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
CD0754	Display of SCN	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
CD0755	Display of CVN	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
CD0756	Display of model check number	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
CD0757	Correction programming of ignition	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
CD0758	Correction programming of fuel quantity	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
CD0759	Correction programming of electric fan for combustion engine or air conditi	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
CD0760	Correction programming of specified idle speed in selector lever position "P	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
CD0761	Correction programming of specified idle speed with gear range engaged	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
CD0762	Default initialization	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
CD0763	Natural gas operationCorrection value	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
CD0764	Correction programming of fuel quantity(Natural gas operation)	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
CD0765	Display of coding data	SG LML VL-LED matrix of left front lamp unit
CD0766	Display of coding data	SG-LML-VR-LED matrix of right front lamp unit
CD0767	Commissioning of control unit "E1n8 (Actuation module 2, LED exterior lig	E1n8 (Actuation module 2, LED exterior lighting, left front)
CD0768	Commissioning of control unit "E2n8 (Actuation module 2, LED exterior lig	E2n8 (Actuation module 2, LED exterior lighting, right front)
CD0769	Display of SCN	N3/10-Motor electronics "ME1778" for combustion engine "M279"
CD0770	Display of CVN	N3/10-Motor electronics "ME1778" for combustion engine "M279"
CD0771	Display of model check number	N3/10-Motor electronics "ME1778" for combustion engine "M279"
CD0772	Correction programming of ignition	N3/10-Motor electronics "ME1778" for combustion engine "M279"
CD0773	Correction programming of fuel quantity	N3/10-Motor electronics "ME1778" for combustion engine "M279"
CD0774	Correction programming of specified idle speed in selector lever position "P	N3/10-Motor electronics "ME1778" for combustion engine "M279"
CD0775	Correction programming of specified idle speed with gear range engaged	N3/10-Motor electronics "ME1778" for combustion engine "M279"
CD0776	ValveMassage function	MKS LF-Left front multicontour seat
CD0777	ValveMassage function	AMKS RF-Active multicontour seat(N32/22)
CD0778	Display of CVN	RBS-Regenerative braking system
CD0779	Events	RBS-Regenerative braking system
CD0780	Check coding "Hill Start Assist".	RBS-Regenerative braking system
CD0781	Special function FIN	RBS-Regenerative braking system
CD0782	Reading of parameter data for the component "M56 (Vacuum pump)"	PTCU-Common powertrain controller(N127)
CD0783	Writing of parameter data for the component "M56 (Vacuum pump)"	PTCU-Common powertrain controller(N127)
CD0784	Resetting of parameter data for the component "M56 (Vacuum pump)"	PTCU-Common powertrain controller(N127)

CD0785	Reading of fare settings	PTCU-Common powertrain controller(N127)
CD0786	Writing of fare settings	PTCU-Common powertrain controller(N127)
CD0787	Resetting of fare settings	PTCU-Common powertrain controller(N127)
CD0788	Writing of the VIN	PTCU-Common powertrain controller(N127)
CD0789	Performance of a control unit power-down	PTCU-Common powertrain controller(N127)
CD0790	Special function1	ESP-Electric stability program(N30/4)
CD0791	Special function2	ESP-Electric stability program(N30/4)
CD0792	Display of SCN	VG-Transfer case
CD0793	Display of SCN	N3/10-Motor electronics "MED1775" for combustion engine "M178"
CD0794	Display of CVN	N3/10-Motor electronics "MED1775" for combustion engine "M178"
CD0795	Display of model check number	N3/10-Motor electronics "MED1775" for combustion engine "M178"
CD0796	Correction programming of ignition	N3/10-Motor electronics "MED1775" for combustion engine "M178"
CD0797	Correction programming of fuel quantity	N3/10-Motor electronics "MED1775" for combustion engine "M178"
CD0798	Correction programming of specified idle speed in selector lever position "P"	N3/10-Motor electronics "MED1775" for combustion engine "M178"
CD0799	Correction programming of specified idle speed with gear range engaged	N3/10-Motor electronics "MED1775" for combustion engine "M178"
CD0800	Injector injection quantity adjustment	N3/10-Motor electronics "MED1775" for combustion engine "M178"

XT **TOOL**

Special Functions

No.	Functions Name	System Name
SP0001	AC compressor	AAC-Automatic air conditioning
SP0002	Breaking-in of refrigerant compressor	AAC-Automatic air conditioning
SP0003	Breaking-in procedure after replacement of refrigerant compressor	AAC-Automatic air conditioning
SP0004	Breaking-in of refrigerant compressor	AAC-Automatic air conditioning
SP0005	Check of the adjustment range of the actuator motors	AAC-Automatic air conditioning
SP0006	Normalization of actuator motors	AAC-Automatic air conditioning
SP0007	Normalizing of positioning motors	AAC-Automatic air conditioning
SP0008	Teach-in of actuator motors	AAC-Automatic air conditioning
SP0009	Teach-in of actuator motors after actuator motor replacement	AAC-Automatic air conditioning
SP0010	Steering variant	AB-Airbag
SP0011	Calibration of plunger travel	ABC-ABC active body control
SP0012	Initial startup with automatic takeover of settings of previous control unit	ABC-ABC active body control
SP0013	Raise and lower the suspension struts at high speed	ABC-ABC active body control
SP0014	Raise and lower the suspension struts at high speed	ABC-ABC active body control
SP0015	Raise and lower the suspension struts at low speed	ABC-ABC active body control
SP0016	Raise and lower the suspension struts at medium speed	ABC-ABC active body control
SP0017	Raise and lower the suspension struts at medium speed	ABC-ABC active body control
SP0018	Reset of calibrations	ABC-ABC active body control
SP0019	Driving test	ABR-Adaptive Brake
SP0020	Erase zero point offset error of component N49 (Steering angle sensor)	ABR-Adaptive Brake
SP0021	PML speed-sensitive power steering	ABR-Adaptive Brake
SP0022	Tyre pressure loss alarm (activated)	ABR-Adaptive Brake
SP0023	Reset of compressor operating time	ADS-Adaptive damping system
SP0024	Initial startup with automatic takeover of settings of previous control unit	AIRmatic
SP0025	Level calibration	AIRmatic
SP0026	Breaking-in procedure after replacement of refrigerant compressor	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater
SP0027	Normalizing of positioning motors	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater
SP0028	Teach-in of actuator motors after actuator motor replacement	C AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater
SP0029	Activate fuel pump	CDI 3-Common Rail Diesel Injection3
SP0030	Adjustment of injector injection quantities	CDI 3-Common Rail Diesel Injection3

SP0031	B79/2 (Transmission neutral position sensor)	CDI 3-Common Rail Diesel Injection3
SP0032	Injector injection quantity adjustment	CDI 3-Common Rail Diesel Injection3
SP0033	Oxidation catalytic converter	CDI 3-Common Rail Diesel Injection3
SP0034	Regeneration of diesel particulate filter	CDI 3-Common Rail Diesel Injection3
SP0035	Replacement component Diesel particulate filter	CDI 3-Common Rail Diesel Injection3
SP0036	Reset of lambda values	CDI 3-Common Rail Diesel Injection3
SP0037	Reset quantity mean value adaptation data	CDI 3-Common Rail Diesel Injection3
SP0038	Resetting of contamination level of air filter	CDI 3-Common Rail Diesel Injection3
SP0039	Resetting of learned values of component 'B6/1 (Camshaft Hall sensor)'	CDI 3-Common Rail Diesel Injection3
SP0040	Teach in of throttle valve stop	CDI 3-Common Rail Diesel Injection3
SP0041	Teach-in of diesel particulate filter after replacement of control unit 'N3/9 (CDI control unit)'	CDI 3-Common Rail Diesel Injection3
SP0042	Teach-in of intake port shutoff	CDI 3-Common Rail Diesel Injection3
SP0043	Teach-in process after replacement of component 'AdBlue metering valve'	CDI 3-Common Rail Diesel Injection3
SP0044	Teach-in process after replacement of component 'B16/15 (Temperature sensor upstream of SCR catalytic converter)'	CDI 3-Common Rail Diesel Injection3
SP0045	Teach-in process after replacement of component 'Diesel particulate filter'	CDI 3-Common Rail Diesel Injection3
SP0046	Teach-in process after replacement of component 'SCR catalytic converter'	CDI 3-Common Rail Diesel Injection3
SP0047	Teach-in process after replacing NOx sensor	CDI 3-Common Rail Diesel Injection3
SP0048	Adjustment of injector injection quantities	CDI 4-Common Rail Diesel Injection
SP0049	Diesel particulate filter Configuration	CDI 4-Common Rail Diesel Injection
SP0050	Diesel particulate filter Purge control	CDI 4-Common Rail Diesel Injection
SP0051	Rapid teach-in of zero quantity calibration values	CDI 4-Common Rail Diesel Injection
SP0052	Regeneration of the diesel particulate filter while driving	CDI 4-Common Rail Diesel Injection
SP0053	Replacement component Diesel particulate filter	CDI 4-Common Rail Diesel Injection
SP0054	Reset quantity mean value adaptation data	CDI 4-Common Rail Diesel Injection
SP0055	Reset values for HFM drift compensation	CDI 4-Common Rail Diesel Injection
SP0056	Resetting air filter learned values after air filter replacement	CDI 4-Common Rail Diesel Injection
SP0057	Teach in of throttle valve stop	CDI 4-Common Rail Diesel Injection
SP0058	Activate fuel pump	CDI 6-Common Rail Diesel Injection
SP0059	Adjustment of injector injection quantities	CDI 6-Common Rail Diesel Injection
SP0060	B28/8(Differential pressure sensor (DPF))	CDI 6-Common Rail Diesel Injection
SP0061	G3/2(Oxygen sensor upstream of catalytic converter)	CDI 6-Common Rail Diesel Injection
SP0062	Quick teach-in of values of zero quantity calibration	CDI 6-Common Rail Diesel Injection
SP0063	Regeneration of diesel particulate filter	CDI 6-Common Rail Diesel Injection
SP0064	Replacement of component 'Diesel particulate filter'	CDI 6-Common Rail Diesel Injection
SP0065	Reset values of HFM drift compensation	CDI 6-Common Rail Diesel Injection

SP0066	Reset values of quantity mean value adaptation	CDI 6-Common Rail Diesel Injection
SP0067	Resetting of contamination level of air filter	CDI 6-Common Rail Diesel Injection
SP0068	Teach in of throttle valve stop	CDI 6-Common Rail Diesel Injection
SP0069	Teach in used diesel particulate filter	CDI 6-Common Rail Diesel Injection
SP0070	Y74(Pressure control valve)	CDI 6-Common Rail Diesel Injection
SP0071	Activate fuel pump	CDI 60LS-Common Rail Diesel Injection
SP0072	B16/15 (Temperature sensor upstream of SCR catalytic converter)	CDI 60LS-Common Rail Diesel Injection
SP0073	B28/8 (DPF differential pressure sensor)	CDI 60LS-Common Rail Diesel Injection
SP0074	G3/2 (Oxygen sensor upstream of catalytic converter)	CDI 60LS-Common Rail Diesel Injection
SP0075	Injector injection quantity adjustment	CDI 60LS-Common Rail Diesel Injection
SP0076	Oxidation catalytic converter	CDI 60LS-Common Rail Diesel Injection
SP0077	Quick teach-in of values of zero quantity calibration	CDI 60LS-Common Rail Diesel Injection
SP0078	Regeneration of the diesel particulate filter while driving	CDI 60LS-Common Rail Diesel Injection
SP0079	Replacing component 'Diesel particulate filter'	CDI 60LS-Common Rail Diesel Injection
SP0080	Reset values of HFM drift compensation	CDI 60LS-Common Rail Diesel Injection
SP0081	Reset values of quantity mean value adaptation	CDI 60LS-Common Rail Diesel Injection
SP0082	Resetting of contamination level of air filter	CDI 60LS-Common Rail Diesel Injection
SP0083	SCR catalytic converter	CDI 60LS-Common Rail Diesel Injection
SP0084	Teach in of throttle valve stop	CDI 60LS-Common Rail Diesel Injection
SP0085	Teach in used diesel particulate filter	CDI 60LS-Common Rail Diesel Injection
SP0086	Teach-in process after replacing Nox sensor	CDI 60LS-Common Rail Diesel Injection
SP0087	Y129 (AdBlue metering valve)	CDI 60LS-Common Rail Diesel Injection
SP0088	Y74 (Pressure regulating valve)	CDI 60LS-Common Rail Diesel Injection
SP0089	Activate fuel pump	CDI-Common Rail Diesel Injection
SP0090	Adjustment of injector injection quantities	CDI-Common Rail Diesel Injection
SP0091	Reset quantity mean value adaptation data	CDI-Common Rail Diesel Injection
SP0092	Reset values for HFM drift compensation	CDI-Common Rail Diesel Injection
SP0093	Resetting air filter learned values after air filter replacement	CDI-Common Rail Diesel Injection
SP0094	Teach-in of diesel particulate filter after replacement of engine control unit without transfer of values	CDI-Common Rail Diesel Injection
SP0095	Teach-in process after replacement of component (B28/8(Differential pressure sensor(DPF))	CDI-Common Rail Diesel Injection
SP0096	Teach-in process after replacement of component G3/1(O2 sensor downstream TWC)	CDI-Common Rail Diesel Injection
SP0097	Teach-in process after replacement of component Y100/2(Boost pressure regulator)	CDI-Common Rail Diesel Injection
SP0098	Teach-in process after replacement of component Y74(Pressure control valve)	CDI-Common Rail Diesel Injection
SP0099	Teach-in process after replacement of component diesel particulate filter	CDI-Common Rail Diesel Injection
SP0100	Teaching in the diesel particulate filter after replacing the engine control unit	CDI-Common Rail Diesel Injection
SP0101	Activate fuel pump	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0102	B16/15 (Temperature sensor upstream of SCR catalytic converter)	CDI-Motor electronics 'CR42' for combustion engine 'OM607'

SP0103	B79/2 (Transmission neutral position sensor)	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0104	Diesel particulate filter	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0105	G3/2(Oxygen sensor upstream of catalytic converter)	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0106	Injector injection quantity adjustment	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0107	Oxidation catalytic converter	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0108	Quick teach-in of values of zero quantity calibration	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0109	Reset values of HFM drift compensation	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0110	Reset values of quantity mean value adaptation	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0111	Resetting of contamination level of air filter	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0112	Teach in of throttle valve stop	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0113	Y129 (AdBlue metering valve)	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0114	Y74(Pressure control valve)	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0115	Y94 (Quantity control valve)	CDI-Motor electronics 'CR42' for combustion engine 'OM607'
SP0116	Activate fuel pump	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0117	Injector injection quantity adjustment	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0118	Regeneration of the diesel particulate filter while driving	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0119	Resetting of learned values of component 'B4/6 (Rail pressure sensor)'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0120	Resetting of learned values of component 'Diesel particulate filter'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0121	Resetting of learned values of component 'Fuel system high pressure pump'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0122	Resetting of learned values of component 'G3/2 (Oxygen sensor upstream of catalytic converter)'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0123	Resetting of learned values of component 'Turbocharger'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0124	Status of teach-in processes	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0125	Teach in component 'M16/57 (Exhaust flap controller)'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0126	Teach in component 'M16/6 (Throttle valve actuator)'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0127	Teach in component 'Y27/7 (Exhaust gas recirculation actuator, low pressure)'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0128	Teach in component 'Y27/8 (Exhaust gas recirculation actuator, high pressure)'	CDI-Motor electronics 'CRR1' for combustion engine 'OM607'
SP0129	Activate fuel pump	CDID-Common Rail Diesel Injection
SP0130	Injector injection quantity adjustment	CDID-Common Rail Diesel Injection
SP0131	Learning component'Y94 (Quantity control valve)'	CDID-Common Rail Diesel Injection
SP0132	Regeneration of diesel particulate filter	CDID-Common Rail Diesel Injection
SP0133	Replacement component Diesel particulate filter	CDID-Common Rail Diesel Injection
SP0134	Reset of lambda values	CDID-Common Rail Diesel Injection
SP0135	Reset values of quantity mean value adaptation	CDID-Common Rail Diesel Injection
SP0136	Resetting of contamination level of air filter	CDID-Common Rail Diesel Injection
SP0137	Teach in of throttle valve stop	CDID-Common Rail Diesel Injection
SP0138	Teach in used diesel particulate filter	CDID-Common Rail Diesel Injection

SP0139	Teach-in of intake port shutoff	CDID-Common Rail Diesel Injection
SP0140	Initial startup	DTR-Distronic
SP0141	Calibration of control unit 'N128 (Electric parking brake control unit)'	EFB-Electronic parking brake
SP0142	Replacing brake pads	EFB-Electronic parking brake
SP0143	Reset of compressor operating time	ELC-Electronic level control
SP0144	Calibration of the torque sensor	ES-Electrical power steering
SP0145	Erase zero point offset error of component N49 (Steering angle sensor)	ESP-Electronic stability program
SP0146	Erase zero point offset error of component N49 (Steering angle sensor).	ESP-Electronic stability program
SP0147	Reset offset value of signal 'Steering angle'	ESP-Electronic stability program
SP0148	Tyre pressure loss alarm (activated)	ESP-Electronic stability program
SP0149	Adaptation values of shift 1-2	ETC-Electronic transmission control
SP0150	Adaptation values of shift 2-1	ETC-Electronic transmission control
SP0151	Adaptation values of shift 2-3	ETC-Electronic transmission control
SP0152	Adaptation values of shift 3-2	ETC-Electronic transmission control
SP0153	Adaptation values of shift 3-4	ETC-Electronic transmission control
SP0154	Adaptation values of shift 4-3	ETC-Electronic transmission control
SP0155	Adaptation values of shift 4-5	ETC-Electronic transmission control
SP0156	Adaptation values of shift 5-4	ETC-Electronic transmission control
SP0157	Adaptation values of shift 5-6	ETC-Electronic transmission control
SP0158	Adaptation values of shift 6-5	ETC-Electronic transmission control
SP0159	Adaptation values of shift 6-7	ETC-Electronic transmission control
SP0160	Adaptation values of shift 7-6	ETC-Electronic transmission control
SP0161	Display all adaptation data	ETC-Electronic transmission control
SP0162	Resetting of adaptation data	ETC-Electronic transmission control
SP0163	Resetting of adaptation data - Hydraulic brake	ETC-Electronic transmission control
SP0164	Resetting of adaptation data(Torque converter lockup clutch)	ETC-Electronic transmission control
SP0165	Reverse gear	ETC-Electronic transmission control
SP0166	Switch off solenoid valve for torque converter lockup clutch	ETC-Electronic transmission control
SP0167	Switch off the incline recognition for dynamometer mode	ETC-Electronic transmission control
SP0168	Torque converter lockup clutch	ETC-Electronic transmission control
SP0169	Y3/8s1(Selection range sensor(VGS))	ETC-Electronic transmission control
SP0170	Activate control module N26/5 (Electric steering lock control module)	EZS-Electronic ignition switch
SP0171	Switch off solenoid valve for torque converter lockup clutch	FCVT-Continuously variable automatic transmission
SP0172	N121 (Trunk lid control control unit)	HKS-Tailgate control (N121/1)
SP0173	N121/1 (Liftgate control control unit)	HKS-Tailgate control (N121/1)
SP0174	Curve illumination	HRA-Automatic headlamp range adjustment and headlamp control
SP0175	Headlamp range adjustment	HRA-Automatic headlamp range adjustment and headlamp control

SP0176	Maintenance light reset	IC-Instrument cluster
SP0177	Confirmation of general maintenance	ICM-Instrument cluster with maintenance interval display
SP0178	Maintenance light reset	ICM-Instrument cluster with maintenance interval display
SP0179	Reset general maintenance	ICM-Instrument cluster with maintenance interval display
SP0180	Activate fuel pump	ME 9.7-Motor electronics 9.7
SP0181	Correction programming of fuel quantity	ME 9.7-Motor electronics 9.7
SP0182	Correction programming of ignition	ME 9.7-Motor electronics 9.7
SP0183	Correction programming of specified idle speed in selector lever position P or N	ME 9.7-Motor electronics 9.7
SP0184	Correction programming of specified idle speed with gear range engaged	ME 9.7-Motor electronics 9.7
SP0185	Reset of cold start adaptation values	ME 9.7-Motor electronics 9.7
SP0186	Teach in of throttle valve stop	ME 9.7-Motor electronics 9.7
SP0187	Activate fuel pump	ME SFI-Motor electronics
SP0188	Correction programming of fuel quantity	ME SFI-Motor electronics
SP0189	Correction programming of ignition	ME SFI-Motor electronics
SP0190	Correction programming of specified idle speed in selector lever position P or N	ME SFI-Motor electronics
SP0191	Correction programming of specified idle speed with gear range engaged	ME SFI-Motor electronics
SP0192	Correction programming of the electric suction fan for engine or air conditioning	ME SFI-Motor electronics
SP0193	Resetting of mixture adaptation	ME SFI-Motor electronics
SP0194	Teach in component B79/2 (Transmission neutral position sensor)	ME SFI-Motor electronics
SP0195	Teach in of throttle valve stop	ME SFI-Motor electronics
SP0196	Activate fuel pump	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'
SP0197	Correction programming of fuel quantity	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'
SP0198	Correction programming of specified idle speed in selector lever position P or N	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'
SP0199	Correction programming of specified idle speed with gear range engaged	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'
SP0200	Injector injection quantity adjustment	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'
SP0201	Resetting of adaptation values	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'
SP0202	Teach in of throttle valve stop	ME-Motor electronics 'MED177AMG' for combustion engine 'M152'
SP0203	Activate fuel pump	ME-Motor electronics 'MED40' for combustion engine 'M270'
SP0204	Injector injection quantity adjustment	ME-Motor electronics 'MED40' for combustion engine 'M270'
SP0205	Resetting of adaptation values	ME-Motor electronics 'MED40' for combustion engine 'M270'
SP0206	Teach in of throttle valve stop	ME-Motor electronics 'MED40' for combustion engine 'M270'
SP0207	Teach-in of positions for camshafts	ME-Motor electronics 'MED40' for combustion engine 'M270'
SP0208	Activate fuel pump	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'

SP0209	Correction programming of fuel quantity	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0210	Correction programming of ignition	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0211	Correction programming of specified idle speed in selector lever position P or N	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0212	Correction programming of specified idle speed with gear range engaged	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0213	Injector injection quantity adjustment	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0214	Resetting of adaptation values	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0215	Teach in of throttle valve stop	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0216	Teach-in of positions for camshafts	ME-Motor electronics 'MED40AMG' for combustion engine 'M133'
SP0217	B79/3 (Manual transmission main shifter shaft position sensor)	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0218	Correction programming of fuel quantity	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0219	Correction programming of ignition	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0220	Correction programming of specified idle speed	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0221	Injector injection quantity adjustment	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0222	Resetting of adaptation values	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0223	Resetting reading of frequency counter for ethanol teach-in processes	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0224	Teach in of throttle valve stop	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0225	Teach-in of positions for camshafts	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0226	Teaching in the ethanol proportion in the fuel	ME-Motor electronics 'MED40CNG' for combustion engine 'M274'
SP0227	Activate fuel pump	MED 17.7-Motor electronics for direct injection 17.7
SP0228	Correction programming of fuel quantity	MED 17.7-Motor electronics for direct injection 17.7
SP0229	Correction programming of specified idle speed in selector lever position P or N	MED 17.7-Motor electronics for direct injection 17.7
SP0230	Correction programming of specified idle speed with gear range engaged	MED 17.7-Motor electronics for direct injection 17.7
SP0231	Injector injection quantity adjustment	MED 17.7-Motor electronics for direct injection 17.7
SP0232	Resetting of adaptation values	MED 17.7-Motor electronics for direct injection 17.7
SP0233	Teach in of throttle valve stop	MED 17.7-Motor electronics for direct injection 17.7
SP0234	Teach-in process after replacement of the combustion engine	MED 17.7-Motor electronics for direct injection 17.7
SP0235	Activate fuel pump	MED 9.7-Motor electronics for direct injection 9.7
SP0236	Correction programming of fuel quantity	MED 9.7-Motor electronics for direct injection 9.7
SP0237	Correction programming of ignition	MED 9.7-Motor electronics for direct injection 9.7
SP0238	Correction programming of specified idle speed in selector lever position P or N	MED 9.7-Motor electronics for direct injection 9.7
SP0239	Correction programming of specified idle speed with gear range engaged	MED 9.7-Motor electronics for direct injection 9.7
SP0240	Resetting of adaptation data	MED 9.7-Motor electronics for direct injection 9.7
SP0241	Teach in of throttle valve stop	MED 9.7-Motor electronics for direct injection 9.7
SP0242	Teach-in process after replacement of the combustion engine	MED 9.7-Motor electronics for direct injection 9.7

SP0243	Activate system 'SBC'	SBC-Sensotronic Brake Control
SP0244	Response threshold of speed sensors	SBC-Sensotronic Brake Control
SP0245	System 'SBC' deactivated	SBC-Sensotronic Brake Control
SP0246	Initial startup	SCM [MRM]-Steering column module
SP0247	Resetting of operating hours counters of component 'E1(Left front lamp unit)'	SG SW L-Left headlamp
SP0248	Zero position adjustment	SG SW L-Left headlamp
SP0249	Resetting of operating hours counters of component 'E2(Right front lamp unit)'	SG SW R-Right headlamp
SP0250	Resetting of operating hours counters of component 'Xenon headlamp, left'	SG SW-Control unit 'Headlamp'
SP0251	Resetting of operating hours counters of component 'Xenon headlamp, right'	SG SW-Control unit 'Headlamp'
SP0252	Zero position adjustment	SG SW-Control unit 'Headlamp'
SP0253	Initial startup with automatic takeover of settings of previous control unit	Suspension
SP0254	Initial startup with manual settings input for new control unit/Level calibration	Suspension
SP0255	Reset compressor operating time	Suspension
SP0256	Reset of operating hours counter	XALWA L-Xenon headlamp, left
SP0257	EP:Reset of operating hours counter	XALWA R-Xenon headlamp, right
SP0258	Reset of operating hours counter	XALWA R-Xenon headlamp, right
SP0300	Road test	"ABR-Adaptive Brake"
SP0301	Tire pressure loss warnerActivating	"ABR-Adaptive Brake"
SP0302	Erase zero point offset error of component N49 (Steering angle sensor).	"ABR-Adaptive Brake"
SP0303	Calibration of control unit N47-5 (ESP control unit)	"ABR-Adaptive Brake"
SP0304	Tourist mode-Adaptation of headlamps from left-hand traffic system to right-hand traffic system or	"XALWA L-Xenon headlamp, left"
SP0305	Resetting operating hours counter	"XALWA L-Xenon headlamp, left"
SP0306	Tourist mode-Adaptation of headlamps from left-hand traffic system to right-hand traffic system or	"XALWA L-Xenon headlamp, left"
SP0307	Resetting operating hours counter	"XALWA L-Xenon headlamp, left"
SP0308	Tourist mode-Adaptation of headlamps from left-hand traffic system to right-hand traffic system or	"XALWA R-Xenon headlamp, right"
SP0309	Resetting operating hours counter	"XALWA R-Xenon headlamp, right"
SP0310	Tourist mode-Adaptation of headlamps from left-hand traffic system to right-hand traffic system or	"XALWA R-Xenon headlamp, right"
SP0311	Resetting operating hours counter	"XALWA R-Xenon headlamp, right"
SP0312	Adjustment of injector injection quantities	"CDI 60LS-Common Rail Diesel Injection"
SP0313	Regeneration of diesel particulate filter when driving	"CDI 60LS-Common Rail Diesel Injection"
SP0314	Teaching in the diesel particulate filter after replacing the engine control unit	"CDI 60LS-Common Rail Diesel Injection"
SP0315	Teach-in process after replacement of component Diesel particulate filter	"CDI 60LS-Common Rail Diesel Injection"
SP0316	Teach-in process after replacement of component SCR-Catalytic converter	"CDI 60LS-Common Rail Diesel Injection"
SP0317	Learning of the throttle valve stop	"CDI 60LS-Common Rail Diesel Injection"
SP0318	Teach-in process after replacement of component Diesel oxidation catalytic converter	"CDI 60LS-Common Rail Diesel Injection"
SP0319	Teach-in process after replacement of component B16/15 (Temperature sensor upstream of SCR catalytic converter)	"CDI 60LS-Common Rail Diesel Injection"

SP0320	Teach-in process after replacement of component B28/8 (Pressure differential sensor (DPF))	"CDI 60LS-Common Rail Diesel Injection"
SP0321	Teach-in process after replacement of component G3/2 (O2 sensor upstream of KAT)	"CDI 60LS-Common Rail Diesel Injection"
SP0322	Teach-in process after replacement of component NOx sensor	"CDI 60LS-Common Rail Diesel Injection"
SP0323	Teach-in process after replacement of component Y74 (Pressure control valve)	"CDI 60LS-Common Rail Diesel Injection"
SP0324	Teach-in process after replacement of component Y129 (AdBlue? metering valve)	"CDI 60LS-Common Rail Diesel Injection"
SP0325	Activate fuel pump.	"CDI 60LS-Common Rail Diesel Injection"
SP0326	Reset quantity mean value adaptation data.	"CDI 60LS-Common Rail Diesel Injection"
SP0327	Rapid teach-in of zero quantity calibration values	"CDI 60LS-Common Rail Diesel Injection"
SP0328	Reset values for HFM drift compensation.	"CDI 60LS-Common Rail Diesel Injection"
SP0329	Resetting air filter learned values after air filter replacement	"CDI 60LS-Common Rail Diesel Injection"
SP0330	Cancellation of limitation of engine starts(USA)/Cancellation of limitation of remaining distance	"CDI 60LS-Common Rail Diesel Injection"
SP0331	Reset of fault message 'Fault in AdBlue system' in instrument cluster	"CDI 60LS-Common Rail Diesel Injection"
SP0332	Injector injection quantity adjustment (manual input)	"CDI 3-Common Rail Diesel Injection3"
SP0333	Injector injection quantity adjustment (input via data scanner)	"CDI 3-Common Rail Diesel Injection3"
SP0334	Regeneration of diesel particulate filter	"CDI 3-Common Rail Diesel Injection3"
SP0335	Regeneration of diesel particulate filter when driving	"CDI 3-Common Rail Diesel Injection3"
SP0336	Activate fuel pump.	"CDI 3-Common Rail Diesel Injection3"
SP0337	Resetting air filter learned values after air filter replacement	"CDI 3-Common Rail Diesel Injection3"
SP0338	Teach-in process after replacement of component Diesel particulate filter	"CDI 3-Common Rail Diesel Injection3"
SP0339	Teaching in the diesel particulate filter after replacing the engine control unit	"CDI 3-Common Rail Diesel Injection3"
SP0340	Teach in component M16/6 (Throttle valve actuator).	"CDI 3-Common Rail Diesel Injection3"
SP0341	Teach in component M55 (Inlet port shutoff motor).	"CDI 3-Common Rail Diesel Injection3"
SP0342	Teach in component Y77/1 (Charge pressure positioner).	"CDI 3-Common Rail Diesel Injection3"
SP0343	Resetting the lambda values	"CDI 3-Common Rail Diesel Injection3"
SP0344	Detach the transport protection of control module ISM, personalize or activate the control module.	"ISM-Shift module"
SP0345	Disable key or key track.	"EZS-Electronic ignition switch"
SP0346	Disable key or key track with the workshop key.	"EZS-Electronic ignition switch"
SP0347	Once again authorize key or key track.	"EZS-Electronic ignition switch"
SP0348	Program replacement keys.	"EZS-Electronic ignition switch"
SP0349	Activate control module N73 (EIS [EZS] control unit).	"EZS-Electronic ignition switch"
SP0350	Test procedure for voltage comparison	"SG EM-Electric motor control unit"
SP0351	Test procedure for rpm comparison	"SG EM-Electric motor control unit"
SP0352	Normalizing of positioning motors	"AAC-Automatic air conditioning"
SP0353	Check of adjustment range of positioning motors	"AAC-Automatic air conditioning"
SP0354	Teach-in of actuator motors after actuator motor replacement	"AAC-Automatic air conditioning"
SP0355	Breaking-in procedure after replacement of refrigerant compressor	"AAC-Automatic air conditioning"
SP0356	Teach-in of rotary potentiometers for the air outlets	"AAC-Automatic air conditioning"

SP0357	Level calibration	"AIRmatic"
SP0358	Activate fuel pump.	"ME SF 17.7-Motor electronics 17.7"
SP0359	Learning of the throttle valve stop	"ME SF 17.7-Motor electronics 17.7"
SP0360	Teach in of drive authorization system	"ME SF 17.7-Motor electronics 17.7"
SP0361	Teach-in process after engine replacement	"ME SF 17.7-Motor electronics 17.7"
SP0362	Resetting of adaptation data	"ME SF 17.7-Motor electronics 17.7"
SP0363	Resetting the cold-start adaptation values	"ME SF 17.7-Motor electronics 17.7"
SP0364	Sensor rotor adaptation	"ME SF 17.7-Motor electronics 17.7"
SP0365	Activate fuel pump.	"ME 2.7.2-Motor electronics 2.7.2"
SP0366	Teach in of drive authorization system	"ME 2.7.2-Motor electronics 2.7.2"
SP0367	Resetting of mixture adaptation	"ME 2.7.2-Motor electronics 2.7.2"
SP0368	Reset lambda adaptation	"ME 2.7.2-Motor electronics 2.7.2"
SP0369	Default initialization	"ME 2.7.2-Motor electronics 2.7.2"
SP0370	Activate fuel pump.	"ME 2.7.2-Motor electronics 2.7.2"
SP0371	Teach in of drive authorization system	"ME 2.7.2-Motor electronics 2.7.2"
SP0372	Resetting of mixture adaptation	"ME 2.7.2-Motor electronics 2.7.2"
SP0373	Reset lambda adaptation	"ME 2.7.2-Motor electronics 2.7.2"
SP0374	Default initialization	"ME 2.7.2-Motor electronics 2.7.2"
SP0375	Activate fuel pump.	"ME 9.7-Motor electronics 9.7"
SP0376	Learning of the throttle valve stop	"ME 9.7-Motor electronics 9.7"
SP0377	Teach in of drive authorization system	"ME 9.7-Motor electronics 9.7"
SP0378	Teach-in process after engine replacement	"ME 9.7-Motor electronics 9.7"
SP0379	Resetting of adaptation data	"ME 9.7-Motor electronics 9.7"
SP0380	Resetting the cold-start adaptation values	"ME 9.7-Motor electronics 9.7"
SP0381	Sensor rotor adaptation	"ME 9.7-Motor electronics 9.7"
SP0382	Activate fuel pump.	"ME 9.7 (AMG)-Motor electronics 9.7 (AMG)"
SP0383	Learning of the throttle valve stop	"ME 9.7 (AMG)-Motor electronics 9.7 (AMG)"
SP0384	Teach in of drive authorization system	"ME 9.7 (AMG)-Motor electronics 9.7 (AMG)"
SP0385	Teach-in of camshaft positions	"ME 9.7 (AMG)-Motor electronics 9.7 (AMG)"
SP0386	Resetting of adaptation data	"ME 9.7 (AMG)-Motor electronics 9.7 (AMG)"
SP0387	Resetting the cold-start adaptation values	"ME 9.7 (AMG)-Motor electronics 9.7 (AMG)"
SP0388	Sensor rotor adaptation	"ME 9.7 (AMG)-Motor electronics 9.7 (AMG)"
SP0389	Activate fuel pump.	"MED 17.7-Motor electronics for direct injection 17.7"
SP0390	Learning of the throttle valve stop	"MED 17.7-Motor electronics for direct injection 17.7"
SP0391	Teach in of drive authorization system	"MED 17.7-Motor electronics for direct injection 17.7"
SP0392	Teach-in process after engine replacement	"MED 17.7-Motor electronics for direct injection 17.7"
SP0393	Teach in ethanol portion in fuel.	"MED 17.7-Motor electronics for direct injection 17.7"

SP0394	Teach-in process for component M16/45 (EGR [ARF] actuator motors)	"MED 17.7-Motor electronics for direct injection 17.7"
SP0395	Resetting of adaptation data	"MED 17.7-Motor electronics for direct injection 17.7"
SP0396	Resetting the cold-start adaptation values	"MED 17.7-Motor electronics for direct injection 17.7"
SP0397	Resetting the reading of the counter for ethanol teach-in processes	"MED 17.7-Motor electronics for direct injection 17.7"
SP0398	Sensor rotor adaptation	"MED 17.7-Motor electronics for direct injection 17.7"
SP0399	Quick test of mixture adaptation	"MED 17.7-Motor electronics for direct injection 17.7"
SP0400	Enabling of engine start after crash event	"MED 17.7-Motor electronics for direct injection 17.7"
SP0401	Steering column module	"Dr side SAM-Driver signal acquisition and actuation module"
SP0402	Road test	"ABR-Adaptive Brake"
SP0403	Tire pressure loss warner	"ABR-Adaptive Brake"
SP0404	Erase zero point offset error of component Steering angle sensor.	"ABR-Adaptive Brake"
SP0405	Calibration of control unit ABR	"ABR-Adaptive Brake"
SP0406	Refill AdBlue.	"SCR-Selective Catalytic Reduction"
SP0407	Erasing adaptation values after replacement of AdBlue fluid	"SCR-Selective Catalytic Reduction"
SP0408	Teach-in process after replacement of component Y129 (AdBlue? metering valve)	"SCR-Selective Catalytic Reduction"
SP0409	Cancellation of limitation of engine starts-Cancellation of limitation of remaining distance	"SCR-Selective Catalytic Reduction"
SP0410	Reset of fault message 'Fault in AdBlue system' in instrument cluster	"SCR-Selective Catalytic Reduction"
SP0411	Normalizing-Rear left and right	"ESA R-Electric seat adjustment rear"
SP0412	Normalization of all seat adjustment motors	"ESA FL-Electric seat adjustment front left"
SP0413	Change standard distance of travel.	"ESA FL-Electric seat adjustment front left"
SP0414	Adjust end of forward range.	"ESA FL-Electric seat adjustment front left"
SP0415	Adjust end of forward range.	"ESA FL-Electric seat adjustment front left"
SP0416	Adjust beginning of rearward range	"ESA FL-Electric seat adjustment front left"

SP0417	Normalization of all seat adjustment motors	"ESA FR-Electric seat adjustment front right"
SP0418	Change standard distance of travel.	"ESA FR-Electric seat adjustment front right"
SP0419	Adjust end of forward range.	"ESA FR-Electric seat adjustment front right"
SP0420	Adjust end of forward range.	"ESA FR-Electric seat adjustment front right"
SP0421	Adjust beginning of rearward range	"ESA FR-Electric seat adjustment front right"
SP0422	Write wheel electronics identification number.	"TPM-Tire pressure monitor"
SP0423	Write specified tire pressure values.	"TPM-Tire pressure monitor"
SP0424	Initialization of power closing	"DCM RL-Door control module rear left"
SP0425	Initialization of power closing	"DCM RR-Door control module rear right"
SP0426	Initialization of power closing	"DCM FL-Door control module front left"
SP0427	Initialization of power closing	"DCM FR-Door control module front right"
SP0428	Teach-in process for anti-pinch protection function of panoramic sliding sunroofRoller sun blind	"PSD-Panoramic sliding roof(Interior CAN bus)"
SP0429	Performing adaptation(Wet start-off clutch (NAK))	"ETC-Electronic transmission control"
SP0430	Adaptation values of shift 1-2:	"ETC-Electronic transmission control"
SP0431	Adaptation values of shift 2-3:	"ETC-Electronic transmission control"
SP0432	Adaptation values of shift 3-4:	"ETC-Electronic transmission control"
SP0433	Adaptation values of shift 4-5:	"ETC-Electronic transmission control"
SP0434	Adaptation values of shift 5-6:	"ETC-Electronic transmission control"
SP0435	Adaptation values of shift 6-7:	"ETC-Electronic transmission control"
SP0436	Resetting of adaptation data	"ETC-Electronic transmission control"
SP0437	Adaptation values of shift 7-6:	"ETC-Electronic transmission control"
SP0438	Adaptation values of shift 6-5:	"ETC-Electronic transmission control"
SP0439	Adaptation values of shift 5-4:	"ETC-Electronic transmission control"
SP0440	Adaptation values of shift 4-3:	"ETC-Electronic transmission control"
SP0441	Adaptation values of shift 3-2:	"ETC-Electronic transmission control"
SP0442	Adaptation values of shift 2-1:	"ETC-Electronic transmission control"
SP0443	Resetting of adaptation data	"ETC-Electronic transmission control"
SP0444	Reverse gear	"ETC-Electronic transmission control"
SP0445	UPSHIFT	"ETC-Electronic transmission control"
SP0446	DOWNSHIFT	"ETC-Electronic transmission control"
SP0447	Acceleration downshifts	"ETC-Electronic transmission control"
SP0448	Resetting of adaptation data(Torque converter lockup clutch)	"ETC-Electronic transmission control"
SP0449	Adaptation via torque ranges	"ETC-Electronic transmission control"
SP0450	Fill time adaptation of the torque converter lockup clutch	"ETC-Electronic transmission control"
SP0451	Thrust-Program	"ETC-Electronic transmission control"
SP0452	ASSYST settings	"ASSYST-Active Service System"
SP0453	Re-initialization of AdBlue range	"ASSYST-Active Service System"

SP0454	Learning component A8/3 (STH radio remote control transmitter)	"ASSYST-Active Service System"
SP0455	Adaptation of the gearshifts	"ETC-Electronic transmission control"
SP0456	Upshifts	VGS-Fully integrated transmission control
SP0457	Downshifts	VGS-Fully integrated transmission control
SP0458	Acceleration downshifts	VGS-Fully integrated transmission control
SP0459	Standstill adaptation	VGS-Fully integrated transmission control
SP0460	Upshifts	VGS-Transmission control for 7-speed transimssion
SP0461	Downshifts	VGS-Transmission control for 7-speed transimssion
SP0462	Acceleration downshifts	VGS-Transmission control for 7-speed transimssion
SP0463	Standstill adaptation	VGS-Transmission control for 9-speed transimssion
SP0464	Adaptation procedure for torque converter lockup clutch	VGS-Transmission control for 9-speed transimssion
SP1000	Injector injection quantity adjustment	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1001	Activation of fuel pump	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1002	Teach-in of drive authorization system	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1003	Teach-in of intake port shutoff	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1004	Teach in of throttle valve stop	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1005	Teach-in process of component "B28/8 (DPF differential pressure sensor)"	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1006	Resetting of learned values of component "B6/1 (Camshaft Hall sensor)"	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1007	B79/2 (Transmission neutral position sensor)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1008	Teach in component "Y77/1 (Boost pressure positioner)".	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1009	Quick teach-in of values of zero quantity calibration	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1010	Quick teach-in of the zero quantity calibration values at idle	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1011	Quick teach-in of the zero quantity calibration values while driving	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1012	Reset values of HFM drift compensation.	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1013	Resetting of contamination level of air filter	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1014	Oxidation catalytic converter	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1015	Teach-in of diesel particulate filter after replacement of control unit "N3/9 (CDI control unit)"	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1016	Teach-in process after replacement of component "Diesel particulate filter"	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1017	Enabling of engine start after crash event	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1018	Bleeding of high-pressure fuel circuit	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1019	Perform teach-in process for component "Y129 (AdBlue?metering valve)".	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1020	Perform teach-in process for component "B16/15 (Temperature sensor upstream of SCR catalytic	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1021	Reset learned values of components "NOx sensor upstream of SCR catalytic converter" and "NOx	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1022	Reset learned values for AdBlue?metering.	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1023	Teach-in process after replacement of component "SCR catalytic converter"	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1024	Resetting of learned values of component "M16/46 (Low-pressure exhaust gas recirculation actuator	N3/9-Motor electronics "CDID3" for combustion engine "OM651"

SP1025	Activate fuel pump.	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1026	Teach-in process of component "B53/1 (Clutch pedal sensor)"	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1027	Resetting learned values "Exhaust gas recirculation (low pressure)"	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1028	Teach-in process after replacement of diesel particulate filter combined with NOx storage catalytic	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1029	Teach-in of diesel particulate filter combined with NOx storage catalytic converter after replacement	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
SP1030	Status of teach-in processes	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1031	Teach-in of drive authorization system	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1032	Regeneration of the diesel particulate filter while driving	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1033	Injector injection quantity adjustment	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1034	Resetting of learned values of component "Fuel injectors"	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1035	Teach in component "M16/6 (Throttle valve actuator)".	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1036	Teach in component "Y27/8 (Exhaust gas recirculation actuator, high pressure)".	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1037	Teach in component "Y27/7 (Exhaust gas recirculation actuator, low pressure)".	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1038	Teach in component "M16/57 (Exhaust flap controller)".	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1039	Resetting of learned values of component "B4/6 (Rail pressure sensor)"	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1040	Resetting of learned values of component "Fuel system high pressure pump"	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1041	Resetting of learned values of component "B28/8 (Differential pressure sensor (DPF))"	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1042	Resetting of learned values of component "G3/2 (Oxygen sensor upstream of catalytic converter)"	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1043	Resetting of learned values of component "Turbocharger"	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1044	Resetting of learned values of component "Diesel particulate filter"	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1045	Activation of fuel pump	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1046	B79/3 (Manual transmission main shifter shaft position sensor)	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
SP1047	Confirmation of general maintenance	IC-Instrument cluster
SP1048	Reset general maintenance.	IC-Instrument cluster
SP1049	Activation	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
SP1050	Deactivation	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
SP1051	Teach-in of a spare key	EZS-Electronic ignition switch
SP1052	Activation of control unit "N73 (Electronic ignition lock control unit)"	EZS-Electronic ignition switch
SP1053	Initial startup:ESL [ELV]	EZS-Electronic ignition switch
SP1054	Activate function "Tire pressure loss warning".	ESP-Electronic stability program(N30/4)
SP1055	Calibration of component "Acceleration sensor"	ESP-Electronic stability program(N30/4)
SP1056	Write identification numbers of tire pressure sensors.	TPM-Tire pressure monitor(N88)
SP1057	Activate comfort telephony.	AUDIO-Audio or COMAND(A2-A40/3)
SP1058	Comfort telephony	AUDIO-Audio or COMAND(A2-A40/3)
SP1059	Pairing:Audio or COMAND-mbrace(Internet connection)	AUDIO-Audio or COMAND(A2-A40/3)

SP1060	Restore initial authorization certificate for VPN connection.	AUDIO-Audio or COMAND(A2-A40/3)
SP1061	Teach-in process"Current date(GPS data)"	AUDIO-Audio or COMAND(A2-A40/3)
SP1062	Resetting of learned values of component "A90 (COLLISION PREVENTION ASSIST controller	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)
SP1063	Calibration of microphone for sound system	SOUND-Bose sound system
SP1064	Level calibration	ADS-Adaptive damping system(N51/5)
SP1065	N121/1 (Liftgate control control unit)	HKS-Tailgate control
SP1066	Calibration	MFK-Multifunction camera
SP1067	Calibration	MFK-Multifunction camera(A40/11)
SP1068	Retrofitting	MFK-Multifunction camera(A40/11)
SP1069	Normalization of actuator motors	AAC-Automatic air conditioning
SP1070	Teach-in of actuator motors	AAC-Automatic air conditioning
SP1071	Breaking-in of refrigerant compressor	AAC-Automatic air conditioning
SP1072	Teach in component "A8/3 (Stationary heater radio remote control transmitter)".	STH-Stationary heater
SP1073	Calibration of component "A91b1 (Electric power steering torque sensor)"	ES-Electrical power steering(N68)
SP1074	Resetting the center position of the steering	ES-Electrical power steering(N68)
SP1075	Reset of coding	ES-Electrical power steering(N68)
SP1076	Teach-in process of anti-pinch protection	PSD-Control module 'Panoramic sliding roof '(A98)
SP1077	Coding	HUD-Head up display
SP1078	Normalization and adaptation	ESV Driver-Electric seat adjustmnet Driver with memory function
SP1079	Normalization	ESV Driver-Electric seat adjustmnet Driver with memory function
SP1080	Normalization and adaptation	ESV Front passenger-Electric seat adjustment Front passenger with memory
SP1081	Normalization	ESV Front passenger-Electric seat adjustment Front passenger with memory
SP1082	Initial startup	TRM-Trailer recognition module (N28/1)
SP1083	Erasing of initialization values	TRM-Trailer recognition module (N28/1)
SP1084	Calibration of long range radar sensor	DTR-DISTRONIC (A89)
SP1085	Normalization of power window	LFD-Left front door
SP1086	Normalization of power window	DCU RF-Right front door
SP1087	Calibration of control unit "N128 (Electric parking brake control unit)"	EFB-Electronic parking brake(N128)
SP1088	Calibration of steering angle sensor	RFK-Backup camera
SP1089	Calibration of reversing camera	RFK-Backup camera
SP1090	Zero position adjustment	SG SW-Control unit 'Headlamp'(N71/1)
SP1091	Resetting the operating hours counter of component "Left xenon headlamp"	SG SW-Control unit 'Headlamp'(N71/1)
SP1092	Resetting the operating hours counter of component "Right xenon headlamp"	SG SW-Control unit 'Headlamp'(N71/1)
SP1093	Tourist mode	SG SW-Control unit 'Headlamp'(N71/1)
SP1094	Zero position adjustment	SG SW L-Left headlamp

SP1095	Adjustment of headlamps via diagnosis	SG SW L-Left headlamp
SP1096	Resetting of operating hours counters of component "E1 (Left front lamp unit)"	SG SW L-Left headlamp
SP1097	Resetting of operating hours counters of component "E1m4 (Left front lamp unit fan motor 1)"	SG SW L-Left headlamp
SP1098	Adaptation of codings of control units to lamp unit	SG SW L-Left headlamp
SP1099	Adaptation of coding of control unit to lamp unit	SG SW L-Left headlamp
SP1100	Resetting of assignment of control unit "E1n9" to vehicle side	SG SW L-Left headlamp
SP1101	Zero position adjustment	SG SW L-Left headlamp(E1n9)
SP1102	Adjustment of headlamps via diagnosis	SG SW L-Left headlamp(E1n9)
SP1103	Resetting of operating hours counters of component "E1 (Left front lamp unit)"	SG SW L-Left headlamp(E1n9)
SP1104	Resetting of operating hours counters of component "E1m4 (Left front lamp unit fan motor 1)"	SG SW L-Left headlamp(E1n9)
SP1105	Resetting of operating hours counters of component "E1m5 (Left front lamp unit fan motor 2)"	SG SW L-Left headlamp(E1n9)
SP1106	Adaptation of codings of control units to lamp unit	SG SW L-Left headlamp(E1n9)
SP1107	Adaptation of coding of control unit to lamp unit	SG SW L-Left headlamp(E1n9)
SP1108	Resetting of assignment of control unit "E1n9" to vehicle side	SG SW L-Left headlamp(E1n9)
SP1109	Resetting of operating hours counters of component "E2 (Right front headlamp unit)"	SG SW R-Right headlamp
SP1110	Resetting of operating hours counters of component "E2m4 (Right front lamp unit fan motor 1)"	SG SW R-Right headlamp
SP1111	Resetting of operating hours counters of component "E2m5 (Right front lamp unit fan motor 2)"	SG SW R-Right headlamp
SP1112	Adaptation of codings of control units to lamp unit	SG SW R-Right headlamp
SP1113	Adaptation of coding of control unit to lamp unit	SG SW R-Right headlamp
SP1114	Resetting of assignment of control unit "E1n9" to vehicle side	SG SW R-Right headlamp
SP1115	Adaptation of codings of control units to lamp unit	SG SW R-Right headlamp(E1n9)
SP1116	Adaptation of coding of control unit to lamp unit	SG SW R-Right headlamp(E1n9)
SP1117	Resetting of assignment of control unit "E1n9" to vehicle side	SG SW R-Right headlamp(E1n9)
SP1118	Resetting of operating hours counters of component "E2 (Right front headlamp unit)"	SG SW R-Right headlamp(E1n9)
SP1119	Resetting of operating hours counters of component "E2m4 (Right front lamp unit fan motor 1)"	SG SW R-Right headlamp(E1n9)
SP1120	Resetting of operating hours counters of component "E2m5 (Right front lamp unit fan motor 2)"	SG SW R-Right headlamp(E1n9)
SP1121	Parameterization and adaptation of windshield	B38/2-Rain/light sensor(RGLS)
SP1122	Resetting the oil service data	VG-All wheel drive
SP1123	Replacement of component "Transfer case"	VG-All wheel drive
SP1124	Function test of component "Y68/3 (All-wheel drive solenoid valve)" while driving	VG-All wheel drive
SP1125	Resetting of learned values of component "Y68/3 (All-wheel drive solenoid valve)"	VG-All wheel drive
SP1126	Normalization and adaptation	DKG-Electronic transmission control for double-plate clutch transmission
SP1127	Teach-in of drive authorization system	DKG-Electronic transmission control for double-plate clutch transmission
SP1128	Display of EEPROM values	DKG-Electronic transmission control for double-plate clutch transmission
SP1129	B28/18 (Low-pressure exhaust gas recirculation differential pressure sensor)	N127 (Drivetrain control unit)

SP1130	Teach in component "M16/46 (Low-pressure exhaust gas recirculation actuator motor)".	N127 (Drivetrain control unit)
SP1131	Teach in component "M16/57 (Exhaust flap controller actuator motor)".	N127 (Drivetrain control unit)
SP1132	B79/3 (Manual transmission main shifter shaft position sensor)	PTCU-Common powertrain controller(N127)
SP1133	Resetting reading of frequency counter for ethanol teach-in processes	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1134	Enabling of engine start after crash event	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1135	Reset of mixture adaptation values	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1136	Resetting of values for sensor rotor adaptation	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1137	Resetting of learned values of component "Gasoline particulate filter"	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1138	Reset learned values for diagnosis of CAN bus through control unit "N3/10 (ME-SFI [ME] control	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1139	B79/2 (Transmission neutral position sensor)	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1140	Teaching in the ethanol proportion in the fuel	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1141	Teach-in of exhaust gas recirculation actuator	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1142	Activation of fuel pump	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1143	Teach in of throttle valve stop	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1144	Perform teach-in process "Sensor rotor adaptation".	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1145	Teach-in of drive authorization system	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1146	Status of teach-in processes	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1147	B79/3 (Manual transmission main shifter shaft position sensor)	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1148	Teach-in of positions for camshafts	N3/10-Motor electronics "MED40" for combustion engine "M274"
SP1149	Activation of fuel pump	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
SP1150	Teach-in of drive authorization system	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
SP1151	Teach in of throttle valve stop	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
SP1152	Teach-in of positions for camshafts	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
SP1153	Resetting of adaptation values	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
SP1154	Status of teach-in processes	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
SP1155	Enabling of engine start after crash event	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
SP1156	Resetting of learned values of component "Gasoline particulate filter"	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
SP1157	Special maintenance	IC-Instrument cluster
SP1158	Calibration of 360?camera at front end	CAMERA-360 camera(N148)
SP1159	Calibration of 360?camera at rear end	CAMERA-360 camera(N148)
SP1160	Calibration of 360?camera in left outside mirror	CAMERA-360 camera(N148)
SP1161	Calibration of 360?camera in right outside mirror	CAMERA-360 camera(N148)
SP1162	Calibration of multiple 360?cameras	CAMERA-360 camera(N148)
SP1163	Calibration of steering angle sensor	CAMERA-360 camera(N148)
SP1164	Injector injection quantity adjustment	N3/9-Motor electronics "CR43" for combustion engine "OM651"

SP1165	Activate fuel pump.	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1166	Teach-in of drive authorization system	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1167	Teach-in of intake port shutoff	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1168	Teach in of throttle valve stop	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1169	Perform teach-in process for component "B16/15 (Temperature sensor upstream of SCR catalytic	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1170	Perform teach-in process for component "B28/8 (DPF differential pressure sensor)".	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1171	Teach-in process of component "B79/2 (Transmission neutral position sensor)"	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1172	Teach-in process of component "G3/2 (Oxygen sensor upstream of catalytic converter)"	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1173	Teach-in process of component "M16/46 (Low-pressure exhaust gas recirculation actuator motor)"	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1174	Perform teach-in process for component "Y129 (AdBlue?metering valve)".	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1175	Teach-in process of component "Y74 (Pressure regulating valve)"	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1176	Teach-in process of component "Y94 (Quantity control valve)"	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1177	Quick teach-in of values of zero quantity calibration	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1178	Reset values of quantity mean value adaptation.	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1179	Reset values of HFM drift compensation.	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1180	Resetting of contamination level of air filter	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1181	Teach-in process after replacement of component "Oxidation catalytic converter"	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1182	Teach-in of diesel particulate filter after replacement of control unit "N3/9 (CDI control unit)"	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1183	Teach-in process after replacement of component "Diesel particulate filter"	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1184	Reset learned values of components "NOx sensor upstream of SCR catalytic converter" and "NOx	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1185	Reset learned values for AdBlue?metering.	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1186	Teach-in process after replacement of component "SCR catalytic converter"	N3/9-Motor electronics "CR43" for combustion engine "OM651"
SP1187	Injector injection quantity adjustment	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1188	Activate fuel pump.	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1189	Teach-in of drive authorization system	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1190	Teach in of throttle valve stop	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1191	Perform teach-in process for component "B16/15 (Temperature sensor upstream of SCR catalytic	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1192	Teach-in process after replacement of component "B28/8 (DPF differential pressure sensor)"	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1193	Teach-in process after replacement of component "G3/2 (Oxygen sensor upstream of catalytic	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1194	Perform teach-in process for component "Y129 (AdBlue?metering valve)".	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1195	Teach-in process after replacement of component "Y74 (Pressure regulating valve)"	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1196	Quick teach-in of values of zero quantity calibration	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1197	Reset values of quantity mean value adaptation.	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1198	Reset values of HFM drift compensation.	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1199	Resetting of contamination level of air filter	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"

SP1200	Teach-in process after replacement of component "Oxidation catalytic converter"	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1201	Teach-in of diesel particulate filter after replacement of control unit "N3/9 (CDI control unit)"	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1202	Teach-in process after replacement of component "Diesel particulate filter"	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1203	Teach-in process after replacement of component "SCR catalytic converter"	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1204	Reset learned values of components "NOx sensor upstream of SCR catalytic converter" and "NOx	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1205	Reset learned values for AdBlue?metering.	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
SP1206	Injector injection quantity adjustment	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1207	Activate fuel pump.	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1208	Teach in of throttle valve stop	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1209	Teach-in of drive authorization system	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1210	Quick teach-in of values of zero quantity calibration	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1211	Teach-in process after replacement of component "B28/8 (DPF differential pressure sensor)"	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1212	Teach-in process after replacement of component "G3/2 (Oxygen sensor upstream of catalytic	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1213	Teach-in process after replacement of component "Y74 (Pressure regulating valve)"	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1214	Teach-in process after replacement of component "Diesel particulate filter"	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1215	Teach-in of diesel particulate filter after replacement of control unit "N3/9 (CDI control unit)"	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1216	Teach-in process after replacement of combined diesel particulate filter with oxidation catalytic	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1217	Teach-in of combined diesel particulate filter with oxidation catalytic converter after replacement of	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1218	Teach-in process after replacement of component "Oxidation catalytic converter"	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1219	Teach-in of oxidation catalytic converter after replacement of control unit "N3/9 (CDI control unit)"	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1220	Perform teach-in process for component "Y129 (AdBlue?metering valve)".	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1221	Teach-in process after replacement of component "SCR catalytic converter"	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1222	Perform teach-in process for component "B16/15 (Temperature sensor upstream of SCR catalytic	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1223	Reset values of HFM drift compensation.	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1224	Reset values of quantity mean value adaptation.	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1225	Resetting of contamination level of air filter	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1226	Reset learned values of components "NOx sensor upstream of SCR catalytic converter" and "NOx	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1227	Reset learned values for AdBlue?metering.	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1228	Reset learned values for diagnosis of CAN bus through control unit "N3/9 (CDI control unit)".	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
SP1229	Adaptation of component "Torque converter lockup clutch"	Y3/8n4-Fully integrated transmission control
SP1230	Adaptation of wet start-up clutch (NAK)	Y3/8n4-Fully integrated transmission control
SP1231	Extended adaptation of "Wet clutch" component when driving	Y3/8n4-Fully integrated transmission control
SP1232	Assignment of hydraulic shift elements	Y3/8n4-Fully integrated transmission control
SP1233	Upshifts	Y3/8n4-Fully integrated transmission control
SP1234	Downshifts	Y3/8n4-Fully integrated transmission control

SP1235	Acceleration downshifts	Y3/8n4-Fully integrated transmission control
SP1236	Standstill adaptation	Y3/8n4-Fully integrated transmission control
SP1237	Adaptation values of shift operations	Y3/8n4-Fully integrated transmission control
SP1238	Resetting the service life data of the torque converter	Y3/8n4-Fully integrated transmission control
SP1239	Resetting of service life data of automatic transmission	Y3/8n4-Fully integrated transmission control
SP1240	Resetting learned values "Deceleration mode"	Y3/8n4-Fully integrated transmission control
SP1241	Teach-in of drive authorization system	Y3/8n4-Fully integrated transmission control
SP1242	Teach-in of selection range sensor	Y3/8n4-Fully integrated transmission control
SP1243	Teach-in of position sensor of park pawl	Y3/8n4-Fully integrated transmission control
SP1244	Assignment of hydraulic shift elements	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
SP1245	Adaptation procedure for torque converter lockup clutch	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
SP1246	Adaptation of wet start-up clutch (NAK)	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
SP1247	Upshifts	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
SP1248	Downshifts	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
SP1249	Acceleration downshifts	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
SP1250	Shift	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
SP1251	Reverse gear	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
SP1252	Torque converter	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
SP1253	Resetting learned values "Deceleration mode"	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
SP1254	Teach-in of drive authorization system	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
SP1255	Teach-in of selection range sensor	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
SP1256	Teach-in of position sensor of park pawl	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9
SP1257	Shift qualityHistory	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9
SP1258	Resetting the service life data of the shift elements	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9
SP1259	Standstill adaptation	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9
SP1260	Adaptation procedure for torque converter lockup clutch	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9
SP1261	Resetting of learned values of component "Park pawl"	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9
SP1262	Resetting the calculated fill level of the AdBlue?tank	SCR-Selective Catalytic Reduction
SP1263	Teach-in process after replacement of component "AdBlue?metering valve"	SCR-Selective Catalytic Reduction
SP1264	Resetting of adaptation values-Factor for long-term adaptation of SCR exhaust aftertreatment system	SCR-Selective Catalytic Reduction
SP1265	Teach-in process after replacement of component "SCR catalytic converter"	SCR-Selective Catalytic Reduction
SP1266	Resetting the adaptation values of the NOx sensors	SCR-Selective Catalytic Reduction
SP1267	Cancellation of limitation of remaining distance	SCR-Selective Catalytic Reduction
SP1268	Resetting the calculated fill level of the AdBlue?tank	SCR-Selective catalytic reduction
SP1269	Resetting adaptation values of component "A103/2ml (AdBlue?delivery pump)"	SCR-Selective catalytic reduction

SP1270	Calibration of component "A103/1b5 (AdBlue?fill level sensor)"	SCR-Selective catalytic reduction
SP1271	Resetting of adaptation values-Factor for long-term adaptation of SCR exhaust aftertreatment system	SCR-Selective catalytic reduction
SP1272	Teach-in process after replacement of component "AdBlue?metering valve"	SCR-Selective catalytic reduction
SP1273	Teach-in process after replacement of component "SCR catalytic converter"	SCR-Selective catalytic reduction
SP1274	Perform voltage adjustment.	SG EM-Power electronics
SP1275	Reset of "L20 (Electric machine rotor position sensor)" component	SG EM-Power electronics
SP1276	Calculation of average value for transition resistance of ground strap of component "N83/1 (DC/DC	SG EM-Power electronics
SP1277	High-voltage component lock	BMS-Battery management system(N82/2)
SP1278	Reactivate tire pressure loss warning.	ESP-Electronic stability program(N30/4)
SP1279	Calibration of component "A7/3 (Traction system hydraulic unit)"	ESP-Electronic stability program(N30/4)
SP1280	Calibration of component "B24/15 (Yaw rate sensor for lateral and longitudinal acceleration)"	ESP-Electronic stability program(N30/4)
SP1281	Production	ESP-Electronic stability program(N30/4)
SP1282	Reset offset value of signal "Steering angle".	ESP-Regenerative braking system(N30/6)
SP1283	Activate function "Tire pressure loss warning".	ESP-Regenerative braking system(N30/6)
SP1284	Calibrate separation and intake valves in component "A7/3 (Traction system hydraulic unit)".	ESP-Regenerative braking system(N30/6)
SP1285	Teach in component "B37/1 (Pedal angle sensor)".	ESP-Regenerative braking system(N30/6)
SP1286	Resetting the operating hours counter of component "M56 (Vacuum pump)"	ESP-Regenerative braking system(N30/6)
SP1287	Development data	ESP-Regenerative braking system(N30/6)
SP1288	Reset frequency counter "Emergency stop".	SGR-Radar sensors control unit
SP1289	Initial startup of components "B29/2 (Left front bumper DISTRONIC (DTR) sensor)" and "B29/3	SGR-Radar sensors control unit
SP1290	Read out actual values "Offset value of component "Left front short range radar"" and "Offset value of	SGR-Radar sensors control unit
SP1291	Reset learned values.	SGR-Radar sensors control unit
SP1292	Reset of reading of frequency counter "Crash event"	SGR-Radar sensors control unit(N62/1)
SP1293	Initial startup of components "B29/2 (Left front bumper DISTRONIC (DTR) sensor)" and "B29/3	SGR-Radar sensors control unit(N62/1)
SP1294	Read out actual values "Offset value of component "Left front short range radar"" and "Offset value of	SGR-Radar sensors control unit(N62/1)
SP1295	Writing of vehicle identification number	SGR-Radar sensors control unit(N62/1)
SP1296	Reset learned values.	SGR-Radar sensors control unit(N62/1)
SP1297	Reset frequency counter "Emergency stop".	SGR-Radar sensors control unit(N62/1)
SP1298	Calibration of component "N148 (360?camera control unit)"	CAMERA-360 camera(N148)
SP1299	Transfer of calibration values	CAMERA-360 camera(N148)
SP1300	Special measures	CAMERA-360 camera(N148)
SP1301	Reset of compressor operating time	ADS-Adaptive damping system(N51/5)
SP1302	Reset of coding	ES-Electric power steering(N68)
SP1303	Reset learned values.	ES-Electric power steering(N68)
SP1304	Teach-in process of anti-pinch protection	SD-Control module 'Sliding roof' (A98/1)

SP1305	Teach-in process of anti-pinch protection	PSD-Control module 'Panoramic sliding roof'(A98)
SP1306	Calculation of average value for transition resistance of ground strap of component "N83/1 (DC/DC	DDW-DC/DC converter(N83/1)
SP1307	Pairing of Mercedes-Benz headphones	D FOL-Display in left rear passenger compartment
SP1308	Pairing of other headphones(Only for the development department)	D FOL-Display in left rear passenger compartment
SP1309	Manufacturer default setting	D FOL-Display in left rear passenger compartment
SP1310	Currently paired headphones	D FOL-Display in left rear passenger compartment
SP1311	Pairing of Mercedes-Benz headphones(Only for the development department)	D FOL-Display in left rear passenger compartment
SP1312	Calibrate control unit "A80 (Intelligent servo module for DIRECT SELECT)".	ISM-Shift module
SP1313	Teach-in of drive authorization system	ISM-Shift module
SP1314	Variant coding reset	ISM-Shift module
SP1315	Pairing of Mercedes-Benz headphones	D FOR-Display in right rear passenger compartment
SP1316	Pairing of other headphones(Only for the development department)	D FOR-Display in right rear passenger compartment
SP1317	Manufacturer default setting	D FOR-Display in right rear passenger compartment
SP1318	Currently paired headphones	D FOR-Display in right rear passenger compartment
SP1319	Pairing of Mercedes-Benz headphones(Only for the development department)	D FOR-Display in right rear passenger compartment
SP1320	Calibration	NSA-Night View Assist(N101)
SP1321	Normalization of power window	DCU LR-Left rear door(N69/3)
SP1322	Normalization of power window	DCU RR-Right rear door(N69/4)
SP1323	Teach in of sensors	RC-Roll control(B38/2)
SP1324	Calibration of component "N15/7 (Transfer case control module)"	VG-Transfer case
SP1325	Adaptation of codings of control units to lamp unit	E1n7 (Actuation module, LED exterior lighting, left front)
SP1326	Adaptation of coding of control unit to lamp unit	E1n7 (Actuation module, LED exterior lighting, left front)
SP1327	Resetting of operating hours counters of component "E1m5 (Left front lamp unit fan motor 2)"	E1n7 (Actuation module, LED exterior lighting, left front)
SP1328	Adaptation of codings of control units to lamp unit	AMLAB L 2-Actuation module 2, LED exterior lighting, left front(E1n8)
SP1329	Adaptation of coding of control unit to lamp unit	AMLAB L 2-Actuation module 2, LED exterior lighting, left front(E1n8)
SP1330	Resetting of operating hours counters of component "E1m5 (Left front lamp unit fan motor 2)"	AMLAB L 2-Actuation module 2, LED exterior lighting, left front(E1n8)
SP1331	Adaptation of codings of control units to lamp unit	E2n7 (Actuation module, LED exterior lighting, right front)
SP1332	Adaptation of coding of control unit to lamp unit	E2n7 (Actuation module, LED exterior lighting, right front)
SP1333	Adaptation of codings of control units to lamp unit	AMLAB R 2-Actuation module 2, LED exterior lighting, right front(E2n8)
SP1334	Adaptation of coding of control unit to lamp unit	AMLAB R 2-Actuation module 2, LED exterior lighting, right front(E2n8)
SP1335	Reset of mixture adaptation values	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1336	Resetting of values for sensor rotor adaptation	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1337	Enabling of engine start after crash event	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1338	Resetting reading of frequency counter for ethanol teach-in processes	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1339	Resetting learned values of component parts "Left" and "Right" Gasoline particulate filter	N3/10-Motor electronics "MED177" for combustion engine "M276"

SP1340	Resetting of learned values of component "Gasoline particulate filter" Right	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1341	Resetting of learned values of component "Gasoline particulate filter" Left	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1342	Teach-in of drive authorization system	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1343	Teaching in the ethanol proportion in the fuel	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1344	Teach-in of exhaust gas recirculation actuators	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1345	Activate fuel pump.	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1346	Teach-in process after replacement of the combustion engine	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1347	Teach in of throttle valve stop	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1348	Perform teach-in process "Sensor rotor adaptation" during driving operation.	N3/10-Motor electronics "MED177" for combustion engine "M276"
SP1349	Reset of mixture adaptation values	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1350	Resetting of values for sensor rotor adaptation	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1351	Enabling of engine start after crash event	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1352	Resetting reading of frequency counter for ethanol teach-in processes	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1353	Resetting learned values of component parts "Left" and "Right" Gasoline particulate filter	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1354	Resetting of learned values of component "Gasoline particulate filter"Right	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1355	Resetting of learned values of component "Gasoline particulate filter"Left	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1356	Reset learned values for diagnosis of CAN bus through control unit "N3/10 (ME-SFI [ME] control	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1357	Activation of fuel pump	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1358	Teach-in of drive authorization system	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1359	Teach in of throttle valve stop	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1360	Teach-in of exhaust gas recirculation actuators	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1361	Teaching in the ethanol proportion in the fuel	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1362	Teach-in process after replacement of the combustion engine	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1363	Perform teach-in process "Sensor rotor adaptation" during driving operation.	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1364	Teach-in of used fuel injectors	N3/10-Motor electronics "MED177V6LA" for combustion engine
SP1365	Vehicle data	CGW[ZGW]-Central gateway
SP1366	Vehicle data	CGW-Central gateway
SP1367	Reset offset value of signal "Steering angle".	ESP- Electric stability program
SP1368	Activate function "Tire pressure loss warning".	ESP- Electric stability program
SP1369	Calibration of intake valves	ESP- Electric stability program
SP1370	Calibration of separation valves	ESP- Electric stability program
SP1371	Calibrate control unit "N30/4 (Electronic Stability Program control unit)".	ESP- Electric stability program
SP1372	Level calibration	ADS-Adaptive damping system
SP1373	Normalization and adaptation	N32/1 (Driver seat control unit)
SP1374	Normalization	N32/1 (Driver seat control unit)

SP1375	Separate normalization of steering column	N32/1 (Driver seat control unit)
SP1376	Normalization and adaptation	N32/2 (Front passenger seat control unit)
SP1377	Normalization	N32/2 (Front passenger seat control unit)
SP1378	Activation of fuel pump	MED177AMG-Motor electronics 'MED177AMG' for combustion engine
SP1379	Teach in of throttle valve stop	MED177AMG-Motor electronics 'MED177AMG' for combustion engine
SP1380	Teach-in of drive authorization system	MED177AMG-Motor electronics 'MED177AMG' for combustion engine
SP1381	Resetting of adaptation values	MED177AMG-Motor electronics 'MED177AMG' for combustion engine
SP1382	Activate fuel pump.	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
SP1383	Teach in of throttle valve stop	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
SP1384	M59 (Intake manifold swirl flap actuator motor)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
SP1385	Reset of mixture adaptation values	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
SP1386	Teach-in of drive authorization system	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
SP1387	Acceleration of sensor rotor adaptation	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
SP1388	Perform teach-in process for control unit "ME".	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
SP1389	B79/2 (Transmission neutral position sensor)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
SP1390	Activation of fuel pump	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
SP1391	Teach-in of drive authorization system	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
SP1392	Resetting of adaptation values	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
SP1393	Reset of cold start adaptation values	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
SP1394	Sensor rotor adaptation	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
SP1395	Teach-in of positions for camshafts	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
SP1396	Operating time of component "M75/7 (Rear high-voltage battery coolant pump)"	BMS-H-Battery management system, rear (master)
SP1397	M75/7 (Rear high-voltage battery coolant pump)	BMS-H-Battery management system, rear (master)
SP1398	Unlock high-voltage component lock.	BMS-H-Battery management system, rear (master)
SP1399	Reset of control unit "N82/8 (Rear battery management system control unit (slave))"	BMS-H-Battery management system, rear (master)
SP1400	Confirmation of general maintenance	IC-Instrument cluster(A1)
SP1401	Reset general maintenance.	IC-Instrument cluster(A1)
SP1402	Road test	ESP-Electronic stability program(N30/4)
SP1403	Reset offset value of signal "Steering angle".	ESP-Electronic stability program(N30/4)
SP1404	Calibration of intake valves	ESP-Electronic stability program(N30/4)
SP1405	Calibration of separation valves	ESP-Electronic stability program(N30/4)
SP1406	ESP?calibration at standstill	ESP-Electric stability program(N30/4)
SP1407	Initial startup of component "Front left electrical machine"	ELM-VL-Front left electrical machine
SP1408	FBS3-teach-in processes	ELM-VL-Front left electrical machine
SP1409	Write tire pressure specified values.	TPM-Tire pressure monitor(N88)

SP1410	Customer-specific data	Audio-Audio or COMAND
SP1411	Activate comfort telephony.	Audio-Audio or COMAND
SP1412	Teach-in process Current date GPS data	Audio-Audio or COMAND
SP1413	Initial startup of component "Front right electrical machine"	ELM-VR-Front right electrical machine
SP1414	Initial startup of component "Rear left electrical machine"	ELM-HL-Rear left electrical machine
SP1415	Initial startup of component "Rear right electrical machine"	ELM-HR-Rear right electrical machine
SP1416	FBS3-teach-in processes	ELM-HR-Rear right electrical machine
SP1417	Writing of the VIN	PTCU-MA-Drivetrain (master)
SP1418	Bleeding of coolant circuit(Electric drive)	PTCU-MA-Drivetrain (master)
SP1419	Bleeding of coolant circuit(High-voltage battery)	PTCU-MA-Drivetrain (master)
SP1420	Check of coolant level of coolant circuit for high-voltage battery	PTCU-MA-Drivetrain (master)
SP1421	Bedding in new brake pads	EFB-Electric parking brake
SP1422	Operating time of component "M75/5 (Front high-voltage battery coolant pump)"	BMS-V-Battery management system, front (slave)
SP1423	M75/5 (Front high-voltage battery coolant pump)	BMS-V-Battery management system, front (slave)
SP1424	Unlock high-voltage component lock.	BMS-V-Battery management system, front (slave)
SP1425	Reset of control unit "N82/7 (Front battery management system control unit (slave))"	BMS-V-Battery management system, front (slave)
SP1426	Operating time of component "M75/6 (Center high-voltage battery coolant pump)"	BMS-M-Battery management system, center (master)
SP1427	Measurements before replacement of components High-voltage battery:Writing the offset	BMS-M-Battery management system, center (master)
SP1428	After replacement of component "High-voltage battery":Writing the offset value: Kilometer reading	BMS-M-Battery management system, center (master)
SP1429	M75/6 (Center high-voltage battery coolant pump)	BMS-M-Battery management system, center (master)
SP1430	Unlock high-voltage component lock.	BMS-M-Battery management system, center (master)
SP1431	Reset of control unit "N82/6 (Battery management system control unit (master))"	BMS-M-Battery management system, center (master)
SP1432	Injector injection quantity adjustment	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1433	Activate fuel pump.	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1434	Teach-in of drive authorization system	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1435	Teach-in of intake port shutoff	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1436	Teach in of throttle valve stop	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1437	Perform teach-in process for component "B16/15 (Temperature sensor upstream of SCR catalytic	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1438	Teach-in process of component "B28/8 (Differential pressure sensor (DPF))"	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1439	Teach-in process of component "B79/2 (Transmission neutral position sensor)"	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1440	Teach-in process of component "G3/2 (Oxygen sensor upstream of catalytic converter)"	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1441	Perform teach-in process for component "Y129 (AdBlue?metering valve)".	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1442	Teach-in process of component "Y74 (Pressure regulating valve)"	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1443	Teach-in process of component "Y94 (Quantity control valve)"	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1444	Quick teach-in of values of zero quantity calibration	N3/9-Motor electronics "CR42" for combustion engine "OM651"

SP1445	Reset values of quantity mean value adaptation.	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1446	Reset values of HFM drift compensation.	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1447	Resetting of contamination level of air filter	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1448	Teach-in process of component "Oxidation catalytic converter"	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1449	Teach-in of diesel particulate filter after replacement of control unit "N3/9 (CDI control unit)"	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1450	Perform teach-in process for component "Diesel particulate filter".	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1451	Teach-in process after replacement of component "SCR catalytic converter"	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1452	Reset learned values of components "NOx sensor upstream of SCR catalytic converter" and "NOx	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1453	Reset learned values for AdBlue?metering.	N3/9-Motor electronics "CR42" for combustion engine "OM651"
SP1454	Injector injection quantity adjustment	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1455	Teach-in of diesel particulate filter after replacement of control unit "N3/9 (CDI control unit)"	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1456	Reset values of quantity mean value adaptation.	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1457	Quick teach-in of values of zero quantity calibration	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1458	Teach in of throttle valve stop	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1459	Activate fuel pump.	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1460	Teach-in of drive authorization system	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1461	Reset values of HFM drift compensation.	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1462	Replace component "Diesel particulate filter".	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1463	Resetting of contamination level of air filter	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1464	Y74 (Pressure regulating valve)	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1465	B28/8 (DPF differential pressure sensor)	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
SP1466	Injector injection quantity adjustment	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
SP1467	Teach-in of diesel particulate filter after replacement of control unit "N3/9 (CDI control unit)"	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
SP1468	Reset values of quantity mean value adaptation.	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
SP1469	Quick teach-in of values of zero quantity calibration	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
SP1470	Teach in of throttle valve stop	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
SP1471	Activate fuel pump.	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
SP1472	Teach-in of drive authorization system	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
SP1473	Reset values of HFM drift compensation.	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
SP1474	Replace component "Diesel particulate filter".	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
SP1475	G3/2 (Oxygen sensor upstream of catalytic converter)	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
SP1476	Resetting of contamination level of air filter	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
SP1477	Y74 (Pressure regulating valve)	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
SP1478	B28/8 (DPF differential pressure sensor)	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
SP1479	Injector injection quantity adjustment	N3/9-Motor electronics "CDI" for combustion engine "OM646"

SP1480	Activate fuel pump.	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1481	Teach in of throttle valve stop	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1482	Teach in component "Y94 (Quantity control valve)".	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1483	Reset values of quantity mean value adaptation.	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1484	Teach-in of drive authorization system	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1485	Teach in used diesel particulate filter.	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1486	Replace component "Diesel particulate filter".	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1487	Quick teach-in of the zero quantity calibration values for calibration point 230.0bar	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1488	Quick teach-in of the zero quantity calibration values for calibration point 600.0bar	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1489	Number of injection period corrections for all fuel injectors	N3/9-Motor electronics "CDI" for combustion engine "OM646"
SP1490	Teach-in of a spare key	EZS-Electronic ignition lock
SP1491	Activation of control unit "N73 (Electronic ignition lock control unit)"	EZS-Electronic ignition lock
SP1492	Activation of control unit "N26/5 (Electric steering lock control unit)"	EZS-Electronic ignition lock
SP1493	Teach in component "B24/15 (Yaw rate sensor for lateral and longitudinal acceleration)".	ESP- Electric stability program
SP1494	Road test	ESP- Electric stability program
SP1495	N121/1 (Liftgate control control unit)	TLC-Trunk lid control
SP1496	N121 (Trunk lid control control unit)	TLC-Trunk lid control
SP1497	Teach-in process of anti-pinch protection	PSD-Control module 'Panoramic sliding roof'(A98)
SP1498	Teach-in process of anti-pinch protection	OCP-Overhead control panel
SP1499	Normalization of power window	DCU LF-Left front door(N69/1)
SP1500	Normalization of power window	DCU RF-Right front door(N69/2)
SP1501	Resetting of calibration settings	RFK-Backup camera
SP1502	Zero position adjustment	XALWA L-Xenon headlamp, left
SP1503	Reset of operating hours counter	XALWA L-Xenon headlamp, left
SP1504	Tourist mode	XALWA L-Xenon headlamp, left
SP1505	Reset of operating hours counter	XALWA R-Xenon headlamp, right
SP1506	Definition	N15/3The fault occurs when charging of the fuel injector takes too long.5
SP1507	Information on the adaptation limit values	N15/3The fault occurs when charging of the fuel injector takes too long.5
SP1508	Assignment of hydraulic shift elements	N15/3The fault occurs when charging of the fuel injector takes too long.5
SP1509	Display of all adaptation data	N15/3The fault occurs when charging of the fuel injector takes too long.5
SP1510	Adaptation of the gearshifts	N15/3The fault occurs when charging of the fuel injector takes too long.5
SP1511	Resetting of adaptation values	N15/3The fault occurs when charging of the fuel injector takes too long.5
SP1512	Adaptation procedure for torque converter lockup clutch	N15/3The fault occurs when charging of the fuel injector takes too long.5
SP1513	Teach in of throttle valve stop	N3/10-Motor electronics "ME97" for combustion engine "M272"
SP1514	Activation of fuel pump	N3/10-Motor electronics "ME97" for combustion engine "M272"

SP1515	Teach-in of drive authorization system	N3/10-Motor electronics "ME97" for combustion engine "M272"
SP1516	Teaching in the ethanol proportion in the fuel	N3/10-Motor electronics "ME97" for combustion engine "M272"
SP1517	Resetting of adaptation values	N3/10-Motor electronics "ME97" for combustion engine "M272"
SP1518	Reset of cold start adaptation values	N3/10-Motor electronics "ME97" for combustion engine "M272"
SP1519	Resetting reading of frequency counter for ethanol teach-in processes	N3/10-Motor electronics "ME97" for combustion engine "M272"
SP1520	Sensor rotor adaptation	N3/10-Motor electronics "ME97" for combustion engine "M272"
SP1521	Teach-in process after replacement of the combustion engine	N3/10-Motor electronics "ME97" for combustion engine "M272"
SP1522	Teach in of throttle valve stop	N3/10-Motor electronics "MED97" for combustion engine "M272"
SP1523	Activation of fuel pump	N3/10-Motor electronics "MED97" for combustion engine "M272"
SP1524	Teach-in of drive authorization system	N3/10-Motor electronics "MED97" for combustion engine "M272"
SP1525	Resetting of adaptation values	N3/10-Motor electronics "MED97" for combustion engine "M272"
SP1526	Sensor rotor adaptation	N3/10-Motor electronics "MED97" for combustion engine "M272"
SP1527	Teach-in process after replacement of the combustion engine	N3/10-Motor electronics "MED97" for combustion engine "M272"
SP1528	Activate fuel pump.	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
SP1529	Teach in of throttle valve stop	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
SP1530	Teach-in of stop for boost pressure control flap	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
SP1531	Teach-in of drive authorization system	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
SP1532	Resetting of values for sensor rotor adaptation	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
SP1533	Acceleration of sensor rotor adaptation	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
SP1534	Reset of mixture adaptation values	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
SP1535	Perform teach-in process for control unit "ME".	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
SP1536	Teach-in process of anti-pinch protection	PSD-Control module Panoramic sliding roof
SP1537	Tire pressure loss warning	ESP-Electronic stability program(N30/4)
SP1538	Normalization of left rear power window	REAR-Rear control unit(N22/6)
SP1539	Normalization of right rear power window	REAR-Rear control unit(N22/6)
SP1540	Zero position adjustment	XALWA L-Left xenon headlamp(E1n1)
SP1541	Tourist mode	XALWA L-Left xenon headlamp(E1n1)
SP1542	Reset of operating hours counter	XALWA L-Left xenon headlamp(E1n1)
SP1543	Reset of operating hours counter	XALWA R-Right xenon headlamp(E2n1)
SP1544	Perform voltage adjustment.	PE-Power electronics(N129/1)
SP1545	Reset of "L20 (Electric machine rotor position sensor)" component	PE-Power electronics(N129/1)
SP1546	The contact of the ground strap is faulty.	PE-Power electronics(N129/1)
SP1547	Teach-in of drive authorization system	PE-Power electronics(N129/1)
SP1548	Deactivate transport protection.	BMS-Battery management system(N82/2)
SP1549	Injector injection quantity adjustment	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"

SP1550	Teach-in of diesel particulate filter after replacement of control unit "N3/9 (CDI control unit)"	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1551	Reset values of quantity mean value adaptation.	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1552	Quick teach-in of values of zero quantity calibration	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1553	Teach in of throttle valve stop	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1554	Activate fuel pump.	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1555	Teach-in of drive authorization system	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1556	Reset values of HFM drift compensation.	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1557	Replace component "Diesel particulate filter".	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1558	Resetting of contamination level of air filter	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1559	Y74 (Pressure regulating valve)	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1560	B28/8 (DPF differential pressure sensor)	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1561	G3/2 (Oxygen sensor upstream of catalytic converter)	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1562	Oxidation catalytic converter	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1563	Teach-in process after replacement of component "SCR catalytic converter"	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1564	Reset learned values of components "NOx sensor upstream of SCR catalytic converter" and "NOx	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1565	Reset learned values for AdBlue?metering.	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1566	Perform teach-in process for component "Y129 (AdBlue?metering valve)".	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1567	Perform teach-in process for component "B16/15 (Temperature sensor upstream of SCR catalytic	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
SP1568	Reset of compressor operating time	ELC-Electronic level control
SP1569	Level calibration	ELC-Electronic level control
SP1570	Unlock high-voltage component lock.	BMS-Battery management system(N82/2)
SP1571	Perform voltage adjustment.	BMS-Battery management system(N82/2)
SP1572	Activation of fuel pump	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1573	Teach-in of drive authorization system	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1574	Teach in of throttle valve stop	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1575	Teach-in of exhaust gas recirculation actuator	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1576	Teach-in of positions for camshafts	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1577	B79/3 (Manual transmission main shifter shaft position sensor)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1578	Teaching in the ethanol proportion in the fuel	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1579	Resetting reading of frequency counter for ethanol teach-in processes	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1580	Resetting of adaptation values	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1581	Status of teach-in processes	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1582	Commissioning of control unit "N118/2 (CNG control unit)"	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1583	Bleeding after replacement of fuel components	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1584	Perform teach-in process "Sensor rotor adaptation".	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"

SP1585	Enable natural gas operation after crash event.	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
SP1586	Activate fuel pump.	N3/10-Motor electronics "SIM271KECNG" for combustion engine
SP1587	Teach in of throttle valve stop	N3/10-Motor electronics "SIM271KECNG" for combustion engine
SP1588	Teach-in of stop for boost pressure control flap	N3/10-Motor electronics "SIM271KECNG" for combustion engine
SP1589	Teach-in of drive authorization system	N3/10-Motor electronics "SIM271KECNG" for combustion engine
SP1590	Acceleration of sensor rotor adaptation	N3/10-Motor electronics "SIM271KECNG" for combustion engine
SP1591	Resetting of values for sensor rotor adaptation	N3/10-Motor electronics "SIM271KECNG" for combustion engine
SP1592	Reset of mixture adaptation values	N3/10-Motor electronics "SIM271KECNG" for combustion engine
SP1593	Perform teach-in process for control unit "ME".	N3/10-Motor electronics "SIM271KECNG" for combustion engine
SP1594	Y107/1 (Gas cylinder shutoff valves)	N3/10-Motor electronics "SIM271KECNG" for combustion engine
SP1595	Enable natural gas operation	N3/10-Motor electronics "SIM271KECNG" for combustion engine
SP1596	PRESSURE CONTROL	N3/10-Motor electronics "SIM271KECNG" for combustion engine
SP1597	Resetting of operating hours counters of component "E1 (Left front lamp unit)"	SG LML VL-LED matrix of left front lamp unit
SP1598	Resetting the operating hours counter of component "E1m4 (Left front lamp unit fan motor 1)"	SG LML VL-LED matrix of left front lamp unit
SP1599	Commissioning of control unit "E1n8 (Actuation module 2, LED exterior lighting, left front)"	XALWA L-Left xenon headlamp(E1n1)
SP1600	Commissioning of control unit "E1n7 (Actuation module, LED exterior lighting, left front)"	XALWA L-Left xenon headlamp(E1n1)
SP1601	Commissioning of control unit "E2n8 (Actuation module 2, LED exterior lighting, right front)"	XALWA R-Right xenon headlamp(E2n1)
SP1602	Commissioning of control unit "E2n7 (Actuation module, LED exterior lighting, right front)"	XALWA R-Right xenon headlamp(E2n1)
SP1603	Activation of fuel pump	N3/10-Motor electronics "ME1778" for combustion engine "M279"
SP1604	Teach-in of drive authorization system	N3/10-Motor electronics "ME1778" for combustion engine "M279"
SP1605	Teach in of throttle valve stop	N3/10-Motor electronics "ME1778" for combustion engine "M279"
SP1606	Resetting of adaptation values	N3/10-Motor electronics "ME1778" for combustion engine "M279"
SP1607	Resetting of calibration values	ABC-Active body control(N51/2)
SP1608	Level calibration	ABC-Active body control(N51/2)
SP1609	Calibration of stroke of suspension struts	ABC-Active body control(N51/2)
SP1610	Vehicle load condition comparison	ABC-Active body control(N51/2)
SP1611	Calibration of component "B24/12 (ABC lateral acceleration sensor)"	ABC-Active body control(N51/2)
SP1612	Initial startup after repair	ABC-Active body control(N51/2)
SP1613	Normalization of left rear power window	STC-Soft top control(N52)
SP1614	Normalization of right rear power window	STC-Soft top control(N52)
SP1615	Normalization of trunk lid control	STC-Soft top control(N52)
SP1616	Teach in component "B24/15 (Yaw rate, lateral and longitudinal acceleration sensor)".	RBS-Regenerative braking system
SP1617	Teach in component "B37/1 (Pedal angle sensor)".	RBS-Regenerative braking system
SP1618	Activate function "Tire pressure loss warning".	RBS-Regenerative braking system
SP1619	Check component "B37/1 (Pedal angle sensor)".	RBS-Regenerative braking system

SP1620	Check component "S9/1 (Brake light switch)".	RBS-Regenerative braking system
SP1621	Check offset value of component "N49 (Steering angle sensor)".	RBS-Regenerative braking system
SP1622	Teach-in process of component "N158 (Park pawl control unit)"	PTCU-Common powertrain controller(N127)
SP1623	Teach-in process of component "M56 (Vacuum pump)"	PTCU-Common powertrain controller(N127)
SP1624	Calibration of component "Acceleration sensor"	ESP-Electric stability program(N30/4)
SP1625	Calibration of component "A7/3 (Traction system hydraulic unit)"	ESP-Electric stability program(N30/4)
SP1626	Reset of mixture adaptation values	N3/10-Motor electronics "MED1775" for combustion engine "M178"
SP1627	Resetting of values for sensor rotor adaptation	N3/10-Motor electronics "MED1775" for combustion engine "M178"
SP1628	Enabling of engine start after crash event	N3/10-Motor electronics "MED1775" for combustion engine "M178"
SP1629	Reset learned values for diagnosis of CAN bus through control unit "N3/10 (ME-SFI [ME] control	N3/10-Motor electronics "MED1775" for combustion engine "M178"
SP1630	Teach-in of used fuel injectors	N3/10-Motor electronics "MED1775" for combustion engine "M178"
SP1631	Teach-in process after replacement of the combustion engine	N3/10-Motor electronics "MED1775" for combustion engine "M178"
SP1632	Teach-in of throttle valve end stops of right and left throttle valve actuators	N3/10-Motor electronics "MED1775" for combustion engine "M178"
SP1633	Activation of fuel pump	N3/10-Motor electronics "MED1775" for combustion engine "M178"
SP1634	Perform teach-in process "Sensor rotor adaptation" during driving operation.	N3/10-Motor electronics "MED1775" for combustion engine "M178"

XT **TOOL**

Actions

No.	Functions Name	System Name
ACT0000	Compression test	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0001	B76/1 (Condensation sensor for fuel filter with heating element)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0002	M3 (Fuel pump)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0003	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0004	M13/7 (Transmission oil cooling coolant circulation pump)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0005	M16/6 (Throttle valve actuator)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0006	Actuation of component "M16/6 (Throttle valve actuator)" with automatic	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0007	M43/6 (Low temperature circuit circulation pump 1)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0008	M55 (Intake port shutoff actuator motor)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0009	N14/3 (Glow output stage)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0010	R39/1 (Vent line heating element)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0011	R48 (Coolant thermostat heating element)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0012	Y27/9 (Exhaust gas recirculation actuator)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0013	Actuation of component "Y27/9 (Exhaust gas recirculation actuator)" with	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0014	Y31/4 (Wastegate control pressure transducer)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0015	Y58/13 (Heat exchanger shutoff valve)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0016	Y77/1 (Boost pressure positioner)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0017	Y84 (Radiator shutters actuator)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0018	Y85 (Exhaust gas recirculation cooler bypass switchover valve)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0019	Y93 (Boost pressure control flap pressure transducer)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0020	Switchable engine mounts	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0021	Check contacts of components "Y123 (Left switchable engine mount)" and	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0022	Y130 (Engine oil pump valve)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0023	Y131 (Oil spray nozzles shutoff valve)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0024	Y133 (Coolant pump switchover valve)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0025	Y76 (Fuel injectors)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0026	Injector shutoff	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0027	Actuation of components "Y93 (Boost pressure control flap pressure	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0028	M4/7 (fan motor)	N3/9-Motor electronics "CDID3" for combustion engine "OM651"
ACT0029	M16/6 (Throttle valve actuator)	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
ACT0030	M16/57 (Exhaust flap controller)	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
ACT0031	Y27/8 (Exhaust gas recirculation actuator, high pressure)	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
ACT0032	Y27/7 (Exhaust gas recirculation actuator, low pressure)	N3/3-Motor electronics "OM607" for combustion engine "CRR1"

ACT0033	Y77/1 (Boost pressure regulator)	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
ACT0034	Y76 (Fuel injectors)	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
ACT0035	Diagnostic glowing	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
ACT0036	N33/2 (DPF regeneration heater booster control unit)	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
ACT0037	Rail pressure	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
ACT0038	A92/3 (Fuel filter module)	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
ACT0039	F32k1 (Decoupling relay)	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
ACT0040	M4/7 (fan motor)	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
ACT0041	M13/7 (Transmission oil cooling coolant circulation pump)	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
ACT0042	Status of circuit 87	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
ACT0043	Y84 (Radiator shutters actuator)	N3/3-Motor electronics "OM607" for combustion engine "CRR1"
ACT0044	Control unit reset	E call [Europe]-Emergency call system
ACT0045	Workshop mode	E call [Europe]-Emergency call system
ACT0046	Status LEDs	E call [Europe]-Emergency call system
ACT0047	Emergency call	E call [Europe]-Emergency call system
ACT0048	Self-test	E call [Europe]-Emergency call system
ACT0049	Speaker	E call [Europe]-Emergency call system
ACT0050	A1h1 (Warning buzzer)	IC-Instrument cluster
ACT0051	Mechanical instrument pointers	IC-Instrument cluster
ACT0052	A1p13 (Multifunction display)	IC-Instrument cluster
ACT0053	Indicator lamps	IC-Instrument cluster
ACT0054	A1e8 (Instrument illumination)	IC-Instrument cluster
ACT0055	Control unit reset	IC-Instrument cluster
ACT0056	Segments on speedometer	IC-Instrument cluster
ACT0057	USB interface	KOMO-Communication module Telematics services
ACT0058	Control unit reset	KOMO-Communication module Telematics services
ACT0059	Self-test	KOMO-Communication module Telematics services
ACT0060	Workshop mode	KOMO-Communication module Telematics services
ACT0061	Restoration of initial authorization certificate	KOMO-Communication module Telematics services
ACT0062	Transfer VIN to control unit "N112/2 (Telematics services communication	KOMO-Communication module Telematics services
ACT0063	Transfer certain digits of the VIN to the control unit "N112/2 (Telematics	KOMO-Communication module Telematics services
ACT0064	Manufacturer default setting	KOMO-Communication module Telematics services
ACT0065	Reset operating condition.	KOMO-Communication module Telematics services
ACT0066	Special function	KOMO-Communication module Telematics services
ACT0067	H4/61 (Instrument cluster speaker)	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
ACT0068	H4/27 (Center instrument panel speaker)	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem

ACT0069	H4/48 (Emergency call speaker)	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
ACT0070	Muting	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
ACT0071	Central locking	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
ACT0072	Restoration of initial authorization certificate	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
ACT0073	Self-test	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
ACT0074	Control unit reset	KOMO/mbrace-Communication module 'Telematics services'/Notrufsystem
ACT0075	Self-test	TS-Telematic system(N123/4)
ACT0076	H4/27 (Center instrument panel speaker)	TS-Telematic system(N123/4)
ACT0077	Muting	TS-Telematic system(N123/4)
ACT0078	Control unit reset	TS-Telematic system(N123/4)
ACT0079	Button illumination of multifunction steering wheel	SCM-Steering column module(N80)
ACT0080	Illumination of component "S16/13 (DIRECT SELECT lever)"	SCM-Steering column module(N80)
ACT0081	S40/4v1 (SPEEDTRONIC light-emitting diode)	SCM-Steering column module(N80)
ACT0082	S59/1e1 (Steering wheel heater indicator lamp)	SCM-Steering column module(N80)
ACT0083	R22/4 (Steering wheel heater)	SCM-Steering column module(N80)
ACT0084	M99 (Steering wheel vibration motor)	SCM-Steering column module(N80)
ACT0085	Actuate LEDs.	AMG DRVU-AMG DRIVE UNIT(N145)
ACT0086	LEDs of component "S192 (Transmission mode rotary switch)"	AMG DRVU-AMG DRIVE UNIT(N145)
ACT0087	Actuate rear spoiler.	AMG DRVU-AMG DRIVE UNIT(N145)
ACT0088	A7/3m1 (High-pressure and return flow pump)	ESP-Electronic stability program(N30/4)
ACT0089	A7/3y11 (Left rear pressure regulating valve (pressure release))	ESP-Electronic stability program(N30/4)
ACT0090	Unlocking of component "Navigation module"	NAV-Navigation module(A2/30)
ACT0091	Output of test sound	NAV-Navigation module(A2/30)
ACT0092	Measured volume level of microphone	NAV-Navigation module(A2/30)
ACT0093	Measurement of reception field strength	NAV-Navigation module(A2/30)
ACT0094	Self-test of control unit "ATA [EDW]/tow-away protection/interior protection"	IMS-Interior motion sensor
ACT0095	Erase alarm sources	IMS-Interior motion sensor
ACT0096	Actuation of components "S93/3s1 (Tow-away protection button)" and	IMS-Interior motion sensor
ACT0097	A69/1 (Left front tire pressure sensor)	TPM-Tire pressure monitor(N88)
ACT0098	A69/2 (Right front tire pressure sensor)	TPM-Tire pressure monitor(N88)
ACT0099	A69/3 (Left rear tire pressure sensor)	TPM-Tire pressure monitor(N88)
ACT0100	A69/4 (Right rear tire pressure sensor)	TPM-Tire pressure monitor(N88)
ACT0101	Wake-up line	AUDIO-Audio or COMAND(A2-A40/3)
ACT0102	Internal fan	AUDIO-Audio or COMAND(A2-A40/3)
ACT0103	External fan	AUDIO-Audio or COMAND(A2-A40/3)
ACT0104	Determination of number of receivable radio transmitters	AUDIO-Audio or COMAND(A2-A40/3)

ACT0105	Wiring test of radio antennas	AUDIO-Audio or COMAND(A2-A40/3)
ACT0106	Measurement of reception field strength	AUDIO-Audio or COMAND(A2-A40/3)
ACT0107	Antenna measuring drive	AUDIO-Audio or COMAND(A2-A40/3)
ACT0108	Speaker	AUDIO-Audio or COMAND(A2-A40/3)
ACT0109	Electrical self-test of microphones.	AUDIO-Audio or COMAND(A2-A40/3)
ACT0110	Volume level	AUDIO-Audio or COMAND(A2-A40/3)
ACT0111	Color display	AUDIO-Audio or COMAND(A2-A40/3)
ACT0112	Sample display	AUDIO-Audio or COMAND(A2-A40/3)
ACT0113	TV tuner	AUDIO-Audio or COMAND(A2-A40/3)
ACT0114	AUX jack	AUDIO-Audio or COMAND(A2-A40/3)
ACT0115	Navigation	AUDIO-Audio or COMAND(A2-A40/3)
ACT0116	Display illumination	AUDIO-Audio or COMAND(A2-A40/3)
ACT0117	Extending/retracting the display	AUDIO-Audio or COMAND(A2-A40/3)
ACT0118	Backup camera	AUDIO-Audio or COMAND(A2-A40/3)
ACT0119	B84/3 (Reversing camera)	AUDIO-Audio or COMAND(A2-A40/3)
ACT0120	B84/5 (Front passenger outside mirror camera)	AUDIO-Audio or COMAND(A2-A40/3)
ACT0121	B84/6 (Passenger-side outside mirror backup camera)	AUDIO-Audio or COMAND(A2-A40/3)
ACT0122	Check CD/DVD insert and eject.	AUDIO-Audio or COMAND(A2-A40/3)
ACT0123	Self-test	AUDIO-Audio or COMAND(A2-A40/3)
ACT0124	Slot for memory cardTest	AUDIO-Audio or COMAND(A2-A40/3)
ACT0125	TestUSB interface	AUDIO-Audio or COMAND(A2-A40/3)
ACT0126	Erase customer-specific data	AUDIO-Audio or COMAND(A2-A40/3)
ACT0127	Speaker(Development data)	AUDIO-Audio or COMAND(A2-A40/3)
ACT0128	Init NTG45	AUDIO-Audio or COMAND(A2-A40/3)
ACT0129	Self-test of mobile phone cradle	AUDIO-Audio or COMAND(A2-A40/3)
ACT0130	Perform control unit reset.	AUDIO-Audio or COMAND(A2-A40/3)
ACT0131	Restart MOST ring.	AUDIO-Audio or COMAND(A2-A40/3)
ACT0132	A1e52 (COLLISION PREVENTION ASSIST warning lamp)	CPA-Control unit 'COLLISION PREVENTION ASSIST'(A90)
ACT0133	Power supply of taximeter	Multifunction control unit-Multifunction control unit
ACT0134	Power supply (10.0A) for peripheral devices	Multifunction control unit-Multifunction control unit
ACT0135	Power supply (5.0A) for peripheral devices	Multifunction control unit-Multifunction control unit
ACT0136	Output "Windshield heater"	Multifunction control unit-Multifunction control unit
ACT0137	Power supply of roof sign lamp	Multifunction control unit-Multifunction control unit
ACT0138	Power supply for flashing lights in trunk lid or liftgate	Multifunction control unit-Multifunction control unit
ACT0139	Power supply of two-way radio	Multifunction control unit-Multifunction control unit
ACT0140	Output "Circuit 58"	Multifunction control unit-Multifunction control unit

ACT0141	Output "Circuit 58d"	Multifunction control unit-Multifunction control unit
ACT0142	Output "Circuit 15"	Multifunction control unit-Multifunction control unit
ACT0143	Output "Status of taximeter"	Multifunction control unit-Multifunction control unit
ACT0144	Output for indicator lamp of roof sign main switch	Multifunction control unit-Multifunction control unit
ACT0145	Output for indicator lamp of button "Two-way radio cut-in"	Multifunction control unit-Multifunction control unit
ACT0146	Output for indicator lamp of button "Two-way radio main switch"	Multifunction control unit-Multifunction control unit
ACT0147	Output "Radio help call"	Multifunction control unit-Multifunction control unit
ACT0148	Output "Seat occupied recognition"	Multifunction control unit-Multifunction control unit
ACT0149	Output "Status of buttons for horns"	Multifunction control unit-Multifunction control unit
ACT0150	Output "Travel distance"	Multifunction control unit-Multifunction control unit
ACT0151	Self-test	SG MSND-Engine sound
ACT0152	Wake-up line	SG MSND-Engine sound
ACT0153	Speaker	SG MSND-Engine sound
ACT0154	Activation Sound system	SG MSND-Engine sound
ACT0155	Deactivation Engine sound	SG MSND-Engine sound
ACT0156	KEYLESS GO system test	KG-KEYLESS GO(N69/5)
ACT0157	KEYLESS-GO key search	KG-KEYLESS GO(N69/5)
ACT0158	Self-test	SOUND-Sound system
ACT0159	Actuation of fan	SOUND-Sound system
ACT0160	Lighting	SOUND-Sound system
ACT0161	Actuation of speakers	SOUND-Sound system
ACT0162	H4/73 (Right door midrange speaker)	SOUND-Sound system
ACT0163	H4/4h2 (Right rear woofer)	SOUND-Sound system
ACT0164	H4/29 (Woofer)	SOUND-Sound system
ACT0165	Left front speaker group	SOUND-Sound system
ACT0166	H4/2h2 (Right front door woofer)	SOUND-Sound system
ACT0167	H4/27 (Center instrument panel speaker)	SOUND-Sound system
ACT0168	H4/76 (Center instrument panel tweeter)	SOUND-Sound system
ACT0169	H4/54 (Left rear surround speaker)	SOUND-Sound system
ACT0170	H4/1h2 (Left front door woofer)	SOUND-Sound system
ACT0171	Right front speaker group	SOUND-Sound system
ACT0172	H4/57 (Right rear surround speaker)	SOUND-Sound system
ACT0173	H4/3 (Left rear speaker)	SOUND-Sound system
ACT0174	H4/35 (Center rear tweeter)/H4/77 (Center rear tweeter)	SOUND-Sound system
ACT0175	H4/72 (Left door midrange speaker)	SOUND-Sound system
ACT0176	H4/3h2 (Left rear woofer)	SOUND-Sound system

ACT0177	H4/4 (Right rear speaker)	SOUND-Sound system
ACT0178	1H4/29 (Woofer)-Solenoid 1	SOUND-Sound system
ACT0179	Solenoid 2 of speaker H4/29 (Woofer)-Solenoid 2	SOUND-Sound system
ACT0180	H4/77 (Center rear tweeter)	SOUND-Sound system
ACT0181	H4/1h1 (Left front door tweeter)	SOUND-Sound system
ACT0182	H4/2h1 (Right front door tweeter)	SOUND-Sound system
ACT0183	H4/23 (Left instrument panel speaker)	SOUND-Sound system
ACT0184	H4/24 (Right instrument panel speaker)	SOUND-Sound system
ACT0185	Electrical self-test of speakers	SOUND-Bose sound system
ACT0186	Actuation of speakers	SOUND-Bose sound system
ACT0187	Left front speaker group	SOUND-Bose sound system
ACT0188	H4/1h2 (Left front door woofer)	SOUND-Bose sound system
ACT0189	Right front speaker group	SOUND-Bose sound system
ACT0190	H4/2h2 (Right front door woofer)	SOUND-Bose sound system
ACT0191	H4/3 (Left rear speaker)	SOUND-Bose sound system
ACT0192	H4/4 (Right rear speaker)	SOUND-Bose sound system
ACT0193	H4/76 (Center instrument panel tweeter)	SOUND-Bose sound system
ACT0194	H4/29 (Woofer)	SOUND-Bose sound system
ACT0195	H4/54 (Left rear surround speaker)	SOUND-Bose sound system
ACT0196	H4/57 (Right rear surround speaker)	SOUND-Bose sound system
ACT0197	Control device	SOUND-Bose sound system
ACT0198	Actuation of fan	SOUND-Bose sound system
ACT0199	Test of microphone for sound system	SOUND-Bose sound system
ACT0200	H4/27 (Center instrument panel speaker)	SOUND-Bose sound system
ACT0201	H4/38 (Rear woofer)Solenoid 1	SOUND-Bose sound system
ACT0202	H4/38 (Rear woofer)Solenoid 2	SOUND-Bose sound system
ACT0203	H4/88 (Left door bass speaker)	SOUND-Bose sound system
ACT0204	H4/89 (Right door bass speaker)	SOUND-Bose sound system
ACT0205	H4/49 (Center rear speaker)	SOUND-Bose sound system
ACT0206	Fan self-test	SOUND-Bose sound system
ACT0207	Y51 (Left front axle damping valve unit)	ADS-Adaptive damping system(N51/5)
ACT0208	Y52 (Right front axle damping valve unit)	ADS-Adaptive damping system(N51/5)
ACT0209	Y53 (Left rear axle damping valve unit)	ADS-Adaptive damping system(N51/5)
ACT0210	Y54 (Right rear axle damping valve unit)	ADS-Adaptive damping system(N51/5)
ACT0211	M51/3m1 (Tailgate control electric motor)	HKS-Tailgate control
ACT0212	H4/60 (Liftgate control warning buzzer)	HKS-Tailgate control

ACT0213	Usage is only permissible in consultation with your hotline.	HKS-Tailgate control
ACT0214	Check signal line to component "COMAND".	TV-TV tuner
ACT0215	Check signal line to component "AVE-H".	TV-TV tuner
ACT0216	Wiring test of TV antennas	TV-TV tuner
ACT0217	Reception measurement for TV antennas by input of channel number	TV-TV tuner
ACT0218	Reception measurement for TV antennas by input of frequency	TV-TV tuner
ACT0219	Antenna measuring drive	TV-TV tuner
ACT0220	Frequency of use of TV antennas	TV-TV tuner
ACT0221	Actuation of fan	TV-TV tuner
ACT0222	Restart MOST ring.	TV-TV tuner
ACT0223	Reset	TV-TV tuner
ACT0224	Check signal line to component "COMAND".	TV-TV tuner
ACT0225	Check signal line to component "AVE-H".	TV-TV tuner
ACT0226	Wiring test of TV antennas	TV-TV tuner
ACT0227	Reception measurement for TV antennas by input of channel number	TV-TV tuner
ACT0228	Reception measurement for TV antennas by input of frequency	TV-TV tuner
ACT0229	Antenna measuring drive	TV-TV tuner
ACT0230	Frequency of use of TV antennas	TV-TV tuner
ACT0231	Actuation of fan	TV-TV tuner
ACT0232	Restart MOST ring.	TV-TV tuner
ACT0233	Reset	TV-TV tuner
ACT0234	R50 (Auxiliary heater heating element)	MFK-Multifunction camera
ACT0235	M99 (Steering wheel vibration motor)	MFK-Multifunction camera
ACT0236	R50 (Auxiliary heater heating element)	MFK-Multifunction camera(A40/11)
ACT0237	M99 (Steering wheel vibration motor)	MFK-Multifunction camera(A40/11)
ACT0238	A9 (Refrigerant compressor)	AAC-Automatic air conditioning
ACT0239	A9/5 (Electric refrigerant compressor)	AAC-Automatic air conditioning
ACT0240	Y19/3 (Evaporator shutoff valve)	AAC-Automatic air conditioning
ACT0241	A9y1 (Refrigerant compressor magnetic clutch)	AAC-Automatic air conditioning
ACT0242	M4/7 (fan motor)	AAC-Automatic air conditioning
ACT0243	M13/5 (Coolant circulation pump)	AAC-Automatic air conditioning
ACT0244	A32n1 (Blower regulator)	AAC-Automatic air conditioning
ACT0245	R22/3 (PTC heater booster)	AAC-Automatic air conditioning
ACT0246	N33/5 (High-voltage PTC heater)	AAC-Automatic air conditioning
ACT0247	M91/6 (Heater circuit circulation pump)	AAC-Automatic air conditioning
ACT0248	Rear windshield heater	AAC-Automatic air conditioning

ACT0249	Switch and controls illumination of component "N22/7 (Automatic air	AAC-Automatic air conditioning
ACT0250	LEDs of component "N22/7 (Automatic air conditioning control and operating	AAC-Automatic air conditioning
ACT0251	M2/5 (Fresh air/recirculated air flap actuator motor)	AAC-Automatic air conditioning
ACT0252	M2/4 (Central air distribution actuator motor)	AAC-Automatic air conditioning
ACT0253	M2/6 (Left blend air flap actuator motor)	AAC-Automatic air conditioning
ACT0254	M2/7 (Right blend air flap actuator motor)	AAC-Automatic air conditioning
ACT0255	Reception measurement	DAB-Digital Audio Broadcasting
ACT0256	Antenna measuring drive	DAB-Digital Audio Broadcasting
ACT0257	Bit error rate	DAB-Digital Audio Broadcasting
ACT0258	Control unit reset	DAB-Digital Audio Broadcasting
ACT0259	Function check	STH-Stationary heater
ACT0260	Activation of stationary heater in test mode	STH-Stationary heater
ACT0261	Unlock component "A6 (Stationary heater heater unit)".	STH-Stationary heater
ACT0262	Teach in component "A8/3 (Stationary heater radio remote control	STH-Stationary heater
ACT0263	Display test	Drive Kit Plus-Drive kit for iPhone
ACT0264	HDMIInterface	Drive Kit Plus-Drive kit for iPhone
ACT0265	H4/27 (Center instrument panel speaker)	Drive Kit Plus-Drive kit for iPhone
ACT0266	Self-test	Drive Kit Plus-Drive kit for iPhone
ACT0267	Test picture display	NAVI20-Navigation(N125/2)
ACT0268	Speaker	NAVI20-Navigation(N125/2)
ACT0269	Panoramic sliding sunroof	PSD-Control module 'Panoramic sliding roof'(A98)
ACT0270	Roller sun blind	PSD-Control module 'Panoramic sliding roof'(A98)
ACT0271	A76 (Left front reversible emergency tensioning retractor)	RevETR LF-Left front reversible emergency tensioning retractor
ACT0272	Display	HUD-Head up display
ACT0273	Display brightness	HUD-Head up display
ACT0274	Mirror glass	HUD-Head up display
ACT0275	A76/1 (Right front reversible emergency tensioning retractor)	RevETR RF-Right front reversible emergency tensioning retractor
ACT0276	M27/1 (Driver seat fore/aft adjustment motor)	ESV Driver-Electric seat adjustmnet Driver with memory function
ACT0277	M27/2 (Driver seat height adjustment motor)	ESV Driver-Electric seat adjustmnet Driver with memory function
ACT0278	M27/3 (Driver seat inclination adjustment motor)	ESV Driver-Electric seat adjustmnet Driver with memory function
ACT0279	M27/4 (Head restraint adjustment motor, driver seat)	ESV Driver-Electric seat adjustmnet Driver with memory function
ACT0280	M27/5 (Driver seat backrest inclination adjustment motor)	ESV Driver-Electric seat adjustmnet Driver with memory function
ACT0281	M27/8 (Seat adjustment motor, seat cushion length, driver seat)	ESV Driver-Electric seat adjustmnet Driver with memory function
ACT0282	Steering column adjustment	ESV Driver-Electric seat adjustmnet Driver with memory function
ACT0283	Test signal line of component "A2/82 (Satellite Digital Audio Radio (SDAR)	SDAR-Satellite radio
ACT0284	Test signal line of component "A28/11 (Multifunction antenna)".	SDAR-Satellite radio

ACT0285	Actuation of fan	SDAR-Satellite radio
ACT0286	Self-test of control unit "HD radio"	SDAR-Satellite radio
ACT0287	Reception measurement	TB5-TV tuner Tuner unit
ACT0288	External feed and supply voltage	TB5-TV tuner Tuner unit
ACT0289	Signal quality	TB5-TV tuner Tuner unit
ACT0290	Signal level	TB5-TV tuner Tuner unit
ACT0291	Restart MOST ring.	TB5-TV tuner Tuner unit
ACT0292	Supply voltageAntenna amplifier	TB5-TV tuner Tuner unit
ACT0293	Antenna measuring drive	TB5-TV tuner Tuner unit
ACT0294	Actuation of fan	TB5-TV tuner Tuner unit
ACT0295	Self-test	TV tuner (TV)
ACT0296	Signal/noise ratio	TV tuner (TV)
ACT0297	Bit error rate	TV tuner (TV)
ACT0298	Antenna measuring drive	TV tuner (TV)
ACT0299	Reception field strength	TV tuner (TV)
ACT0300	External feed and supply voltage	TV tuner (TV)
ACT0301	Control unit reset	TV tuner (TV)
ACT0302	M28/1 (Front passenger seat fore/aft adjustment motor)	ESV Front passenger-Electric seat adjustment Front passenger with memory function
ACT0303	M28/2 (Front passenger seat height adjustment motor)	ESV Front passenger-Electric seat adjustment Front passenger with memory function
ACT0304	M28/3 (Front passenger seat inclination adjustment motor)	ESV Front passenger-Electric seat adjustment Front passenger with memory function
ACT0305	M28/4 (Head restraint adjustment motor, front passenger seat)	ESV Front passenger-Electric seat adjustment Front passenger with memory function
ACT0306	M28/5 (Front passenger seat backrest inclination adjustment motor)	ESV Front passenger-Electric seat adjustment Front passenger with memory function
ACT0307	M28/8 (Seat adjustment motor, seat cushion length, front passenger seat)	ESV Front passenger-Electric seat adjustment Front passenger with memory function
ACT0308	Steering column adjustment	ESV Front passenger-Electric seat adjustment Front passenger with memory function
ACT0309	Self-test	MIF-Media interface
ACT0310	Right turn signal	TRM-Trailer recognition module (N28/1)
ACT0311	Left turn signal	TRM-Trailer recognition module (N28/1)
ACT0312	Left taillamp	TRM-Trailer recognition module (N28/1)
ACT0313	Right taillamp	TRM-Trailer recognition module (N28/1)
ACT0314	Brake light	TRM-Trailer recognition module (N28/1)
ACT0315	Rear fog light	TRM-Trailer recognition module (N28/1)
ACT0316	Backup lamp	TRM-Trailer recognition module (N28/1)
ACT0317	Terminal 30G "Trailer socket"	TRM-Trailer recognition module (N28/1)
ACT0318	Indicator lamp of switch "S62/24"	TRM-Trailer recognition module (N28/1)
ACT0319	Indicator lamp of component "A63"	TRM-Trailer recognition module (N28/1)
ACT0320	Switch and controls illumination of switch "S62/24"	TRM-Trailer recognition module (N28/1)

ACT0321	Unlocking of trailer hitch	TRM-Trailer recognition module (N28/1)
ACT0322	Left turn signal	Trailer recognition module-Trailer recognition
ACT0323	Right turn signal	Trailer recognition module-Trailer recognition
ACT0324	Left taillamp	Trailer recognition module-Trailer recognition
ACT0325	Right taillamp	Trailer recognition module-Trailer recognition
ACT0326	Brake light	Trailer recognition module-Trailer recognition
ACT0327	Rear fog light	Trailer recognition module-Trailer recognition
ACT0328	Backup lamp	Trailer recognition module-Trailer recognition
ACT0329	Terminal 30G "Trailer socket"	Trailer recognition module-Trailer recognition
ACT0330	Terminal 15G "Trailer socket"	Trailer recognition module-Trailer recognition
ACT0331	Indicator lamp of switch "S142/2"	Trailer recognition module-Trailer recognition
ACT0332	Indicator lamp of component "A63"	Trailer recognition module-Trailer recognition
ACT0333	Switch and controls illumination of switch "S142/2"	Trailer recognition module-Trailer recognition
ACT0334	Extension and retraction of trailer hitch	Trailer recognition module-Trailer recognition
ACT0335	Menu11772	SAM-Signal acquisition and actuation module(N10)
ACT0336	Daytime running lights	SAM-Signal acquisition and actuation module(N10)
ACT0337	Trunk lamps	SAM-Signal acquisition and actuation module(N10)
ACT0338	Front fog lamp	SAM-Signal acquisition and actuation module(N10)
ACT0339	E3/1 (Inner left rear lamp unit)	SAM-Signal acquisition and actuation module(N10)
ACT0340	E3/1e5 (Left rear fog light)	SAM-Signal acquisition and actuation module(N10)
ACT0341	E4/1 (Inner right rear lamp unit)	SAM-Signal acquisition and actuation module(N10)
ACT0342	Resetting reading of frequency counter	SAM-Signal acquisition and actuation module(N10)
ACT0343	Illuminated door sill moldings	SAM-Signal acquisition and actuation module(N10)
ACT0344	F34 (Interior fuse box)	SAM-Signal acquisition and actuation module(N10)
ACT0345	Transport mode	SAM-Signal acquisition and actuation module(N10)
ACT0346	F33k1 (Circuit 30g relay)	SAM-Signal acquisition and actuation module(N10)
ACT0347	M14/10 (Tank cap central locking actuator)	SAM-Signal acquisition and actuation module(N10)
ACT0348	F4 (Rear fuse box)	SAM-Signal acquisition and actuation module(N10)
ACT0349	Side-marker lamp	SAM-Signal acquisition and actuation module(N10)
ACT0350	Erase alarm sources	SAM-Signal acquisition and actuation module(N10)
ACT0351	Windshield wiper	SAM-Signal acquisition and actuation module(N10)
ACT0352	Switch and controls illumination of switch "S88/10 (Trunk lid emergency	SAM-Signal acquisition and actuation module(N10)
ACT0353	Switch and controls illumination of switch "S62/36 (Tailgate control button)"	SAM-Signal acquisition and actuation module(N10)
ACT0354	F34kF (Circuit 30g relay)	SAM-Signal acquisition and actuation module(N10)
ACT0355	E5/1 (Left front fog lamp)	SAM-Signal acquisition and actuation module(N10)
ACT0356	M5/1 (Windshield washer system pump)	SAM-Signal acquisition and actuation module(N10)

ACT0357	E1 (Left front lamp unit)	SAM-Signal acquisition and actuation module(N10)
ACT0358	E2 (Right front lamp unit)	SAM-Signal acquisition and actuation module(N10)
ACT0359	E3 (Left rear lamp unit)	SAM-Signal acquisition and actuation module(N10)
ACT0360	E21 (Center brake lamp)	SAM-Signal acquisition and actuation module(N10)
ACT0361	M14/7 (Liftgate central locking motor)	SAM-Signal acquisition and actuation module(N10)
ACT0362	M5/2 (Headlamp cleaning system pump)	SAM-Signal acquisition and actuation module(N10)
ACT0363	E4 (Right rear lamp unit)	SAM-Signal acquisition and actuation module(N10)
ACT0364	E4e5 (Right rear fog light)	SAM-Signal acquisition and actuation module(N10)
ACT0365	Heating of component "R2/1 (Spray nozzle heating)"	SAM-Signal acquisition and actuation module(N10)
ACT0366	Heating of component "E5/1 (Left front fog lamp)"	SAM-Signal acquisition and actuation module(N10)
ACT0367	Heating of component "R2/11 (Spray nozzle hose heater)"	SAM-Signal acquisition and actuation module(N10)
ACT0368	Heating of component "Wischerblatt"	SAM-Signal acquisition and actuation module(N10)
ACT0369	Backup lamp	SAM-Signal acquisition and actuation module(N10)
ACT0370	E7 (Backup lamp)	SAM-Signal acquisition and actuation module(N10)
ACT0371	E3/1 (Rear fog lamp)	SAM-Signal acquisition and actuation module(N10)
ACT0372	Front turn signal lamps	SAM-Signal acquisition and actuation module(N10)
ACT0373	Running board courtesy light	SAM-Signal acquisition and actuation module(N10)
ACT0374	Door handle illumination "rear doors"	SAM-Signal acquisition and actuation module(N10)
ACT0375	Ambiance illumination "instrument panel and rear doors"	SAM-Signal acquisition and actuation module(N10)
ACT0376	Confirmation of battery change	SAM-Signal acquisition and actuation module(N10)
ACT0377	Activate demo mode of exterior lights.	SAM-Signal acquisition and actuation module(N10)
ACT0378	Left rear power window	SAM-Signal acquisition and actuation module(N10)
ACT0379	Right rear power window	SAM-Signal acquisition and actuation module(N10)
ACT0380	M5/3 (Rear windshield washer system pump)	SAM-Signal acquisition and actuation module(N10)
ACT0381	License plate lamps	SAM-Signal acquisition and actuation module(N10)
ACT0382	Rear doors	SAM-Signal acquisition and actuation module(N10)
ACT0383	Ambiance illumination "Rear doors"	SAM-Signal acquisition and actuation module(N10)
ACT0384	Footwell lamps	SAM-Signal acquisition and actuation module(N10)
ACT0385	Actuation of fuel pump	FSCU05-Control unit Fuel pump
ACT0386	Left outside mirror adjustment	LFD-Left front door
ACT0387	Left mirror heater	LFD-Left front door
ACT0388	Folding in/out of left outside mirror	LFD-Left front door
ACT0389	Mirror dimming	LFD-Left front door
ACT0390	Left memory function	LFD-Left front door
ACT0391	Blind Spot Assist	LFD-Left front door
ACT0392	Door handle illumination "Left front door"	LFD-Left front door

ACT0393	Switch illumination "Left front door"	LFD-Left front door
ACT0394	Turn signal lamp in left outside mirror	LFD-Left front door
ACT0395	LEDs	LFD-Left front door
ACT0396	Exit and warning lamp "Left front door"	LFD-Left front door
ACT0397	E17/43 (Left front door ambiance illumination)	LFD-Left front door
ACT0398	Ambient illumination	LFD-Left front door
ACT0399	LED of switch "Rear passenger compartment seat heater"	LFD-Left front door
ACT0400	Left front power window	LFD-Left front door
ACT0401	Denormalization of left front power window	LFD-Left front door
ACT0402	Central locking "Left front door"	LFD-Left front door
ACT0403	Additional door lock "Left front door"	LFD-Left front door
ACT0404	Start control unit reset.	LFD-Left front door
ACT0405	Right outside mirror adjustment	DCU RF-Right front door
ACT0406	Right mirror heater	DCU RF-Right front door
ACT0407	Folding in/out of right outside mirror	DCU RF-Right front door
ACT0408	Mirror dimming	DCU RF-Right front door
ACT0409	Right memory function	DCU RF-Right front door
ACT0410	Blind Spot Assist	DCU RF-Right front door
ACT0411	Door handle illumination "Right front door"	DCU RF-Right front door
ACT0412	Switch illumination "Right front door"	DCU RF-Right front door
ACT0413	Turn signal lamp in right outside mirror	DCU RF-Right front door
ACT0414	LEDs	DCU RF-Right front door
ACT0415	Exit and warning lamp "Right front door"	DCU RF-Right front door
ACT0416	E17/44 (Right front door ambiance illumination)	DCU RF-Right front door
ACT0417	Ambient illumination	DCU RF-Right front door
ACT0418	LED of switch "Rear passenger compartment seat heater"	DCU RF-Right front door
ACT0419	Right front power window	DCU RF-Right front door
ACT0420	Denormalization of right front power window	DCU RF-Right front door
ACT0421	Central locking "Right front door"	DCU RF-Right front door
ACT0422	Additional door lock "Right front door"	DCU RF-Right front door
ACT0423	Start control unit reset.	DCU RF-Right front door
ACT0424	Reception measurement	TV-TV tuner
ACT0425	External feed and supply voltage	TV-TV tuner
ACT0426	Signal quality	TV-TV tuner
ACT0427	Signal level	TV-TV tuner
ACT0428	Supply voltageAntenna amplifier	TV-TV tuner

ACT0429	Self-test	TV-TV tuner
ACT0430	Signal/noise ratio	TV-TV tuner
ACT0431	Bit error rate	TV-TV tuner
ACT0432	Reception field strength	TV-TV tuner
ACT0433	External feed and supply voltage	TV-TV tuner
ACT0434	Control unit reset	TV-TV tuner
ACT0435	Electric parking brake	EFB-Electronic parking brake(N128)
ACT0436	M76/1 (Left electric parking brake actuator motor)	EFB-Electronic parking brake(N128)
ACT0437	M76/2 (Right electric parking brake actuator motor)	EFB-Electronic parking brake(N128)
ACT0438	Move to the assembly position	EFB-Electronic parking brake(N128)
ACT0439	B84/3 (Reversing camera)	RFK-Backup camera
ACT0440	B84/6 (Passenger-side outside mirror backup camera)	RFK-Backup camera
ACT0441	Symbol illuminationA40/9 (Audio/COMAND control panel)	COU-Audio/COMAND operating unit (A40/9)
ACT0442	Display in "SERVICE" position	ZAN-Audio/COMAND display
ACT0443	Extending/retracting the display	ZAN-Audio/COMAND display
ACT0444	Color display	ZAN-Audio/COMAND display
ACT0445	Sample display	ZAN-Audio/COMAND display
ACT0446	Display illumination	ZAN-Audio/COMAND display
ACT0447	Brightness	ZAN-Audio/COMAND display
ACT0448	Control unit reset	ZAN-Audio/COMAND display
ACT0449	Self-test	ZAN-Audio/COMAND display
ACT0450	Test picture display	ZAN-Audio/COMAND display
ACT0451	Headlamp range adjustment	SG SW-Control unit 'Headlamp'(N71/1)
ACT0452	Active curve illumination	SG SW-Control unit 'Headlamp'(N71/1)
ACT0453	Intelligent Light System	SG SW-Control unit 'Headlamp'(N71/1)
ACT0454	Cornering illumination	SG SW-Control unit 'Headlamp'(N71/1)
ACT0455	High beams	SG SW-Control unit 'Headlamp'(N71/1)
ACT0456	Headlamp range adjustment	SG SW L-Left headlamp
ACT0457	Active curve illumination	SG SW L-Left headlamp
ACT0458	Active curve illumination with steering angle	SG SW L-Left headlamp
ACT0459	Intelligent light spread	SG SW L-Left headlamp
ACT0460	LED exterior lights	SG SW L-Left headlamp
ACT0461	Fan	SG SW L-Left headlamp
ACT0462	Headlamp range adjustment	SG SW L-Left headlamp(E1n9)
ACT0463	Active curve illumination	SG SW L-Left headlamp(E1n9)
ACT0464	Active curve illumination with steering angle	SG SW L-Left headlamp(E1n9)

ACT0465	Intelligent light spread	SG SW L-Left headlamp(E1n9)
ACT0466	LED exterior lights	SG SW L-Left headlamp(E1n9)
ACT0467	Fan	SG SW L-Left headlamp(E1n9)
ACT0468	Headlamp range adjustment	SG SW R-Right headlamp
ACT0469	Active curve illumination	SG SW R-Right headlamp
ACT0470	Active curve illumination with steering angle	SG SW R-Right headlamp
ACT0471	Intelligent light spread	SG SW R-Right headlamp
ACT0472	LED exterior lights	SG SW R-Right headlamp
ACT0473	Fan	SG SW R-Right headlamp
ACT0474	Headlamp range adjustment	SG SW R-Right headlamp(E1n9)
ACT0475	Active curve illumination	SG SW R-Right headlamp(E1n9)
ACT0476	Active curve illumination with steering angle	SG SW R-Right headlamp(E1n9)
ACT0477	Intelligent light spread	SG SW R-Right headlamp(E1n9)
ACT0478	LED exterior lights	SG SW R-Right headlamp(E1n9)
ACT0479	Fan	SG SW R-Right headlamp(E1n9)
ACT0480	Interior lamp	OCP-Control unit 'Overhead control panel'
ACT0481	Reading lamps	OCP-Control unit 'Overhead control panel'
ACT0482	Rear lamp	OCP-Control unit 'Overhead control panel'
ACT0483	Mirror lamps of sun visors	OCP-Control unit 'Overhead control panel'
ACT0484	Warning indicator "front parking system"	PARK-Parking system (N62)
ACT0485	Warning indicator "rear parking system"	PARK-Parking system (N62)
ACT0486	Activation	N32/2 (Front passenger seat control unit)
ACT0487	Activation	N32/1 (Driver seat control unit)
ACT0488	Actuation of function "Illumination"	DSI-DIRECT SELECT interface(N150)
ACT0489	Y68/3 (All-wheel drive solenoid valve)	VG-All wheel drive
ACT0490	Actuate component "H3/1 (Alarm siren)".	AS-Alarm siren(H3/1)
ACT0491	N42 (Camera cover control unit)	KAB-Control unit Camera cover
ACT0492	Self-test of control unit "N42 (Camera cover control unit)"	KAB-Control unit Camera cover
ACT0493	Valve flushing	DKG-Electronic transmission control for double-plate clutch transmission
ACT0494	Workshop test	DKG-Electronic transmission control for double-plate clutch transmission
ACT0495	Coolant pump actuation	DKG-Electronic transmission control for double-plate clutch transmission
ACT0496	Test of park pawl	DKG-Electronic transmission control for double-plate clutch transmission
ACT0497	Self-test of system "Differential lock"	DKG-Electronic transmission control for double-plate clutch transmission
ACT0498	Actuation of fuel pump	FSCU-Fuel pump
ACT0499	Empty fuel tank.	FSCU-Fuel pump
ACT0500	M16/57 (Exhaust flap controller)	N127 (Drivetrain control unit)

ACT0501	M16/46 (Low-pressure exhaust gas recirculation actuator motor)	N127 (Drivetrain control unit)
ACT0502	A92/3 (Fuel filter module)	PTCU-Common powertrain controller(N127)
ACT0503	F32k1 (Decoupling relay)	PTCU-Common powertrain controller(N127)
ACT0504	M4/7 (fan motor)	PTCU-Common powertrain controller(N127)
ACT0505	M13/7 (Transmission oil cooling coolant circulation pump)	PTCU-Common powertrain controller(N127)
ACT0506	Status of circuit 87	PTCU-Common powertrain controller(N127)
ACT0507	Y84 (Radiator shutters actuator)	PTCU-Common powertrain controller(N127)
ACT0508	M3 (Fuel pump)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0509	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0510	M16/6 (Throttle valve actuator)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0511	R39/2 (Wide open throttle operation vent line heating element)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0512	Y49/1 (Intake camshaft solenoid)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0513	Y49/2 (Exhaust camshaft solenoid)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0514	Y58/1 (Purging switchover valve)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0515	Y58/4 (Activated charcoal canister shutoff valve)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0516	Y76 (Fuel injectors)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0517	Y31/5 (Boost pressure control pressure transducer)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0518	Y84 (Radiator shutters actuator)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0519	Y94 (Quantity control valve)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0520	Y101 (Deceleration air switchover valve)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0521	Y130 (Engine oil pump valve)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0522	Y133 (Coolant pump switchover valve)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0523	A1e58 (Engine diagnosis indicator lamp)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0524	Mixture formation	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0525	Rail pressure reduction	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0526	Y49/8 (Intake camshaft valve lift switching actuator)	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0527	Exhaust gas recirculation	N3/10-Motor electronics "MED40" for combustion engine "M274"
ACT0528	M3 (Fuel pump)	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
ACT0529	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
ACT0530	M16/6 (Throttle valve actuator)	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
ACT0531	M44 (charge air cooler circulation pump)	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
ACT0532	Y49/1 (Intake camshaft solenoid)	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
ACT0533	Y49/2 (Exhaust camshaft solenoid)	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
ACT0534	Y58/1 (Purging switchover valve)	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
ACT0535	Y76 (Fuel injectors)	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
ACT0536	Y77/1 (Boost pressure positioner)	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"

ACT0537	Y94 (Quantity control valve)	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
ACT0538	Y130 (Engine oil pump valve)	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
ACT0539	A1e58 (Engine diagnosis indicator lamp)	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
ACT0540	Mixture formation	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
ACT0541	Rail pressure reduction	N3/10-Motor electronics "MED40AMG" for combustion engine "M133"
ACT0542	360?camera	CAMERA-360 camera(N148)
ACT0543	A1e58 (Engine diagnosis indicator lamp)	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0544	Check component "Fuel filter heater".	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0545	M16/6 (Throttle valve actuator)	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0546	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0547	M55 (Intake port shutoff actuator motor)	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0548	R39/1 (Vent line heating element)	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0549	R48 (Coolant thermostat heating element)	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0550	Y130 (Engine oil pump valve)	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0551	Y131 (Oil spray nozzles shutoff valve)	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0552	Y133 (Coolant pump switchover valve)	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0553	Y27/9 (Exhaust gas recirculation actuator)	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0554	Y31/4 (Wastegate control pressure transducer)	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0555	Y84 (Radiator shutters actuator)	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0556	Y85 (Exhaust gas recirculation cooler bypass switchover valve)	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0557	Injector shutoff	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0558	Compression test	N3/9-Motor electronics "CR43" for combustion engine "OM651"
ACT0559	M3 (Fuel pump)	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
ACT0560	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
ACT0561	M16/6 (Throttle valve actuator)	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
ACT0562	M55 (Intake port shutoff actuator motor)	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
ACT0563	R39/1 (Vent line heating element)	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
ACT0564	R48 (Coolant thermostat heating element)	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
ACT0565	Switchable engine mounts Y123 (Left switchable engine mount) Y123/1 (Right	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
ACT0566	Y77/1 (Boost pressure positioner)	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
ACT0567	Y85 (Exhaust gas recirculation cooler bypass switchover valve)	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
ACT0568	Y27/9 (Exhaust gas recirculation actuator)	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
ACT0569	Perform diagnostic glowing.	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
ACT0570	Injector shutoff	N3/9-Motor electronics "CDI60LS" for combustion engine "OM642"
ACT0571	Injector shutoff	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
ACT0572	M16/6 (Throttle valve actuator)	N3/9-Motor electronics "CDI61" for combustion engine "OM642"

ACT0573	M3 (Fuel pump)	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
ACT0574	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
ACT0575	M55 (Intake port shutoff actuator motor)	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
ACT0576	Diagnostic glowing	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
ACT0577	R39/1 (Vent line heating element)	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
ACT0578	R48 (Coolant thermostat heating element)	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
ACT0579	Y133 (Coolant pump switchover valve)	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
ACT0580	Y27/9 (Exhaust gas recirculation actuator)	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
ACT0581	Y77/1 (Boost pressure positioner)	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
ACT0582	Y84 (Radiator shutters actuator)	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
ACT0583	Y85 (Exhaust gas recirculation cooler bypass switchover valve)	N3/9-Motor electronics "CDI61" for combustion engine "OM642"
ACT0584	Switch off incline recognition for dynamometer mode.	Y3/8n4-Fully integrated transmission control
ACT0585	Shift transmission to neutral position.	Y3/8n4-Fully integrated transmission control
ACT0586	Switch off incline recognition for dynamometer mode.	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.7
ACT0587	Switch off incline recognition for dynamometer mode.	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9
ACT0588	Valve flushing	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9
ACT0589	Closing of torque converter lockup clutch	Y3/8n4-The fault occurs when charging of the fuel injector takes too long.9
ACT0590	A103/2y1 (AdBlue?switchover valve)	SCR-Selective Catalytic Reduction
ACT0591	AdBlue?delivery pump	SCR-Selective Catalytic Reduction
ACT0592	Dynamic test of component "A103/2m1 (AdBlue?delivery pump)"	SCR-Selective Catalytic Reduction
ACT0593	AdBlue?return	SCR-Selective Catalytic Reduction
ACT0594	Visual leak test	SCR-Selective Catalytic Reduction
ACT0595	Y129 (AdBlue?metering valve)	SCR-Selective Catalytic Reduction
ACT0596	Test of AdBlue?metering amount	SCR-Selective Catalytic Reduction
ACT0597	A103/1r1 (AdBlue?tank heating element)	SCR-Selective Catalytic Reduction
ACT0598	A103/1r2 (AdBlue?pressure line heating element)	SCR-Selective Catalytic Reduction
ACT0599	A103/2r1 (AdBlue?delivery module heating element)	SCR-Selective Catalytic Reduction
ACT0600	A103/2m1 (AdBlue?delivery pump)	SCR-Selective catalytic reduction
ACT0601	A103/2m2 (AdBlue?extraction pump)	SCR-Selective catalytic reduction
ACT0602	A103/1r1 (AdBlue?tank heating element)	SCR-Selective catalytic reduction
ACT0603	R7/1 (AdBlue?pressure line heating element)	SCR-Selective catalytic reduction
ACT0604	Y129 (AdBlue?metering valve)	SCR-Selective catalytic reduction
ACT0605	Visual leak test	SCR-Selective catalytic reduction
ACT0606	Isolation measurement with open contactors-Relay "OPEN"	BMS-Battery management system(N82/2)
ACT0607	Signal generator for interlock circuit	BMS-Battery management system(N82/2)
ACT0608	High-voltage component lock	BMS-Battery management system(N82/2)

ACT0609	Battery capacity/Determination of status of high-voltage battery	BMS-Battery management system(N82/2)
ACT0610	Self-test of control unit "DVD player"	AVE H-Rear audio video unit
ACT0611	Output of test sound	AVE H-Rear audio video unit
ACT0612	Output of an audio and video signal from control unit "COMAND" on the	AVE H-Rear audio video unit
ACT0613	Output of an audio and video signal from the DVD player on the displays in	AVE H-Rear audio video unit
ACT0614	Output of an audio and video signal from the AUX jack on the displays in the	AVE H-Rear audio video unit
ACT0615	Actuator control	TPAD-Touchpad
ACT0616	Control unit reset	TPAD-Touchpad
ACT0617	Calibration of touch-sensitive surface	TPAD-Touchpad
ACT0618	Indicator lamp "Green" of component "X58/23 (Charger feed-in socket)"	SG LG-Charger
ACT0619	Indicator lamp "Red" of component "X58/23 (Charger feed-in socket)"	SG LG-Charger
ACT0620	Indicator lamp "White" of component "X58/23 (Charger feed-in socket)"	SG LG-Charger
ACT0621	Locking or unlocking of charging cable on component "X58/23 (Charger feed-	SG LG-Charger
ACT0622	Locking/unlocking of socket flap	SG LG-Charger
ACT0623	High-voltage component lock	SG LG-Charger
ACT0624	M56 (Vacuum pump)	ESP-Regenerative braking system(N30/6)
ACT0625	A7/3m1 (High-pressure and return flow pump)	ESP-Regenerative braking system(N30/6)
ACT0626	A7/3y11 (Left rear pressure regulating valve (pressure release))	ESP-Regenerative braking system(N30/6)
ACT0627	Control unit reset	COU-Audio/COMAND operating unit (A40/9)
ACT0628	Actuation of pneumatic pump	PPAMKS-Pneumatic pump for active multicontour seat
ACT0629	Clear fault memory	PPAMKS-Pneumatic pump for active multicontour seat
ACT0630	Check overall system for leaktightness and compressed air supply.	PPAMKS-Pneumatic pump for active multicontour seat
ACT0631	M40 (Multicontour seat pneumatic pump)	PPAMKS-Pneumatic pump for multicontour seat
ACT0632	M40/1 (Dynamic multicontour seat pneumatic pump)	PPAMKS-Pneumatic pump for multicontour seat
ACT0633	M40/1 (Active multicontour seat pneumatic pump)	PPAMKS-Pneumatic pump for multicontour seat
ACT0634	Compressed air valveDRAINING	PPAMKS-Pneumatic pump for multicontour seat
ACT0635	Check overall system for leaktightness and compressed air supply.	PPAMKS-Pneumatic pump for multicontour seat
ACT0636	Actuation of air cushion of upper lumbar support	MKS LF-Left front multicontour seat
ACT0637	Actuation of air cushion of lower lumbar support	MKS LF-Left front multicontour seat
ACT0638	Actuation of air cushions in seat side bolsters	MKS LF-Left front multicontour seat
ACT0639	Actuation of air cushion "Seat cushion length"	MKS LF-Left front multicontour seat
ACT0640	ActuationM25/8 (Left front multicontour seat pneumatic pump)	MKS LF-Left front multicontour seat
ACT0641	Check compressed air line between control unit "N32/29 (Driver multicontour	MKS LF-Left front multicontour seat
ACT0642	Check compressed air line between control unit "N32/30 (Front passenger	MKS LF-Left front multicontour seat
ACT0643	Check overall system for leaktightness and compressed air supply.	MKS LF-Left front multicontour seat
ACT0644	NO	CAMERA-360 camera(N148)

ACT0645	Actuation of air cushion of upper lumbar support	MKS RF-Right front multicontour seat
ACT0646	Actuation of air cushion of lower lumbar support	MKS RF-Right front multicontour seat
ACT0647	Actuation of air cushions in seat side bolsters	MKS RF-Right front multicontour seat
ACT0648	Actuation of air cushion "Seat cushion length"	MKS RF-Right front multicontour seat
ACT0649	ActuationM25/9 (Right front multicontour seat pneumatic pump)	MKS RF-Right front multicontour seat
ACT0650	Check compressed air line between control unit "N32/30 (Front passenger	MKS RF-Right front multicontour seat
ACT0651	Check compressed air line between control unit "N32/29 (Driver multicontour	MKS RF-Right front multicontour seat
ACT0652	Check overall system for leaktightness and compressed air supply.	MKS RF-Right front multicontour seat
ACT0653	Calibration of microphone for sound system	SOUND-Bose sound system
ACT0654	H4/1h1 (Left front door tweeter)	SOUND-Bose sound system
ACT0655	H4/2h1 (Right front door tweeter)	SOUND-Bose sound system
ACT0656	H4/3h2 (Left rear woofer)	SOUND-Bose sound system
ACT0657	H4/4h2 (Right rear woofer)	SOUND-Bose sound system
ACT0658	Self-test	SOUND-Bose sound system
ACT0659	Actuate LEDs.	SOUND-Bose sound system
ACT0660	Y36/6y5 (AIRMATIC central reservoir filling valve)	ADS-Adaptive damping system(N51/5)
ACT0661	A9/1y1 (AIRMATIC pressure relief valve)	ADS-Adaptive damping system(N51/5)
ACT0662	K67 (AIRMATIC relay)	ADS-Adaptive damping system(N51/5)
ACT0663	Move to calibrated vehicle level (automatically).	ADS-Adaptive damping system(N51/5)
ACT0664	Move to calibrated vehicle level (manually).	ADS-Adaptive damping system(N51/5)
ACT0665	Y36/6y1 (Left front level control valve)	ADS-Adaptive damping system(N51/5)
ACT0666	Y36/6y2 (Right front level control valve)	ADS-Adaptive damping system(N51/5)
ACT0667	Y36/6y3 (Left rear level control valve)	ADS-Adaptive damping system(N51/5)
ACT0668	Y36/6y4 (Right rear level control valve)	ADS-Adaptive damping system(N51/5)
ACT0669	Left front suspension strut	ADS-Adaptive damping system(N51/5)
ACT0670	Right front suspension strut	ADS-Adaptive damping system(N51/5)
ACT0671	Right rear suspension strut	ADS-Adaptive damping system(N51/5)
ACT0672	Left rear suspension strut	ADS-Adaptive damping system(N51/5)
ACT0673	F58kT (AIRmatic relay)	ADS-Adaptive damping system(N51/5)
ACT0674	Self-test	ECS-N123/4 Emergency call system control unit
ACT0675	H4/27 (Center instrument panel speaker)	ECS-N123/4 Emergency call system control unit
ACT0676	Muting	ECS-N123/4 Emergency call system control unit
ACT0677	Erase fault memory.	TV-TV tuner
ACT0678	M4/7 (Combustion engine and air conditioning with integrated control fan	AAC-Automatic air conditioning
ACT0679	F4kB (Rear window heater relay)	AAC-Automatic air conditioning
ACT0680	F58kS (Wiper park position heater relay)	AAC-Automatic air conditioning

ACT0681	Switch and controls illumination	AAC-Automatic air conditioning
ACT0682	N29 (Electronic blower regulator)	AAC-Automatic air conditioning
ACT0683	N29/8 (Booster blower electronic blower controller)	AAC-Automatic air conditioning
ACT0684	N29/2 (Rear air conditioning electronic blower regulator)	AAC-Automatic air conditioning
ACT0685	M2/8 (Left defroster flap actuator motor)	AAC-Automatic air conditioning
ACT0686	M2/9 (Right defroster flap actuator motor)	AAC-Automatic air conditioning
ACT0687	M2/10 (Left footwell flap actuator motor)	AAC-Automatic air conditioning
ACT0688	M2/11 (Right footwell flap actuator motor)	AAC-Automatic air conditioning
ACT0689	M2/21 (Rear actuator motor blend air flap with shutoff function)	AAC-Automatic air conditioning
ACT0690	M2/35 (Rear air distribution flap actuator motor)	AAC-Automatic air conditioning
ACT0691	M2/12 (Left center air vent flap actuator motor)	AAC-Automatic air conditioning
ACT0692	M2/13 (Right center air vent flap actuator motor)	AAC-Automatic air conditioning
ACT0693	M16/33 (Left B-pillar air distribution actuator motor)	AAC-Automatic air conditioning
ACT0694	M16/34 (Right B-pillar air distribution actuator motor)	AAC-Automatic air conditioning
ACT0695	M2/16 (Defroster flap actuator motor)	AAC-Automatic air conditioning
ACT0696	M2/22 (Center vent flap positioning motor)	AAC-Automatic air conditioning
ACT0697	M2/15 (Footwell flap positioning motor)	AAC-Automatic air conditioning
ACT0698	M2/21 (Fresh air flap actuator)	AAC-Automatic air conditioning
ACT0699	Windshield heater	AAC-Automatic air conditioning
ACT0700	Y19/9 (Rear air conditioning evaporator shutoff valve)	AAC-Automatic air conditioning
ACT0701	Y19/3 (Front evaporator shutoff valve)	AAC-Automatic air conditioning
ACT0702	Y16 (Stationary heater switchover valve)	AAC-Automatic air conditioning
ACT0703	N18/9 (Driver side air vent ionizer)	AAC-Automatic air conditioning
ACT0704	Test sound	SOGESTAR2-Sound generator for electric vehicle
ACT0705	Tilting/sliding sunroof	SD-Control module 'Sliding roof' (A98/1)
ACT0706	Panoramic sliding sunroof	PSD-Control module 'Panoramic sliding roof'(A98)
ACT0707	Roller sun blind	PSD-Control module 'Panoramic sliding roof'(A98)
ACT0708	A76 (Left front reversible emergency tensioning retractor)	RevETR LF-Left front reversible emergency tensioning retractor (A76)
ACT0709	A76/1 (Right front reversible emergency tensioning retractor)	RevETR RF-Right front reversible emergency tensioning retractor(A76/1)
ACT0710	N83/1 (DC/DC converter control unit)	DDW-DC/DC converter(N83/1)
ACT0711	Self-test	D FOL-Display in left rear passenger compartment
ACT0712	Test picture display	D FOL-Display in left rear passenger compartment
ACT0713	Output of test sound	D FOL-Display in left rear passenger compartment
ACT0714	Output of an audio and video signal from the DVD player on the displays in	D FOL-Display in left rear passenger compartment
ACT0715	Output of an audio and video signal from the AUX jack on the displays in the	D FOL-Display in left rear passenger compartment
ACT0716	Activation	N32/31 (Left front seat massage function control unit)

ACT0717	Actuation of actuator motor in position "P R N D"	ISM-Shift module
ACT0718	Charging of suspension fluid reservoir	ISM-Shift module
ACT0719	Change to normal mode	ISM-Shift module
ACT0720	Shift transmission to neutral position.	ISM-Shift module
ACT0721	Selection of drive position	ISM-Shift module
ACT0722	Activation	N32/32 (Right front seat massage function control unit)
ACT0723	Self-test	D FOR-Display in right rear passenger compartment
ACT0724	Test picture display	D FOR-Display in right rear passenger compartment
ACT0725	Output of test sound	D FOR-Display in right rear passenger compartment
ACT0726	Output of an audio and video signal from the DVD player on the displays in	D FOR-Display in right rear passenger compartment
ACT0727	Output of an audio and video signal from the AUX jack on the displays in the	D FOR-Display in right rear passenger compartment
ACT0728	Heater pads in rear passenger compartment	REAR-Rear control unit(N10/8)
ACT0729	Left and right pop-out window	REAR-Rear control unit(N10/8)
ACT0730	Ambiance illumination "Cockpit"	REAR-Rear control unit(N10/8)
ACT0731	Illuminated door sill moldings	REAR-Rear control unit(N10/8)
ACT0732	M14/7 (Liftgate central locking motor)	REAR-Rear control unit(N10/8)
ACT0733	E40 (Liftgate ambient lamp)	REAR-Rear control unit(N10/8)
ACT0734	S62/36e1 (Liftgate control button symbol illumination)	REAR-Rear control unit(N10/8)
ACT0735	Code 843 (Electric EASY-ENTRY)	REAR-Rear control unit(N10/8)
ACT0736	Third seat row can be folded forward.	REAR-Rear control unit(N10/8)
ACT0737	M35/2 (Rear camera cover motor)	REAR-Rear control unit(N10/8)
ACT0738	B84 (Infrared camera)	NSA-Night View Assist(N101)
ACT0739	A40/8 (Audio/COMAND display)	NSA-Night View Assist(N101)
ACT0740	Infrared light	NSA-Night View Assist(N101)
ACT0741	Left outside mirror adjustment	DCU LR-Left rear door(N69/3)
ACT0742	Left mirror heater	DCU LR-Left rear door(N69/3)
ACT0743	Folding in/out of left outside mirror	DCU LR-Left rear door(N69/3)
ACT0744	Mirror dimming	DCU LR-Left rear door(N69/3)
ACT0745	Left memory function	DCU LR-Left rear door(N69/3)
ACT0746	Blind Spot Assist	DCU LR-Left rear door(N69/3)
ACT0747	Door handle illumination "Left rear door"	DCU LR-Left rear door(N69/3)
ACT0748	Switch illumination "Left rear door"	DCU LR-Left rear door(N69/3)
ACT0749	Turn signal lamp in left outside mirror	DCU LR-Left rear door(N69/3)
ACT0750	LEDs	DCU LR-Left rear door(N69/3)
ACT0751	Exit and warning lamp "Left rear door"	DCU LR-Left rear door(N69/3)
ACT0752	E17/45 (Left rear door ambiance illumination)	DCU LR-Left rear door(N69/3)

ACT0753	Ambient illumination	DCU LR-Left rear door(N69/3)
ACT0754	LED of switch "Rear passenger compartment seat heater"	DCU LR-Left rear door(N69/3)
ACT0755	Left rear power window	DCU LR-Left rear door(N69/3)
ACT0756	Denormalization of left rear power window	DCU LR-Left rear door(N69/3)
ACT0757	Central locking "Left rear door"	DCU LR-Left rear door(N69/3)
ACT0758	Additional door lock "Left rear door"	DCU LR-Left rear door(N69/3)
ACT0759	Start control unit reset.	DCU LR-Left rear door(N69/3)
ACT0760	Left outside mirror adjustment	DCU RR-Right rear door(N69/4)
ACT0761	Left mirror heater	DCU RR-Right rear door(N69/4)
ACT0762	Folding in/out of left outside mirror	DCU RR-Right rear door(N69/4)
ACT0763	Mirror dimming	DCU RR-Right rear door(N69/4)
ACT0764	Left memory function	DCU RR-Right rear door(N69/4)
ACT0765	Blind Spot Assist	DCU RR-Right rear door(N69/4)
ACT0766	Door handle illumination "Right rear door"	DCU RR-Right rear door(N69/4)
ACT0767	Switch illumination "Right rear door"	DCU RR-Right rear door(N69/4)
ACT0768	Turn signal lamp in left outside mirror	DCU RR-Right rear door(N69/4)
ACT0769	LEDs	DCU RR-Right rear door(N69/4)
ACT0770	Exit and warning lamp "Right rear door"	DCU RR-Right rear door(N69/4)
ACT0771	E17/46 (Right rear door ambiance illumination)	DCU RR-Right rear door(N69/4)
ACT0772	Ambient illumination	DCU RR-Right rear door(N69/4)
ACT0773	LED of switch "Rear passenger compartment seat heater"	DCU RR-Right rear door(N69/4)
ACT0774	Right rear power window	DCU RR-Right rear door(N69/4)
ACT0775	Denormalization of right rear power window	DCU RR-Right rear door(N69/4)
ACT0776	Central locking "Right rear door"	DCU RR-Right rear door(N69/4)
ACT0777	Additional door lock "Right rear door"	DCU RR-Right rear door(N69/4)
ACT0778	Start control unit reset.	DCU RR-Right rear door(N69/4)
ACT0779	Directional control valves	RC-Roll control(B38/2)
ACT0780	Pressure control valves	RC-Roll control(B38/2)
ACT0781	Y86/2 (Active Roll Stabilization throttle valve)	RC-Roll control(B38/2)
ACT0782	Y86/3 (Active roll stabilization safety valve)	RC-Roll control(B38/2)
ACT0783	Bleeding of hydraulic system	RC-Roll control(B38/2)
ACT0784	High-pressure test	RC-Roll control(B38/2)
ACT0785	Vertical calibration	RC-Roll control(B38/2)
ACT0786	Horizontal calibration	RC-Roll control(B38/2)
ACT0787	Switch and controls illumination	HBF-Rear control panel(N72/2)
ACT0788	LEDs	HBF-Rear control panel(N72/2)

ACT0789	Output of an audio and video signal from control unit "TV tuner" on the	AVE H-Rear audio video unit
ACT0790	Activation	PTS-Parktronic system
ACT0791	Shift transfer case.	VG-Transfer case
ACT0792	Actuate component "Y108 (Transfer case switchover magnet)".	VG-Transfer case
ACT0793	Actuate component "Interaxle differential lock".	VG-Transfer case
ACT0794	LED exterior lights	E1n7 (Actuation module, LED exterior lighting, left front)
ACT0795	Fan	E1n7 (Actuation module, LED exterior lighting, left front)
ACT0796	LED exterior lights	AMLAB L 2-Actuation module 2, LED exterior lighting, left front(E1n8)
ACT0797	Fan	AMLAB L 2-Actuation module 2, LED exterior lighting, left front(E1n8)
ACT0798	LED exterior lights	E2n7 (Actuation module, LED exterior lighting, right front)
ACT0799	Fan	E2n7 (Actuation module, LED exterior lighting, right front)
ACT0800	LED exterior lights	AMLAB R 2-Actuation module 2, LED exterior lighting, right front(E2n8)
ACT0801	Fan	AMLAB R 2-Actuation module 2, LED exterior lighting, right front(E2n8)
ACT0802	M16/6 (Throttle valve actuator)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0803	M3 (Fuel pump)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0804	M4/7 (Combustion engine and air conditioning with integrated control fan	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0805	M44 (charge air cooler circulation pump)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0806	Y16/2 (Heating system shutoff valve)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0807	Y49/4 (Left intake camshaft solenoid)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0808	Y49/5 (Right intake camshaft solenoid)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0809	Y49/6 (Left exhaust camshaft solenoid)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0810	Y49/7 (Right exhaust camshaft solenoid)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0811	Y58/1 (Purging switchover valve)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0812	Y58/4 (Activated charcoal canister shutoff valve)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0813	Y76 (Fuel injectors)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0814	Y77/1 (Boost pressure positioner)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0815	Y77/2 (Intake manifold resonance flap switchover valve)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0816	Y77/3 (Intake manifold selector drum switchover valve)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0817	Y84 (Radiator shutters actuator)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0818	Y93 (Exhaust flap switchover valve)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0819	Y130 (Engine oil pump valve)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0820	Y137 (High-temperature/low-temperature circuit switchover valve)	N3/10-Motor electronics "MED177" for combustion engine "M276"
ACT0821	M16/6 (Throttle valve actuator)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0822	M3 (Fuel pump)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0823	M4/7 (Combustion engine and air conditioning with integrated control fan	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0824	M45 (Coolant circulation pump)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"

ACT0825	Y16/2 (Heating system shutoff valve)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0826	Y49/4 (Left intake camshaft solenoid)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0827	Y49/5 (Right intake camshaft solenoid)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0828	Y49/6 (Left exhaust camshaft solenoid)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0829	Y49/7 (Right exhaust camshaft solenoid)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0830	Y58/1 (Purging switchover valve)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0831	Y58/4 (Activated charcoal canister shutoff valve)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0832	Y76 (Fuel injectors)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0833	Y77/1 (Boost pressure positioner)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0834	Y84 (Radiator shutters actuator)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0835	M87 (Radiator shutters actuator motor)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0836	Y93 (Exhaust flap switchover valve)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0837	Y130 (Engine oil pump valve)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0838	Y101/1 (Left bypass air switchover valve)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0839	Y101/2 (Right bypass air switchover valve)	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0840	Exhaust gas recirculation	N3/10-Motor electronics "MED177V6LA" for combustion engine "M276Turbocharger"
ACT0841	Button illumination of multifunction steering wheel	SCCM-Steering column module(N80)
ACT0842	S40/4v1 (SPEEDTRONIC light-emitting diode)	SCCM-Steering column module(N80)
ACT0843	M99 (Steering wheel vibration motor)	SCCM-Steering column module(N80)
ACT0844	S59/1e1 (Steering wheel heater indicator lamp)	SCCM-Steering column module(N80)
ACT0845	Illumination of component "S16/13 (DIRECT SELECT lever)"	SCCM-Steering column module(N80)
ACT0846	MAGIC SKY CONTROL	MSC-MAGIC SKY CONTROL(N53)
ACT0847	Y10 (Speed-sensitive power steering solenoid valve)	ESP- Electric stability program
ACT0848	Y10/1 (Power steering pump quantity control valve)	ESP- Electric stability program
ACT0849	A7/3m1 (High-pressure and return flow pump)	ESP- Electric stability program
ACT0850	A7/3y11 (Left rear pressure regulating valve (pressure release))	ESP- Electric stability program
ACT0851	KEYLESS GO test of ignition key	KG-KEYLESS GO
ACT0852	KEYLESS-GO key search	KG-KEYLESS GO
ACT0853	KEYLESS GO system test	KG-KEYLESS GO
ACT0854	Test of the entire KEYLESS GO system	KG-KEYLESS GO
ACT0855	Opening assists "KEYLESS GO"	KG-KEYLESS GO(N69/5)
ACT0856	KEYLESS GO test of ignition key	KG-KEYLESS GO(N69/5)
ACT0857	Test of the entire KEYLESS GO system	KG-KEYLESS GO(N69/5)
ACT0858	Y51 (Left front axle damping valve unit)	ADS-Adaptive damping system
ACT0859	Y52 (Right front axle damping valve unit)	ADS-Adaptive damping system
ACT0860	Y53 (Left rear axle damping valve unit)	ADS-Adaptive damping system

ACT0861	Y54 (Right rear axle damping valve unit)	ADS-Adaptive damping system
ACT0862	A32m1 (Blower motor)	AAC-Automatic air conditioning
ACT0863	M16/22 (Air distribution flap actuator motor)	AAC-Automatic air conditioning
ACT0864	M2/14 (Blend air flap actuator motor)	AAC-Automatic air conditioning
ACT0865	M27/1 (Driver seat fore/aft adjustment motor)	N32/1 (Driver seat control unit)
ACT0866	M27/2 (Driver seat height adjustment motor)	N32/1 (Driver seat control unit)
ACT0867	M27/3 (Driver seat inclination adjustment motor)	N32/1 (Driver seat control unit)
ACT0868	M27/4 (Head restraint adjustment motor, driver seat)	N32/1 (Driver seat control unit)
ACT0869	M27/5 (Driver seat backrest inclination adjustment motor)	N32/1 (Driver seat control unit)
ACT0870	Steering column adjustment	N32/1 (Driver seat control unit)
ACT0871	M28/1 (Front passenger seat fore/aft adjustment motor)	N32/2 (Front passenger seat control unit)
ACT0872	M28/2 (Front passenger seat height adjustment motor)	N32/2 (Front passenger seat control unit)
ACT0873	M28/3 (Front passenger seat inclination adjustment motor)	N32/2 (Front passenger seat control unit)
ACT0874	M28/4 (Head restraint adjustment motor, front passenger seat)	N32/2 (Front passenger seat control unit)
ACT0875	M28/5 (Front passenger seat backrest inclination adjustment motor)	N32/2 (Front passenger seat control unit)
ACT0876	Voltages	Driver side SAM-Driver signal acquisition and actuation module
ACT0877	ECO start/stop function	Driver side SAM-Driver signal acquisition and actuation module
ACT0878	Exterior illumination	Driver side SAM-Driver signal acquisition and actuation module
ACT0879	Interior illumination	Driver side SAM-Driver signal acquisition and actuation module
ACT0880	Air conditioning	Driver side SAM-Driver signal acquisition and actuation module
ACT0881	Wipe and wash	Driver side SAM-Driver signal acquisition and actuation module
ACT0882	Central lockingRear doors	Driver side SAM-Driver signal acquisition and actuation module
ACT0883	N10/1kO (Fanfare horn relay)	Driver side SAM-Driver signal acquisition and actuation module
ACT0884	Voltages	Driver side SAM-Front signal acquisition and actuation module
ACT0885	ECO start/stop function	Driver side SAM-Front signal acquisition and actuation module
ACT0886	Exterior illumination	Driver side SAM-Front signal acquisition and actuation module
ACT0887	Interior illumination	Driver side SAM-Front signal acquisition and actuation module
ACT0888	Air conditioning	Driver side SAM-Front signal acquisition and actuation module
ACT0889	Wipe and wash	Driver side SAM-Front signal acquisition and actuation module
ACT0890	Central lockingRear doors	Driver side SAM-Front signal acquisition and actuation module
ACT0891	N10/1kO (Fanfare horn relay)	Driver side SAM-Front signal acquisition and actuation module
ACT0892	Taillight	Rear SAM-Rear signal acquisition and actuation module
ACT0893	Side-marker lamp/Taillight	Rear SAM-Rear signal acquisition and actuation module
ACT0894	Rear side-marker lamps	Rear SAM-Rear signal acquisition and actuation module
ACT0895	Background illumination	Rear SAM-Rear signal acquisition and actuation module
ACT0896	Brake light	Rear SAM-Rear signal acquisition and actuation module

ACT0897	Rear fog lamp	Rear SAM-Rear signal acquisition and actuation module
ACT0898	Backup light	Rear SAM-Rear signal acquisition and actuation module
ACT0899	Rear turn signal lamps	Rear SAM-Rear signal acquisition and actuation module
ACT0900	License plate lamps	Rear SAM-Rear signal acquisition and actuation module
ACT0901	Trunk lamp	Rear SAM-Rear signal acquisition and actuation module
ACT0902	E40 (Trunk lid ambient lamp)	Rear SAM-Rear signal acquisition and actuation module
ACT0903	E17/27 (Trunk lid warning/ambient lamp)	Rear SAM-Rear signal acquisition and actuation module
ACT0904	Illumination of component "S62/36 (Tailgate control button)"	Rear SAM-Rear signal acquisition and actuation module
ACT0905	Illumination of component "S88/10 (Trunk lid emergency opening switch)"	Rear SAM-Rear signal acquisition and actuation module
ACT0906	N10/2kA (Circuit 15 relay)	Rear SAM-Rear signal acquisition and actuation module
ACT0907	Relay "Circuit 15R"	Rear SAM-Rear signal acquisition and actuation module
ACT0908	F32k2 (No-load current cutout relay)	Rear SAM-Rear signal acquisition and actuation module
ACT0909	M14/7 (Liftgate central locking motor)	Rear SAM-Rear signal acquisition and actuation module
ACT0910	M14/10 (Tank cap central locking motor)	Rear SAM-Rear signal acquisition and actuation module
ACT0911	M14/18 (Glove compartment central locking actuator motor)/M14/19	Rear SAM-Rear signal acquisition and actuation module
ACT0912	M14/31 (Liftgate lock element)	Rear SAM-Rear signal acquisition and actuation module
ACT0913	Left front seat heater	Rear SAM-Rear signal acquisition and actuation module
ACT0914	Right front seat heater	Rear SAM-Rear signal acquisition and actuation module
ACT0915	N29/5 (Left front seat ventilation blower regulator)	Rear SAM-Rear signal acquisition and actuation module
ACT0916	N29/6 (Right front seat ventilation blower regulator)	Rear SAM-Rear signal acquisition and actuation module
ACT0917	R1 (Rear window heater)	Rear SAM-Rear signal acquisition and actuation module
ACT0918	N10/2kE (Liftgate window wiper relay)	Rear SAM-Rear signal acquisition and actuation module
ACT0919	M24 (Rear window roller sun blind motor)	Rear SAM-Rear signal acquisition and actuation module
ACT0920	M40 (Multicontour seat pneumatic pump)	Rear SAM-Rear signal acquisition and actuation module
ACT0921	Head restraint release in rear passenger compartment	Rear SAM-Rear signal acquisition and actuation module
ACT0922	M24/11 (Trunk partition motor)	Rear SAM-Rear signal acquisition and actuation module
ACT0923	Actuation of load compartment cover	Rear SAM-Rear signal acquisition and actuation module
ACT0924	Erase alarm sources.	Rear SAM-Rear signal acquisition and actuation module
ACT0925	Wiper blade heater	Rear SAM-Rear signal acquisition and actuation module
ACT0926	Transport mode	Rear SAM-Rear signal acquisition and actuation module
ACT0927	E3 (Left rear lamp unit)	Rear SAM-Rear signal acquisition and actuation module
ACT0928	E4 (Right rear lamp unit)	Rear SAM-Rear signal acquisition and actuation module
ACT0929	E3/7 (Center rear lamp unit)	Rear SAM-Rear signal acquisition and actuation module
ACT0930	E3/6 (Rear fog lamp)	Rear SAM-Rear signal acquisition and actuation module
ACT0931	E3/5 (Left rear additional lamp)	Rear SAM-Rear signal acquisition and actuation module
ACT0932	E4/5 (Right rear additional lamp)	Rear SAM-Rear signal acquisition and actuation module

ACT0933	Exterior illuminationComponents197(Only for the development department)	Rear SAM-Rear signal acquisition and actuation module
ACT0934	Exterior illuminationFunctions view197(Only for the development department)	Rear SAM-Rear signal acquisition and actuation module
ACT0935	Exterior illuminationComponents207 / 212(Only for the development	Rear SAM-Rear signal acquisition and actuation module
ACT0936	Exterior illuminationFunctions view207 / 212(Only for the development	Rear SAM-Rear signal acquisition and actuation module
ACT0937	Exterior illuminationComponents204 / 204X ohne ERT(Only for the	Rear SAM-Rear signal acquisition and actuation module
ACT0938	Exterior illuminationFunctions view204 / 204X ohne ERT(Only for the	Rear SAM-Rear signal acquisition and actuation module
ACT0939	STATICCurrentSwitches	Rear SAM-Rear signal acquisition and actuation module
ACT0940	VIA_SAT	Rear SAM-Rear signal acquisition and actuation module
ACT0941	Air admissionSOUND	Rear SAM-Rear signal acquisition and actuation module
ACT0942	Characters	Rear SAM-Rear signal acquisition and actuation module
ACT0943	Taillight	REAR SAM-Rear signal acquisition and actuation module
ACT0944	Side-marker lamp/Taillight	REAR SAM-Rear signal acquisition and actuation module
ACT0945	Rear side-marker lamps	REAR SAM-Rear signal acquisition and actuation module
ACT0946	Background illumination	REAR SAM-Rear signal acquisition and actuation module
ACT0947	Brake light	REAR SAM-Rear signal acquisition and actuation module
ACT0948	Rear fog lamp	REAR SAM-Rear signal acquisition and actuation module
ACT0949	Backup light	REAR SAM-Rear signal acquisition and actuation module
ACT0950	Rear turn signal lamps	REAR SAM-Rear signal acquisition and actuation module
ACT0951	License plate lamps	REAR SAM-Rear signal acquisition and actuation module
ACT0952	Trunk lamp	REAR SAM-Rear signal acquisition and actuation module
ACT0953	E40 (Trunk lid ambient lamp)	REAR SAM-Rear signal acquisition and actuation module
ACT0954	E17/27 (Trunk lid warning/ambient lamp)	REAR SAM-Rear signal acquisition and actuation module
ACT0955	Illumination of component "S62/36 (Tailgate control button)"	REAR SAM-Rear signal acquisition and actuation module
ACT0956	Illumination of component "S88/10 (Trunk lid emergency opening switch)"	REAR SAM-Rear signal acquisition and actuation module
ACT0957	N10/2kA (Circuit 15 relay)	REAR SAM-Rear signal acquisition and actuation module
ACT0958	Relay "Circuit 15R"	REAR SAM-Rear signal acquisition and actuation module
ACT0959	F32k2 (No-load current cutout relay)	REAR SAM-Rear signal acquisition and actuation module
ACT0960	M14/7 (Liftgate central locking motor)	REAR SAM-Rear signal acquisition and actuation module
ACT0961	M14/10 (Tank cap central locking motor)	REAR SAM-Rear signal acquisition and actuation module
ACT0962	M14/18 (Glove compartment central locking actuator motor)/M14/19	REAR SAM-Rear signal acquisition and actuation module
ACT0963	M14/31 (Liftgate lock element)	REAR SAM-Rear signal acquisition and actuation module
ACT0964	Left front seat heater	REAR SAM-Rear signal acquisition and actuation module
ACT0965	Right front seat heater	REAR SAM-Rear signal acquisition and actuation module
ACT0966	N29/5 (Left front seat ventilation blower regulator)	REAR SAM-Rear signal acquisition and actuation module
ACT0967	N29/6 (Right front seat ventilation blower regulator)	REAR SAM-Rear signal acquisition and actuation module
ACT0968	R1 (Rear window heater)	REAR SAM-Rear signal acquisition and actuation module

ACT0969	N10/2kE (Liftgate window wiper relay)	REAR SAM-Rear signal acquisition and actuation module
ACT0970	M24 (Rear window roller sun blind motor)	REAR SAM-Rear signal acquisition and actuation module
ACT0971	M40 (Multicontour seat pneumatic pump)	REAR SAM-Rear signal acquisition and actuation module
ACT0972	Head restraint release in rear passenger compartment	REAR SAM-Rear signal acquisition and actuation module
ACT0973	M24/11 (Trunk partition motor)	REAR SAM-Rear signal acquisition and actuation module
ACT0974	Actuation of load compartment cover	REAR SAM-Rear signal acquisition and actuation module
ACT0975	Erase alarm sources.	REAR SAM-Rear signal acquisition and actuation module
ACT0976	Wiper blade heater	REAR SAM-Rear signal acquisition and actuation module
ACT0977	Transport mode	REAR SAM-Rear signal acquisition and actuation module
ACT0978	E3 (Left rear lamp unit)	REAR SAM-Rear signal acquisition and actuation module
ACT0979	E4 (Right rear lamp unit)	REAR SAM-Rear signal acquisition and actuation module
ACT0980	E3/7 (Center rear lamp unit)	REAR SAM-Rear signal acquisition and actuation module
ACT0981	E3/6 (Rear fog lamp)	REAR SAM-Rear signal acquisition and actuation module
ACT0982	E3/5 (Left rear additional lamp)	REAR SAM-Rear signal acquisition and actuation module
ACT0983	E4/5 (Right rear additional lamp)	REAR SAM-Rear signal acquisition and actuation module
ACT0984	Exterior illuminationComponents197(Only for the development department)	REAR SAM-Rear signal acquisition and actuation module
ACT0985	Exterior illuminationFunctions view197(Only for the development department)	REAR SAM-Rear signal acquisition and actuation module
ACT0986	Exterior illuminationComponents207 / 212(Only for the development	REAR SAM-Rear signal acquisition and actuation module
ACT0987	Exterior illuminationFunctions view207 / 212(Only for the development	REAR SAM-Rear signal acquisition and actuation module
ACT0988	Exterior illuminationComponents204 / 204X ohne ERT(Only for the	REAR SAM-Rear signal acquisition and actuation module
ACT0989	Exterior illuminationFunctions view204 / 204X ohne ERT(Only for the	REAR SAM-Rear signal acquisition and actuation module
ACT0990	STATICCurrentSwitches	REAR SAM-Rear signal acquisition and actuation module
ACT0991	VIA SAT	REAR SAM-Rear signal acquisition and actuation module
ACT0992	Air admissionSOUND	REAR SAM-Rear signal acquisition and actuation module
ACT0993	Characters	REAR SAM-Rear signal acquisition and actuation module
ACT0994	LED of switch "S51/4 (Right rear seat heater button)"	LFD-Left front door
ACT0995	Switch "Roller sun blind for right rear door"	LFD-Left front door
ACT0996	LED of switch "S51/4 (Right rear seat heater button)"	DCU RF-Right front door
ACT0997	Roller sun blind for right rear door	DCU RF-Right front door
ACT0998	Roller sun blind for left rear door	DCU RF-Right front door
ACT0999	M10/5 (Left rear power window motor)	STC-Soft top control(N52)
ACT1000	M10/6 (Right rear power window motor)	STC-Soft top control(N52)
ACT1001	Switch illumination of Vario roof control	STC-Soft top control(N52)
ACT1002	R lock	N15/5 (Electronic selector lever module control unit)
ACT1003	P lock	N15/5 (Electronic selector lever module control unit)
ACT1004	Function illumination	N15/5 (Electronic selector lever module control unit)

ACT1005	Windshield wiper FSW	FSW-Windshield wiper
ACT1006	NO	PTS-Parktronic system
ACT1007	H3/1 (Alarm siren)	AS-Alarm siren(H3/1)
ACT1008	Actuation of components "N70s8 (Interior protection button)" and "N70s9	ATA-ATA[EDW]/tow-away protection/interior protection
ACT1009	Self-test of control unit "Interior protection and tow-away protection"	ATA-ATA[EDW]/tow-away protection/interior protection
ACT1010	M16/6 (Throttle valve actuator)	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
ACT1011	M3 (Fuel pump)	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
ACT1012	M4/7 (Combustion engine and air conditioning with integrated control fan	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
ACT1013	Y16/2 (Heating system shutoff valve)	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
ACT1014	Y49/4 (Left intake camshaft solenoid)	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
ACT1015	Y49/5 (Right intake camshaft solenoid)	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
ACT1016	Y49/6 (Left exhaust camshaft solenoid)	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
ACT1017	Y49/7 (Right exhaust camshaft solenoid)	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
ACT1018	Y58/1 (Purging switchover valve)	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
ACT1019	Y58/4 (Activated charcoal canister shutoff valve)	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
ACT1020	Y76 (Fuel injectors)	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
ACT1021	Y84 (Radiator shutters actuator)	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
ACT1022	Y130 (Engine oil pump valve)	MED177AMG-Motor electronics 'MED177AMG' for combustion engine 'M152'
ACT1023	High fuel pressure	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1024	M3 (Fuel pump)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1025	M4/7 (Combustion engine and air conditioning with integrated control fan	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1026	M16/6 (Throttle valve actuator)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1027	M33 (Electric air pump)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1028	M59 (Intake manifold swirl flap actuator motor)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1029	Y16/2 (Heating system shutoff valve)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1030	Y31/4 (Wastegate control pressure transducer)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1031	Y32 (Air pump switchover valve)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1032	Y49/1 (Intake camshaft solenoid)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1033	Y49/2 (Exhaust camshaft solenoid)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1034	Y58/1 (Purging switchover valve)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1035	Y58/4 (Activated charcoal canister shutoff valve)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1036	Y76 (Fuel injectors)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1037	Y84 (Radiator shutters actuator)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1038	Y101 (Deceleration air switchover valve)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1039	Mixture formation	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1040	Secondary air injection	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"

ACT1041	Y94 (Quantity control valve)	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1042	Thermal management	N3/10-Motor electronics "SIM271DE20" for combustion engine "M271EVO"
ACT1043	Self-test	AUDIO-Audio(A2)
ACT1044	Sample display	AUDIO-Audio(A2)
ACT1045	Antenna measuring drive	AUDIO-Audio(A2)
ACT1046	Wiring test of radio antennas	AUDIO-Audio(A2)
ACT1047	Left front speaker group	AUDIO-Audio(A2)
ACT1048	Right front speaker group	AUDIO-Audio(A2)
ACT1049	H4/3 (Left rear door speaker)	AUDIO-Audio(A2)
ACT1050	H4/4 (Right rear door speaker)	AUDIO-Audio(A2)
ACT1051	TestUSB interface	AUDIO-Audio(A2)
ACT1052	Perform control unit reset.	AUDIO-Audio(A2)
ACT1053	Warning indicators "Parking system"	PTS-Parktronic system
ACT1054	Soft top	STC-Soft top control(N52)
ACT1055	Actuation of left side flap	STC-Soft top control(N52)
ACT1056	Actuation of right side flap	STC-Soft top control(N52)
ACT1057	Actuation of soft top lock	STC-Soft top control(N52)
ACT1058	M3 (Fuel pump)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1059	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1060	M16/3 (Front throttle valve actuator)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1061	M16/4 (Rear throttle valve actuator)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1062	M33 (Electric air pump)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1063	Y22/6 (Intake manifold switchover valve)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1064	Y32 (Air pump switchover valve)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1065	Y32/1 (Air pump 1 switchover valve)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1066	Y32/2 (Air pump 2 switchover valve)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1067	Y49/4 (Left intake camshaft solenoid)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1068	Y49/5 (Right intake camshaft solenoid)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1069	Y49/6 (Left exhaust camshaft solenoid)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1070	Y49/7 (Right exhaust camshaft solenoid)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1071	Y58/1 (Purging switchover valve)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1072	M4/1 (Oil cooler fan motor)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1073	Y58/4 (Activated charcoal canister shutoff valve)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1074	Y62 (Injection valves)	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1075	Compression test	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"
ACT1076	Mixture formation	N3/10-Motor electronics "ME97 AMG" for combustion engine "M156"

ACT1077	M75/7 (Rear high-voltage battery coolant pump)	BMS-H-Battery management system, rear (master)
ACT1078	Isolation measurement	BMS-H-Battery management system, rear (master)
ACT1079	Measurement log for self-discharge of battery cells	BMS-H-Battery management system, rear (master)
ACT1080	A1h1 (Warning buzzer)	IC-Instrument cluster(A1)
ACT1081	Mechanical instrument pointers	IC-Instrument cluster(A1)
ACT1082	A1p13 (Multifunction display)	IC-Instrument cluster(A1)
ACT1083	Indicator lamps	IC-Instrument cluster(A1)
ACT1084	A1e8 (Instrument illumination)	IC-Instrument cluster(A1)
ACT1085	Control unit reset	IC-Instrument cluster(A1)
ACT1086	Segments on speedometer	IC-Instrument cluster(A1)
ACT1087	Button illumination of multifunction steering wheel	SCM [MRM]-Steering column module
ACT1088	Function illumination "SPEEDTRONIC"	SCM [MRM]-Steering column module
ACT1089	Switchover of video signal source	AMG PM-AMG Performance Media(N125/2)
ACT1090	Y10 (Speed-sensitive power steering solenoid valve)	ESP-Electronic stability program(N30/4)
ACT1091	A7/3y7 (Left front pressure regulating valve (pressure release))	ESP-Electronic stability program(N30/4)
ACT1092	Perform current adjustment.	ELM-VL-Front left electrical machine
ACT1093	Perform voltage adjustment.	ELM-VL-Front left electrical machine
ACT1094	L20/4 (Left front electrical machine rotor position sensor)	ELM-VL-Front left electrical machine
ACT1095	Reset of "Sensor "Voltage of high-voltage on-board electrical system""	ELM-VL-Front left electrical machine
ACT1096	Check contact of component "Front left electrical machine".	ELM-VL-Front left electrical machine
ACT1097	Lock high-voltage component lock.	ELM-VL-Front left electrical machine
ACT1098	Unlock high-voltage component lock.	ELM-VL-Front left electrical machine
ACT1099	Reset of frequency counter "Emergency shutoff of component 'N129/4 (Left	ELM-VL-Front left electrical machine
ACT1100	Resetting of frequency counter "Emergency shutoff due to implausible torque	ELM-VL-Front left electrical machine
ACT1101	Perform control unit reset.	ELM-VL-Front left electrical machine
ACT1102	Wake-up line	Audio-Audio or COMAND
ACT1103	Internal fan	Audio-Audio or COMAND
ACT1104	External fan	Audio-Audio or COMAND
ACT1105	Determination of number of receivable radio transmitters	Audio-Audio or COMAND
ACT1106	Wiring test of radio antennas	Audio-Audio or COMAND
ACT1107	Measurement of reception field strength	Audio-Audio or COMAND
ACT1108	Antenna measuring drive	Audio-Audio or COMAND
ACT1109	Speaker	Audio-Audio or COMAND
ACT1110	Electrical self-test of microphones.	Audio-Audio or COMAND
ACT1111	Volume level	Audio-Audio or COMAND
ACT1112	Color display	Audio-Audio or COMAND

ACT1113	Sample display	Audio-Audio or COMAND
ACT1114	TV tuner	Audio-Audio or COMAND
ACT1115	Backup camera	Audio-Audio or COMAND
ACT1116	AUX jack	Audio-Audio or COMAND
ACT1117	Display illumination	Audio-Audio or COMAND
ACT1118	Extending/retracting the display	Audio-Audio or COMAND
ACT1119	Check CD/DVD insert and eject.	Audio-Audio or COMAND
ACT1120	Enable CD/DVD drive.	Audio-Audio or COMAND
ACT1121	Self-test	Audio-Audio or COMAND
ACT1122	BRIGHT	Audio-Audio or COMAND
ACT1123	DARK	Audio-Audio or COMAND
ACT1124	Mittel	Audio-Audio or COMAND
ACT1125	Speaker(Development data)	Audio-Audio or COMAND
ACT1126	Init_NTG4	Audio-Audio or COMAND
ACT1127	Self-test of mobile phone cradle	Audio-Audio or COMAND
ACT1128	Perform control unit reset.	Audio-Audio or COMAND
ACT1129	Restart MOST ring.	Audio-Audio or COMAND
ACT1130	Perform current adjustment.	ELM-VR-Front right electrical machine
ACT1131	Perform voltage adjustment.	ELM-VR-Front right electrical machine
ACT1132	L20/5 (Right front electrical machine rotor position sensor)	ELM-VR-Front right electrical machine
ACT1133	Reset of "Sensor "Voltage of high-voltage on-board electrical system""	ELM-VR-Front right electrical machine
ACT1134	Check contact of component "Front right electrical machine".	ELM-VR-Front right electrical machine
ACT1135	Lock high-voltage component lock.	ELM-VR-Front right electrical machine
ACT1136	Unlock high-voltage component lock.	ELM-VR-Front right electrical machine
ACT1137	Reset of frequency counter "Emergency shutoff of component 'N129/5 (Right	ELM-VR-Front right electrical machine
ACT1138	Resetting of frequency counter "Emergency shutoff due to implausible torque	ELM-VR-Front right electrical machine
ACT1139	Perform control unit reset.	ELM-VR-Front right electrical machine
ACT1140	M2/34 (Ram air flap actuator motor)	AAC-Automatic air conditioning
ACT1141	N19/4 (Electric refrigerant compressor control unit)	AAC-Automatic air conditioning
ACT1142	Perform current adjustment.	ELM-HL-Rear left electrical machine
ACT1143	Perform voltage adjustment.	ELM-HL-Rear left electrical machine
ACT1144	L20/6 (Left rear electrical machine rotor position sensor)	ELM-HL-Rear left electrical machine
ACT1145	Reset of "Sensor "Voltage of high-voltage on-board electrical system""	ELM-HL-Rear left electrical machine
ACT1146	Check contact of component "Rear right electrical machine".	ELM-HL-Rear left electrical machine
ACT1147	Lock high-voltage component lock.	ELM-HL-Rear left electrical machine
ACT1148	Unlock high-voltage component lock.	ELM-HL-Rear left electrical machine

ACT1149	Reset of frequency counter "Emergency shutoff of component 'N129/6 (Left	ELM-HL-Rear left electrical machine
ACT1150	Resetting of frequency counter "Emergency shutoff due to implausible torque	ELM-HL-Rear left electrical machine
ACT1151	Perform control unit reset.	ELM-HL-Rear left electrical machine
ACT1152	Perform current adjustment.	ELM-HR-Rear right electrical machine
ACT1153	Perform voltage adjustment.	ELM-HR-Rear right electrical machine
ACT1154	L20/7 (Right rear electrical machine rotor position sensor)	ELM-HR-Rear right electrical machine
ACT1155	Reset of "Sensor "Voltage of high-voltage on-board electrical system""	ELM-HR-Rear right electrical machine
ACT1156	Check contact of component "A79/7 (Right rear electrical machine)".	ELM-HR-Rear right electrical machine
ACT1157	Lock high-voltage component lock.	ELM-HR-Rear right electrical machine
ACT1158	Unlock high-voltage component lock.	ELM-HR-Rear right electrical machine
ACT1159	Reset of frequency counter "Emergency shutoff of component 'N129/7 (Right	ELM-HR-Rear right electrical machine
ACT1160	Resetting of frequency counter "Emergency shutoff due to implausible torque	ELM-HR-Rear right electrical machine
ACT1161	Perform control unit reset.	ELM-HR-Rear right electrical machine
ACT1162	LED of component "X58/23 (Charger feed-in socket)"	SG LG-Charger
ACT1163	Locking of charging cable	SG LG-Charger
ACT1164	Y139/1 (Drive coolant pump regulation valve)	PTCU-MA-Drivetrain (master)
ACT1165	Y139/3 (High-voltage battery coolant pump regulation valve)	PTCU-MA-Drivetrain (master)
ACT1166	Y139/9 (Climate control coolant pump regulation valve)	PTCU-MA-Drivetrain (master)
ACT1167	Y107/9 (Shutoff valve 2)	PTCU-MA-Drivetrain (master)
ACT1168	Shutoff valves of refrigerant circuit	PTCU-MA-Drivetrain (master)
ACT1169	PTC heater booster	PTCU-MA-Drivetrain (master)
ACT1170	M75/8 (Front electric drive coolant pump)	PTCU-MA-Drivetrain (master)
ACT1171	M75/9 (Rear electric drive coolant pump)	PTCU-MA-Drivetrain (master)
ACT1172	M4/2 (Coolant fan motor)	PTCU-MA-Drivetrain (master)
ACT1173	Circuit 87	PTCU-MA-Drivetrain (master)
ACT1174	Circuit 15	PTCU-MA-Drivetrain (master)
ACT1175	M40 (Differential lock vacuum pump)	PTCU-SL-Drivetrain (slave)
ACT1176	A13 (Electric parking brake control unit)	EFB-Electric parking brake
ACT1177	Move to the assembly position	EFB-Electric parking brake
ACT1178	M75/5 (Front high-voltage battery coolant pump)	BMS-V-Battery management system, front (slave)
ACT1179	Isolation measurement	BMS-V-Battery management system, front (slave)
ACT1180	Measurement log for self-discharge of battery cells	BMS-V-Battery management system, front (slave)
ACT1181	Signal generator for interlock circuit	BMS-M-Battery management system, center (master)
ACT1182	Component "Valve1"CENTER	BMS-M-Battery management system, center (master)
ACT1183	Component "Valve2"CENTER	BMS-M-Battery management system, center (master)
ACT1184	Component "Valve3"CENTER	BMS-M-Battery management system, center (master)

ACT1185	M75/6 (Center high-voltage battery coolant pump)	BMS-M-Battery management system, center (master)
ACT1186	Measurement log for self-discharge of battery cells	BMS-M-Battery management system, center (master)
ACT1187	M13/7 (Transmission oil cooling coolant circulation pump)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1188	M16/6 (Throttle valve actuator)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1189	M3 (Fuel pump)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1190	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1191	M55 (Intake port shutoff actuator motor)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1192	N14/3 (Glow output stage)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1193	R39/1 (Vent line heating element)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1194	R48 (Coolant thermostat heating element)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1195	Y130 (Engine oil pump valve)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1196	Y131 (Oil spray nozzles shutoff valve)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1197	Y133 (Coolant pump switchover valve)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1198	Y27/9 (Exhaust gas recirculation actuator)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1199	Y77/1 (Boost pressure positioner)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1200	Y84 (Radiator shutters actuator)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1201	Y85 (Exhaust gas recirculation cooler bypass switchover valve)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1202	Y93 (Boost pressure control flap pressure transducer)	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1203	Actuation of components "Y93 (Boost pressure control flap pressure	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1204	Injector shutoff	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1205	Compression test	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1206	Switchable engine mounts	N3/9-Motor electronics "CR42" for combustion engine "OM651"
ACT1207	M16/6 (Throttle valve actuator)	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
ACT1208	M3 (Fuel pump)	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
ACT1209	M4/7 (fan motor)	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
ACT1210	M55 (Intake port shutoff actuator motor)	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
ACT1211	Y27/9 (Exhaust gas recirculation actuator)	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
ACT1212	Y77/1 (Boost pressure positioner)	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
ACT1213	Diagnostic glowing	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
ACT1214	Injector shutoff	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
ACT1215	Compression test	N3/9-Motor electronics "CDI6" for combustion engine "OM642"
ACT1216	M16/6 (Throttle valve actuator)	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
ACT1217	M3 (Fuel pump)	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
ACT1218	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
ACT1219	M55 (Intake port shutoff actuator motor)	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
ACT1220	R39/1 (Vent line heating element)	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"

ACT1221	Actuation of components "Y123 (Left switchable engine mount)" and "Y123/1	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
ACT1222	Y27/9 (Exhaust gas recirculation actuator)	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
ACT1223	Y77/1 (Boost pressure positioner)	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
ACT1224	Diagnostic glowing	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
ACT1225	Injector shutoff	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
ACT1226	Compression test	N3/9-Motor electronics "CDI6EU5" for combustion engine "OM642"
ACT1227	Compression test	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1228	M3 (Fuel pump)	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1229	M4/7 (Combustion engine and air conditioning with integrated control fan	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1230	M16/5 (Throttle valve actuator)	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1231	M55 (Intake port shutoff actuator motor)	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1232	R39/1 (Vent line heating element)	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1233	Y27/9 (Exhaust gas recirculation actuator)	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1234	Y85 (Exhaust gas recirculation cooler bypass switchover valve)	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1235	Y100/1 (Boost pressure positioner)	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1236	Diagnostic glowing	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1237	Injector shutoff	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1238	Bleeding of high-pressure fuel circuit	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1239	A1e16 (Preglow indicator lamp)	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1240	A1e58 (Engine diagnosis indicator lamp)	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1241	Pressure drop test	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1242	B2/5 (Hot film mass air flow sensor)	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1243	Test of fuel system high pressure pump	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1244	Test for rail pressure fluctuations	N3/9-Motor electronics "CDI" for combustion engine "OM646"
ACT1245	Compression test	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1246	A1e58 (Engine diagnosis indicator lamp)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1247	M3 (Fuel pump)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1248	M4/7 (Combustion engine and air conditioning with integrated control fan	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1249	M16/6 (Throttle valve actuator)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1250	Actuation of component "M16/6 (Throttle valve actuator)" with automatic	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1251	M55 (Intake port shutoff actuator motor)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1252	N14/3 (Glow output stage)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1253	R39/1 (Vent line heating element)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1254	Y27/9 (Exhaust gas recirculation actuator)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1255	Y31/4 (Wastegate control pressure transducer)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1256	Y77/1 (Boost pressure positioner)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"

ACT1257	Y84 (Radiator shutters actuator)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1258	Y85 (Exhaust gas recirculation cooler bypass switchover valve)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1259	Y93 (Boost pressure control flap pressure transducer)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1260	Switchable engine mounts	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1261	Y131 (Oil spray nozzles shutoff valve)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1262	Y132 (Charge air bypass flap switchover valve)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1263	Y133 (Coolant pump switchover valve)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1264	Actuation of components "Y93 (Boost pressure control flap pressure	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1265	Injector shutoff	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1266	Y76 (Fuel injectors)	N3/9-Motor electronics "CDID2" for combustion engine "OM651"
ACT1267	Actuation of component "H4/31 (Exhaust system sound generator speaker)"	SG SOGE AGA-Sound generator for exhaust system
ACT1268	Actuation of component "H4/31 (Exhaust system sound generator	SG SOGE AGA-Sound generator for exhaust system
ACT1269	Tire pressure loss warning	ESP- Electric stability program
ACT1270	Power supply of peripheral devices	Multifunction control unit-Multifunction control unit
ACT1271	Output "Two-way radio cut-in"	Multifunction control unit-Multifunction control unit
ACT1272	M51/3m1 (Tailgate control electric motor)	TLC-Trunk lid control
ACT1273	M51/3 (Trunk lid control drive unit)	TLC-Trunk lid control
ACT1274	M14/31 (Trunk lid lock element)	TLC-Trunk lid control
ACT1275	Usage is only permissible in consultation with your hotline.	TLC-Trunk lid control
ACT1276	M51/3y1 (Tailgate control magnetic clutch)	TLC-Trunk lid control
ACT1277	Warning indicators "Parking system"	PTS-PARKTRONIC
ACT1278	M2/1 (Rear passenger compartment blower motor)	AAC-Automatic air conditioning
ACT1279	M2/35 (Rear blend air flap actuator motor)	AAC-Automatic air conditioning
ACT1280	M2/21 (Diffuser flap actuator motor)	AAC-Automatic air conditioning
ACT1281	A6m2 (Stationary heater combustion air blower)	STH-Stationary heater
ACT1282	A6r4 (Stationary heater glow plug/flame monitor unit)	STH-Stationary heater
ACT1283	Y16 (Stationary heater switchover valve)	STH-Stationary heater
ACT1284	Y23 (Stationary heater fuel pump)	STH-Stationary heater
ACT1285	Measurement of fuel flow rate	STH-Stationary heater
ACT1286	Deactivation of fault interlock or overheating protection	STH-Stationary heater
ACT1287	Deactivation of safety lock	STH-Stationary heater
ACT1288	Panoramic sliding sunroof	PSD-Control module 'Panoramic sliding roof'(A98)
ACT1289	Roller sun blind	PSD-Control module 'Panoramic sliding roof'(A98)
ACT1290	Reading lamps	OCP-Overhead control panel
ACT1291	Rear lamp	OCP-Overhead control panel
ACT1292	Interior lamp	OCP-Overhead control panel

ACT1293	Automatic illumination test	OCP-Overhead control panel
ACT1294	Tilting/sliding sunroof	OCP-Overhead control panel
ACT1295	Taillight	TRM-Trailer recognition module (N28/1)
ACT1296	Indicator lamp "Trailer hitch LOCKED"	TRM-Trailer recognition module (N28/1)
ACT1297	Taillamps	TRM-Trailer recognition module (N28/1)
ACT1298	Empty fuel tank.	FSCU01-Control unit Fuel pump
ACT1299	Empty fuel tank.	FSCU Left-Control unit 'Left fuel pump'
ACT1300	Left outside mirror adjustment	DCU LF-Left front door(N69/1)
ACT1301	Left mirror heater	DCU LF-Left front door(N69/1)
ACT1302	Folding in/out of left outside mirror	DCU LF-Left front door(N69/1)
ACT1303	Mirror dimming	DCU LF-Left front door(N69/1)
ACT1304	Left memory function	DCU LF-Left front door(N69/1)
ACT1305	Switch illumination "Left front door"	DCU LF-Left front door(N69/1)
ACT1306	Door handle illumination "Left front door"	DCU LF-Left front door(N69/1)
ACT1307	LEDs	DCU LF-Left front door(N69/1)
ACT1308	Exit and warning lamp "Left front door"	DCU LF-Left front door(N69/1)
ACT1309	Turn signal lamp in left outside mirror	DCU LF-Left front door(N69/1)
ACT1310	Left front power window	DCU LF-Left front door(N69/1)
ACT1311	Denormalization of left front power window	DCU LF-Left front door(N69/1)
ACT1312	Central locking "Left front door"	DCU LF-Left front door(N69/1)
ACT1313	Additional door lock "Left front door"	DCU LF-Left front door(N69/1)
ACT1314	Start control unit reset.	DCU LF-Left front door(N69/1)
ACT1315	Right outside mirror adjustment	DCU RF-Right front door(N69/2)
ACT1316	Right mirror heater	DCU RF-Right front door(N69/2)
ACT1317	Folding in/out of right outside mirror	DCU RF-Right front door(N69/2)
ACT1318	Mirror dimming	DCU RF-Right front door(N69/2)
ACT1319	Right memory function	DCU RF-Right front door(N69/2)
ACT1320	Switch illumination "Right front door"	DCU RF-Right front door(N69/2)
ACT1321	Door handle illumination "Right front door"	DCU RF-Right front door(N69/2)
ACT1322	LEDs	DCU RF-Right front door(N69/2)
ACT1323	Exit and warning lamp "Right front door"	DCU RF-Right front door(N69/2)
ACT1324	Turn signal lamp in right outside mirror	DCU RF-Right front door(N69/2)
ACT1325	Right front power window	DCU RF-Right front door(N69/2)
ACT1326	Denormalization of right front power window	DCU RF-Right front door(N69/2)
ACT1327	Central locking "Right front door"	DCU RF-Right front door(N69/2)
ACT1328	Additional door lock "Right front door"	DCU RF-Right front door(N69/2)

ACT1329	Start control unit reset.	DCU RF-Right front door(N69/2)
ACT1330	Right outside mirror adjustment	DCU LR-Left rear door
ACT1331	Right mirror heater	DCU LR-Left rear door
ACT1332	Folding in/out of right outside mirror	DCU LR-Left rear door
ACT1333	Mirror dimming	DCU LR-Left rear door
ACT1334	Right memory function	DCU LR-Left rear door
ACT1335	Blind Spot Assist	DCU LR-Left rear door
ACT1336	Door handle illumination "Left rear door"	DCU LR-Left rear door
ACT1337	Switch illumination "Left rear door"	DCU LR-Left rear door
ACT1338	Turn signal lamp in right outside mirror	DCU LR-Left rear door
ACT1339	LEDs	DCU LR-Left rear door
ACT1340	Exit and warning lamp "Left rear door"	DCU LR-Left rear door
ACT1341	Ambient illumination	DCU LR-Left rear door
ACT1342	LED of switch "S51/3 (Left rear seat heater button)"	DCU LR-Left rear door
ACT1343	E17/45 (Left rear door ambiance illumination)	DCU LR-Left rear door
ACT1344	Left rear power window	DCU LR-Left rear door
ACT1345	Denormalization of left rear power window	DCU LR-Left rear door
ACT1346	Central locking "Left rear door"	DCU LR-Left rear door
ACT1347	Additional door lock "Left rear door"	DCU LR-Left rear door
ACT1348	Start control unit reset.	DCU LR-Left rear door
ACT1349	Roller sun blind for right rear door	DCU LR-Left rear door
ACT1350	Roller sun blind for left rear door	DCU LR-Left rear door
ACT1351	Right outside mirror adjustment	DCU RR-Right rear door
ACT1352	Right mirror heater	DCU RR-Right rear door
ACT1353	Folding in/out of right outside mirror	DCU RR-Right rear door
ACT1354	Mirror dimming	DCU RR-Right rear door
ACT1355	Right memory function	DCU RR-Right rear door
ACT1356	Blind Spot Assist	DCU RR-Right rear door
ACT1357	Door handle illumination "Right rear door"	DCU RR-Right rear door
ACT1358	Switch illumination "Right rear door"	DCU RR-Right rear door
ACT1359	Turn signal lamp in right outside mirror	DCU RR-Right rear door
ACT1360	LEDs	DCU RR-Right rear door
ACT1361	Exit and warning lamp "Right rear door"	DCU RR-Right rear door
ACT1362	Ambient illumination	DCU RR-Right rear door
ACT1363	LED of switch "S51/4 (Right rear seat heater button)"	DCU RR-Right rear door
ACT1364	E17/46 (Right rear door ambiance illumination)	DCU RR-Right rear door

ACT1365	Right rear power window	DCU RR-Right rear door
ACT1366	Denormalization of right rear power window	DCU RR-Right rear door
ACT1367	Central locking "Right rear door"	DCU RR-Right rear door
ACT1368	Additional door lock "Right rear door"	DCU RR-Right rear door
ACT1369	Start control unit reset.	DCU RR-Right rear door
ACT1370	Roller sun blind for right rear door	DCU RR-Right rear door
ACT1371	Roller sun blind for left rear door	DCU RR-Right rear door
ACT1372	B84/5 (Front passenger outside mirror camera)	RFK-Backup camera
ACT1373	E1m1 (Left headlamp range adjustment actuator motor)	XALWA L-Xenon headlamp, left
ACT1374	E1m2 (Left active curve illumination actuator motor)	XALWA L-Xenon headlamp, left
ACT1375	Headlamp range adjustment of both xenon bulbs	XALWA L-Xenon headlamp, left
ACT1376	Active curve illumination of both xenon bulbs	XALWA L-Xenon headlamp, left
ACT1377	Active curve illumination with steering angle	XALWA L-Xenon headlamp, left
ACT1378	Intelligent Light System	XALWA L-Xenon headlamp, left
ACT1379	Light output of xenon bulb	XALWA L-Xenon headlamp, left
ACT1380	E1e9 (Left cornering illumination)	XALWA L-Xenon headlamp, left
ACT1381	E2m1 (Right headlamp range adjustment actuator motor)	XALWA R-Xenon headlamp, right
ACT1382	E2m2 (Right active curve illumination actuator motor)	XALWA R-Xenon headlamp, right
ACT1383	Light output of xenon bulb	XALWA R-Xenon headlamp, right
ACT1384	Intelligent Light System	XALWA R-Xenon headlamp, right
ACT1385	E2e9 (Right cornering illumination)	XALWA R-Xenon headlamp, right
ACT1386	Test picture display	ICI-InCar Internet(N125/3)
ACT1387	Speaker	ICI-InCar Internet(N125/3)
ACT1388	Control unit reset	ICI-InCar Internet(N125/3)
ACT1389	Erase fault memory.	TV-TV tuner
ACT1390	Self-test	CTEL-Mobile phone
ACT1391	Test of telephone connection	CTEL-Mobile phone
ACT1392	Empty fuel tank.	FSCU Right-Control unit 'Right fuel pump'
ACT1393	Test all solenoid valves.	N15/3The fault occurs when charging of the fuel injector takes too long.5
ACT1394	Switch off incline recognition for dynamometer mode.	N15/3The fault occurs when charging of the fuel injector takes too long.5
ACT1395	M3 (Fuel pump)	N3/10-Motor electronics "ME97" for combustion engine "M272"
ACT1396	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/10-Motor electronics "ME97" for combustion engine "M272"
ACT1397	M16/6 (Throttle valve actuator)	N3/10-Motor electronics "ME97" for combustion engine "M272"
ACT1398	M33 (Electric air pump)	N3/10-Motor electronics "ME97" for combustion engine "M272"
ACT1399	Y22/6 (Intake manifold switchover valve)	N3/10-Motor electronics "ME97" for combustion engine "M272"
ACT1400	Y32 (Air pump switchover valve)	N3/10-Motor electronics "ME97" for combustion engine "M272"

ACT1401	Y49/4 (Left intake camshaft solenoid)	N3/10-Motor electronics "ME97" for combustion engine "M272"
ACT1402	Y49/5 (Right intake camshaft solenoid)	N3/10-Motor electronics "ME97" for combustion engine "M272"
ACT1403	Y49/6 (Left exhaust camshaft solenoid)	N3/10-Motor electronics "ME97" for combustion engine "M272"
ACT1404	Y49/7 (Right exhaust camshaft solenoid)	N3/10-Motor electronics "ME97" for combustion engine "M272"
ACT1405	Y58/1 (Purging switchover valve)	N3/10-Motor electronics "ME97" for combustion engine "M272"
ACT1406	Y58/4 (Activated charcoal canister shutoff valve)	N3/10-Motor electronics "ME97" for combustion engine "M272"
ACT1407	Y62 (Injection valves)	N3/10-Motor electronics "ME97" for combustion engine "M272"
ACT1408	Compression test	N3/10-Motor electronics "ME97" for combustion engine "M272"
ACT1409	Mixture formation	N3/10-Motor electronics "ME97" for combustion engine "M272"
ACT1410	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1411	Y16/2 (Heating system shutoff valve)	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1412	M16/6 (Throttle valve actuator)	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1413	Y22/6 (Intake manifold switchover valve)	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1414	Y49/4 (Left intake camshaft solenoid)	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1415	Y49/5 (Right intake camshaft solenoid)	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1416	Y49/6 (Left exhaust camshaft solenoid)	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1417	Y49/7 (Right exhaust camshaft solenoid)	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1418	Y58/1 (Purging switchover valve)	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1419	Y94 (Quantity control valve)	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1420	Y76 (Fuel injectors)	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1421	Y84 (Radiator shutters actuator)	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1422	Y125 (Low temperature circuit shutoff valve)	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1423	Exhaust gas recirculation	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1424	Compression test	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1425	Mixture formation	N3/10-Motor electronics "MED97" for combustion engine "M272"
ACT1426	M3 (Fuel pump)	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
ACT1427	M16/6 (Throttle valve actuator)	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
ACT1428	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
ACT1429	Y49/1 (Intake camshaft solenoid)	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
ACT1430	Y49/2 (Exhaust camshaft solenoid)	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
ACT1431	Y58/1 (Purging switchover valve)	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
ACT1432	Secondary air injection	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
ACT1433	M16/7 (Boost pressure control flap actuator)	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
ACT1434	Y62 (Injection valves)	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
ACT1435	Y58/4 (Activated charcoal canister shutoff valve)	N3/10-Motor electronics "SIM271KE20" for combustion engine "M271"
ACT1436	SBC Hold	ESP-Electronic stability program(N30/4)

ACT1437	Electric refrigerant compressor	A9/5 (Electric refrigerant compressor)
ACT1438	Test image	NSA-Night View Assist(N101)
ACT1439	A10 (Left belt extender)	REAR-Rear control unit(N22/6)
ACT1440	A11 (Right belt extender)	REAR-Rear control unit(N22/6)
ACT1441	M10/5 (Left rear power window motor)	REAR-Rear control unit(N22/6)
ACT1442	Denormalization of power window	REAR-Rear control unit(N22/6)
ACT1443	Overheating protection	REAR-Rear control unit(N22/6)
ACT1444	M10/6 (Right rear power window motor)	REAR-Rear control unit(N22/6)
ACT1445	Illumination of switches "Power window"	REAR-Rear control unit(N22/6)
ACT1446	M96/2 (Wind deflector actuator motor)	REAR-Rear control unit(N22/6)
ACT1447	Switch illumination of soft top control	REAR-Rear control unit(N22/6)
ACT1448	Soft top	REAR-Rear control unit(N22/6)
ACT1449	LEDs of button "S84s4 (Draft stop and wind deflector button)"	REAR-Rear control unit(N22/6)
ACT1450	M28/14 (Actuator motor for head restraint drive in rear passenger	REAR-Rear control unit(N22/6)
ACT1451	Seat heater in left rear passenger compartment	N25/6 (Rear passenger compartment seat heater control unit)
ACT1452	Seat heater in right rear passenger compartment	N25/6 (Rear passenger compartment seat heater control unit)
ACT1453	E1m1 (Left headlamp range adjustment actuator motor)	XALWA L-Left xenon headlamp(E1n1)
ACT1454	E1m2 (Left active curve illumination actuator motor)	XALWA L-Left xenon headlamp(E1n1)
ACT1455	Intelligent Light System	XALWA L-Left xenon headlamp(E1n1)
ACT1456	E1e10 (Left xenon bulb with integrated ignition module)	XALWA L-Left xenon headlamp(E1n1)
ACT1457	E1e9 (Left cornering illumination)	XALWA L-Left xenon headlamp(E1n1)
ACT1458	Active curve illumination with steering angle	XALWA L-Left xenon headlamp(E1n1)
ACT1459	E2m1 (Right headlamp range adjustment actuator motor)	XALWA R-Right xenon headlamp(E2n1)
ACT1460	E2m2 (Right active curve illumination actuator motor)	XALWA R-Right xenon headlamp(E2n1)
ACT1461	Intelligent Light System	XALWA R-Right xenon headlamp(E2n1)
ACT1462	E2e10 (Right xenon bulb with integrated ignition module)	XALWA R-Right xenon headlamp(E2n1)
ACT1463	E2e9 (Right cornering illumination)	XALWA R-Right xenon headlamp(E2n1)
ACT1464	Active curve illumination with steering angle	XALWA R-Right xenon headlamp(E2n1)
ACT1465	Lock high-voltage component lock.	PE-Power electronics(N129/1)
ACT1466	Unlock high-voltage component lock.	PE-Power electronics(N129/1)
ACT1467	Y19/1 (High-voltage battery cooling system shutoff valve)	BMS-Battery management system(N82/2)
ACT1468	Isolation measurement with open contactors	BMS-Battery management system(N82/2)
ACT1469	Isolation measurement with closed contactors	BMS-Battery management system(N82/2)
ACT1470	Actuate component "A100s1 (Contactor)".	BMS-Battery management system(N82/2)
ACT1471	Measurement log for self-discharge of battery cells	BMS-Battery management system(N82/2)
ACT1472	M16/6 (Throttle valve actuator)	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"

ACT1473	M3 (Fuel pump)	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
ACT1474	M4/7 (fan motor)	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
ACT1475	M55 (Intake port shutoff actuator motor)	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
ACT1476	R39/1 (Vent line heating element)	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
ACT1477	Y27/9 (Exhaust gas recirculation actuator)	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
ACT1478	Y77/1 (Boost pressure positioner)	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
ACT1479	Diagnostic glowing	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
ACT1480	Injector shutoff	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
ACT1481	Compression test	N3/9-Motor electronics "CDI6BIN5EU6" for combustion engine "OM642"
ACT1482	R22/4 (Steering wheel heater)	LRH-Steering wheel heater
ACT1483	Actuation of air cushion "Upper lumbar support"	AMKS LF-Active multicontour seat(N32/19)
ACT1484	Actuation of air cushion "Lower lumbar support"	AMKS LF-Active multicontour seat(N32/19)
ACT1485	Actuation of air cushions in seat side bolsters	AMKS LF-Active multicontour seat(N32/19)
ACT1486	Actuation of air cushion "Seat cushion length"	AMKS LF-Active multicontour seat(N32/19)
ACT1487	Actuate LEDs.	AMKS LF-Active multicontour seat(N32/19)
ACT1488	Check overall system for leaktightness and compressed air supply.	AMKS LF-Active multicontour seat(N32/19)
ACT1489	Actuation of air cushion "Upper lumbar support"	AMKS RF-Active multicontour seat(N32/22)
ACT1490	Actuation of air cushion "Lower lumbar support"	AMKS RF-Active multicontour seat(N32/22)
ACT1491	Actuation of air cushions in seat side bolsters	AMKS RF-Active multicontour seat(N32/22)
ACT1492	Actuation of air cushion "Seat cushion length"	AMKS RF-Active multicontour seat(N32/22)
ACT1493	Actuate LEDs.	AMKS RF-Active multicontour seat(N32/22)
ACT1494	Check overall system for leaktightness and compressed air supply.	AMKS RF-Active multicontour seat(N32/22)
ACT1495	Y36/8y1 (Left rear level control valve)	ELC-Electronic level control
ACT1496	Y36/8y2 (Right rear level control valve)	ELC-Electronic level control
ACT1497	K67 (AIRMATIC relay)	ELC-Electronic level control
ACT1498	A9/1y1 (AIRMATIC pressure relief valve)	ELC-Electronic level control
ACT1499	Left rear suspension strut	ELC-Electronic level control
ACT1500	Right rear suspension strut	ELC-Electronic level control
ACT1501	Move to calibrated vehicle level (manually).	ELC-Electronic level control
ACT1502	Fill natural gas system.	N3/10-Motor electronics "CNGCM212" for combustion engine "M271CNG"
ACT1503	Drain natural gas system.	N3/10-Motor electronics "CNGCM212" for combustion engine "M271CNG"
ACT1504	Actuation of component "Y107/2 (Gas safety shutoff valve)"	N3/10-Motor electronics "CNGCM212" for combustion engine "M271CNG"
ACT1505	Y106 (Injection valves)	N3/10-Motor electronics "CNGCM212" for combustion engine "M271CNG"
ACT1506	Operating mode	N3/10-Motor electronics "CNGCM212" for combustion engine "M271CNG"
ACT1507	Y107/1 (Gas cylinder shutoff valves)	N3/10-Motor electronics "CNGCM212" for combustion engine "M271CNG"
ACT1508	Component "Y107/1 (Gas cylinder shutoff valves)"	N3/10-Motor electronics "CNGCM212" for combustion engine "M271CNG"

ACT1509	M3 (Fuel pump)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1510	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1511	M16/6 (Throttle valve actuator)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1512	R39/2 (Wide open throttle operation vent line heating element)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1513	Y49/1 (Intake camshaft solenoid)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1514	Y49/2 (Exhaust camshaft solenoid)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1515	Y58/1 (Purging switchover valve)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1516	Y76 (Fuel injectors)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1517	Y77/1 (Boost pressure positioner)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1518	Y84 (Radiator shutters actuator)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1519	Y94 (Quantity control valve)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1520	Y101 (Deceleration air switchover valve)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1521	Y130 (Engine oil pump valve)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1522	Y133 (Coolant pump switchover valve)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1523	A1e58 (Engine diagnosis indicator lamp)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1524	Mixture formation	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1525	Rail pressure reduction	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1526	Y49/8 (Intake camshaft valve lift switching actuator)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1527	Operating mode	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1528	Shutoff of injection	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1529	Drain natural gas system.	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1530	Enable natural gas operation.	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1531	Y107/1 (Gas cylinder shutoff valves)	N3/10-Motor electronics "MED40CNG" for combustion engine "M270"
ACT1532	M16/6 (Throttle valve actuator)	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1533	M16/7 (Boost pressure control flap actuator)	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1534	Y58/1 (Purging switchover valve)	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1535	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1536	M3 (Fuel pump)	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1537	Y62 (Injection valves)	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1538	Y49/1 (Intake camshaft solenoid)	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1539	Y49/2 (Exhaust camshaft solenoid)	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1540	Y58/4 (Activated charcoal canister shutoff valve)	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1541	Secondary air injection	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1542	Y84 (Radiator shutters actuator)	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1543	Drain natural gas system.	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1544	Fill natural gas system.	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"

ACT1545	Actuation of component "Y107/2 (Gas safety shutoff valve)"	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1546	Y106 (Injection valves)	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1547	Operating mode	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1548	Y107/1 (Gas cylinder shutoff valves)	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1549	Component "Y107/1 (Gas cylinder shutoff valves)"	N3/10-Motor electronics "SIM271KECNG" for combustion engine "M271CNG"
ACT1550	LED exterior lights	SG LML VL-LED matrix of left front lamp unit
ACT1551	Light distribution of LED matrix	SG LML VL-LED matrix of left front lamp unit
ACT1552	Fan	SG LML VL-LED matrix of left front lamp unit
ACT1553	Self-test of system "LED matrix"	SG LML VL-LED matrix of left front lamp unit
ACT1554	LED exterior lights	SG-LML-VR-LED matrix of right front lamp unit
ACT1555	Light distribution of LED matrix	SG-LML-VR-LED matrix of right front lamp unit
ACT1556	Self-test of system "LED matrix"	SG-LML-VR-LED matrix of right front lamp unit
ACT1557	Fan	SG-LML-VR-LED matrix of right front lamp unit
ACT1558	Headlamp range adjustment of both lamps units	XALWA L-Left xenon headlamp(E1n1)
ACT1559	Active curve lights of both lamp units	XALWA L-Left xenon headlamp(E1n1)
ACT1560	M3 (Fuel pump)	N3/10-Motor electronics "ME1778" for combustion engine "M279"
ACT1561	M4/7 (Combustion engine and air conditioning with integrated control fan)	N3/10-Motor electronics "ME1778" for combustion engine "M279"
ACT1562	M16/6 (Throttle valve actuator)	N3/10-Motor electronics "ME1778" for combustion engine "M279"
ACT1563	M44 (charge air cooler circulation pump)	N3/10-Motor electronics "ME1778" for combustion engine "M279"
ACT1564	Y58/1 (Purging switchover valve)	N3/10-Motor electronics "ME1778" for combustion engine "M279"
ACT1565	Y58/4 (Activated charcoal canister shutoff valve)	N3/10-Motor electronics "ME1778" for combustion engine "M279"
ACT1566	Y77/1 (Boost pressure positioner)	N3/10-Motor electronics "ME1778" for combustion engine "M279"
ACT1567	M33 (Electric air pump)	N3/10-Motor electronics "ME1778" for combustion engine "M279"
ACT1568	Y32/1 (Air pump 1 switchover valve)	N3/10-Motor electronics "ME1778" for combustion engine "M279"
ACT1569	Y32/2 (Air pump 2 switchover valve)	N3/10-Motor electronics "ME1778" for combustion engine "M279"
ACT1570	Y101 (Deceleration air switchover valve)	N3/10-Motor electronics "ME1778" for combustion engine "M279"
ACT1571	Y62 (Injection valves)	N3/10-Motor electronics "ME1778" for combustion engine "M279"
ACT1572	Actuation of component "H4/31 (Exhaust system sound generator speaker)"-	SG SOGE AGA-Sound generator for exhaust system
ACT1573	Actuation of air cushion of middle lumbar support	MKS LF-Left front multicontour seat
ACT1574	Actuation of air cushions in seat side bolsters Seat backrest	MKS LF-Left front multicontour seat
ACT1575	Actuation of air cushions in seat side bolsters Seat cushion	MKS LF-Left front multicontour seat
ACT1576	Actuation of air cushion of upper lumbar support	AMKS RF-Active multicontour seat(N32/22)
ACT1577	Actuation of air cushion of middle lumbar support	AMKS RF-Active multicontour seat(N32/22)
ACT1578	Actuation of air cushion of lower lumbar support	AMKS RF-Active multicontour seat(N32/22)
ACT1579	Actuation of air cushions in seat side bolsters Seat backrest	AMKS RF-Active multicontour seat(N32/22)
ACT1580	Actuation of air cushions in seat side bolsters Seat cushion	AMKS RF-Active multicontour seat(N32/22)

ACT1581	Y36/1y1 (Left front suspension strut control valve)	ABC-Active body control(N51/2)
ACT1582	Y36/1y3 (Right front suspension strut control valve)	ABC-Active body control(N51/2)
ACT1583	Y36/2y1 (Left rear suspension strut control valve)	ABC-Active body control(N51/2)
ACT1584	Y36/2y3 (Right rear suspension strut control valve)	ABC-Active body control(N51/2)
ACT1585	Shutoff valves	ABC-Active body control(N51/2)
ACT1586	Y86/1 (ABC throttle valve)	ABC-Active body control(N51/2)
ACT1587	Release of system pressure	ABC-Active body control(N51/2)
ACT1588	Dynamic test	ABC-Active body control(N51/2)
ACT1589	Cyclically alternating actuation of all suspension struts in a circular motion	ABC-Active body control(N51/2)
ACT1590	Cyclically alternating actuation of front and rear suspension struts (pitch)	ABC-Active body control(N51/2)
ACT1591	Move to calibrated vehicle level (manually).	ABC-Active body control(N51/2)
ACT1592	Move to calibrated vehicle level (automatically).	ABC-Active body control(N51/2)
ACT1593	LEDs of component "N72 (Lower control panel control unit)"	ABC-Active body control(N51/2)
ACT1594	Release pressure in suspension struts.	ABC-Active body control(N51/2)
ACT1595	Actuation of air cushion "Upper lumbar support"	BFS LSE-Lumbar support 'Front passenger seat'(N32/24)
ACT1596	Actuation of air cushion "Lower lumbar support"	BFS LSE-Lumbar support 'Front passenger seat'(N32/24)
ACT1597	Denormalization of power window	STC-Soft top control(N52)
ACT1598	Switch illumination "Loading aid"	STC-Soft top control(N52)
ACT1599	M49/1 (Side flaps motor)	STC-Soft top control(N52)
ACT1600	Actuation of trunk lid	STC-Soft top control(N52)
ACT1601	Denormalization of trunk lid control	STC-Soft top control(N52)
ACT1602	H4/60 (Trunk lid control warning buzzer)	STC-Soft top control(N52)
ACT1603	Actuation of air cushion "Upper lumbar support"	LSE FS-N32/23 (Driver seat lumbar support adjustment control unit)
ACT1604	Actuation of air cushion "Lower lumbar support"	LSE FS-N32/23 (Driver seat lumbar support adjustment control unit)
ACT1605	A7/3m1 (High-pressure and return flow pump)	RBS-Regenerative braking system
ACT1606	A7/3y11 (Left rear pressure regulating valve (pressure release))	RBS-Regenerative braking system
ACT1607	M56 (Vacuum pump)	PTCU-Common powertrain controller(N127)
ACT1608	F58kT (Heated windshield relay)	PTCU-Common powertrain controller(N127)
ACT1609	Y19/1 (High-voltage battery cooling shutoff valve)	PTCU-Common powertrain controller(N127)
ACT1610	F58kM (Circuit 87C relay)	PTCU-Common powertrain controller(N127)
ACT1611	F58kN (Terminal 87T relay)	PTCU-Common powertrain controller(N127)
ACT1612	M2/16 (Park pawl actuator motor)	PTCU-Common powertrain controller(N127)
ACT1613	Pre-air conditioning	PTCU-Common powertrain controller(N127)
ACT1614	M51/3m1 (Right liftgate control electric motor)-M51/5m1 (Left liftgate)	HKS-Tailgate control
ACT1615	A7/3m1 (High-pressure and return flow pump)	ESP-Electric stability program(N30/4)
ACT1616	A7/3y11 (Left rear pressure regulating valve (pressure release))	ESP-Electric stability program(N30/4)

ACT1617	Function illumination of component "S62/29 (Fire extinguishing system	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1618	Function illumination of component "S62/41 (Fire extinguishing system	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1619	H13 (Fire extinguishing system warning buzzer)	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1620	Activate air recirculation mode.	FLANFS-Fire extinguishing system and emergency fresh air system
ACT1621	Illuminated door sill moldings	N10/8 (Rear passenger compartment control unit)
ACT1622	Rear passenger compartment seat heater	N10/8 (Rear passenger compartment control unit)
ACT1623	M14/10 (Tank cap central locking motor)	N10/8 (Rear passenger compartment control unit)
ACT1624	M14/7 (Rear-end door central locking motor)	N10/8 (Rear passenger compartment control unit)
ACT1625	LEDs of components "S51/3 (Left rear seat heater button)" and "S51/4 (Right	N10/8 (Rear passenger compartment control unit)
ACT1626	LEDs of component "S51/3 (Left rear seat heater button)"	N10/8 (Rear passenger compartment control unit)
ACT1627	LEDs of component "S51/4 (Right rear seat heater button)"	N10/8 (Rear passenger compartment control unit)
ACT1628	DC/AC converter	N10/8 (Rear passenger compartment control unit)
ACT1629	Sliding roof	N10/8 (Rear passenger compartment control unit)
ACT1630	Soft top	N10/8 (Rear passenger compartment control unit)
ACT1631	Y54 (Right rear axle damper valve unit)	ADS-Adaptive damping system(N51/5)
ACT1632	Actuator motors for headlamp range adjustment	SG SW-Control unit 'Headlamp'(N71/1)
ACT1633	M3 (Fuel pump)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1634	M4/7 (fan motor)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1635	M16/53 (Left exhaust flap actuator motor)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1636	M16/54 (Right exhaust flap actuator motor)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1637	M16/60 (Left throttle valve actuator)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1638	M16/61 (Right throttle valve actuator)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1639	Y16/2 (Heating system shutoff valve)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1640	Y49/4 (Left camshaft intake solenoid)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1641	Y49/5 (Right camshaft intake solenoid)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1642	Y49/6 (Left camshaft exhaust solenoid)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1643	Y49/7 (Right camshaft exhaust solenoid)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1644	Y58/4 (Activated charcoal canister shutoff valve)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1645	Y58/11 (Left purging switchover valve)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1646	Y58/12 (Right purging switchover valve)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1647	Y76 (Fuel injectors)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1648	Y77/1 (Boost pressure control pressure transducer)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1649	Y101/1 (Left bypass air switchover valve)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1650	Y101/2 (Right bypass air switchover valve)	N3/10-Motor electronics "MED1775" for combustion engine "M178"
ACT1651	Y130 (Engine oil pump valve)	N3/10-Motor electronics "MED1775" for combustion engine "M178"