



<https://xtool.es/>
Telefono fijo: +34 937 371 351
sales@xtool.es

Bugatti Function List V12.22

Tips and Instructions:

The programming function only supports H6PRO, H6PRO Master Edition products.

- * This feature is new.
- ✓ This feature is supported.
- ✗ This feature is not supported.
- ※ This feature is partially supported.

System Name	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Read Freeze Frame	Actuation Test	Special Functions	Coding	Programming
03-Brakes 1	✓	✓	✓	✓	※	※	0001-0007		
01-Engine Control Module 1	✓	✓	✓	✓	※	※	0001-0007		
02-Transmission Control Module	✓	✓	✓	✓	※	※	0001-0007		
04-Steering Angle Sender	✓	✓	✓	✓	※	※	0001-0007		
05-Kessy	✓	✓	✓	✓	※	※	0001-0007		
06-Seat Adjustment Passenger Side	✓	✓	✓	✓	※	※	0001-0007		
07-Display Control Unit	✓	✓	✓	✓	※	※	0001-0007		
08-Air Conditioning	✓	✓	✓	✓	※	※	0001-0007		
09-Central Electrics	✓	✓	✓	✓	※	※	0001-0007		
0A-Alternative Fuel Engine	✓	✓	✓	✓	※	※	0001-0007		
0B-Auxiliary Air Heater	✓	✓	✓	✓	※	※	0001-0007		
0C-Rear Axle Steering 2	✓	✓	✓	✓	※	※	0001-0007		
0D-Sliding Door Left	✓	✓	✓	✓	※	※	0001-0007		
0E-Media Player Position 1	✓	✓	✓	✓	※	※	0001-0007		
0F-Radio Tuner - Digital	✓	✓	✓	✓	※	※	0001-0007		
10-Parking Assistance 2	✓	✓	✓	✓	※	※	0001-0007		
11-Engine Control Module 2	✓	✓	✓	✓	※	※	0001-0007		
12-Clutch Control Unit	✓	✓	✓	✓	※	※	0001-0007		
13-Adaptive Cruise Control	✓	✓	✓	✓	※	※	0001-0007		
14-Wheel Dampening Electronics	✓	✓	✓	✓	※	※	0001-0007		
15-Airbag	✓	✓	✓	✓	※	※	0001-0007		
16-Steering Column Electronics	✓	✓	✓	✓	※	※	0001-0007		
17-Dash Board	✓	✓	✓	✓	※	※	0001-0007		
18-Auxiliary Parking Heater	✓	✓	✓	✓	※	※	0001-0007		
19-Gateway	✓	✓	✓	✓	※	※	0001-0007		
1A-Fuel Cell Engine	✓	✓	✓	✓	※	※	0001-0007		
1B-Active Steering	✓	✓	✓	✓	※	※	0001-0007		
1C-Vehicle Position Detection	✓	✓	✓	✓	※	※	0001-0007		

1D-Driver Identification	√	√	√	√	※	※	0001-0007		
1E-Media Player Position 2	√	√	√	√	※	※	0001-0007		
1F-Radio Tuner - Satellite	√	√	√	√	※	※	0001-0007		
20-High Beam Assistance	√	√	√	√	※	※	0001-0007		
21-Battery Energy Control Module 2	√	√	√	√	※	※	0001-0007		
22-All Wheel Control	√	√	√	√	※	※	0001-0007		
23-Brake Boost	√	√	√	√	※	※	0001-0007		
24-Anti Slip Regulation	√	√	√	√	※	※	0001-0007		
25-Immobilizer	√	√	√	√	※	※	0001-0007		
26-Electronic Roof Control	√	√	√	√	※	※	0001-0007		
27-Display Control Unit Rear	√	√	√	√	※	※	0001-0007		
28-Climate Control Unit Rear	√	√	√	√	※	※	0001-0007		
29-Light Control Left	√	√	√	√	※	※	0001-0007		
2A-Control Unit Wireless Charging	√	√	√	√	※	※	0001-0007		
2B-Steering Column Locking	√	√	√	√	※	※	0001-0007		
2C-Seat Allocation Detection	√	√	√	√	※	※	0001-0007		
2D-Voice Amplifier	√	√	√	√	※	※	0001-0007		
2E-Media Player Position 3	√	√	√	√	※	※	0001-0007		
2F-TV Tuner - Digital	√	√	√	√	※	※	0001-0007		
30-Special Function 2	√	√	√	√	※	※	0001-0007		
31-Engine Electronics Group	√	√	√	√	※	※	0001-0007		
32-Lock Electronics	√	√	√	√	※	※	0001-0007		
33-All OBD Systems	√	√	√	√	※	※	0001-0007		
34-Ride Control System	√	√	√	√	※	※	0001-0007		
35-Central Locking Control Module	√	√	√	√	※	※	0001-0007		
36-Seat Adjustment Driver Side	√	√	√	√	※	※	0001-0007		
37-Navigation	√	√	√	√	※	※	0001-0007		
38-Roof Electronic Control Module	√	√	√	√	※	※	0001-0007		
39-Light Control Right	√	√	√	√	※	※	0001-0007		
3A-Special Vehicle Assistant	√	√	√	√	※	※	0001-0007		
3B-Sensor Electronics	√	√	√	√	※	※	0001-0007		
3C-Lane Change Assistant	√	√	√	√	※	※	0001-0007		
3D-Special Function	√	√	√	√	※	※	0001-0007		
3E-Media Player Position 4	√	√	√	√	※	※	0001-0007		
3F-Dynamic Assembly Mounting	√	√	√	√	※	※	0001-0007		
40-Air Conditioning Compressor	√	√	√	√	※	※	0001-0007		
41-Diesel Pump Control Unit	√	√	√	√	※	※	0001-0007		
42-Door Electronics Driver Side	√	√	√	√	※	※	0001-0007		
43-Brake Assistance	√	√	√	√	※	※	0001-0007		

44-Steering Assistance	√	√	√	√	※	※	0001-0007		
45-Interior Monitoring	√	√	√	√	※	※	0001-0007		
46-Central Module Comfort System	√	√	√	√	※	※	0001-0007		
47-Sound System	√	√	√	√	※	※	0001-0007		
48-Seat Adjustment Rear Driver Side	√	√	√	√	※	※	0001-0007		
49-Automatic Light Switch	√	√	√	√	※	※	0001-0007		
4A-Rear Light	√	√	√	√	※	※	0001-0007		
4B-Multifunction Module	√	√	√	√	※	※	0001-0007		
4C-Tire Pressure Monitoring 2	√	√	√	√	※	※	0001-0007		
4D-Data Transmission	√	√	√	√	※	※	0001-0007		
4E-Control Head Rear Right	√	√	√	√	※	※	0001-0007		
4F-Central Electrics 2	√	√	√	√	※	※	0001-0007		
50-Seat Adjustment 3rd Row	√	√	√	√	※	※	0001-0007		
51-Drive Motor Control Module	√	√	√	√	※	※	0001-0007		
52-Door Electronics Passenger Side	√	√	√	√	※	※	0001-0007		
53-Parking Brake	√	√	√	√	※	※	0001-0007		
54-Rear Spoiler	√	√	√	√	※	※	0001-0007		
55-Headlight Regulation	√	√	√	√	※	※	0001-0007		
56-Radio	√	√	√	√	※	※	0001-0007		
57-TV Tuner	√	√	√	√	※	※	0001-0007		
58-Fuel Supply	√	√	√	√	※	※	0001-0007		
59-Towing Protection	√	√	√	√	※	※	0001-0007		
5A-Longitudinal Control	√	√	√	√	※	※	0001-0007		
5B-Seat Adjustment Rear Passenger Side	√	√	√	√	※	※	0001-0007		
5C-Lane Departure Warning System	√	√	√	√	※	※	0001-0007		
5D-Operation	√	√	√	√	※	※	0001-0007		
5E-Control Head Rear Left	√	√	√	√	※	※	0001-0007		
5F-Information Control Unit 1	√	√	√	√	※	※	0001-0007		
60-Tachograph	√	√	√	√	※	※	0001-0007		
61-Battery Regulation	√	√	√	√	※	※	0001-0007		
62-Door Electronics Rear Left	√	√	√	√	※	※	0001-0007		
63-Entry Assistance Driver Side	√	√	√	√	※	※	0001-0007		
64-Stabilizers	√	√	√	√	※	※	0001-0007		
65-Tire Pressure Monitoring 1	√	√	√	√	※	※	0001-0007		
66-Seat Adjustment Rear	√	√	√	√	※	※	0001-0007		
67-Voice Control	√	√	√	√	※	※	0001-0007		
68-Wiper Control Unit	√	√	√	√	※	※	0001-0007		
69-Trailer Function	√	√	√	√	※	※	0001-0007		
6B-Aerodynamics Control Unit	√	√	√	√	※	※	0001-0007		

6C-Camera System Rear View	√	√	√	√	※	※	0001-0007		
6D-Deck Lid Control Unit	√	√	√	√	※	※	0001-0007		
6E-Display Control Roof	√	√	√	√	※	※	0001-0007		
6F-Central Module Comfort System 2	√	√	√	√	※	※	0001-0007		
71-Battery Charger	√	√	√	√	※	※	0001-0007		
72-Door Electronics Rear Right	√	√	√	√	※	※	0001-0007		
73-Entry Assistance Passenger Side	√	√	√	√	※	※	0001-0007		
74-Chassis Control	√	√	√	√	※	※	0001-0007		
75-Telematics Communication Unit	√	√	√	√	※	※	0001-0007		
76-Parking Assistance	√	√	√	√	※	※	0001-0007		
77-Telephone	√	√	√	√	※	※	0001-0007		
78-Sliding Door Right	√	√	√	√	※	※	0001-0007		
7B-Subbus Systems Interface	√	√	√	√	※	※	0001-0007		
7D-Auxiliary Heater	√	√	√	√	※	※	0001-0007		
7E-Dash Board Display Unit	√	√	√	√	※	※	0001-0007		
7F-Information Control Unit 2	√	√	√	√	※	※	0001-0007		
81-Gear Shift Control Module	√	√	√	√	※	※	0001-0007		
82-Head Up Display	√	√	√	√	※	※	0001-0007		
83-Front Observation Module	√	√	√	√	※	※	0001-0007		
84-Night Vision	√	√	√	√	※	※	0001-0007		
85-On-Board Camera	√	√	√	√	※	※	0001-0007		
88-Multi Contour Seat Driver Side	√	√	√	√	※	※	0001-0007		
89-Multi Contour Seat Passenger Side	√	√	√	√	※	※	0001-0007		
8A-Multi Contour Seat Rear Driver Side	√	√	√	√	※	※	0001-0007		
8B-Adaptive Cruise Control 2	√	√	√	√	※	※	0001-0007		
8C-Battery Energy Control Module	√	√	√	√	※	※	0001-0007		
8D-Multi Contour Seat Rear Passenger Side	√	√	√	√	※	※	0001-0007		
8E-Image Processing Electronics	√	√	√	√	※	※	0001-0007		
8F-Pretensioner Front Left	√	√	√	√	※	※	0001-0007		
90-Pretensioner Front Right	√	√	√	√	※	※	0001-0007		
A4-Armrest	√	√	√	√	※	※	0001-0007		
A5-Front Sensors Driver Assistance System	√	√	√	√	※	※	0001-0007		
A6-Microphone Control Unit	√	√	√	√	※	※	0001-0007		
A7-Infotainment Interface	√	√	√	√	※	※	0001-0007		
A8-External Communication Interface	√	√	√	√	※	※	0001-0007		
A9-Actuator For Structure-Borne Sound	√	√	√	√	※	※	0001-0007		
AA-Wheel Brake Rear Right	√	√	√	√	※	※	0001-0007		
AB-Wheel Brake Rear Left	√	√	√	√	※	※	0001-0007		
AC-Reductant Control Module	√	√	√	√	※	※	0001-0007		

AD-Sensors Brake Systems	√	√	√	√	※	※	0001-0007		
B7-Access Startsystem Interface	√	√	√	√	※	※	0001-0007		
B8-Electronic Roof Control 2	√	√	√	√	※	※	0001-0007		
B9-Auxiliary Display Control Unit	√	√	√	√	※	※	0001-0007		
BA-Assembly Mounting	√	√	√	√	※	※	0001-0007		
BB-Door Electronics Rear Driver Side	√	√	√	√	※	※	0001-0007		
BC-Door Electronics Rear Passenger Side	√	√	√	√	※	※	0001-0007		
BD-High Voltage Battery Charge Management	√	√	√	√	※	※	0001-0007		
BE-Sliding Door Rear Left	√	√	√	√	※	※	0001-0007		
BF-Sliding Door Rear Right	√	√	√	√	※	※	0001-0007		
C0-Actuator For Exterior Noise	√	√	√	√	※	※	0001-0007		
C2-Transmission Control Module 2	√	√	√	√	※	※	0001-0007		
C3-Drive Motor Control Module 3	√	√	√	√	※	※	0001-0007		
C4-DC/DC Converter Control Module	√	√	√	√	※	※	0001-0007		
C5-Thermal Management	√	√	√	√	※	※	0001-0007		
C6-Battery Charger Control Module	√	√	√	√	※	※	0001-0007		
C7-Pedestrian Protection	√	√	√	√	※	※	0001-0007		
C8-Auxiliary Display Control Unit 2	√	√	√	√	※	※	0001-0007		
C9-Rear Mirror	√	√	√	√	※	※	0001-0007		
CA-Control Module For Sunroof	√	√	√	√	※	※	0001-0007		
CB-Rear Axle Steering	√	√	√	√	※	※	0001-0007		
CC-Starter / Generator Control Module	√	√	√	√	※	※	0001-0007		
CD-Laser Scanner	√	√	√	√	※	※	0001-0007		
CE-Drive Motor Control Module 2	√	√	√	√	※	※	0001-0007		
CF-Control Unit Lane Change Assistant 2	√	√	√	√	※	※	0001-0007		
D0-Front Axle Lift System	√	√	√	√	※	※	0001-0007		
D1-Center Display	√	√	√	√	※	※	0001-0007		
D4-Roll Control System 1	√	√	√	√	※	※	0001-0007		
D5-Roll Control System 2	√	√	√	√	※	※	0001-0007		
D6-Light Control Left 2	√	√	√	√	※	※	0001-0007		
D7-Light Control Right 2	√	√	√	√	※	※	0001-0007		
D8-Matrix Headlamp Powermodule Left	√	√	√	√	※	※	0001-0007		
D9-Matrix Headlamp Powermodule Right	√	√	√	√	※	※	0001-0007		
DB-Front Corner Radar 1	√	√	√	√	※	※	0001-0007		
DC-Front Corner Radar 2	√	√	√	√	※	※	0001-0007		
DD-Control Module 2 For Sunroof	√	√	√	√	※	※	0001-0007		
DE-Charger 1 Mobile Devices	√	√	√	√	※	※	0001-0007		
DF-Charger 2 Mobile Devices	√	√	√	√	※	※	0001-0007		

Special Functions List

No.	Functions Name	System Name
SP0001	Coding	
SP0002	Basic Settings	
SP0003	Adaptation	
SP0004	Security Access	
SP0005	AdvancedDataStream	
SP0006	Login CodingII	
SP0007	Advanced ID	

XTOOL