



<https://xtool.es/>
 Telefono fijo: +34 937 371 351
 sales@xtool.es

AUDI Function menu V28.07

| Car series | System type | Include car models | Function menu |
|---------------------|---------------------|----------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------|
| AUDI | Diagnostic function | AUDI | 1、 01 Engine 2、 09 Central control 3、 17 Dashboard |
| | | SKODA | 4、 25 Immobiliser 5、 35 Central lock 6、 46 Central comfort module |
| | | VW | 7、 02 Automatic transmission 8、 03 Anti-lock brakes 9、 08 Automatic air conditioning |
| | | BENTLEY | 10、 15 Airbag 11、 16 Steering wheel 12、 19 Gateway can |
| | | SEAT | 13、 44 Power Steering 14、 53 Parking Brake 15、 55 Xenon lamp |
| | Read security code | AUDI | 16、 56 Radio 17、 76 Parking Aid |
| | | SKODA | 1、 17 Dashboard 1.1、 CANDY(3.5th) 1.2、 LAVIDA(3.5th) |
| | | VW | 1.3、 SAGITAR(3.5th) 1.4、 TOURAN(3.5th) |
| | | BENTLEY | 2、 25 Immobiliser 3、 01 Engine |
| | | SEAT | 3.1、 SANTANA VISTA 3.2、 LAVIDA 3.3、 TOUAREG(03-07) 3.4、 BEETLE 3.4.1、 Type 1(-2006) 3.4.2、 Type 2(2007-) 3.5、 Others |
| | Program keys | AUDI | 1、 17 Dashboard |
| | | SKODA | 2、 25 Immobiliser |
| | | VW | 3、 Jetta(2010-) |
| | | BENTLEY | 4、 GTI |
| | | SEAT | |
| | Program remote | AUDI | 1、 09 Central control(CANBUS) 2、 09 Central control(UDS) |
| SKODA | | 3、 35 Central lock(KWP1281) 3.1、 Type 1 3.2、 Type 2 | |
| VW | | 4、 46 Central comfort module(KWP1281) 4.1、 Type 1 4.2、 Type 2 | |
| BENTLEY | | 5、 46 Central comfort module(KWP2000) | |
| SEAT | | 6、 46 Central comfort module(CANBUS) | |
| ECU Synchronization | AUDI | 1、 Imm2 1.1、 Replace the engine ECU 1.2、 Replace the immobilizer ECU | |
| | SKODA | 2、 Imm3 2.1、 Replace the engine ECU 2.2、 Replace the Dashboard | |
| | VW | 3、 Imm3.5 3.1、 Replace the engine ECU | |
| | BENTLEY | 3.2、 Replace the immobilizer ECU | |
| | SEAT | | |

| | | | |
|------|----------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| AUDI | 4th/5th Immobilizer system | 4th Immobilizer system | <ol style="list-style-type: none"> 1、CDC+24C32 2、NEC+24C32 3、9S12XHZ51(Golf6 MM7-2011) 4、NEC+95320 5、NEC+95320(HohnSon/JCI) 6、NEC 35XX 7、NEC+24C64 8、NEC+C64 Color screen 9、NEC+24C64(2013) Blank screen 10、NEC+24C64(2013) Color screen 11、NEC+24C64(2015-) 12、A1/Q3NEC+24C64(-2014) 13、Magotan/CC 14、A6L/Q7 15、AUDI A4R8(2005-) 16、AUDI A4R4(-2004) 17、AUDI A3/TT/R8 |
| | | 5th Immobilizer system | <ol style="list-style-type: none"> 1. Read anti-theft data 2. Display anti-theft data 3. Generate dealer keys 4. Learn the key 5. End the key learning mode 6. Unlock OEM key |
| | | A8/Phaeton/Touareg/Bentley (46 chip) | <ol style="list-style-type: none"> 1、Upload data 2、Download data 3、Generate dealer key 4、Learning key 5、Read PIN code and CS code(OBD) 6、Get the seventh byte of CS code |
| | | Porsche (2007-2010) | <ol style="list-style-type: none"> 1、Upload data 2、Download data 3、Generate dealer key 4、Learning key 5、Read PIN code and CS code(OBD) 6、Get the seventh byte of CS code |
| | MQB platform | <ol style="list-style-type: none"> 1. Read anti-theft data 2. Generate dealer keys 3. Learn the key 4. Reset the instrument | |
| | Online key matching | 4th immo 96-bit key (copy/learn) | <ol style="list-style-type: none"> 1、Upload data 2、Download data 3、Copy key 3、Generate dealer key 5、Learn key(UDS) 6、Unlock key 7、Online mode |
| | | MQB Online Key Matching (Add/All Lose) | <ol style="list-style-type: none"> 1、Upload data 2、Download data 3、Generate dealer key 4、Learn key 5、Online mode |
| | | 5th Key add | <ol style="list-style-type: none"> 1、Upload data 2、Download data 3、Generate dealer key 4、Learn key 5、Online mode |
| | | 5th Key all lose | <ol style="list-style-type: none"> 1、Upload data 2、Download data 3、Generate dealer key 4、Learn key 5、Online mode |
| | Key programmer | <ol style="list-style-type: none"> 1. Generate a special chip 2. Read and write 48 chips 3. Read and write 46 chips 4. Read the remote control frequency | |
| | Read and write ECU | <ol style="list-style-type: none"> 1、J518(1LWH/3L40K)(-2010) 2、J518(0L01Y)(2010-) 3、BCM2(D70F3381/3634) 4、AUDI-ESL | |