



<https://xtool.es/>
Telefono fijo: +34 937 371 351
sales@xtool.es

ROMEO Function List V26.92

Maker	Model	Year	System	Function
ROMEO	147		BCM	1.Number of keys 2.Programming key 3.Read immo password 4.Generate Dealer Key 5.Number of remotes 6.Programming remote
ROMEO	159		TRW	1.Key information 2.Programming key
ROMEO	Brera		TRW	1.Key information 2.Programming key
ROMEO	GIULIA	2015-2018	RFH	1.Read pincode 2.Programming key 3.Clear key 4. Number of keys
ROMEO	Giulietta		BCM 1	1.Number of keys 2.Programming key 3.Read pincode and Pre-coding key 4.Number of remotes 5.Programming remote 6.Read EEPROM
ROMEO	Giulietta		BCM 2	1.Number of keys 2.Programming key 3.Read immo password 4.Generate Dealer Key 5.Unlock key
ROMEO	GT		BCM	1.Number of keys 2.Programming key 3.Read immo password 4.Generate Dealer Key 5.Number of remotes 6.Programming remote

ROMEO	Mito		BCM	<ul style="list-style-type: none"> 1.Number of keys 2.Programming key 3.Read immo password 4.Generate Dealer Key 5.Read EEPROM 6.Write EEPROM
ROMEO	Spide		TRW	<ul style="list-style-type: none"> 1. Key information 2. Programming key
ROMEO	Stelvio	2017-2018	RFH	<ul style="list-style-type: none"> 1.Read pincode 2.Programming key 3.Clear key 4. Number of keys

XTOOL