



<https://xtool.es/>
Telefono fijo: +34 937 371 351
sales@xtool.es

Smart function table V26.17

vehicle	function menu	whether need password	The password can read	Password digits	All keys lost	remote
BR450	Program keys	no	no	none	support	automatic generation
BR451	1. Number of keys 2. Program keys	no	no	none	support	automatic generation
BR453	1. Add key 1.1 Program keys 1.2 Read pincode 1.3 Backup flash data 1.4 Write flash data 2. All key lost 2.1 Read pincode 2.2 Make dealer key 2.3 Program keys 3. Read VIN 4. Write VIN	yes	yes	16	no support	automatic generation

XTOOL