



<https://xtool.es/>
Telefono fijo: +34 937 371 351
sales@xtool.es

Peugeot Function List V10.70

Tips and Instructions:

- * This feature is new.
- ✓ This feature is supported.
- This feature is not supported.
- ※ This feature is partially supported.

Model	System Name	ECU	Read ECU Information	Read Trouble Code	Clear Trouble Code	Live Data	Actuation Test	Special Functions
1007 VAN	Engine	NFU ME744	✓	✓	✓	✓	✓	S0034
1007 VAN	Engine	BOSCH ME7.4.5	✓	✓	✓	✓	✓	S0034
1007 VAN	Engine	KFV S2000PM2	✓	✓	✓	✓	✓	S0034
1007 VAN	Engine	KFU MM6LP	✓	✓	✓	✓	✓	
1007 VAN	Engine	KFV J34P	✓	✓	✓	✓	✓	
1007 VAN	Engine	SIEMENS SID 804	✓	✓	✓	✓	✓	
1007 VAN	Gearbox ECU		✓	✓	✓	✓	✓	
1007 VAN	ABS or ESP ECU	ABS MK70	✓	✓	✓	✓	✓	S0039
1007 VAN	ABS or ESP ECU	ESP MK60	✓	✓	✓	✓	✓	S0035
1007 VAN	Airbag ECU		✓	✓	✓	✓		
1007 VAN	Instrument panel		✓	✓	✓	✓	✓	
1007 VAN	Air Conditioning		✓			✓		
1007 VAN	Sliding side doors module		✓	✓	✓	✓		
1007 VAN	Switch module at the steering wheel		✓	✓	✓	✓		
1007 VAN	Alarm		✓	✓	✓			
1007 VAN	Radio		✓	✓	✓	✓		
1007 VAN	CD Player		✓	✓	✓	✓		
1007 VAN	Parking aid		✓	✓	✓	✓		
1007 VAN	Rain/brightness sensor		✓	✓	✓			
1007 VAN	Display/Telematics		✓	✓	✓	✓		
1007 CAN	Engine	NFU BOSCH ME745	✓	✓	✓	✓	✓	S0034

1007 CAN	Engine	KFV J34P	√	√	√	√	√	S0034
1007 CAN	Engine	KFU MM6LPC	√	√	√	√	√	S0034
1007 CAN	Engine	ME749	√	√	√	√	√	
1007 CAN	Engine	SID 806 DV4	√	√	√	√	√	
1007 CAN	Engine	BOSCH EDC16C3	√	√	√	√	√	S0037
1007 CAN	Gearbox ECU		√	√	√	√	√	
1007 CAN	ABS or ESP ECU	ABS MK70.1	√	√	√	√	√	S0039
1007 CAN	ABS or ESP ECU	ESP MK60 0	√	√	√	√		S0035, S0039
1007 CAN	Airbag ECU		√	√	√	√		
1007 CAN	Power Steering		√	√	√	√		
1007 CAN	Instrument Panel		√	√	√	√	√	
1007 CAN	Sliding side doors module		√	√	√	√		
1007 CAN	ALARM		√	√	√	√		
1007 CAN	Multiplexed Additive Adding Pump (POMPE MUX MGI)		√	√	√	√		
1007 CAN	Air Conditioning		√	√	√	√	√	
1007 CAN	Under inflation detection		√	√	√	√		
1007 CAN	Parking Aid (AAS)		√	√	√	√	√	
1007 CAN	Telematics		√	√	√	√	√	
1007 CAN	Switch module at the steering wheel		√	√	√	√		
1007 CAN	Multifunction Display		√	√	√	√		
1007 CAN	High frequency receiver		√	√	√	√		
1007 CAN	Rain/sunlight sensor		√	√	√			
1007 CAN	RADIO		√	√	√	√		
1007 CAN	Cd player		√	√	√			
1007 CAN	Engine relay unit		√	√	√	√		
1007 CAN	Trailer Relay Unit		√	√	√	√		
106R	Additional Heating		√	√	√	√		S0035, S0039
106REMODELAGE	Engine	CDY BOSCH MA3.1	√	√	√			
106REMODELAGE	Engine	CDZ BOSCH MA3.1	√	√	√			
106REMODELAGE	Engine	HDY BOSCH MA3.1	√	√	√			
106REMODELAGE	Engine	HDZ BOSCH MA3.1	√	√	√			
106REMODELAGE	Engine	KFX BOSCH MP7.3	√	√	√	√		
106REMODELAGE	Engine	KFX MM1AP	√	√	√	√		
106REMODELAGE	Engine	NFX MM1AP	√	√	√	√		

106REMODELAGE	Engine	NFX MM48P	✓	✓	✓	✓		
106REMODELAGE	Engine	NFZ BOSCH MP5.2		✓	✓	✓		
106REMODELAGE	Additional heating		✓	✓	✓	✓		
107	Engine		✓	✓	✓	✓	✓	
107	Gearbox			✓	✓	✓		
107	ABS	ABS BOSCH 8.0 C1		✓	✓	✓		
107	ABS	ESP BOSCH 8.0 C1		✓	✓	✓		
107	air bag ECU		✓	✓	✓			
107	Power steering		✓	✓	✓	✓		S0035
107	Coded anti start			✓	✓	✓		
107	Radio		✓			✓	✓	
206	Engine	DCN2	✓	✓	✓	✓		
206	Engine	EDC15C2	✓	✓	✓	✓	✓	
206	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
206	Engine	EDC16C3	✓	✓	✓	✓	✓	S0036
206	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0036, S0037
206	Engine	J34P	✓	✓	✓	✓	✓	S0034
206	Engine	ME745	✓	✓	✓	✓	✓	S0034
206	Engine	N6A ME749 BIO FLEX	✓	✓	✓	✓	✓	S0034
206	Engine	NFU OR N6A ME749	✓	✓	✓	✓	✓	S0034
206	Engine	V343	✓	✓	✓	✓	✓	
206	Engine	V34 3	✓	✓	✓	✓	✓	
206	Engine	ME744	✓	✓	✓	✓	✓	S0034
206	Gearbox ECU		✓	✓	✓	✓	✓	
206	ABS or ESP ECU	ABS MK70	✓	✓	✓	✓	✓	S0039
206	ABS or ESP ECU	ESP MK60	✓	✓	✓	✓	✓	
206	ABS or ESP ECU	ABS TEVES	✓	✓	✓	✓		
206	Airbag ECU		✓	✓	✓			
206	Power steering		✓	✓	✓	✓		
206	Alarm		✓	✓	✓	✓		
206	Instrument panel		✓	✓	✓	✓	✓	
206	Air Conditioning		✓	✓	✓	✓		
206	Switch module at the steering wheel		✓			✓		
206	On board navigation system		✓	✓	✓	✓		
206	Driving school mode		✓			✓		

206	Rain/brightness sensor		✓	✓	✓			
206	Diesel fuel additive control unit		✓	✓	✓	✓		
206	Display/Telematics	AMF	✓	✓	✓	✓	✓	
206	Display/Telematics	RT3	✓	✓	✓	✓	✓	
206	Radio		✓	✓	✓	✓		
206 MUX	Engine	DCN2	✓	✓	✓	✓		
206 MUX	Engine	EDC15C2	✓	✓	✓	✓	✓	
206 MUX	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
206 MUX	Engine	EDC16C3	✓	✓	✓	✓	✓	S0036
206 MUX	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0036, S0037
206 MUX	Engine	J34P	✓	✓	✓	✓	✓	S0034
206 MUX	Engine	ME745	✓	✓	✓	✓	✓	S0034
206 MUX	Engine	N6A ME749 BIO FLEX	✓	✓	✓	✓	✓	S0034
206 MUX	Engine	NFU OR N6A ME749	✓	✓	✓	✓	✓	S0034
206 MUX	Engine	V343	✓	✓	✓	✓	✓	
206 MUX	Engine	V34 3	✓	✓	✓	✓	✓	
206 MUX	Engine	ME744	✓	✓	✓	✓	✓	S0034
206 MUX	Gearbox ECU		✓	✓	✓	✓		
206 MUX	ABS or ESP ECU	ESP MK60	✓	✓	✓	✓	✓	S0035, S0039
206 MUX	ABS or ESP ECU	ABS MK70	✓	✓	✓	✓	✓	S0039
206 MUX	ABS or ESP ECU	ABS TEVES	✓	✓	✓	✓		
206 MUX	Airbag ECU	SAC CENT AUTOLIV 2	✓	✓	✓			
206 MUX	Airbag ECU	Airbag and seatbelts	✓	✓	✓			
206 MUX	Airbag ECU	Left side airbag	✓	✓	✓			
206 MUX	Airbag ECU	Right side airbag	✓	✓	✓			
206 MUX	Power steering		✓	✓	✓	✓		
206 MUX	Instrument panel		✓	✓	✓	✓	✓	
206 MUX	Air Conditioning		✓	✓	✓	✓		
206 MUX	BSI		✓	✓	✓			S0033
206 MUX	Diesel fuel additive control unit		✓	✓	✓	✓		
206 MUX	Display/Telematics	AMF	✓	✓	✓	✓	✓	
206 MUX	Display/Telematics	RT3	✓	✓	✓	✓	✓	
206 MUX	Radio		✓	✓	✓	✓		
206 MUX	Alarm		✓	✓	✓	✓		
206 MUX	On board navigation system		✓	✓	✓	✓		

206 MUX	Driving school mode		✓			✓		
206 MUX	Rain/brightness sensor		✓	✓	✓			
206 +	Engine	ME745	✓	✓	✓	✓	✓	S0034
206 +	Engine	ME749	✓	✓	✓	✓	✓	S0034
206 +	Engine	ME749 BIO FLEX	✓	✓	✓	✓	✓	S0034
206 +	Engine	J34P	✓	✓	✓	✓	✓	S0034
206 +	Engine	V343	✓	✓	✓	✓	✓	
206 +	Engine	DCN2	✓	✓	✓	✓		
206 +	Engine	EDC15C2	✓	✓	✓	✓	✓	
206 +	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
206 +	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0036, S0037
206 +	Gearbox ECU		✓	✓	✓	✓	✓	
206 +	ABS or ESP ECU	ABSMK70 1	✓	✓	✓	✓	✓	S0039
206 +	ABS or ESP ECU	ESPMK60 0	✓	✓	✓	✓	✓	S0035, S0039
206 +	Airbag ECU		✓	✓	✓			
206 +	Electric Power Steering		✓	✓	✓	✓		
206 +	Instrument panel		✓	✓	✓	✓	✓	
206 +	Air Conditioning		✓	✓	✓	✓		
206 +	BSI		✓	✓	✓			S0033
206 +	Service module		✓	✓	✓	✓	✓	
206 +	Display/Telematics	AMF	✓	✓	✓	✓	✓	
206 +	Display/Telematics	RT3	✓	✓	✓	✓	✓	
207 VAN	Engine	ME745	✓	✓	✓	✓	✓	S0034
207 VAN	Engine	ME749	✓	✓	✓	✓	✓	S0034
207 VAN	Engine	ME749 BIO FLEX	✓	✓	✓	✓	✓	S0034
207 VAN	Engine	J34P	✓	✓	✓	✓	✓	S0034
207 VAN	Engine	V343	✓	✓	✓	✓	✓	
207 VAN	Engine	DCN2	✓	✓	✓	✓		
207 VAN	Engine	EDC15C2	✓	✓	✓	✓	✓	
207 VAN	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
207 VAN	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0036, S0037
207 VAN	Gearbox ECU		✓	✓	✓	✓	✓	
207 VAN	ABS or ESP ECU	ABSMK70 1	✓	✓	✓	✓	✓	S0039
207 VAN	ABS or ESP ECU	ESPMK60 0	✓	✓	✓	✓	✓	S0035, S0039
207 VAN	Airbag ECU		✓	✓	✓			

207 VAN	Electric Power Steering		✓	✓	✓	✓		
207 VAN	Instrument panel		✓	✓	✓	✓	✓	
207 VAN	Air Conditioning		✓	✓	✓	✓		
207 VAN	BSI		✓	✓	✓			S0033
207 VAN	Display/Telematics	AMF	✓	✓	✓	✓	✓	
207 VAN	Display/Telematics	RT3	✓	✓	✓	✓	✓	
207 VAN	Service module		✓	✓	✓	✓	✓	
207 CAN	Engine	ME745	✓	✓	✓	✓	✓	
207 CAN	Engine	MM6LPC	✓	✓	✓	✓	✓	S0034
207 CAN	Engine	J34P	✓	✓	✓	✓	✓	S0034
207 CAN	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
207 CAN	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
207 CAN	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
207 CAN	Engine	MEV17 4 2	✓	✓	✓	✓	✓	S0034
207 CAN	Engine	V341	✓	✓	✓	✓	✓	S0034
207 CAN	Engine	DCN2	✓	✓	✓	✓		
207 CAN	Engine	EDC15C2	✓	✓	✓	✓	✓	
207 CAN	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
207 CAN	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0036, S0037
207 CAN	Engine	EDC16C3	✓	✓	✓			
207 CAN	Engine	EDC17C10	✓	✓	✓			
207 CAN	Engine	HDI SID807	✓	✓	✓			
207 CAN	Engine	HDI SID807 BR2	✓	✓	✓			
207 CAN	Gearbox ECU	Controlled manual gearbox MAP	✓	✓	✓	✓	✓	
207 CAN	Gearbox ECU	AL4 automatic gearbox	✓	✓	✓	✓		
207 CAN	ABS/ESP	MK70.1	✓	✓	✓	✓	✓	S0039
207 CAN	ABS/ESP	ESP MK60 0	✓	✓	✓	✓	✓	S0035, S0039
207 CAN	Airbag ECU		✓	✓	✓	✓		
207 CAN	Power steering		✓	✓	✓	✓		
207 CAN	Instrument Panel		✓	✓	✓	✓	✓	
207 CAN	Air Conditioning		✓	✓	✓	✓	✓	
207 CAN	Multiplexed Additive Adding Pump (POMPE MUX MGI)		✓	✓	✓	✓		
207 CAN	ALARM		✓	✓	✓	✓	✓	

207 CAN	Under inflation detection	Recent ECU	✓	✓	✓	✓		
207 CAN	Under inflation detection	DSG UDS	✓	✓	✓			
207 CAN	Battery charge status unit	Recent ECU	✓	✓	✓	✓		S003A
207 CAN	Battery charge status unit	BECB	✓	✓	✓			
207 CAN	Battery charge status unit	BECB GEN2	✓	✓	✓			
207 CAN	Hands Free Kit	Hands Free Kit (BOITIER NOMADE)	✓	✓	✓	✓	✓	
207 CAN	Hands Free Kit	Hands Free Kit (KML)	✓			✓	✓	
207 CAN	Driving School Mode		✓	✓	✓			
207 CAN	Headlamp Height Corrector		✓	✓	✓	✓	✓	
207 CAN	Multifunction Display	Recent ECU	✓	✓	✓	✓	✓	
207 CAN	Multifunction Display	EMF A	✓	✓	✓			
207 CAN	Multifunction Display	EMF C	✓	✓	✓			
207 CAN	RADIO	Recent ECU	✓	✓	✓	✓	✓	
207 CAN	RADIO	AutoRadio	✓	✓	✓			
207 CAN	RADIO	RD45	✓	✓	✓			
207 CAN	Switch module at the steering wheel		✓	✓	✓	✓	✓	
207 CAN	Folding roof		✓	✓	✓	✓	✓	
207 CAN	High frequency receiver		✓	✓	✓	✓		
207 CAN	Rain/sunlight sensor		✓	✓	✓			
207 CAN	Telematics	Telematic case	✓	✓	✓	✓	✓	
207 CAN	Telematics	Radio alarm	✓	✓	✓	✓		
207 CAN	Warning light showing seat belt not fastened		✓					
207 CAN	Parking assistance		✓	✓	✓			
207 CAN	built-in systems interface		✓	✓	✓			
207 CAN	engine wiring housing		✓	✓	✓			
207 CAN	Trailer Relay Unit		✓	✓	✓			
207 CAN	CD changer / external CD player		✓	✓	✓			
207 CAN	Service module / Independent telematic unit		✓	✓	✓			
207 i	Engine	ME745	✓	✓	✓	✓	✓	S0034
207 i	Engine	ME749	✓	✓	✓	✓	✓	S0034
207 i	Engine	ME749 BIO FLEX	✓	✓	✓	✓	✓	S0034
207 i	Engine	J34P	✓	✓	✓	✓	✓	S0034

207 i	Engine	V343	✓	✓	✓	✓	✓	
207 i	Engine	DCN2	✓	✓	✓	✓		
207 i	Engine	EDC15C2	✓	✓	✓	✓	✓	
207 i	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
207 i	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0036, S0037
207 i	Gearbox ECU		✓	✓	✓	✓	✓	
207 i	ABS or ESP ECU	ABSMK70 1	✓	✓	✓	✓	✓	S0039
207 i	ABS or ESP ECU	ESPMK60 0	✓	✓	✓	✓	✓	S0035, S0039
207 i	Airbag ECU		✓	✓	✓			
207 i	Electric Power Steering		✓	✓	✓	✓		
207 i	Instrument panel		✓	✓	✓	✓	✓	
207 i	Air Conditioning		✓	✓	✓	✓		
207 i	Display/Telematics	AMF	✓	✓	✓	✓	✓	
207 i	Display/Telematics	RT3	✓	✓	✓	✓	✓	
207 i	Service module		✓	✓	✓	✓	✓	
207 +	Engine	ME745	✓	✓	✓	✓	✓	
207 +	Engine	MM6LPC	✓	✓	✓	✓	✓	S0034
207 +	Engine	J34P	✓	✓	✓	✓	✓	S0034
207 +	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
207 +	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
207 +	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
207 +	Engine	MEV17 4 2	✓	✓	✓	✓	✓	S0034
207 +	Engine	V341	✓	✓	✓	✓	✓	S0034
207 +	Engine	DCN2	✓	✓	✓	✓		
207 +	Engine	EDC15C2	✓	✓	✓	✓	✓	
207 +	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
207 +	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0036, S0037
207 +	Gearbox ECU	Controlled manual gearbox MAP	✓	✓	✓	✓	✓	
207 +	Gearbox ECU	AL4 automatic gearbox	✓	✓	✓	✓		
207 +	ABS/ESP	MK70.1	✓	✓	✓	✓	✓	S0039
207 +	ABS/ESP	ESP MK60 0	✓	✓	✓	✓	✓	S0035, S0039
207 +	Airbag ECU	SAC AUTOLIV	✓	✓	✓	✓		
207 +	Airbag ECU	SAC GONFLABLE	✓	✓	✓	✓	✓	
207 +	Power steering		✓	✓	✓	✓		

207 +	Instrument Panel		✓	✓	✓	✓	✓	
207 +	Air Conditioning		✓	✓	✓	✓	✓	
207 +	Multiplexed Additive Adding Pump (POMPE MUX MGI)		✓	✓	✓	✓		
207 +	ALARM		✓	✓	✓	✓	✓	
207 +	Under inflation detection		✓	✓	✓	✓		
207 +	Battery charge status unit		✓	✓	✓	✓		S003A
207 +	Hands Free Kit	Hands Free Kit (BOITIER NOMADE)	✓	✓	✓	✓	✓	
207 +	Hands Free Kit	Hands Free Kit (KML)	✓			✓	✓	
207 +	Driving School Mode		✓	✓	✓			
207 +	Headlamp Height Corrector		✓	✓	✓	✓	✓	
207 +	Multifunction Display		✓	✓	✓	✓	✓	
207 +	RADIO		✓	✓	✓	✓	✓	
207 +	Switch module at the steering wheel		✓	✓	✓	✓	✓	
207 +	Folding roof		✓	✓	✓	✓	✓	
207 +	High frequency receiver		✓	✓	✓	✓		
207 +	Rain/sunlight sensor		✓	✓	✓			
207 +	Telematics	Telematic case	✓	✓	✓	✓	✓	
207 +	Telematics	Radio alarm	✓	✓	✓	✓		
207 +	Warning light showing seat belt not fastened		✓					
208	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037
208	Engine	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
208	Engine	V46	✓	✓	✓	✓		
208	Engine	MEV17 4 2	✓	✓	✓	✓		S0034
208	Engine	MED17 4 2	✓	✓	✓	✓		S0034
208	Engine	CMM MD1CS003	✓	✓	✓			
208	Engine	CMM V56	✓	✓	✓			
208	Engine	ME745 EC5	✓	✓	✓			
208	Engine	ME749 EC5	✓	✓	✓			
208	Engine	MED17 4 4	✓	✓	✓			
208	Engine	MEVD17 4 2	✓	✓	✓			
208	Engine	MEVD17 4 4	✓	✓	✓			
208	Engine	V344	✓	✓	✓			

208	Engine	V345	✓	✓	✓			
208	Engine	V46 21	✓	✓	✓			
208	Engine	V46 52	✓	✓	✓			
208	Engine	V46 6	✓	✓	✓			
208	Engine	VD46	✓	✓	✓			
208	Gearbox	CFC300P	✓	✓	✓	✓	✓	
208	Gearbox	BVMP	✓	✓	✓	✓		
208	Gearbox	BVA AL4	✓	✓	✓	✓	✓	
208	Gearbox	BVA AM6 AT6 UDS	✓	✓	✓			
208	ABS or ESP ECU	ABS MK100	✓	✓	✓	✓	✓	S0039
208	ABS or ESP ECU	ESPMK100	✓	✓	✓	✓	✓	S0039
208	Air bag		✓	✓	✓	✓		
208	Electric power steering		✓	✓	✓	✓		
208	Anti theft alarm		✓	✓	✓	✓	✓	
208	Instrument panel		✓	✓	✓	✓	✓	
208	Air conditioning	Recent ECU	✓	✓	✓	✓		
208	Air conditioning	TDC CH MUX	✓	✓	✓			
208	Air conditioning	TDC RF MUX	✓	✓	✓			
208	Trailer relay unit		✓	✓	✓	✓		
208	Parking aid		✓	✓	✓			
208	Radio	Recent ECU	✓	✓	✓	✓	✓	
208	Radio	RDE	✓	✓	✓			
208	Rain sunlight sensor		✓	✓	✓	✓		
208	Independent telematic unit(BTA)		✓	✓	✓	✓		
208	Multiplexed control panel		✓	✓	✓	✓		
208	External CD player		✓	✓	✓	✓	✓	
208	Controls on the steering wheel		✓	✓	✓	✓		
208	Battery charge status unit		✓			✓		S003A
208	Telematics	Recent ECU	✓	✓	✓	✓		
208	Telematics	SMEG PLUS	✓	✓	✓			
208	Siren		✓	✓	✓	✓		
208	Multiplexed additive pump	Recent ECU	✓	✓	✓	✓		
208	Multiplexed additive pump	PADDGO	✓	✓	✓			
208	Switch module under the steering wheel		✓	✓	✓	✓	✓	

208	Lighting relay unit		✓	✓	✓	✓		
208	Touch screen		✓	✓	✓			
208	Audio amplifier		✓	✓	✓			
208	Vehicle Distance Assistance		✓	✓	✓			
208	Voltage maintaining device	DMTC	✓					
208	Voltage maintaining device	DMTR	✓	✓	✓			
208	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
208	driving school module		✓	✓	✓			
208	Control panel dot matrix display	MATT C 2010	✓	✓	✓			
208	Control panel dot matrix display	MATT M 2010	✓	✓	✓			
208	Control panel dot matrix display	MATT P 2010	✓	✓	✓			
208	Service module / Independent telematic unit	BTA	✓	✓	✓			
208	Service module / Independent telematic unit	BTA_2	✓	✓	✓			
208	Service module / Independent telematic unit	BTA_3R	✓	✓	✓			
208	Service module / Independent telematic unit	BTA_3S	✓	✓	✓			
208	diesel fuel additive pump		✓	✓	✓			
208	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓			
208	Telematic unit (RTx) or audio-navigation	RCC	✓	✓	✓			
208 (Ai91)	Engine	V34.4 Essence[A]	✓	✓	✓	✓		
208 (Ai91)	Engine	V34.4 Flex Fuel[B]	✓	✓	✓	✓		
208 (Ai91)	Engine	V34.5 Essence[A]	✓	✓	✓	✓		
208 (Ai91)	Engine	V34.5 Flex Fuel[B]	✓	✓	✓	✓		
208 (Ai91)	Engine	MED17 4 4	✓	✓	✓	✓		
208 (Ai91)	Engine	ME749 EC5[NFP]	✓	✓	✓	✓		
208 (Ai91)	Engine	ME749 EC5[NFN]	✓	✓	✓	✓		
208 (Ai91)	AT BVA AL		✓	✓	✓	✓		
208 (Ai91)	ABS or ESP ECU	ABS MK100	✓	✓	✓	✓		
208 (Ai91)	ABS or ESP ECU	ESPMK100	✓	✓	✓	✓		
208 (Ai91)	Airbag		✓	✓	✓	✓		

208(Ai91)	Power steering electric pump unit		√	√	√	√		
208(Ai91)	Anti theft alarm		√	√	√	√		
208(Ai91)	Instrument Panel		√	√	√	√		
208(Ai91)	Air Conditioning		√	√	√	√		
208(Ai91)	BSI		√	√	√	√		
208(Ai91)	Parking Aid(AAS)		√	√	√	√		
208(Ai91)	CD player		√	√	√	√		
208(Ai91)	Independent telematic unit(BTA)	108	√	√	√	√		
208(Ai91)	Independent telematic unit(BTA)	SMEG PLUS	√	√	√	√		
208(Ai91)	Steering Wheel Switching Module		√	√	√	√		
208(Ai91)	AutoRadio		√	√	√	√		
208(Ai91)	Rain sensor		√	√	√	√		
208(Ai91)	Multiplexed control panel		√	√	√	√		
208(Ai91)	VCI		√	√	√	√		
208(Ai91)	Siren		√	√	√	√		
208(Ai91)	Telematics unit		√	√	√	√		
301	Engine	V46	√	√	√	√	√	
301	Engine	V46 21	√	√	√	√	√	
301	Engine	EDC17C10 BR2	√	√	√	√	√	S0036, S0037
301	Engine	ME745 EC5	√	√	√	√	√	S0034
301	Gearbox ECU	BVA AL4	√	√	√	√	√	
301	Gearbox ECU	MAPS UDS	√	√	√	√		
301	Gearbox ECU	BVA AM6 AT6 UDS	√	√	√	√		
301	ABS	ABS MK100	√	√	√	√	√	S0039
301	ABS	ESPMK100	√	√	√	√	√	S0039
301	Airbag		√	√	√	√		
301	Electric power steering		√	√	√	√		
301	Instrument panel		√	√	√	√	√	
301	BSI		√	√	√	√		S0033
301	Multiplexed Additive Adding Pump		√	√	√	√		
301	Parking aid		√	√	√	√		
301	Multi function display	EMF A	√	√	√			
301	Multi function display	EMF C	√	√	√	√		
301	RADIO	AUTORADIO	√	√	√	√	√	
301	RADIO	RD45	√	√	√	√	√	

301	Steering Wheel Switching Module		✓	✓	✓	✓		
301	Trailer Relay Unit		✓	✓	✓	✓		
306R	Engine	EDC16C3		✓	✓		✓	S0036, S0037
306R	Engine	HDI SID803		✓	✓		✓	S0037
306R	Engine	ME745		✓	✓		✓	S0034
306R	Engine	MM6LP		✓	✓			
306R	Gearbox ECU		✓	✓	✓	✓		
306R	ABS/ESP		✓	✓	✓	✓		
306R	Airbag ECU	Airbag and seatbelts	✓	✓	✓			
306R	Airbag ECU	Left side airbag	✓	✓	✓			
306R	Airbag ECU	Right side airbag	✓	✓	✓			
307 VAN	Engine	EDC16C3		✓	✓		✓	S0036, S0037
307 VAN	Engine	HDI SID803		✓	✓		✓	S0037
307 VAN	Engine	ME745		✓	✓		✓	S0034
307 VAN	Engine	MM6LP		✓	✓			
307 VAN	Engine	ME744	✓	✓	✓	✓	✓	S0034
307 VAN	Gearbox ECU		✓	✓	✓	✓	✓	
307 VAN	ABS/ESP	ABS BOSCH8	✓	✓	✓	✓	✓	
307 VAN	ABS/ESP	ESP BOSCH8	✓	✓	✓	✓	✓	S0035, S0039
307 VAN	ABS/ESP	ESP BOSCH57	✓	✓	✓	✓	✓	S0035, S0039
307 VAN	ABS/ESP	ABS BOSCH53	✓	✓	✓	✓		
307 VAN	Air bags		✓	✓	✓			
307 VAN	Power Steering		✓	✓	✓	✓		
307 VAN	Instrument panel		✓	✓	✓	✓	✓	
307 VAN	Air Conditioning		✓	✓	✓	✓		
307 VAN	Diesel fuel additive control unit		✓	✓	✓	✓		
307 VAN	Alarm		✓	✓	✓	✓		
307 VAN	Switch module at the steering wheel		✓			✓		
307 VAN	Multi function display		✓	✓	✓	✓	✓	
307 VAN	Parking aid		✓	✓	✓	✓		
307 VAN	Radio		✓	✓	✓	✓	✓	
307 VAN	CD Player		✓	✓	✓	✓		
307 VAN	Driving school mode		✓			✓		
307 VAN	Roll over ECU		✓	✓	✓	✓		
307 VAN	Sun roof	TO WEBASTO	✓	✓	✓	✓		

307 VAN	Sun roof	TOUV TEXTON	✓	✓	✓	✓		
307 CAN	Engine	ME745	✓	✓	✓	✓	✓	S0034, S0040, S0041, S0042
307 CAN	Engine	KFU MM6LP	✓	✓	✓	✓	✓	S0034
307 CAN	Engine	RFK MM6LP	✓	✓	✓	✓	✓	S0034
307 CAN	Engine	RFN MM6LP	✓	✓	✓	✓	✓	S0034
307 CAN	Engine	RFJ MM6LPB	✓	✓	✓	✓	✓	S0034
307 CAN	Engine	KFU MM6LPC	✓	✓	✓	✓	✓	S0034
307 CAN	Engine	ME749	✓	✓	✓	✓	✓	S0034
307 CAN	Engine	ME749 BioFlex	✓	✓	✓	✓	✓	
307 CAN	Engine	ME749 EC5	✓	✓	✓	✓	✓	
307 CAN	Engine	MM6KP BioFlex	✓	✓	✓	✓	✓	S0034
307 CAN	Engine	MM6KP Non BioFlex	✓	✓	✓	✓	✓	
307 CAN	Engine	DCM3.4	✓	✓	✓	✓	✓	S0036, S0037
307 CAN	Engine	EDC15C2	✓	✓	✓	✓	✓	
307 CAN	Engine	9HV BOSCH EDC16C3	✓	✓	✓	✓	✓	S0036
307 CAN	Engine	9HX BOSCH EDC16C3	✓	✓	✓	✓	✓	
307 CAN	Engine	9HY BOSCH EDC16C3	✓	✓	✓	✓	✓	
307 CAN	Engine	9HZ BOSCH EDC16C3	✓	✓	✓	✓	✓	
307 CAN	Engine	HDI SID803	✓	✓	✓	✓	✓	
307 CAN	Engine	HDI SID803A	✓	✓	✓	✓	✓	
307 CAN	Engine	MM6LP	✓	✓	✓			
307 CAN	Engine	MM6LPB	✓	✓	✓			
307 CAN	Gearbox ECU	BVA AL4 AT8	✓	✓	✓	✓		
307 CAN	Gearbox ECU	AM6 automatic gearbox	✓	✓	✓	✓	✓	
307 CAN	ABS/ESP	ABS8 BOSCH	✓	✓	✓	✓	✓	S0039
307 CAN	ABS/ESP	ABS8.1	✓	✓	✓	✓	✓	S0039
307 CAN	ABS/ESP	ESP BOC SH8	✓	✓	✓	✓	✓	S0039
307 CAN	ABS/ESP	ESP8.1	✓	✓	✓	✓	✓	S0035, S0039
307 CAN	Air bag	SAC AUTOLIV	✓	✓	✓	✓		
307 CAN	Air bag	SAC GONFLABLE	✓	✓	✓	✓		
307 CAN	Power Steering		✓	✓	✓	✓	✓	
307 CAN	Instrument panel		✓	✓	✓	✓	✓	
307 CAN	Air Conditioning		✓	✓	✓	✓	✓	

307 CAN	BSI		✓	✓	✓			S0033
307 CAN	Multiplexed additive adding pump ECU		✓	✓	✓	✓	✓	
307 CAN	Parking aid		✓	✓	✓	✓	✓	
307 CAN	Under inflation detection		✓	✓	✓	✓		
307 CAN	Multi function display	Recent ECU	✓	✓	✓	✓	✓	
307 CAN	Multi function display	EMF C	✓	✓	✓			
307 CAN	Multi function display	EMF A	✓	✓	✓			
307 CAN	Radio		✓	✓	✓	✓	✓	
307 CAN	CD Player		✓	✓	✓			
307 CAN	Switch module at the steering wheel		✓	✓	✓	✓	✓	
307 CAN	Hand Free Kit	Recent ECU	✓	✓	✓	✓	✓	
307 CAN	Hand Free Kit	KML	✓	✓	✓			
307 CAN	Telematics		✓	✓	✓	✓	✓	
307 CAN	Alarm		✓	✓	✓	✓	✓	
307 CAN	Driver's door module		✓	✓	✓	✓	✓	
307 CAN	Passenger door module		✓	✓	✓	✓	✓	
307 CAN	Retractable roof		✓	✓	✓	✓	✓	
307 CAN	Sun roof		✓	✓	✓	✓		
307 CAN	Rain/brightness sensor		✓	✓	✓			
307 CAN	diesel additive		✓	✓	✓			
307 CAN	engine wiring housing		✓	✓	✓			
307 CAN	Trailer Relay Unit		✓	✓	✓			
307 CAN	driving school module		✓	✓	✓			
307 CAN	Hands-free Kit / Portable Unit		✓	✓	✓			
307 CAN	Service module / Independent telematic unit		✓	✓	✓			
307 CAN	diesel fuel additive pump		✓	✓	✓			
307 CAN	High frequency receiver		✓	✓	✓			
308	Engine	ME745	✓	✓	✓	✓	✓	
308	Engine	ME745 EC5	✓	✓	✓	✓	✓	S0034
308	Engine	ME749	✓	✓	✓	✓	✓	
308	Engine	ME749 EC5	✓	✓	✓	✓	✓	S0034
308	Engine	MM6LPB	✓	✓	✓	✓	✓	
308	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
308	Engine	EMV17 4 2	✓	✓	✓	✓	✓	S0034

308	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
308	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
308	Engine	MED17 4 2	✓	✓	✓	✓	✓	
308	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
308	Engine	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
308	Engine	MEVD17 4 2	✓	✓	✓	✓	✓	S0034
308	Engine	MM6KP Bio Flex1	✓	✓	✓	✓	✓	S0034
308	Engine	MM6KP Bio Flex2	✓	✓	✓	✓	✓	S0034
308	Engine	EDC16C3	✓	✓	✓	✓	✓	
308	Engine	DCM34	✓	✓	✓	✓	✓	S0036, S0037
308	Engine	DCM35	✓	✓	✓	✓	✓	S0036, S0037
308	Engine	DCM35 BR2	✓	✓	✓	✓	✓	S0036, S0037
308	Engine	SID807	✓	✓	✓	✓	✓	S0037
308	Engine	SID807 BR2	✓	✓	✓	✓	✓	S0037
308	Engine	EDC17C10	✓	✓	✓	✓	✓	S0036, S0037
308	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0036, S0037
308	Engine	MED17 4 4	✓	✓	✓			
308	Gearbox ECU	BVA AT8	✓	✓	✓	✓	✓	
308	Gearbox ECU	BVA AM6	✓	✓	✓	✓	✓	
308	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
308	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
308	ABS or ESP ECU	ABS81	✓	✓	✓	✓	✓	S0039
308	ABS or ESP ECU	ESP81	✓	✓	✓	✓	✓	S0035, S0039
308	Air bag		✓	✓	✓	✓		
308	Power steering		✓	✓	✓	✓	✓	
308	Instrument Panel		✓	✓	✓	✓	✓	
308	AC CLIM		✓	✓	✓	✓	✓	
308	BSI		✓	✓	✓			S0033
308	Alarm	ALARME	✓	✓	✓	✓	✓	
308	Alarm	LIN ALARM	✓	✓	✓	✓	✓	
308	Hands Free Kit	Hands Free Kit (BOITIER NOMADE)	✓	✓	✓	✓	✓	
308	Hands Free Kit	Hands Free Kit (KML)	✓	✓	✓	✓	✓	
308	Under inflation detection	Recent ECU	✓	✓	✓	✓		
308	Under inflation detection	DSG UDS	✓	✓	✓			

308	Steering Wheel Switching Module		✓	✓	✓	✓	✓	
308	Driver's Door Module		✓	✓	✓	✓	✓	
308	Driving School Mode		✓	✓	✓			
308	Driver's Seat Memory Unit		✓	✓	✓	✓	✓	
308	Passenger Seat Memorisation Module		✓	✓	✓	✓	✓	
308	Headlamp Height Corrector		✓	✓	✓	✓	✓	
308	Multiplexed Additive Adding Pump	ADDITIVE PUMP PADDGO	✓	✓	✓	✓	✓	
308	Multiplexed Additive Adding Pump	ADDITIVE PUMP PADDGO E5	✓	✓	✓	✓		
308	Parking Aid(AAS)		✓	✓	✓	✓		
308	Pedestrian Impact Detection Unit		✓	✓	✓	✓		
308	Battery change status unit	BECB	✓	✓	✓	✓		S003A
308	Battery change status unit	BECB GEN2	✓	✓	✓	✓		S003A
308	CD player		✓	✓	✓			
308	Engine relay unit		✓	✓	✓	✓	✓	
308	ESSUIV		✓	✓	✓	✓		
308	Hi fi amplifier		✓	✓	✓	✓		
308	Lane departure warning system		✓	✓	✓	✓	✓	
308	Control panel dot matrix display		✓	✓	✓	✓	✓	
308	Multi function display	EMF A	✓	✓	✓	✓	✓	
308	Multi function display	EMF C	✓	✓	✓	✓	✓	
308	RADIO	AUTORADIO	✓	✓	✓	✓	✓	
308	RADIO	RD43	✓	✓	✓	✓		
308	RADIO	RD45	✓	✓	✓	✓	✓	
308	Rain Sensor		✓	✓	✓			
308	SUN ROOF		✓	✓	✓	✓		
308	TOITESC		✓	✓	✓	✓		
308	Trailer relay unit		✓	✓	✓	✓	✓	
308	Service module	BLVV (KWP)	✓	✓	✓	✓		
308	Service module	BTA	✓	✓	✓	✓		
308	Service module	MD SERV	✓	✓	✓	✓		
308	Service module	BLVV	✓	✓	✓			
308	Voltage maintaining device		✓					
308	Moving panel deflector		✓	✓	✓			
308	High frequency receiver		✓	✓	✓			

308	Telematic unit (RTx) or audio-navigation	BOITIER_TELEMATIQUE	✓	✓	✓			
308	Telematic unit (RTx) or audio-navigation	RADIONAV_NG4	✓	✓	✓			
308	Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG	✓	✓	✓			
308	Telematic unit (RTx) or audio-navigation	RADIONAV_RNEGC	✓	✓	✓			
308	Telematic unit (RTx) or audio-navigation	RADIONAV_RNEG_ECO	✓	✓	✓			
308	Telematic unit (RTx) or audio-navigation	RNEG2010	✓	✓	✓			
308	seat belt not fastened warning lights unit		✓					
308 4 Portes	Engine	ME745	✓	✓	✓	✓	✓	
308 4 Portes	Engine	ME745 EC5	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	ME749	✓	✓	✓	✓	✓	
308 4 Portes	Engine	ME749 EC5	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MM6LPB	✓	✓	✓	✓	✓	
308 4 Portes	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	EMV17 4 2	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MED17 4 2	✓	✓	✓	✓	✓	
308 4 Portes	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MEVD17 4 2	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MM6KP Bio Flex1	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	MM6KP Bio Flex2	✓	✓	✓	✓	✓	S0034
308 4 Portes	Engine	EDC16C3	✓	✓	✓	✓	✓	
308 4 Portes	Engine	DCM34	✓	✓	✓	✓	✓	S0036, S0037
308 4 Portes	Engine	DCM35	✓	✓	✓	✓	✓	S0036, S0037
308 4 Portes	Engine	DCM35 BR2	✓	✓	✓	✓	✓	S0036, S0037
308 4 Portes	Engine	SID807	✓	✓	✓	✓	✓	S0037
308 4 Portes	Engine	SID807 BR2	✓	✓	✓	✓	✓	S0037

308 4 Portes	Engine	EDC17C10	✓	✓	✓	✓	✓	S0036, S0037
308 4 Portes	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0036, S0037
308 4 Portes	Gearbox ECU	BVA AT8	✓	✓	✓	✓	✓	
308 4 Portes	Gearbox ECU	BVA AM6	✓	✓	✓	✓	✓	
308 4 Portes	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
308 4 Portes	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
308 4 Portes	ABS or ESP ECU	ABS81	✓	✓	✓	✓	✓	S0039
308 4 Portes	ABS or ESP ECU	ESP81	✓	✓	✓	✓	✓	S0035, S0039
308 4 Portes	Air bag		✓	✓	✓	✓		
308 4 Portes	Power steering		✓	✓	✓	✓	✓	
308 4 Portes	Instrument Panel		✓	✓	✓	✓	✓	
308 4 Portes	AC CLIM		✓	✓	✓	✓	✓	
308 4 Portes	BSI		✓	✓	✓			S0033
308 4 Portes	Alarm	ALARME	✓	✓	✓	✓	✓	
308 4 Portes	Alarm	LIN ALARM	✓	✓	✓	✓	✓	
308 4 Portes	Hands Free Kit	Hands Free Kit (BOITIER NOMADE)	✓	✓	✓	✓	✓	
308 4 Portes	Hands Free Kit	Hands Free Kit (KML)	✓	✓	✓	✓	✓	
308 4 Portes	Under inflation detection		✓	✓	✓	✓		
308 4 Portes	Steering Wheel Switching Module		✓	✓	✓	✓	✓	
308 4 Portes	Driver's Door Module		✓	✓	✓	✓	✓	
308 4 Portes	Driving School Mode		✓	✓	✓			
308 4 Portes	Driver's Seat Memory Unit		✓	✓	✓	✓	✓	
308 4 Portes	Passenger Seat Memorisation Module		✓	✓	✓	✓	✓	
308 4 Portes	Headlamp Height Corrector		✓	✓	✓	✓	✓	
308 4 Portes	Multiplexed Additive Adding Pump	ADDITIVE PUMP PADDGO	✓	✓	✓	✓	✓	
308 4 Portes	Multiplexed Additive Adding Pump	ADDITIVE PUMP PADDGO E5	✓	✓	✓	✓		
308 4 Portes	Parking Aid (AAS)		✓	✓	✓	✓		
308 4 Portes	Pedestrian Impact Detection Unit		✓	✓	✓	✓		
308 4 Portes	Battery change status unit	BECB	✓	✓	✓	✓		S003A
308 4 Portes	Battery change status unit	BECB GEN2	✓	✓	✓	✓		S003A
308 4 Portes	CD player		✓	✓	✓			
308 4 Portes	Engine relay unit		✓	✓	✓	✓	✓	
308 4 Portes	ESSUIV		✓	✓	✓	✓		

308 4 Portes	Hi fi amplifier		✓	✓	✓	✓		
308 4 Portes	Lane departure warning system		✓	✓	✓	✓	✓	
308 4 Portes	Control panel dot matrix display		✓	✓	✓	✓	✓	
308 4 Portes	Multi function display	EMF A	✓	✓	✓	✓	✓	
308 4 Portes	Multi function display	EMF C	✓	✓	✓	✓	✓	
308 4 Portes	RADIO	AUTORADIO	✓	✓	✓	✓	✓	
308 4 Portes	RADIO	RD43	✓	✓	✓	✓		
308 4 Portes	RADIO	RD45	✓	✓	✓	✓	✓	
308 4 Portes	Rain Sensor		✓	✓	✓			
308 4 Portes	SUN ROOF		✓	✓	✓	✓		
308 4 Portes	TOITESC		✓	✓	✓	✓		
308 4 Portes	Trailer relay unit		✓	✓	✓	✓	✓	
308 4 Portes	Service module	BLVV (KWP)	✓	✓	✓	✓		
308 4 Portes	Service module	BTA	✓	✓	✓	✓		
308 4 Portes	Service module	MD SERV	✓	✓	✓	✓		
3008	Engine	MED17 4 2	✓	✓	✓	✓	✓	S0034
3008	Engine	MEV17 4 2	✓	✓	✓	✓	✓	
3008	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
3008	Engine	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
3008	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
3008	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
3008	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
3008	Engine	MM6KP bio	✓	✓	✓	✓	✓	S0034
3008	Engine	DCM35	✓	✓	✓	✓	✓	S0036, S0037
3008	Engine	DCM35 BR2	✓	✓	✓	✓	✓	S0036, S0037
3008	Engine	DCM35 HY	✓	✓	✓	✓	✓	S0036, S0037
3008	Engine	EDC16C3	✓	✓	✓	✓	✓	S0036, S0037
3008	Engine	SID807	✓	✓	✓	✓	✓	S0037
3008	Engine	SID807 BR2	✓	✓	✓	✓	✓	S0037
3008	Engine	DCM6. 2	✓	✓	✓			
3008	Engine	EDC17C60	✓	✓	✓			
3008	Engine	MED17 4 4	✓	✓	✓			
3008	Engine	VD46	✓	✓	✓			
3008	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
3008	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	

3008	Gearbox ECU	CFC300P HY	✓	✓	✓	✓	✓	
3008	Gearbox ECU	BVA AM6 AT6 UDS	✓	✓	✓			
3008	ABS or ESP ECU		✓	✓	✓	✓	✓	S0035, S0038, S0039
3008	Air bag		✓	✓	✓	✓		
3008	Power steering		✓	✓	✓	✓	✓	
3008	Instrument Panel		✓	✓	✓	✓	✓	
3008	Air Conditioning		✓	✓	✓	✓	✓	
3008	Electric parking brake	Recent ECU	✓	✓	✓	✓	✓	S0038
3008	Electric parking brake	FSE	✓	✓	✓			
3008	BSI		✓	✓	✓			S0033
3008	Under inflation detection	Recent ECU	✓	✓	✓	✓		
3008	Under inflation detection	DSG	✓	✓	✓			
3008	Under inflation detection	DSG UDS	✓	✓	✓			
3008	ALARM		✓	✓	✓	✓	✓	
3008	Assistance In Complying With The Inter Vehicle Time Artiv		✓	✓	✓	✓		
3008	Battery charge status unit	Recent ECU	✓			✓		S003A
3008	Battery charge status unit	BECB	✓	✓	✓			
3008	Battery charge status unit	BECB GEN2	✓	✓	✓			
3008	Hands Free Kit		✓	✓	✓	✓	✓	
3008	Windscreen Wiper Control Unit		✓	✓	✓			
3008	Driver's Door Module		✓	✓	✓	✓	✓	
3008	Headlamp Height Corrector		✓	✓	✓	✓	✓	
3008	Lane Departure Warning System		✓	✓	✓	✓		
3008	Multifunction Display	Multifunction Display A	✓	✓	✓	✓	✓	
3008	Multifunction Display	Multifunction Display C	✓	✓	✓	✓	✓	
3008	Multiplexed Additive Adding Pump	POMPE MUX MGI	✓	✓	✓	✓	✓	
3008	Multiplexed Additive Adding Pump	POMPE MUX TI	✓	✓	✓	✓	✓	
3008	Multiplexed Additive Adding Pump	PADDGO	✓	✓	✓			
3008	Multiplexed Additive Adding Pump	PADDGO E5	✓	✓	✓			
3008	Multiplexed Additive Adding Pump	PADDGO TI E6	✓	✓	✓			
3008	Parking Aid(AAS)	Recent ECU	✓	✓	✓	✓	✓	

3008	Parking Aid(AAS)	AAS	✓	✓	✓			
3008	RADIO	Recent ECU	✓	✓	✓	✓	✓	
3008	RADIO	RD45	✓	✓	✓			
3008	Service Module	Service Module(BTA)	✓	✓	✓	✓	✓	
3008	Service Module	Service Module(MD SERV)	✓	✓	✓	✓	✓	
3008	Service Module	BLVV	✓	✓	✓			
3008	Telematics	Telematics(RADIONAV NG4)	✓	✓	✓	✓	✓	
3008	Telematics	Telematics(RADIONAV RNEG)	✓	✓	✓	✓		
3008	Anti slip mode selector		✓			✓	✓	
3008	Audio amplifier		✓	✓	✓		✓	
3008	CD player		✓	✓	✓			
3008	Control panel dot matrix display		✓	✓	✓	✓	✓	
3008	High Head Vision	VTH	✓	✓	✓	✓		
3008	High Head Vision	VTH UDS	✓	✓	✓			
3008	Network isolation unit		✓			✓		
3008	Rain sensor		✓	✓	✓			
3008	Switch module at the steering wheel		✓	✓	✓	✓	✓	
3008	Not Fastened warning lingt(TNB)		✓					
3008	Traction control mode selector		✓					
3008	engine wiring housing		✓	✓	✓			
3008	Trailer Relay Unit		✓	✓	✓			
3008	Voltage maintaining device	DMTC	✓					
3008	Voltage maintaining device	DMTR	✓	✓	✓			
3008	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
3008	High frequency receiver		✓	✓	✓			
3008	Telematic unit (RTx) or audio-navigation		✓	✓	✓			
3008 Hybrid4	Engine	MED17 4 2	✓	✓	✓	✓	✓	S0034
3008 Hybrid4	Engine	MEV17 4 2	✓	✓	✓	✓	✓	
3008 Hybrid4	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
3008 Hybrid4	Engine	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
3008 Hybrid4	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034

3008 Hybrid4	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
3008 Hybrid4	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
3008 Hybrid4	Engine	MM6KP bio	✓	✓	✓	✓	✓	S0034
3008 Hybrid4	Engine	DCM35	✓	✓	✓	✓	✓	S0036, S0037
3008 Hybrid4	Engine	DCM35 BR2	✓	✓	✓	✓	✓	S0036, S0037
3008 Hybrid4	Engine	DCM35 HY	✓	✓	✓	✓	✓	S0036, S0037
3008 Hybrid4	Engine	EDC16C3	✓	✓	✓	✓	✓	S0036, S0037
3008 Hybrid4	Engine	SID807	✓	✓	✓	✓	✓	S0037
3008 Hybrid4	Engine	SID807 BR2	✓	✓	✓	✓	✓	S0037
3008 Hybrid4	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
3008 Hybrid4	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
3008 Hybrid4	Gearbox ECU	CFC300P HY	✓	✓	✓	✓	✓	
3008 Hybrid4	ABS or ESP ECU		✓	✓	✓	✓	✓	S0035, S0038, S0039
3008 Hybrid4	Air bag		✓	✓	✓	✓		
3008 Hybrid4	Power steering		✓	✓	✓	✓	✓	
3008 Hybrid4	Instrument Panel		✓	✓	✓	✓	✓	
3008 Hybrid4	Air Conditioning		✓	✓	✓	✓	✓	
3008 Hybrid4	Electric parking brake		✓	✓	✓	✓	✓	S0038
3008 Hybrid4	BSI		✓	✓	✓			S0033
3008 Hybrid4	Under inflation detection		✓	✓	✓	✓		
3008 Hybrid4	ALARM		✓	✓	✓	✓	✓	
3008 Hybrid4	Assistance In Complying With The Inter Vehicle Time Artiv		✓	✓	✓	✓		
3008 Hybrid4	Battery charge status unit		✓			✓		S003A
3008 Hybrid4	Hands Free Kit		✓	✓	✓	✓	✓	
3008 Hybrid4	Windscreen Wiper Control Unit		✓	✓	✓			
3008 Hybrid4	Driver's Door Module		✓	✓	✓	✓	✓	
3008 Hybrid4	Headlamp Height Corrector		✓	✓	✓	✓	✓	
3008 Hybrid4	Lane Departure Warning System		✓	✓	✓	✓		
3008 Hybrid4	Multifunction Display	Multifunction Display A	✓	✓	✓	✓	✓	
3008 Hybrid4	Multifunction Display	Multifunction Display C	✓	✓	✓	✓	✓	
3008 Hybrid4	Multiplexed Additive Adding Pump	POMPE MUX MGI	✓	✓	✓	✓	✓	

3008 Hybrid4	Multiplexed Additive Adding Pump	POMPE MUX TI	√	√	√	√	√	
3008 Hybrid4	Parking Aid(AAS)		√	√	√	√	√	
3008 Hybrid4	RADIO		√	√	√	√	√	
3008 Hybrid4	Service Module	Service Module(BTA)	√	√	√	√	√	
3008 Hybrid4	Service Module	Service Module(MD SERV)	√	√	√	√	√	
3008 Hybrid4	Telematics	Telematics(RADIONAV NG4)	√	√	√	√	√	
3008 Hybrid4	Telematics	Telematics(RADIONAV RNEG)	√	√	√	√		
3008 Hybrid4	Anti slip mode selector		√			√	√	
3008 Hybrid4	Audio amplifier		√	√	√		√	
3008 Hybrid4	CD player		√	√	√			
3008 Hybrid4	Control panel dot matrix display		√	√	√	√	√	
3008 Hybrid4	High Head Vision		√	√	√	√		
3008 Hybrid4	Network isolation unit		√			√		
3008 Hybrid4	Rain sensor		√	√	√			
3008 Hybrid4	Switch module at the steering wheel		√	√	√	√	√	
3008 Hybrid4	Not Fastened warning lingt(TNB)		√					
3008 China	Engine	MM6KP	√	√	√	√	√	S0034
3008 China	Engine	MED17 4 2	√	√	√	√	√	S0034
3008 China	Engine	MEV17 4 2	√	√	√	√	√	
3008 China	Engine	MED17 4 EURO4	√	√	√	√	√	S0034
3008 China	Engine	MED17 4 EURO5	√	√	√	√	√	S0034
3008 China	Engine	MEV17 4 EURO4	√	√	√	√	√	S0034
3008 China	Engine	MEV17 4 EURO5	√	√	√	√	√	S0034
3008 China	Engine	MM6KP	√	√	√	√	√	S0034
3008 China	Engine	MM6KP bio	√	√	√	√	√	S0034
3008 China	Engine	DCM35	√	√	√	√	√	S0036, S0037
3008 China	Engine	DCM35 BR2	√	√	√	√	√	S0036, S0037
3008 China	Engine	DCM35 HY	√	√	√	√	√	S0036, S0037
3008 China	Engine	EDC16C3	√	√	√	√	√	S0036, S0037
3008 China	Engine	SID807	√	√	√	√	√	S0037
3008 China	Engine	SID807 BR2	√	√	√	√	√	S0037
3008 China	Engine	MED17 4 4	√	√	√	√		S0034

3008 China	Gearbox ECU	BVA AM6 AT6 EURO5	√	√	√	√	√	
3008 China	Gearbox ECU	CFC300P	√	√	√	√	√	
3008 China	Gearbox ECU	CFC300P HY	√	√	√	√	√	
3008 China	ABS or ESP ECU		√	√	√	√	√	S0035, S0038, S0039
3008 China	Air bag		√	√	√	√		
3008 China	Power steering		√	√	√	√	√	
3008 China	Instrument Panel		√	√	√	√	√	
3008 China	Air Conditioning		√	√	√	√	√	
3008 China	Electric parking brake		√	√	√	√	√	S0038
3008 China	BSI		√	√	√			S0033
3008 China	Under inflation detection		√	√	√	√		
3008 China	ALARM		√	√	√	√	√	
3008 China	Assistance In Complying With The Inter Vehicle Time Artiv		√	√	√	√		
3008 China	Battery charge status unit		√			√		S003A
3008 China	Hands Free Kit		√	√	√	√	√	
3008 China	Windscreen Wiper Control Unit		√	√	√			
3008 China	Driver's Door Module		√	√	√	√	√	
3008 China	Headlamp Height Corrector		√	√	√	√	√	
3008 China	Lane Departure Warning System		√	√	√	√		
3008 China	Multifunction Display	Multifunction Display A	√	√	√	√	√	
3008 China	Multifunction Display	Multifunction Display C	√	√	√	√	√	
3008 China	Multiplexed Additive Adding Pump	POMPE MUX MGI	√	√	√	√	√	
3008 China	Multiplexed Additive Adding Pump	POMPE MUX TI	√	√	√	√	√	
3008 China	Parking Aid(AAS)		√	√	√	√	√	
3008 China	RADIO		√	√	√	√	√	
3008 China	Service Module	Service Module (BTA)	√	√	√	√	√	
3008 China	Service Module	Service Module (MD SERV)	√	√	√	√	√	
3008 China	Telematics	Telematics (RADIONAV NG4)	√	√	√	√	√	

3008 China	Telematics	Telematics (RADIONAV RNEG)	✓	✓	✓	✓		
3008 China	Anti slip mode selector		✓			✓	✓	
3008 China	Audio amplifier		✓	✓	✓		✓	
3008 China	CD player		✓	✓	✓			
3008 China	Control panel dot matrix display		✓	✓	✓	✓	✓	
3008 China	High Head Vision		✓	✓	✓	✓		
3008 China	Network isolation unit		✓			✓		
3008 China	Rain sensor		✓	✓	✓			
3008 China	Switch module at the steering wheel		✓	✓	✓	✓	✓	
3008 China	Not Fastened warning lingt (TNB)		✓					
5008	Engine	MED17 4 2	✓	✓	✓	✓	✓	S0034
5008	Engine	MEV17 4 2	✓	✓	✓	✓	✓	
5008	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
5008	Engine	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
5008	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
5008	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
5008	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
5008	Engine	MM6KP bio	✓	✓	✓	✓	✓	S0034
5008	Engine	DCM35	✓	✓	✓	✓	✓	S0036, S0037
5008	Engine	DCM35 BR2	✓	✓	✓	✓	✓	S0036, S0037
5008	Engine	DCM35 HY	✓	✓	✓	✓	✓	S0036, S0037
5008	Engine	EDC16C3	✓	✓	✓	✓	✓	S0036, S0037
5008	Engine	SID807	✓	✓	✓	✓	✓	S0037
5008	Engine	SID807 BR2	✓	✓	✓	✓	✓	S0037
5008	Engine	DCM6. 2	✓	✓	✓			
5008	Engine	EDC17C60	✓	✓	✓			
5008	Engine	MED17 4 4	✓	✓	✓			
5008	Engine	VD46	✓	✓	✓			
5008	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
5008	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
5008	Gearbox ECU	CFC300P HY	✓	✓	✓	✓	✓	
5008	Gearbox ECU	BVA AM6 AT6 UDS	✓	✓	✓			
5008	ABS or ESP ECU		✓	✓	✓	✓	✓	S0035, S0038, S0039

5008	Air bag		✓	✓	✓	✓		
5008	Power steering		✓	✓	✓	✓	✓	
5008	Instrument Panel		✓	✓	✓	✓	✓	
5008	Air Conditioning		✓	✓	✓	✓	✓	
5008	Electric parking brake	Recent ECU	✓	✓	✓	✓	✓	S0038
5008	Electric parking brake	FSE	✓	✓	✓			
5008	BSI		✓	✓	✓			S0033
5008	Under inflation detection	Recent ECU	✓	✓	✓	✓		
5008	Under inflation detection	DSG	✓	✓	✓			
5008	Under inflation detection	DSG UDS	✓	✓	✓			
5008	ALARM		✓	✓	✓	✓	✓	
5008	Assistance In Complying With The Inter Vehicle Time Artiv		✓	✓	✓	✓		
5008	Battery charge status unit	Recent ECU	✓			✓		S003A
5008	Battery charge status unit	BECB	✓	✓	✓			
5008	Battery charge status unit	BECB GEN2	✓	✓	✓			
5008	Hands Free Kit		✓	✓	✓	✓	✓	
5008	Windscreen Wiper Control Unit	Recent ECU	✓	✓	✓			
5008	Windscreen Wiper Control Unit	MOTEV	✓	✓	✓			
5008	Driver's Door Module		✓	✓	✓	✓	✓	
5008	Headlamp Height Corrector		✓	✓	✓	✓	✓	
5008	Lane Departure Warning System		✓	✓	✓	✓		
5008	Multifunction Display	Multifunction Display A	✓	✓	✓	✓	✓	
5008	Multifunction Display	Multifunction Display C	✓	✓	✓	✓	✓	
5008	Multiplexed Additive Adding Pump	POMPE MUX MGI	✓	✓	✓	✓	✓	
5008	Multiplexed Additive Adding Pump	POMPE MUX TI	✓	✓	✓	✓	✓	
5008	Multiplexed Additive Adding Pump	PADDGO	✓	✓	✓			
5008	Multiplexed Additive Adding Pump	PADDGO E5	✓	✓	✓			
5008	Multiplexed Additive Adding Pump	PADDGO TI E6	✓	✓	✓			
5008	Parking Aid(AAS)	Recent ECU	✓	✓	✓	✓	✓	
5008	Parking Aid(AAS)	AAS	✓	✓	✓			
5008	RADIO	Recent ECU	✓	✓	✓	✓	✓	
5008	RADIO	RD45	✓	✓	✓			

5008	Service Module	Service Module (BTA)	✓	✓	✓	✓	✓	
5008	Service Module	Service Module (MD SERV)	✓	✓	✓	✓	✓	
5008	Service Module	BLVV	✓	✓	✓			
5008	Telematics	Telematics (RADIONAV NG4)	✓	✓	✓	✓	✓	
5008	Telematics	Telematics (RADIONAV RNEG)	✓	✓	✓	✓		
5008	Anti slip mode selector		✓			✓	✓	
5008	Audio amplifier		✓	✓	✓		✓	
5008	CD player		✓	✓	✓			
5008	Control panel dot matrix display		✓	✓	✓	✓	✓	
5008	High Head Vision	Recent ECU	✓	✓	✓	✓		
5008	High Head Vision	VTH UDS	✓	✓	✓			
5008	Network isolation unit	Recent ECU	✓			✓		
5008	Network isolation unit	BIR	✓					
5008	Rain sensor		✓	✓	✓			
5008	Switch module at the steering wheel	Recent ECU	✓	✓	✓	✓	✓	
5008	Switch module at the steering wheel	HDC	✓	✓	✓			
5008	Not Fastened warning light (TNB)		✓					
5008	engine wiring housing		✓	✓	✓			
5008	Trailer Relay Unit		✓	✓	✓			
5008	Voltage maintaining device	DMTC	✓					
5008	Voltage maintaining device	DMTR	✓	✓	✓			
5008	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
5008	High frequency receiver		✓	✓	✓			
5008	Telematic unit (RTx) or audio-navigation		✓	✓	✓			
405	Engine		✓	✓	✓	✓	✓	S0034
405	AT BVA AL		✓	✓	✓	✓		
406	Engine	EDC15C2	✓	✓	✓	✓	✓	
406	Engine	HDI SID803	✓	✓	✓	✓	✓	
406	Engine	ME744	✓	✓	✓	✓	✓	S0034
406	Engine	HDI SID803		✓	✓		✓	S0037
406	Gearbox ECU		✓	✓	✓	✓		

406	ABS/ESP		✓	✓	✓	✓		
406	Airbag ECU	Airbag and seatbelts	✓	✓	✓			
406	Airbag ECU	Left side airbag	✓	✓	✓			
406	Airbag ECU	Right side airbag	✓	✓	✓			
406R	Engine	6FZ SAGEM S2000	✓	✓	✓	✓		
406R	Engine	LFX MM1AP	✓	✓	✓	✓		
406R	Engine	LFY BOSCH MP7.3	✓	✓	✓	✓		
406R	Engine	LFY SAGEM SL96	✓	✓	✓	✓		
406R	Engine	R6F MM4.8P	✓	✓	✓	✓		
406R	Engine	XFZ BOSCH MP7.0	✓	✓	✓	✓		
406R	Gearbox ECU	Auto Gearbox ZF4HP20	✓	✓	✓	✓	✓	
406R	Gearbox ECU	BVA ZF	✓	✓	✓	✓	✓	
406R	Gearbox ECU	BVA AL4	✓	✓	✓	✓	✓	
406R	ABS/ESP		✓	✓	✓	✓		
406R	Airbag ECU	SAC CENT AUTOLIV 2	✓	✓	✓			
406R	Airbag ECU	Airbag and seatbelts	✓	✓	✓			
406R	Power Steering		✓			✓		
406R	Instrument panel		✓	✓	✓	✓	✓	
406R	Air Conditioning		✓	✓	✓	✓		
406R	Multi function display		✓	✓	✓	✓	✓	
406R	Radio		✓	✓	✓	✓	✓	
406R	Seat and mirrors with memory		✓	✓	✓	✓		
406R	Diesel fuel additive control unit		✓	✓	✓	✓		
406R	On board navigation system		✓	✓	✓	✓		
406R	Rain/brightness sensor		✓	✓	✓			
406R	CD Player		✓	✓	✓	✓	✓	
406R Coupe	Engine	EDC15C2	✓	✓	✓	✓	✓	
406R Coupe	Engine	HDI SID803	✓	✓	✓	✓	✓	
406R Coupe	Engine	ME744	✓	✓	✓	✓	✓	S0034
406R Coupe	Engine	HDI SID803		✓	✓		✓	S0037
406R Coupe	Gearbox ECU	Auto Gearbox ZF4HP20	✓	✓	✓	✓	✓	
406R Coupe	Gearbox ECU	Auto Gearbox AL4	✓	✓	✓	✓	✓	
406R Coupe	Gearbox ECU	BVA ZF	✓	✓	✓	✓	✓	
406R Coupe	Gearbox ECU	BVA AL4	✓	✓	✓	✓	✓	
406R Coupe	ABS/ESP		✓	✓	✓	✓		

406R Coupe	Airbag ECU	SAC CENT AUTOLIV 2	✓	✓	✓			
406R Coupe	Airbag ECU	Airbag and seatbelts	✓	✓	✓			
406R Coupe	Power Steering		✓			✓		
406R Coupe	Instrument panel		✓	✓	✓	✓	✓	
406R Coupe	Air Conditioning		✓	✓	✓	✓		
406R Coupe	Multi function display		✓	✓	✓	✓	✓	
406R Coupe	Radio		✓	✓	✓	✓	✓	
406R Coupe	Alarm		✓	✓	✓	✓		
406R Coupe	Diesel fuel additive control unit		✓	✓	✓	✓		
406R Coupe	On board navigation system		✓	✓	✓	✓		
406R Coupe	Rain/brightness sensor		✓	✓	✓			
406R Coupe	CD Player		✓	✓	✓	✓	✓	
407	Engine	ME747	✓	✓	✓	✓	✓	
407	Engine	MM6LP	✓	✓	✓	✓	✓	
407	Engine	MM6LPB	✓	✓	✓	✓	✓	
407	Engine	6FZ S2000PM2	✓	✓	✓	✓	✓	
407	Engine	MM6KP Non BioFlex	✓	✓	✓	✓	✓	
407	Engine	MM6KP BioFlex	✓	✓	✓	✓	✓	S0034
407	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
407	Engine	SID201	✓	✓	✓	✓	✓	S0037
407	Engine	DCM34	✓	✓	✓	✓	✓	S0036, S0037
407	Engine	DCM35	✓	✓	✓	✓	✓	S0036, S0037
407	Engine	EDC17CP11	✓	✓	✓	✓	✓	S0036, S0037
407	Engine	EDC16C3 (CAN)	✓	✓	✓	✓	✓	S0036, S0037
407	Engine	EDC16C3 (kwp)	✓	✓	✓	✓	✓	
407	Engine	EDC16CP39	✓	✓	✓	✓	✓	S0037
407	Engine	HDI SID803	✓	✓	✓	✓	✓	
407	Engine	HDI SID803A	✓	✓	✓	✓	✓	S0037
407	Gearbox ECU	BVA AM6 (KWP)	✓	✓	✓	✓	✓	
407	Gearbox ECU	BVA AL4	✓	✓	✓	✓	✓	
407	Gearbox ECU	BVA ZF	✓	✓	✓	✓	✓	
407	Gearbox ECU	BVA AM6	✓	✓	✓	✓	✓	
407	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
407	ABS	ESP EBC 440 CAN	✓	✓	✓	✓	✓	
407	ABS	ESP EBC 440 K	✓	✓	✓	✓	✓	

407	ABS	81 ESP	✓	✓	✓	✓	✓	S0035, S0039
407	SRS		✓	✓	✓	✓		
407	Instrument panel		✓	✓	✓	✓	✓	
407	Air conditioning		✓	✓	✓	✓	✓	
407	BSI		✓	✓	✓			S0033
407	Diesel fuel additive control unit		✓	✓	✓	✓	✓	
407	Driver's Seat Memory Unit		✓	✓	✓	✓	✓	
407	Passenger Seat Memorisation Module		✓	✓	✓	✓	✓	
407	Additional heating		✓	✓	✓	✓	✓	
407	Power steering		✓	✓	✓	✓	✓	
407	Parking aid		✓	✓	✓	✓	✓	
407	Battery charge status unit	BECB	✓	✓	✓	✓		S003A
407	Battery charge status unit	BECB GEN2	✓	✓	✓	✓		S003A
407	Multi function display		✓	✓	✓	✓		
407	Radio		✓	✓	✓	✓	✓	
407	CD player		✓	✓	✓			
407	Under inflation detection		✓	✓	✓	✓		
407	High frequency receiver		✓	✓	✓	✓		
407	Alarm		✓	✓	✓	✓	✓	
407	Driver's door module		✓	✓	✓	✓	✓	
407	Passenger door module		✓	✓	✓	✓	✓	
407	Sun roof		✓	✓	✓	✓		
407	Rain/sunlight sensor		✓	✓	✓			
407	Switch module at the steering wheel		✓	✓	✓	✓	✓	
407	Hands Free Kit	KML	✓	✓	✓	✓	✓	
407	Hands Free Kit	BOITIER NOMADE	✓	✓	✓	✓	✓	
407	Telematics	TELEMATIC CASE	✓	✓	✓	✓	✓	
407	Telematics	RADIONAV RNEG	✓	✓	✓	✓		
408 (T73)	Engine	ME745	✓	✓	✓	✓	✓	
408 (T73)	Engine	ME745 EC5	✓	✓	✓	✓	✓	S0034
408 (T73)	Engine	ME749	✓	✓	✓	✓	✓	
408 (T73)	Engine	ME749 EC5	✓	✓	✓	✓	✓	S0034
408 (T73)	Engine	MM6LPB	✓	✓	✓	✓	✓	
408 (T73)	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
408 (T73)	Engine	EMV17 4 2	✓	✓	✓	✓	✓	S0034

408 (T73)	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
408 (T73)	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
408 (T73)	Engine	MED17 4 2	✓	✓	✓	✓	✓	
408 (T73)	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
408 (T73)	Engine	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
408 (T73)	Engine	MEVD17 4 2	✓	✓	✓	✓	✓	S0034
408 (T73)	Engine	MM6KP Bio Flex1	✓	✓	✓	✓	✓	S0034
408 (T73)	Engine	MM6KP Bio Flex2	✓	✓	✓	✓	✓	S0034
408 (T73)	Engine	EDC16C3	✓	✓	✓	✓	✓	
408 (T73)	Engine	DCM34	✓	✓	✓	✓	✓	S0036, S0037
408 (T73)	Engine	DCM35	✓	✓	✓	✓	✓	S0036, S0037
408 (T73)	Engine	DCM35 BR2	✓	✓	✓	✓	✓	S0036, S0037
408 (T73)	Engine	SID807	✓	✓	✓	✓	✓	S0037
408 (T73)	Engine	SID807 BR2	✓	✓	✓	✓	✓	S0037
408 (T73)	Engine	EDC17C10	✓	✓	✓	✓	✓	S0036, S0037
408 (T73)	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0036, S0037
408 (T73)	Gearbox ECU	BVA AT8	✓	✓	✓	✓	✓	
408 (T73)	Gearbox ECU	BVA AM6	✓	✓	✓	✓	✓	
408 (T73)	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
408 (T73)	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
408 (T73)	ABS or ESP ECU	ABS81	✓	✓	✓	✓	✓	S0039
408 (T73)	ABS or ESP ECU	ESP81	✓	✓	✓	✓	✓	S0035, S0039
408 (T73)	Air bag		✓	✓	✓	✓		
408 (T73)	Power steering		✓	✓	✓	✓	✓	
408 (T73)	Instrument Panel		✓	✓	✓	✓	✓	
408 (T73)	AC CLIM		✓	✓	✓	✓	✓	
408 (T73)	BSI		✓	✓	✓			S0033
408 (T73)	Alarm	ALARME	✓	✓	✓	✓	✓	
408 (T73)	Alarm	LIN ALARM	✓	✓	✓	✓	✓	
408 (T73)	Hands Free Kit	Hands Free Kit (BOITIER NOMADE)	✓	✓	✓	✓	✓	
408 (T73)	Hands Free Kit	Hands Free Kit (KML)	✓	✓	✓	✓	✓	
408 (T73)	Under inflation detection		✓	✓	✓	✓		
408 (T73)	Steering Wheel Switching Module		✓	✓	✓	✓	✓	
408 (T73)	Driver's Door Module		✓	✓	✓	✓	✓	

408(T73)	Driving School Mode		✓	✓	✓			
408(T73)	Driver's Seat Memory Unit		✓	✓	✓	✓	✓	
408(T73)	Passenger Seat Memorisation Module		✓	✓	✓	✓	✓	
408(T73)	Headlamp Height Corrector		✓	✓	✓	✓	✓	
408(T73)	Multiplexed Additive Adding Pump	ADDITIVE PUMP PADDGO	✓	✓	✓	✓	✓	
408(T73)	Multiplexed Additive Adding Pump	ADDITIVE PUMP PADDGO E5	✓	✓	✓	✓		
408(T73)	Parking Aid(AAS)		✓	✓	✓	✓		
408(T73)	Pedestrian Impact Detection Unit		✓	✓	✓	✓		
408(T73)	Battery change status unit	BECB	✓	✓	✓	✓		S003A
408(T73)	Battery change status unit	BECB GEN2	✓	✓	✓	✓		S003A
408(T73)	CD player		✓	✓	✓			
408(T73)	Engine relay unit		✓	✓	✓	✓	✓	
408(T73)	ESSUIV		✓	✓	✓	✓		
408(T73)	Hi fi amplifier		✓	✓	✓	✓		
408(T73)	Lane departure warning system		✓	✓	✓	✓	✓	
408(T73)	Control panel dot matrix display		✓	✓	✓	✓	✓	
408(T73)	Multi function display	EMF A	✓	✓	✓	✓	✓	
408(T73)	Multi function display	EMF C	✓	✓	✓	✓	✓	
408(T73)	RADIO	AUTORADIO	✓	✓	✓	✓	✓	
408(T73)	RADIO	RD43	✓	✓	✓	✓		
408(T73)	RADIO	RD45	✓	✓	✓	✓	✓	
408(T73)	Rain Sensor		✓	✓	✓			
408(T73)	SUN ROOF		✓	✓	✓	✓		
408(T73)	TOITESC		✓	✓	✓	✓		
408(T73)	Trailer relay unit		✓	✓	✓	✓	✓	
408(T73)	Service module	BLVV(KWP)	✓	✓	✓	✓		
408(T73)	Service module	BTA	✓	✓	✓	✓		
408(T73)	Service module	MD SERV	✓	✓	✓	✓		
508	Engine	MED17 4 2	✓	✓	✓	✓	✓	S0034
508	Engine	MEV17 4 2	✓	✓	✓	✓	✓	S0034
508	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
508	Engine	MM6KP Bio Flex1	✓	✓	✓	✓	✓	S0034
508	Engine	MM6KP Bio Flex2	✓	✓	✓	✓	✓	S0034
508	Engine	DCM34	✓	✓	✓	✓	✓	S0036, S0037

508	Engine	DCM35	✓	✓	✓	✓	✓	
508	Engine	DCM35 HY	✓	✓	✓	✓	✓	S0036, S0037
508	Engine	EDC17CP42	✓	✓	✓	✓	✓	S0037
508	Engine	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
508	Engine	MED17 4 4	✓	✓	✓	✓		S0034
508	Engine	MED17 4 4EP8	✓	✓	✓	✓		
508	Engine	DCM6. 2	✓	✓	✓			
508	Engine	EDC17C60	✓	✓	✓			
508	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
508	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
508	Gearbox ECU	CFC300P HY	✓	✓	✓	✓		
508	Gearbox ECU	BVA AM6 AT6 UDS	✓	✓	✓	✓		
508	ABS	ABS81	✓	✓	✓	✓	✓	S0035, S0039
508	ABS	ESP81	✓	✓	✓	✓	✓	S0035, S0038 , S0039
508	Airbag		✓	✓	✓	✓		
508	Power steering electric pump unit		✓	✓	✓	✓	✓	
508	Anti theft alarm		✓	✓	✓	✓	✓	
508	Instrument panel		✓	✓	✓	✓	✓	
508	Air Conditioning		✓	✓	✓	✓	✓	
508	Electric secondary brake		✓	✓	✓	✓		S0038
508	BSI		✓	✓	✓			S0033
508	Under inflation detection	Recent ECU	✓	✓	✓	✓		
508	Under inflation detection	DSG UDS	✓	✓	✓			
508	Battery charge status unit		✓			✓		
508	Headlamp height adjuster/directional headlamp		✓	✓	✓	✓	✓	
508	Engine relay unit		✓	✓	✓	✓		
508	Trailer relay unit		✓	✓	✓	✓		
508	Parking aid		✓	✓	✓	✓		
508	Multifunction Display	Multifunction Display A	✓	✓	✓	✓		
508	Multifunction Display	Multifunction Display C	✓	✓	✓	✓		
508	Telematics unit	Recent ECU	✓	✓	✓	✓	✓	

508	Telematics unit	NAC	✓	✓	✓			
508	Telematics unit	SMEG PLUS	✓	✓	✓			
508	Active damper electronic unit		✓	✓	✓	✓		
508	Multiplexed control panel		✓	✓	✓	✓		
508	Control panel dot matrix display	Recent ECU	✓	✓	✓			
508	Control panel dot matrix display	MATT M 2010	✓	✓	✓			
508	Radio		✓	✓	✓	✓	✓	
508	Radio amplifier		✓	✓	✓	✓		
508	Switch module under the steering wheel		✓	✓	✓	✓	✓	
508	Driver's Door Module		✓	✓	✓	✓	✓	
508	Motorised Boot ECU		✓	✓	✓	✓		
508	High Head Vision		✓	✓	✓	✓		
508	Main beams assistant ECU		✓	✓	✓	✓		
508	Electric steering lock		✓	✓	✓	✓		
508	Touch screen		✓	✓	✓			
508	Seat driver position memory module.		✓	✓	✓			
508	Hands-free unit		✓	✓	✓			
508	supplies protection and management unit		✓	✓	✓			
508	External CD player		✓	✓	✓			
508	Additional Heating		✓	✓	✓			
508	rear air conditioning		✓					
508	Dynamic headlamp height adjuster		✓	✓	✓			
508	rain and sunlight sensor		✓	✓	✓			
508	Controls on the steering wheel / Integral controls steering wheel		✓	✓	✓			
508	Voltage maintaining device	DMTC	✓					
508	Voltage maintaining device	DMTR	✓	✓	✓			
508	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
508	Electronic key reader		✓	✓	✓			
508	Control panel dot matrix display		✓	✓	✓			
508	Service module / Independent telematic unit	BTA	✓	✓	✓			

508	Service module / Independent telematic unit	BTA_2	√	√	√			
508	Service module / Independent telematic unit	BTA_3R	√	√	√			
508	Service module / Independent telematic unit	BTA_3S	√	√	√			
508	front right wiper motor	ESV_D	√	√	√			
508	front right wiper motor	MOTED_UDS	√	√	√			
508	front left wiper motor	ESV_G	√	√	√			
508	front left wiper motor	MOTEV_UDS	√	√	√			
508	seat belt not fastened warning lights unit		√					
508 Hybrid4	Engine	MED17_4_2	√	√	√	√	√	S0034
508 Hybrid4	Engine	MEV17_4_2	√	√	√	√	√	S0034
508 Hybrid4	Engine	MM6KP	√	√	√	√	√	S0034
508 Hybrid4	Engine	MM6KP Bio Flex1	√	√	√	√	√	S0034
508 Hybrid4	Engine	MM6KP Bio Flex2	√	√	√	√	√	S0034
508 Hybrid4	Engine	DCM34	√	√	√	√	√	S0036, S0037
508 Hybrid4	Engine	DCM35	√	√	√	√	√	
508 Hybrid4	Engine	DCM35 HY	√	√	√	√	√	S0036, S0037
508 Hybrid4	Engine	EDC17CP42	√	√	√	√	√	S0037
508 Hybrid4	Engine	HDI SID807 BR2	√	√	√	√	√	S0037
508 Hybrid4	Engine	MED17_4_4	√	√	√	√		S0034
508 Hybrid4	Engine	MED17_4_4EP8	√	√	√	√		
508 Hybrid4	Gearbox ECU	BVA AM6 AT6 EURO5	√	√	√	√	√	
508 Hybrid4	Gearbox ECU	CFC300P	√	√	√	√	√	
508 Hybrid4	Gearbox ECU	CFC300P HY	√	√	√	√		
508 Hybrid4	Gearbox ECU	BVA AM6 AT6 UDS	√	√	√	√		
508 Hybrid4	ABS	ABS81	√	√	√	√	√	S0035, S0039
508 Hybrid4	ABS	ESP81	√	√	√	√	√	S0035, S0038, S0039
508 Hybrid4	Airbag		√	√	√	√		
508 Hybrid4	Power steering electric pump unit		√	√	√	√	√	
508 Hybrid4	Instrument panel		√	√	√	√	√	
508 Hybrid4	Air Conditioning		√	√	√	√	√	

508 Hybrid4	BSI		✓	✓	✓			S0033
508 Hybrid4	Under inflation detection		✓	✓	✓	✓		
508 Hybrid4	Battery charge status unit		✓			✓		
508 Hybrid4	Headlamp height adjuster/directional headlamp		✓	✓	✓	✓	✓	
508 Hybrid4	Engine relay unit		✓	✓	✓	✓		
508 Hybrid4	Trailer relay unit		✓	✓	✓	✓		
508 Hybrid4	Parking aid		✓	✓	✓	✓		
508 Hybrid4	Anti theft alarm		✓	✓	✓	✓	✓	
508 Hybrid4	Multifunction Display	Multifunction Display A	✓	✓	✓	✓		
508 Hybrid4	Multifunction Display	Multifunction Display C	✓	✓	✓	✓		
508 Hybrid4	Telematics unit		✓	✓	✓	✓	✓	
508 Hybrid4	Active damper electronic unit		✓	✓	✓	✓		
508 Hybrid4	Multiplexed control panel		✓	✓	✓	✓		
508 Hybrid4	Control panel dot matrix display		✓	✓	✓			
508 Hybrid4	Radio		✓	✓	✓	✓	✓	
508 Hybrid4	Radio amplifier		✓	✓	✓	✓		
508 Hybrid4	Switch module under the steering wheel		✓	✓	✓	✓	✓	
508 Hybrid4	Driver's Door Module		✓	✓	✓	✓	✓	
508 Hybrid4	Motorised Boot ECU		✓	✓	✓	✓		
508 Hybrid4	High Head Vision		✓	✓	✓	✓		
508 Hybrid4	Electric secondary brake		✓	✓	✓	✓		S0038
508 Hybrid4	Main beams assistant ECU		✓	✓	✓	✓		
508 Hybrid4	Electric steering lock		✓	✓	✓	✓		
508 RXH	Engine	MED17 4 2	✓	✓	✓	✓	✓	S0034
508 RXH	Engine	MEV17 4 2	✓	✓	✓	✓	✓	S0034
508 RXH	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
508 RXH	Engine	MM6KP Bio Flex1	✓	✓	✓	✓	✓	S0034
508 RXH	Engine	MM6KP Bio Flex2	✓	✓	✓	✓	✓	S0034
508 RXH	Engine	DCM34	✓	✓	✓	✓	✓	S0036, S0037
508 RXH	Engine	DCM35	✓	✓	✓	✓	✓	
508 RXH	Engine	DCM35 HY	✓	✓	✓	✓	✓	S0036, S0037

508 RXH	Engine	EDC17CP42	✓	✓	✓	✓	✓	S0037
508 RXH	Engine	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
508 RXH	Engine	MED17 4 4	✓	✓	✓	✓		S0034
508 RXH	Engine	MED17 4 4EP8	✓	✓	✓	✓		
508 RXH	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
508 RXH	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
508 RXH	Gearbox ECU	CFC300P HY	✓	✓	✓	✓		
508 RXH	Gearbox ECU	BVA AM6 AT6 UDS	✓	✓	✓	✓		
508 RXH	ABS	ABS81	✓	✓	✓	✓	✓	S0035, S0039
508 RXH	ABS	ESP81	✓	✓	✓	✓	✓	S0035, S0038 , S0039
508 RXH	Airbag		✓	✓	✓	✓		
508 RXH	Power steering electric pump unit		✓	✓	✓	✓	✓	
508 RXH	Instrument panel		✓	✓	✓	✓	✓	
508 RXH	Air Conditioning		✓	✓	✓	✓	✓	
508 RXH	BSI		✓	✓	✓			S0033
508 RXH	Under inflation detection		✓	✓	✓	✓		
508 RXH	Battery charge status unit		✓			✓		
508 RXH	Headlamp height adjuster/directional headlamp		✓	✓	✓	✓	✓	
508 RXH	Engine relay unit		✓	✓	✓	✓		
508 RXH	Trailer relay unit		✓	✓	✓	✓		
508 RXH	Parking aid		✓	✓	✓	✓		
508 RXH	Anti theft alarm		✓	✓	✓	✓	✓	
508 RXH	Multifunction Display	Multifunction Display A	✓	✓	✓	✓		
508 RXH	Multifunction Display	Multifunction Display C	✓	✓	✓	✓		
508 RXH	Telematics unit		✓	✓	✓	✓	✓	
508 RXH	Active damper electronic unit		✓	✓	✓	✓		
508 RXH	Multiplexed control panel		✓	✓	✓	✓		
508 RXH	Control panel dot matrix display		✓	✓	✓			
508 RXH	Radio		✓	✓	✓	✓	✓	
508 RXH	Radio amplifier		✓	✓	✓	✓		

508 RXH	Switch module under the steering wheel		✓	✓	✓	✓	✓	
508 RXH	Driver's Door Module		✓	✓	✓	✓	✓	
508 RXH	Motorised Boot ECU		✓	✓	✓	✓		
508 RXH	High Head Vision		✓	✓	✓	✓		
508 RXH	Electric secondary brake		✓	✓	✓	✓		S0038
508 RXH	Main beams assistant ECU		✓	✓	✓	✓		
508 RXH	Electric steering lock		✓	✓	✓	✓		
508 RXH Hybrid4	Engine	MED17 4 2	✓	✓	✓	✓	✓	S0034
508 RXH Hybrid4	Engine	MEV17 4 2	✓	✓	✓	✓	✓	S0034
508 RXH Hybrid4	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
508 RXH Hybrid4	Engine	MM6KP Bio Flex1	✓	✓	✓	✓	✓	S0034
508 RXH Hybrid4	Engine	MM6KP Bio Flex2	✓	✓	✓	✓	✓	S0034
508 RXH Hybrid4	Engine	DCM34	✓	✓	✓	✓	✓	S0036, S0037
508 RXH Hybrid4	Engine	DCM35	✓	✓	✓	✓	✓	
508 RXH Hybrid4	Engine	DCM35 HY	✓	✓	✓	✓	✓	S0036, S0037
508 RXH Hybrid4	Engine	EDC17CP42	✓	✓	✓	✓	✓	S0037
508 RXH Hybrid4	Engine	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
508 RXH Hybrid4	Engine	MED17 4 4	✓	✓	✓	✓		S0034
508 RXH Hybrid4	Engine	MED17 4 4EP8	✓	✓	✓	✓		
508 RXH Hybrid4	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
508 RXH Hybrid4	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
508 RXH Hybrid4	Gearbox ECU	CFC300P HY	✓	✓	✓	✓		
508 RXH Hybrid4	Gearbox ECU	BVA AM6 AT6 UDS	✓	✓	✓	✓		
508 RXH Hybrid4	ABS	ABS81	✓	✓	✓	✓	✓	S0035, S0039
508 RXH Hybrid4	ABS	ESP81	✓	✓	✓	✓	✓	S0035, S0038, S0039
508 RXH Hybrid4	Airbag		✓	✓	✓	✓		
508 RXH Hybrid4	Power steering electric pump unit		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Anti theft alarm		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Instrument panel		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Air Conditioning		✓	✓	✓	✓	✓	
508 RXH Hybrid4	BSI		✓	✓	✓			S0033
508 RXH Hybrid4	Under inflation detection		✓	✓	✓	✓		
508 RXH Hybrid4	Battery charge status unit		✓			✓		

508 RXH Hybrid4	Headlamp height adjuster/directional headlamp		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Engine relay unit		✓	✓	✓	✓		
508 RXH Hybrid4	Trailer relay unit		✓	✓	✓	✓		
508 RXH Hybrid4	Parking aid		✓	✓	✓	✓		
508 RXH Hybrid4	Multifunction Display	Multifunction Display A	✓	✓	✓	✓		
508 RXH Hybrid4	Multifunction Display	Multifunction Display C	✓	✓	✓	✓		
508 RXH Hybrid4	Telematics unit		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Active damper electronic unit		✓	✓	✓	✓		
508 RXH Hybrid4	Multiplexed control panel		✓	✓	✓	✓		
508 RXH Hybrid4	Control panel dot matrix display		✓	✓	✓			
508 RXH Hybrid4	Radio		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Radio amplifier		✓	✓	✓	✓		
508 RXH Hybrid4	Switch module under the steering wheel		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Driver's Door Module		✓	✓	✓	✓	✓	
508 RXH Hybrid4	Motorised Boot ECU		✓	✓	✓	✓		
508 RXH Hybrid4	High Head Vision		✓	✓	✓	✓		
508 RXH Hybrid4	Electric secondary brake		✓	✓	✓	✓		S0038
508 RXH Hybrid4	Main beams assistant ECU		✓	✓	✓	✓		
508 RXH Hybrid4	Electric steering lock		✓	✓	✓	✓		
605	Engine	R6E BOSCH MP5.2		✓	✓	✓		
605	Engine	RFV BOSCH MP5.2		✓	✓	✓		
605	Engine	RGX BOSCH MP3.2		✓	✓			
605	Engine	XFZ BOSCH MP7.0	✓	✓	✓	✓		
607	Engine	EDC15C2	✓	✓	✓	✓	✓	
607	Engine	HDI SID803	✓	✓	✓	✓	✓	
607	Gearbox ECU		✓	✓	✓	✓	✓	
607	ABS/ESP		✓	✓	✓	✓		
607	Airbag ECU		✓	✓	✓			
607	Air Conditioning		✓	✓	✓	✓		
607 R	Engine	ME747	✓	✓	✓	✓	✓	S0034
607 R	Engine	MM6LP	✓	✓	✓	✓	✓	S0034

607 R	Engine	MM6LPB	✓	✓	✓	✓	✓	
607 R	Engine	EDC15C2	✓	✓	✓	✓	✓	
607 R	Engine	EDC16CP39	✓	✓	✓	✓	✓	S0037
607 R	Engine	SID201	✓	✓	✓	✓	✓	S0037
607 R	Engine	SID 803	✓	✓	✓	✓	✓	
607 R	Engine	HDI SID803A	✓	✓	✓	✓	✓	
607 R	Gearbox ECU	AM6 Automatic gearbox	✓	✓	✓	✓	✓	
607 R	Gearbox ECU	4HP20 Automatic gearbox	✓	✓	✓	✓	✓	
607 R	ABS		✓	✓	✓	✓	✓	
607 R	Airbag ECU		✓	✓	✓	✓		
607 R	Power steering		✓	✓	✓	✓		
607 R	Instrument panel		✓	✓	✓	✓	✓	
607 R	Air Conditioning		✓	✓	✓	✓	✓	
607 R	Diesel fuel additive control unit		✓	✓	✓	✓	✓	
607 R	Parking aid		✓	✓	✓	✓	✓	
607 R	Driver's Seat Memory Unit		✓	✓	✓	✓	✓	
607 R	Under inflation detection		✓	✓	✓	✓		
607 R	Multifunction display	EMF A	✓	✓	✓	✓	✓	
607 R	Multifunction display	EMF C	✓	✓	✓	✓	✓	
607 R	Radio		✓	✓	✓	✓	✓	
607 R	CD player		✓	✓	✓			
607 R	Switch module at the steering wheel		✓	✓	✓	✓	✓	
607 R	Hands Free kit		✓	✓	✓	✓	✓	
607 R	Alarm		✓	✓	✓	✓	✓	
607 R	Motorised Boot ECU		✓	✓	✓	✓		
607 R	Driver's Door Module		✓	✓	✓	✓	✓	
607 R	Passenger door module		✓	✓	✓	✓	✓	
607 R	Rain/sunlight sensor		✓	✓	✓	✓		
607 R	Piloted suspension		✓	✓	✓	✓		
607 R	Telematics		✓	✓	✓	✓	✓	
806	Engine	EDC15C2	✓	✓	✓	✓	✓	
806	Engine	HDI SID803	✓	✓	✓	✓	✓	
806	Engine	9HY_BOSCH_EDC16C3_EUR 04	✓	✓	✓	✓	✓	

806	ABS/ESP		✓	✓	✓	✓		
806	Airbag ECU		✓	✓	✓			
807 VAN	Engine	EDC15C2	✓	✓	✓	✓	✓	
807 VAN	Engine	HDI SID803	✓	✓	✓	✓	✓	
807 VAN	Engine	9HY_BOSCH_EDC16C3_EUR 04	✓	✓	✓	✓	✓	
807 VAN	Gearbox ECU	BVA AL4	✓	✓	✓	✓		
807 VAN	Gearbox ECU	Auto Gearbox ZF4HP20	✓	✓	✓	✓	✓	
807 VAN	ABS/ESP		✓	✓	✓	✓	✓	S0035, S0039
807 VAN	Airbag ECU		✓	✓	✓			
807 VAN	Instrument panel		✓	✓	✓	✓	✓	
807 VAN	Air Conditioning		✓	✓	✓	✓		
807 VAN	Multi function display		✓	✓	✓	✓	✓	
807 VAN	Radio		✓	✓	✓	✓		
807 VAN	Alarm		✓	✓	✓	✓		
807 VAN	Driver's door module		✓	✓	✓	✓		
807 VAN	Passenger door module		✓	✓	✓	✓		
807 VAN	Diesel fuel additive control unit		✓	✓	✓	✓		
807 VAN	CD Player		✓	✓	✓	✓		
807 VAN	Switch module at the steering wheel		✓	✓	✓	✓		
807 CAN	Engine	MM6LPB	✓	✓	✓	✓	✓	
807 CAN	Engine	EDC16CP39	✓	✓	✓	✓	✓	S0037
807 CAN	Engine	EDC15C2	✓	✓	✓	✓	✓	
807 CAN	Engine	HDI SID803A	✓	✓	✓	✓	✓	
807 CAN	Engine	DCM35	✓	✓	✓	✓	✓	S0036, S0037
807 CAN	Gearbox ECU	Auto gearbox AL4	✓	✓	✓	✓	✓	
807 CAN	Gearbox ECU	Auto gearbox Am6	✓	✓	✓	✓	✓	
807 CAN	Gearbox ECU	BVA AM6 Euro5	✓	✓	✓	✓	✓	
807 CAN	ABS	ESP81 BOSCH	✓	✓	✓	✓	✓	S0035, S0039
807 CAN	ABS	ESP8 BOSCH	✓	✓	✓	✓	✓	S0035, S0039
807 CAN	Airbag		✓	✓	✓	✓		
807 CAN	Electric Power Steering		✓	✓	✓	✓		
807 CAN	Instrument panel		✓	✓	✓	✓	✓	
807 CAN	Air conditioning		✓	✓	✓	✓	✓	
807 CAN	BSI		✓	✓	✓			S0033

807 CAN	Alarm		✓	✓	✓	✓	✓	
807 CAN	Parking assistance		✓	✓	✓	✓	✓	
807 CAN	Driver's Door Module		✓	✓	✓	✓	✓	
807 CAN	Passenger's door module		✓	✓	✓	✓	✓	
807 CAN	Multifunction screen	Multifunction display A	✓	✓	✓	✓	✓	
807 CAN	Multifunction screen	Multifunction display C	✓	✓	✓	✓	✓	
807 CAN	CD Player		✓	✓	✓			
807 CAN	Under inflation detection		✓	✓	✓	✓		
807 CAN	Diesel Additive Function		✓	✓	✓	✓	✓	
807 CAN	Driver's Seat Memory Unit		✓	✓	✓	✓	✓	
807 CAN	Front Sunroof		✓	✓	✓	✓		
807 CAN	Middle Sunroof		✓	✓	✓	✓		
807 CAN	Rear Sunroof		✓	✓	✓	✓		
807 CAN	Hands Free Kit	BOITIER NOMADE	✓	✓	✓	✓	✓	
807 CAN	Hands Free Kit	KML	✓	✓	✓	✓	✓	
807 CAN	Radio	AutoRadio	✓	✓	✓	✓	✓	
807 CAN	Radio	RD45	✓	✓	✓	✓	✓	
807 CAN	Rain Sensor/Brightness		✓	✓	✓			
807 CAN	Steering Wheel Switching Module		✓	✓	✓	✓	✓	
807 CAN	Trailer Relay Unit		✓	✓	✓	✓		
4007	Engine	SFZ 4B12 MIVEC EURO4	✓	✓	✓	✓	✓	
4007	Engine	AFZ 4B11 MIVEC EURO4	✓	✓	✓	✓	✓	
4007	Engine	SFY 4B12 MIVEC EURO5	✓	✓	✓	✓	✓	
4007	Engine	4HN EDC16CP39	✓	✓	✓	✓	✓	S0037
4007	Engine	4HK EDC16CP39	✓	✓	✓	✓	✓	S0037
4007	Gearbox ECU	CVT Gearbox	✓	✓	✓	✓		
4007	Gearbox ECU	DCT Controlled gearbox	✓	✓	✓	✓		
4007	ABS or ESP ECU	ABS	✓	✓	✓	✓		
4007	ABS or ESP ECU	ESP	✓	✓	✓	✓		S0035
4007	Airbag ECU		✓	✓	✓	✓		
4007	IMMOBILISER		✓	✓	✓	✓		
4007	Instrument Panel		✓	✓	✓	✓	✓	S0033

4007	Air Conditioning		✓	✓	✓	✓		
4007	Hands Free Kit(KML)		✓	✓	✓	✓		
4007	Coded Anti Start		✓	✓	✓	✓		
4007	Flywheel Angle Sensor		✓	✓	✓			S0035
4007	Levier Getrag		✓	✓	✓	✓		
4007	On Board Navigation System		✓	✓	✓			
4007	RADIO		✓	✓	✓	✓	✓	
4007	Static AFS		✓	✓	✓	✓		
4007	4x4 transmission		✓	✓	✓	✓		
4007	Parking assistance		✓	✓	✓	✓		
4007	Driver s Door Module		✓	✓	✓	✓		
4007	Passenger through module		✓	✓	✓	✓		
4007	Steering wheel angle sensor		✓	✓	✓			S0035
4007	SUN ROOF		✓	✓	✓	✓		
4008	Engine	MIVEC	✓	✓	✓	✓	✓	
4008	Engine	CMM 4A92	✓	✓	✓	✓	✓	
4008	Engine	HDI 4N13	✓	✓	✓	✓	✓	
4008	Engine	HDI SID807 J3J4	✓	✓	✓	✓	✓	
4008	AT		✓	✓	✓	✓		
4008	ABS	ABS 4X4	✓	✓	✓	✓		
4008	ABS	ESP 4X4	✓	✓	✓	✓	✓	
4008	SRS		✓	✓	✓	✓	✓	
4008	Immobiliser	KOS	✓	✓	✓	✓	✓	
4008	Immobiliser	WCM	✓	✓	✓	✓		
4008	Instrument panel		✓	✓	✓	✓	✓	S0033
4008	Air conditioning		✓	✓	✓	✓	✓	
4008	BSI		✓	✓	✓	✓	✓	
4008	Alarm			✓	✓	✓		
4008	Directional headlamps		✓	✓	✓	✓	✓	
4008	Driver's door module		✓	✓	✓	✓		
4008	Power steering		✓	✓	✓	✓		
4008	Parking assistance		✓	✓	✓	✓		
4008	Radio		✓	✓	✓	✓		
4008	DARA(STT MMC)		✓	✓	✓	✓		
4008	Navigation		✓	✓	✓			

4008	Rain Sensor		✓	✓	✓	✓		
4008	Rear final drive piloted clutch		✓	✓	✓	✓		
4008	Steering wheel angle sensor		✓	✓	✓			S0035
Bipper	Engine	KFT V34.2	✓	✓	✓	✓	✓	
Bipper	Engine	KFV V34P	✓	✓	✓	✓		
Bipper	Engine	8HS EDC16C34	✓	✓	✓	✓		
Bipper	Engine	HDI 8DF2	✓	✓	✓	✓		
Bipper	Engine	HDI 8DF3	✓	✓	✓	✓		
Bipper	AT	BVMP	✓	✓	✓	✓		
Bipper	AT	BVMP MTA	✓	✓	✓	✓		
Bipper	ABS	ABS 81	✓	✓	✓	✓	✓	
Bipper	ABS	ESP 81	✓	✓	✓	✓		S0035
Bipper	SRS		✓	✓	✓	✓		
Bipper	Instrument panel		✓	✓	✓	✓	✓	
Bipper	Parking Aid(AAS)		✓	✓	✓	✓		
Boxer	Engine	DCU102	✓	✓	✓	✓		
Boxer	Engine	TUB EDC16C39	✓	✓	✓	✓		
Boxer	Engine	EDC17CP52	✓	✓	✓	✓		S0037
Boxer	ABS/ESP		✓	✓	✓	✓		
Boxer 3	Engine	DCU102	✓	✓	✓	✓		
Boxer 3	Engine	TUB EDC16C39	✓	✓	✓	✓		
Boxer 3	Engine	EDC17CP52	✓	✓	✓	✓		S0037
Boxer 3	ABS	ABS ABS8 0	✓	✓	✓	✓	✓	S0039
Boxer 3	ABS	ABS ASR8 0	✓	✓	✓	✓	✓	S0039
Boxer 3	ABS	ABS ESP8 0	✓	✓	✓	✓	✓	S0035, S0039
Boxer 3	SRS SAC TRW		✓	✓	✓	✓		
Boxer 3	Power steering		✓	✓	✓	✓		
Boxer 3	Instrument Panel		✓	✓	✓	✓		
Boxer 3	AC CLIMATISATION		✓	✓	✓	✓		
Boxer 3	Additional Heating		✓	✓	✓	✓	✓	
Boxer 3	Parking Aid		✓	✓	✓	✓		
Boxer 3	Piloted Suspension		✓	✓	✓	✓		
Boxer 3	Tachograph		✓	✓	✓	✓		
Boxer 3	Telematics		✓	✓	✓	✓		
Boxer 3 minibus	Engine	DCU102	✓	✓	✓	✓		

Boxer 3 minibus	Engine	TUB EDC16C39	✓	✓	✓	✓		
Boxer 3 minibus	Engine	EDC17CP52	✓	✓	✓	✓		S0037
Boxer 3 minibus	ABS	ABS ABS8 0	✓	✓	✓	✓	✓	S0039
Boxer 3 minibus	ABS	ABS ASR8 0	✓	✓	✓	✓	✓	S0039
Boxer 3 minibus	ABS	ABS ESP8 0	✓	✓	✓	✓	✓	S0035, S0039
Boxer 3 minibus	Power steering		✓	✓	✓	✓		
Boxer 3 minibus	Instrument Panel		✓	✓	✓	✓		
Boxer 3 minibus	AC		✓	✓	✓	✓		
Boxer 3 minibus	RSR		✓	✓	✓	✓		
Boxer 3 minibus	Parking Aid(AAS)		✓	✓	✓	✓		
Boxer 3 minibus	Additional Heating		✓	✓	✓	✓	✓	
Boxer 3 minibus	Tachograph		✓	✓	✓	✓		
Boxer 3 minibus	Telematics		✓	✓	✓	✓		
Expert	Engine	DCN2	✓	✓	✓	✓		
Expert	Engine	EDC15C2	✓	✓	✓	✓	✓	
Expert	AT		✓	✓	✓	✓		
Expert	ABS or ESP ECU	BOSCH ABS5.3	✓	✓	✓	✓		
Expert	ABS or ESP ECU	BENDIX	✓	✓	✓	✓	✓	
Expert	Airbag ECU		✓	✓	✓			
Expert 2	Engine	RFH MM6KP	✓	✓	✓	✓	✓	S0034
Expert 2	Engine	9HU EDC16C3	✓	✓	✓	✓	✓	
Expert 2	Engine	SID803	✓	✓	✓	✓	✓	S0037
Expert 2	Engine	RHH DCM3.5	✓	✓	✓	✓	✓	S0036, S0037
Expert 2	Engine	DCM3.5 BR2	✓	✓	✓	✓	✓	S0036, S0037
Expert 2	Engine	EDC17C10 BR2	✓	✓	✓	✓		
Expert 2	AT		✓	✓	✓	✓	✓	
Expert 2	ABS	ABS 8.1	✓	✓	✓	✓	✓	S0035, S0039
Expert 2	ABS	ABS8	✓	✓	✓	✓	✓	S0035, S0039
Expert 2	ABS	ESP 8.1	✓	✓	✓	✓	✓	S0035, S0039
Expert 2	ABS	ESP8	✓	✓	✓	✓	✓	S0035, S0039
Expert 2	SRS		✓	✓	✓	✓		
Expert 2	Instrument Panel		✓	✓	✓	✓		
Expert 2	Additional Heating		✓	✓	✓	✓	✓	
Expert 2	RADIO		✓	✓	✓	✓		
Hoggar	Engine	ME745	✓	✓	✓	✓	✓	S0034

Hoggar	Engine	ME749	✓	✓	✓	✓	✓	S0034
Hoggar	Engine	ME749 BIO FLEX	✓	✓	✓	✓	✓	S0034
Hoggar	Engine	J34P	✓	✓	✓	✓	✓	S0034
Hoggar	Engine	V343	✓	✓	✓	✓	✓	
Hoggar	Engine	DCN2	✓	✓	✓	✓	✓	
Hoggar	Engine	EDC15C2	✓	✓	✓	✓	✓	
Hoggar	Engine	EDC16C3DV4	✓	✓	✓	✓	✓	S0036
Hoggar	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0036, S0037
Hoggar	Gearbox ECU		✓	✓	✓	✓	✓	
Hoggar	ABS or ESP ECU	ABSMK70 1	✓	✓	✓	✓	✓	S0039
Hoggar	ABS or ESP ECU	ESPMK60 0	✓	✓	✓	✓	✓	S0035, S0039
Hoggar	Airbag ECU		✓	✓	✓			
Hoggar	Electric Power Steering		✓	✓	✓	✓		
Hoggar	Instrument panel		✓	✓	✓	✓	✓	
Hoggar	Air Conditioning		✓	✓	✓	✓		
Hoggar	BSI		✓	✓	✓			S0033
Hoggar	Display/Telematics	AMF	✓	✓	✓	✓	✓	
Hoggar	Display/Telematics	RT3	✓	✓	✓	✓	✓	
Hoggar	Service module		✓	✓	✓	✓	✓	
RCZ	Engine	ME745	✓	✓	✓	✓	✓	
RCZ	Engine	ME745 EC5	✓	✓	✓	✓	✓	S0034
RCZ	Engine	ME749	✓	✓	✓	✓	✓	
RCZ	Engine	ME749 EC5	✓	✓	✓	✓	✓	S0034
RCZ	Engine	MM6LPB	✓	✓	✓	✓	✓	
RCZ	Engine	MM6KP	✓	✓	✓	✓	✓	S0034
RCZ	Engine	EMV17 4 2	✓	✓	✓	✓	✓	S0034
RCZ	Engine	MEV17 4 EURO4	✓	✓	✓	✓	✓	S0034
RCZ	Engine	MEV17 4 EURO5	✓	✓	✓	✓	✓	S0034
RCZ	Engine	MED17 4 2	✓	✓	✓	✓	✓	
RCZ	Engine	MED17 4 EURO4	✓	✓	✓	✓	✓	S0034
RCZ	Engine	MED17 4 EURO5	✓	✓	✓	✓	✓	S0034
RCZ	Engine	MEVD17 4 2	✓	✓	✓	✓	✓	S0034
RCZ	Engine	MM6KP Bio Flex1	✓	✓	✓	✓	✓	S0034
RCZ	Engine	MM6KP Bio Flex2	✓	✓	✓	✓	✓	S0034
RCZ	Engine	EDC16C3	✓	✓	✓	✓	✓	

RCZ	Engine	DCM34	✓	✓	✓	✓	✓	S0036, S0037
RCZ	Engine	DCM35	✓	✓	✓	✓	✓	S0036, S0037
RCZ	Engine	DCM35 BR2	✓	✓	✓	✓	✓	S0036, S0037
RCZ	Engine	SID807	✓	✓	✓	✓	✓	S0037
RCZ	Engine	SID807 BR2	✓	✓	✓	✓	✓	S0037
RCZ	Engine	EDC17C10	✓	✓	✓	✓	✓	S0036, S0037
RCZ	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0036, S0037
RCZ	Gearbox ECU	BVA AT8	✓	✓	✓	✓	✓	
RCZ	Gearbox ECU	BVA AM6	✓	✓	✓	✓	✓	
RCZ	Gearbox ECU	BVA AM6 AT6 EURO5	✓	✓	✓	✓	✓	
RCZ	Gearbox ECU	CFC300P	✓	✓	✓	✓	✓	
RCZ	ABS or ESP ECU	ABS81	✓	✓	✓	✓	✓	S0039
RCZ	ABS or ESP ECU	ESP81	✓	✓	✓	✓	✓	S0035, S0039
RCZ	Air bag		✓	✓	✓	✓		
RCZ	Power steering		✓	✓	✓	✓	✓	
RCZ	Instrument Panel		✓	✓	✓	✓	✓	
RCZ	AC CLIM		✓	✓	✓	✓	✓	
RCZ	Alarm	ALARME	✓	✓	✓	✓	✓	
RCZ	Alarm	LIN ALARM	✓	✓	✓	✓	✓	
RCZ	Hands Free Kit	Hands Free Kit (BOITIER NOMADE)	✓	✓	✓	✓	✓	
RCZ	Hands Free Kit	Hands Free Kit (KML)	✓	✓	✓	✓	✓	
RCZ	Under inflation detection		✓	✓	✓	✓		
RCZ	Steering Wheel Switching Module		✓	✓	✓	✓	✓	
RCZ	Driver's Door Module		✓	✓	✓	✓	✓	
RCZ	Driving School Mode		✓	✓	✓			
RCZ	Driver's Seat Memory Unit		✓	✓	✓	✓	✓	
RCZ	Passenger Seat Memorisation Module		✓	✓	✓	✓	✓	
RCZ	Headlamp Height Corrector		✓	✓	✓	✓	✓	
RCZ	Multiplexed Additive Adding Pump	ADDITIVE PUMP PADDGO	✓	✓	✓	✓	✓	
RCZ	Multiplexed Additive Adding Pump	ADDITIVE PUMP PADDGO E5	✓	✓	✓	✓		
RCZ	Parking Aid (AAS)		✓	✓	✓	✓		
RCZ	Pedestrian Impact Detection Unit		✓	✓	✓	✓		
RCZ	Battery change status unit	BECB	✓	✓	✓	✓		S003A

RCZ	Battery change status unit	BECEB GEN2	✓	✓	✓	✓		S003A
RCZ	CD player		✓	✓	✓			
RCZ	Engine relay unit		✓	✓	✓	✓	✓	
RCZ	ESSUIV		✓	✓	✓	✓		
RCZ	Hi fi amplifier		✓	✓	✓	✓		
RCZ	Lane departure warning system		✓	✓	✓	✓	✓	
RCZ	Control panel dot matrix display		✓	✓	✓	✓	✓	
RCZ	Multi function display	EMF A	✓	✓	✓	✓	✓	
RCZ	Multi function display	EMF C	✓	✓	✓	✓	✓	
RCZ	RADIO	AUTORADIO	✓	✓	✓	✓	✓	
RCZ	RADIO	RD43	✓	✓	✓	✓		
RCZ	RADIO	RD45	✓	✓	✓	✓	✓	
RCZ	Rain Sensor		✓	✓	✓			
RCZ	SUN ROOF		✓	✓	✓	✓		
RCZ	TOITESC		✓	✓	✓	✓		
RCZ	Trailer relay unit		✓	✓	✓	✓	✓	
RCZ	Service module	BLVV (KWP)	✓	✓	✓	✓		
RCZ	Service module	BTA	✓	✓	✓	✓		
RCZ	Service module	MD SERV	✓	✓	✓	✓		
Partner	Engine	EDC16C3	✓	✓	✓	✓	✓	S0036
Partner	Engine	BOSCH ME749	✓	✓	✓	✓	✓	S0034
Partner	Engine	1.6 16v BOSCH Motronic ME 7.4.5[NFR]	✓	✓	✓	✓	✓	S0034
Partner	Engine	9HT BOSCH EDC16C3	✓	✓	✓	✓	✓	
Partner	ABS/ESP	ESP BOSCH57	✓	✓	✓	✓	✓	S0035, S0039
Partner	ABS/ESP	ABS BOSCH 8 KwpEcu	✓	✓	✓	✓	✓	
Partner	ABS/ESP	ESP BOSCH8 KwpECU	✓	✓	✓	✓	✓	S0035, S0039
Partner	ABS/ESP	ABS 81 KwpECU	✓	✓	✓	✓	✓	
Partner	ABS/ESP	ABS BOSCH53	✓	✓	✓	✓		
Partner	Airbag ECU	SAC CENT AUTOLIV	✓	✓	✓			
Partner	Airbag ECU	Airbag and seatbelts	✓	✓	✓			
Partner	Instrument panel		✓	✓	✓	✓	✓	
Partner	Additional Heating		✓	✓	✓	✓		
Partner	Switch module at the steering wheel		✓			✓		

Partner	Alarm		✓	✓	✓	✓		
Partner	Display/Telematics		✓	✓	✓	✓	✓	
Partner	CD Player		✓	✓	✓	✓		
Partner	Radio		✓	✓	✓	✓	✓	
Partner	Rain/brightness sensor		✓	✓	✓			
Partner 2	Engine	1.6 16v BOSCH Motronic ME 7.4.5[NFR]	✓	✓	✓	✓	✓	
Partner 2	Engine	1.6 BOSCH HDI EDC16C34[9HW]	✓	✓	✓	✓	✓	
Partner 2	ABS		✓	✓	✓	✓	✓	S0035, S0039
Partner 2	SRS		✓	✓	✓	✓		
Partner B9	Engine	ME745	✓	✓	✓	✓	✓	
Partner B9	Engine	MEV17.4	✓	✓	✓	✓	✓	S0034
Partner B9	Engine	MEV17 4 2	✓	✓	✓	✓	✓	
Partner B9	Engine	EDC16C3	✓	✓	✓	✓	✓	S0036, S0037
Partner B9	Engine	HDI SID807	✓	✓	✓	✓	✓	S0037
Partner B9	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0036, S0037
Partner B9	Engine	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
Partner B9	Engine	EDC17C60	✓	✓	✓	✓		S0037
Partner B9	AT		✓	✓	✓	✓	✓	
Partner B9	ABS	ABS 8.1	✓	✓	✓	✓	✓	S0035, S0039
Partner B9	ABS	ESP 8.1	✓	✓	✓	✓	✓	S0035, S0039
Partner B9	SRS		✓	✓	✓	✓		
Partner B9	Power steering		✓	✓	✓	✓	✓	
Partner B9	Air Conditioning		✓	✓	✓	✓	✓	
Partner B9	Under inflation detection		✓	✓	✓	✓		
2008	Engine	ME745 EC5	✓	✓	✓	✓	✓	S0034
2008	Engine	V46	✓	✓	✓	✓		
2008	Engine	MEV17 4 2	✓	✓	✓	✓	✓	S0034
2008	Engine	MED17 4 2	✓	✓	✓	✓	✓	S0034
2008	Engine	ME749 EC5	✓	✓	✓	✓	✓	S0034
2008	Engine	HDI SID807 BR2	✓	✓	✓	✓	✓	S0037
2008	Engine	VD46	✓	✓	✓	✓		
2008	Engine	MED17 4 4	✓	✓	✓	✓		S0034

2008	Engine	CMM MD1CS003	✓	✓	✓			
2008	Engine	CMM V56	✓	✓	✓			
2008	Engine	CMM VD56	✓	✓	✓			
2008	Engine	EDC17C10 BR2	✓	✓	✓			
2008	Engine	EDC17C60	✓	✓	✓			
2008	Engine	MEVD17 4 2	✓	✓	✓			
2008	Engine	MEVD17 4 4	✓	✓	✓			
2008	Engine	V344	✓	✓	✓			
2008	Engine	V345	✓	✓	✓			
2008	Engine	V46 21	✓	✓	✓			
2008	Engine	V46 52	✓	✓	✓			
2008	Engine	V46 6	✓	✓	✓			
2008	Gearbox	CFC300P	✓	✓	✓	✓	✓	
2008	Gearbox	BVMP	✓	✓	✓	✓		
2008	Gearbox	BVA AL4	✓	✓	✓	✓	✓	
2008	Gearbox	MAPS UDS	✓	✓	✓	✓		
2008	Gearbox	BVA AM6 AT6 UDS	✓	✓	✓			
2008	Gearbox	BVMP MCP UDS	✓	✓	✓			
2008	ABS or ESP ECU	ABS MK100	✓	✓	✓	✓	✓	S0039
2008	ABS or ESP ECU	ESPMK100	✓	✓	✓	✓	✓	S0039
2008	Air bag		✓	✓	✓	✓		
2008	Electric power steering	Recent ECU	✓	✓	✓	✓		
2008	Electric power steering	DAE	✓	✓	✓			
2008	Air conditioning	Recent ECU	✓	✓	✓	✓		
2008	Air conditioning	TDC CH MUX	✓	✓	✓			
2008	Air conditioning	TDC RFTA MUX	✓	✓	✓			
2008	Air conditioning	TDC RF MUX	✓	✓	✓			
2008	BSI		✓	✓	✓			S0033
2008	Control panel dot matrix display	Recent ECU	✓	✓	✓			
2008	Control panel dot matrix display	MATT M 2010	✓	✓	✓			
2008	Parking aid		✓	✓	✓	✓		
2008	Switch module under the steering wheel		✓	✓	✓	✓	✓	
2008	Rain sunlight sensor		✓	✓	✓	✓		
2008	Controls on the steering wheel		✓	✓	✓	✓		

2008	Electric steering lock		✓	✓	✓	✓		
2008	Instrument panel		✓	✓	✓	✓	✓	
2008	Multiplexed control panel		✓	✓	✓	✓		
2008	Touch screen		✓	✓	✓			
2008	anti-theft alarm		✓	✓	✓			
2008	Audio amplifier		✓	✓	✓			
2008	Vehicle Distance Assistance		✓	✓	✓			
2008	Traction control mode selector		✓					
2008	battery charge status control unit		✓	✓	✓			
2008	Trailer Relay Unit		✓	✓	✓			
2008	External CD player		✓	✓	✓			
2008	Voltage maintaining device	DMTC	✓					
2008	Voltage maintaining device	DMTR	✓	✓	✓			
2008	Voltage maintaining device	DMTR DTC3B	✓	✓	✓			
2008	Control panel dot matrix display	MATT C 2010	✓	✓	✓			
2008	Control panel dot matrix display	MATT P 2010	✓	✓	✓			
2008	Service module / Independent telematic unit	BTA	✓	✓	✓			
2008	Service module / Independent telematic unit	BTA_2	✓	✓	✓			
2008	diesel fuel additive pump	PADDGO	✓	✓	✓			
2008	diesel fuel additive pump	PADDGO TI E6	✓	✓	✓			
2008	Intrusion alarm siren		✓	✓	✓			
2008	Telematic unit (RTx) or audio-navigation	NAC	✓	✓	✓			
2008	Telematic unit (RTx) or audio-navigation	RCC	✓	✓	✓			
2008	Telematic unit (RTx) or audio-navigation	SMEG_PLUS	✓	✓	✓			
2008	Telematic unit (RTx) or audio-navigation	SMEG	✓	✓	✓	✓		
308S	Engine	V46 52	✓	✓	✓	✓		
308S	Engine	VD46	✓	✓	✓	✓		
308S	Engine	V46 32 Y2	✓	✓	✓	✓		
308S	Engine	MED17 4 4	✓	✓	✓	✓		S0034

308S	Gearbox ECU		✓	✓	✓	✓		
308S	ABS or ESP ECU		✓	✓	✓	✓		S0035, S0038, S0039
308S	Air bag		✓	✓	✓	✓		
308S	Power steering		✓	✓	✓	✓		
308S	Instrument Panel		✓	✓	✓	✓		
308S	AC CLIM		✓	✓	✓	✓		
308S	BSI		✓	✓	✓			S0033
308S	Alarm	ALARME	✓	✓	✓	✓	✓	
308S	Alarm	LIN ALARM	✓	✓	✓	✓	✓	
308S	Steering Wheel Switching Module		✓	✓	✓	✓		
308S	Driver's Seat Memory Unit		✓	✓	✓	✓	✓	
308S	Headlamp Height Corrector		✓	✓	✓	✓	✓	
308S	Parking Aid(AAS)		✓	✓	✓			
308S	Cd player		✓	✓	✓			
308S	Engine relay unit		✓	✓	✓	✓		
308S	Control panel dot matrix display		✓	✓	✓			
308S	Multi function display		✓	✓	✓	✓		
308S	RADIO	AUTORADIO	✓	✓	✓	✓	✓	
308S	RADIO	RD43	✓	✓	✓	✓		
308S	RADIO	RD45	✓	✓	✓	✓	✓	
308S	Rain Sensor			✓	✓	✓		
308S	Multiplexed control panel		✓	✓	✓			
308S	Service module		✓	✓	✓	✓		
308S	Controls on the steering wheel			✓	✓	✓		
308S	Touch screen		✓	✓	✓			
308S	Telematics		✓	✓	✓	✓		
308S	Voltage stabilizing device		✓	✓	✓			
308S	Electronic key reader			✓	✓			
308S	Electric steering lock			✓	✓			
308S	Telematics unit		✓	✓	✓	✓		
308(T9)	Engine	5FV MED 17.4.2 EURO 5	✓	✓	✓	✓	✓	
308(T9)	Engine	DCM6.2 DW10FD TED4 - 150CV	✓	✓	✓	✓	✓	
308(T9)	Engine	HDI SID807 BR2	✓	✓	✓	✓	✓	

308 (T9)	Engine	MED17 4 4	✓	✓	✓	✓		S0034
308 (T9)	Engine	9HP EDC17C10 BR2	✓	✓	✓	✓	✓	
308 (T9)	Engine	MEVD17 4 4	✓	✓	✓	✓		
308 (T9)	Engine	VD46	✓	✓	✓	✓		
308 (T9)	Engine	V46 21	✓	✓	✓	✓		
308 (T9)	Engine	EDC17C60	✓	✓	✓	✓		
308 (T9)	Gearbox ECU		✓	✓	✓	✓		
308 (T9)	ABS or ESP ECU		✓	✓	✓	✓		S0035, S0038 , S0039
308 (T9)	Air bag		✓	✓	✓	✓		
308 (T9)	Power steering		✓	✓	✓	✓		
308 (T9)	Instrument Panel		✓	✓	✓	✓		
308 (T9)	AC CLIM		✓	✓	✓	✓		
308 (T9)	BSI		✓	✓	✓			S0033
308 (T9)	Alarm		✓	✓	✓	✓		
308 (T9)	Steering Wheel Switching Module	COM2008P	✓	✓	✓	✓		
308 (T9)	Steering Wheel Switching Module	HDC	✓	✓	✓	✓	✓	
308 (T9)	Driver's Seat Memory Unit		✓	✓	✓	✓	✓	
308 (T9)	Display	EMF C UDS	✓	✓	✓	✓		
308 (T9)	Display	MULTIFUNCTION SCREEN WITH PIXELS (C-)	✓	✓	✓			
308 (T9)	Display	EMF DGT UDS	✓	✓	✓	✓		
308 (T9)	Headlamp height adjuster/directional headlamp		✓	✓	✓	✓	✓	
308 (T9)	External CD player		✓	✓	✓	✓	✓	
308 (T9)	Electronic key reader		✓	✓	✓	✓		
308 (T9)	Electric steering lock		✓	✓	✓	✓		
308 (T9)	Diesel Additive Function		✓	✓	✓	✓		
308 (T9)	Telematics unit		✓	✓	✓	✓	✓	
308 (T9)	Vehicle distance assistance system		✓	✓	✓	✓		
308 (T9)	Controls on the steering wheel			✓	✓	✓		
308 (T9)	Touch screen		✓	✓	✓	✓		
308 (T9)	Rain Sensor			✓	✓	✓		
308 (T9)	Parking Aid (AAS)		✓	✓	✓	✓		
308 (T9)	Audio amplifier		✓	✓	✓			

308(T9)	Multiplexed control panel		√	√	√			
308(T9)	Radio telephone transceiver control unit		√	√	√	√		
308(T9)	Radio		√	√	√	√		
308(T9)	Control panel dot matrix display		√	√	√			
308(T9)	Voltage stabilizing device		√	√	√			
408(T93)	Engine	V46 52	√	√	√	√		
408(T93)	Engine	VD46	√	√	√	√		
408(T93)	Engine	V46 32 Y2	√	√	√	√		
408(T93)	Engine	MED17 4 4	√	√	√	√		S0034
408(T93)	Gearbox ECU		√	√	√	√		
408(T93)	ABS or ESP ECU		√	√	√	√		S0035, S0038, S0039
408(T93)	Air bag		√	√	√	√		
408(T93)	Power steering		√	√	√	√		
408(T93)	Instrument Panel		√	√	√	√		
408(T93)	AC CLIM		√	√	√	√		
408(T93)	BSI		√	√	√			S0033
408(T93)	Telematics		√	√	√	√	√	
408(T93)	Radio telephone transceiver control unit		√	√	√	√		
408(T93)	Rain Sensor			√	√	√		
408(T93)	Multiplexed control panel		√	√	√			
408(T93)	Driver's Seat Memory Unit		√	√	√	√	√	
408(T93)	Control panel dot matrix display		√	√	√			
408(T93)	Electronic key reader		√	√	√	√		
408(T93)	Electric steering lock		√	√	√	√		
408(T93)	Voltage stabilizing device		√	√	√			
408(T93)	Radio		√	√	√	√		
408(T93)	Steering Wheel Switching Module	COM2008P	√	√	√	√		
408(T93)	Steering Wheel Switching Module	HDC	√	√	√	√	√	
408(T93)	Headlamp height adjuster/directional headlamp		√	√	√	√	√	
408(T93)	Parking Aid(AAS)		√	√	√	√		
408(T93)	Display	EMF C UDS	√	√	√	√		

408(T93)	Display	EMF A UDS	✓	✓	✓	✓		
408(T93)	Display	Touch screen	✓	✓	✓	✓		
408(T93)	Touch screen		✓	✓	✓	✓		
408(T93)	Alarm		✓	✓	✓	✓	✓	
408(T93)	Controls on the steering wheel			✓	✓	✓		
3008(P48)	Engine	DCM6.2 DW10FD TED4 - 150CV	✓	✓	✓	✓	✓	
3008(P48)	Engine	MED17 4 4	✓	✓	✓	✓		S0034
3008(P48)	Engine	EDC17C60	✓	✓	✓	✓		
3008(P48)	Engine	VD46	✓	✓	✓	✓		
3008(P48)	Engine	MED17 4 4EP8	✓	✓	✓	✓		
3008(P48)	Gearbox ECU		✓	✓	✓	✓		
3008(P48)	ABS or ESP ECU		✓	✓	✓	✓		S0035, S0038, S0039
3008(P48)	Air bag		✓	✓	✓	✓		
3008(P48)	Power steering		✓	✓	✓	✓		
3008(P48)	Instrument Panel	COMBINE UDS	✓	✓	✓	✓	✓	
3008(P48)	Instrument Panel	CIROCCO	✓	✓	✓	✓		
3008(P48)	AC CLIM		✓	✓	✓	✓		
3008(P48)	BSI		✓	✓	✓			S0033
3008(P48)	Display		✓	✓	✓	✓		
3008(P48)	Steering Wheel Switching Module		✓	✓	✓	✓	✓	
3008(P48)	Headlamp height adjuster/directional headlamp		✓	✓	✓	✓	✓	
3008(P48)	External CD player		✓	✓	✓	✓	✓	
3008(P48)	Driver's door control panel	PDPC UDS	✓	✓	✓	✓		
3008(P48)	Driver's door control panel	PDPC	✓	✓	✓	✓	✓	
3008(P48)	Electric steering lock		✓	✓	✓	✓		
3008(P48)	Vehicle distance assistance system		✓	✓	✓	✓		
3008(P48)	Controls on the steering wheel			✓	✓	✓		
3008(P48)	Rain Sensor			✓	✓	✓		
3008(P48)	Parking Aid(AAS)		✓	✓	✓	✓		
3008(P48)	Audio amplifier		✓	✓	✓			
3008(P48)	Multiplexed control panel		✓	✓	✓			
3008(P48)	ALARM		✓	✓	✓	✓		

3008(P48)	Voltage stabilizing device		√	√	√			
3008(P48)	Body control module		√	√	√	√		
3008(P48)	Automatic Gearbox Electric Control Unit		√	√	√	√		
4008(China)	Engine	DCM6.2 DW10FD TED4 - 150CV	√	√	√	√	√	
4008(China)	Engine	MED17 4 4	√	√	√	√		S0034
4008(China)	Engine	EDC17C60	√	√	√	√		
4008(China)	Engine	VD46	√	√	√	√		
4008(China)	Engine	MED17 4 4EP8	√	√	√	√		
4008(China)	Gearbox ECU		√	√	√	√		
4008(China)	ABS or ESP ECU		√	√	√	√		S0035, S0038, S0039
4008(China)	Air bag		√	√	√	√		
4008(China)	Power steering		√	√	√	√		
4008(China)	Instrument Panel	COMBINE UDS	√	√	√	√	√	
4008(China)	Instrument Panel	CIROCCO	√	√	√	√		
4008(China)	AC CLIM		√	√	√	√		
4008(China)	BSI		√	√	√			S0033
4008(China)	Display		√	√	√	√		
4008(China)	Steering Wheel Switching Module		√	√	√	√	√	
4008(China)	Headlamp height adjuster/directional headlamp		√	√	√	√	√	
4008(China)	External CD player		√	√	√	√	√	
4008(China)	Driver's door control panel	PDPC UDS	√	√	√	√		
4008(China)	Driver's door control panel	PDPC	√	√	√	√	√	
4008(China)	Electric steering lock		√	√	√	√		
4008(China)	Vehicle distance assistance system		√	√	√	√		
4008(China)	Controls on the steering wheel			√	√	√		
4008(China)	Rain Sensor			√	√	√		
4008(China)	Parking Aid(AAS)		√	√	√	√		
4008(China)	Audio amplifier		√	√	√			
4008(China)	Multiplexed control panel		√	√	√			
4008(China)	ALARM		√	√	√	√		
4008(China)	Voltage stabilizing device		√	√	√			

4008 (China)	Body control module		✓	✓	✓	✓		
4008 (China)	Automatic Gearbox Electric Control Unit		✓	✓	✓	✓		
5008 (P84)	Engine	DCM6.2 DW10FD TED4 - 150CV	✓	✓	✓	✓	✓	
5008 (P84)	Engine	MED17 4 4	✓	✓	✓	✓		S0034
5008 (P84)	Engine	EDC17C60	✓	✓	✓	✓		
5008 (P84)	Engine	VD46	✓	✓	✓	✓		
5008 (P84)	Engine	MED17 4 4EP8	✓	✓	✓	✓		
5008 (P84)	Gearbox ECU		✓	✓	✓	✓		
5008 (P84)	ABS or ESP ECU		✓	✓	✓	✓		S0035, S0038, S0039
5008 (P84)	Air bag		✓	✓	✓	✓		
5008 (P84)	Power steering		✓	✓	✓	✓		
5008 (P84)	Instrument Panel	COMBINE UDS	✓	✓	✓	✓	✓	
5008 (P84)	Instrument Panel	CIROCCO	✓	✓	✓	✓		
5008 (P84)	AC CLIM		✓	✓	✓	✓		
5008 (P84)	BSI		✓	✓	✓			S0033
5008 (P84)	Display		✓	✓	✓	✓		
5008 (P84)	Steering Wheel Switching Module		✓	✓	✓	✓	✓	
5008 (P84)	Headlamp height adjuster/directional headlamp		✓	✓	✓	✓	✓	
5008 (P84)	External CD player		✓	✓	✓	✓	✓	
5008 (P84)	Driver's door control panel	PDPC UDS	✓	✓	✓	✓		
5008 (P84)	Driver's door control panel	PDPC	✓	✓	✓	✓	✓	
5008 (P84)	Electric steering lock		✓	✓	✓	✓		
5008 (P84)	Vehicle distance assistance system		✓	✓	✓	✓		
5008 (P84)	Controls on the steering wheel			✓	✓	✓		
5008 (P84)	Rain Sensor			✓	✓	✓		
5008 (P84)	Parking Aid (AAS)		✓	✓	✓	✓		
5008 (P84)	Audio amplifier		✓	✓	✓			
5008 (P84)	Multiplexed control panel		✓	✓	✓			
5008 (P84)	ALARM		✓	✓	✓	✓		
5008 (P84)	Voltage stabilizing device		✓	✓	✓			
5008 (P84)	Body control module		✓	✓	✓	✓		

5008 (P84)	Automatic Gearbox Electric Control Unit		√	√	√	√		
Partner Electric (B9E)	Engine		√	√	√	√		
Partner Electric (B9E)	ABS or ESP ECU	ESP81	√	√	√	√	√	S0035, S0039
Partner Electric (B9E)	ABS or ESP ECU	ESP 90	√	√	√	√		S0035, S0038, S0039
Partner Electric (B9E)	Airbag		√	√	√	√		
Partner Electric (B9E)	Power steering electric pump unit		√	√	√	√	√	
Partner Electric (B9E)	Instrument Panel		√	√	√	√	√	
Partner Electric (B9E)	Air Conditioning		√	√	√	√	√	
Partner Electric (B9E)	BSI		√	√	√			S0033
Partner Electric (B9E)	Radio or wireless telephone (radio part)	RADIO	√	√	√	√		
Partner Electric (B9E)	Radio or wireless telephone (radio part)	RD45	√	√	√	√	√	
Partner Electric (B9E)	Parking Aid (AAS)		√	√	√	√		
Partner Electric (B9E)	Vehicle charger for traction battery		√	√	√	√		
Partner Electric (B9E)	Passenger compartment air heating resistor		√	√	√	√		
Partner Electric (B9E)	Air-conditioning compressor		√	√	√	√		
Partner Electric (B9E)	Electric vehicle management electronic control unit		√	√	√	√		
Partner Electric (B9E)	Service module		√	√	√	√	√	

Partner Electric (B9E)	Multi function display	Multifunction display A	✓	✓	✓	✓	✓	
Partner Electric (B9E)	Multi function display	Multifunction Display C	✓	✓	✓	✓	✓	
Partner Electric (B9E)	Drive transmission system interface ECU		✓	✓	✓	✓	✓	
Partner Electric (B9E)	Alarm		✓	✓	✓	✓		
Partner Electric (B9E)	Rain sensor		✓	✓	✓			
Partner Electric (B9E)	Independent telematic unit (BTA)	RNEG2010	✓	✓	✓	✓		
Partner Electric (B9E)	Independent telematic unit (BTA)	Telematics (RADIONAV RNEG)	✓	✓	✓	✓	✓	
Partner Electric (B9E)	Motor management electronic control unit		✓	✓	✓	✓		
Partner Electric (B9E)	Battery charge status unit		✓	✓	✓	✓		
Partner Electric (B9E)	Engine relay unit		✓	✓	✓	✓		
Partner Electric (B9E)	Steering Wheel Switching Module		✓	✓	✓	✓	✓	
Partner2 (M69)	Engine	EDC17C10 BR2	✓	✓	✓	✓	✓	S0037
Partner2 (M69)	Engine	ME749 EC5	✓	✓	✓	✓	✓	S0034
Partner2 (M69)	ABS or ESP ECU		✓	✓	✓	✓	✓	S0039
Partner2 (M69)	Airbag		✓	✓	✓	✓		
Partner2 (M69)	Instrument Panel		✓	✓	✓	✓	✓	
Partner2 (M69)	BSI		✓	✓	✓			S0033
Partner2 (M69)	Steering Wheel Switching Module		✓	✓	✓	✓	✓	
308 (TX9)	Engine	MED17 4 4	✓	✓	✓	✓		S0034
308 (TX9)	Engine	VD46	✓	✓	✓	✓		
308 (TX9)	Engine	V46 52	✓	✓	✓	✓		
308 (TX9)	AT BVA AL		✓	✓	✓	✓		
308 (TX9)	ABS or ESP ECU		✓	✓	✓	✓		S0035, S0038, S0039

308 (TX9)	Airbag		✓	✓	✓	✓		
308 (TX9)	Power steering electric pump unit		✓	✓	✓	✓		
308 (TX9)	Instrument Panel		✓	✓	✓	✓		
308 (TX9)	Air Conditioning		✓	✓	✓	✓		
308 (TX9)	BSI		✓	✓	✓			S0033
308 (TX9)	AutoRadio		✓	✓	✓	✓	✓	
308 (TX9)	Parking Aid(AAS)		✓	✓	✓	✓		
308 (TX9)	Steering Wheel Switching Module		✓	✓	✓	✓	✓	
308 (TX9)	Multi function display		✓	✓	✓	✓		
308 (TX9)	Electronic steering lock		✓	✓	✓	✓		
308 (TX9)	Controls on the steering wheel		✓	✓	✓	✓		
308 (TX9)	Rain sensor		✓	✓	✓	✓		
308 (TX9)	Battery charge status unit		✓	✓	✓	✓		S003A
308 (TX9)	Telematics unit		✓	✓	✓	✓		
308 (TX9)	Multiplexed control panel	SMEG AUDIO- NAVIGATION+	✓	✓	✓	✓		
308 (TX9)	Multiplexed control panel	AUTORADIO RD45 ET CLIMATISATION MANUELLE	✓	✓	✓	✓		
308 (TX9)	Control panel dot matrix display		✓	✓	✓			
EXPERT (KO)	Engine	DCM6.2	✓	✓	✓	✓		
EXPERT (KO)	Engine	EDC17C10 BR2	✓	✓	✓	✓		
EXPERT (KO)	Engine	EDC17C60	✓	✓	✓	✓		
EXPERT (KO)	AT BVA AL	BVA AM6 AT6 UDS	✓	✓	✓	✓		
EXPERT (KO)	AT BVA AL	BVMP MCP UDS	✓	✓	✓	✓		
EXPERT (KO)	ABS or ESP ECU		✓	✓	✓	✓		S0035, S0038 , S0039
EXPERT (KO)	Airbag		✓	✓	✓	✓		
EXPERT (KO)	Anti theft alarm		✓	✓	✓	✓		
EXPERT (KO)	Instrument Panel	COMBINE UDS	✓	✓	✓	✓		
EXPERT (KO)	Instrument Panel	CIROCCO	✓	✓	✓	✓		
EXPERT (KO)	Air Conditioning		✓	✓	✓	✓		
EXPERT (KO)	BSI		✓	✓	✓			S0033
EXPERT (KO)	Voltage stabilizing device		✓	✓	✓			
EXPERT (KO)	Parking Aid(AAS)		✓	✓	✓	✓		

EXPERT(KO)	Steering Wheel Switching Module		√	√	√	√	√	
EXPERT(KO)	Multi function display	Multifunction display A	√	√	√			
EXPERT(KO)	Multi function display	Multifunction Display C	√	√	√	√		
EXPERT(KO)	Electronic steering lock		√	√	√	√		
EXPERT(KO)	Battery protection and management unit		√	√	√	√		
EXPERT(KO)	Engine relay unit		√	√	√	√		
EXPERT(KO)	Trailer Relay Unit		√	√	√	√		
EXPERT(KO)	Controls on the steering wheel		√	√	√	√		
EXPERT(KO)	Rain sensor		√	√	√	√		
EXPERT(KO)	Multiplexed control panel		√	√	√	√		
EXPERT(KO)	Siren		√	√	√	√		
EXPERT(KO)	Radio telephone transceiver control unit		√	√	√	√		
EXPERT(KO)	High field of view		√	√	√	√		
EXPERT(KO)	Vehicle distance assistance system		√	√	√	√		
EXPERT(KO)	Battery charge status unit		√	√	√	√		S003A
EXPERT(KO)	Automatic Gearbox Electric Control Unit		√	√	√	√		
Expert 3	Engine	9HU EDC16C3	√	√	√	√	√	S0036
Expert 3	Engine	EDC17C10 BR2	√	√	√	√	√	S0036, S0037
Expert 3	Engine	RFH MM6KP	√	√	√	√	√	S0034
Expert 3	Engine	RHH DW10CTED4-163CV	√	√	√	√		S0036, S0037
Expert 3	Engine	DCM3.5 RHE/RHH	√	√	√	√	√	S0036, S0037
Expert 3	Engine	HDI SID803A	√	√	√	√		S0037
Expert 3	AT BVA AL		√	√	√	√	√	
Expert 3	ABS or ESP ECU	ABS 81	√	√	√	√	√	S0035, S0039
Expert 3	ABS or ESP ECU	ESP81	√	√	√	√	√	S0035, S0039
Expert 3	ABS or ESP ECU	ABS8 BOSCH	√	√	√	√	√	S0035, S0039
Expert 3	ABS or ESP ECU	ESP8 BOSCH	√	√	√	√	√	S0035, S0039
Expert 3	Airbag		√	√	√	√		
Expert 3	Power steering electric pump unit		√	√	√	√		
Expert 3	Instrument Panel		√	√	√	√	√	

Expert 3	Air Conditioning		✓	✓	✓	✓	✓	
Expert 3	BSI		✓	✓	✓			S0033
Expert 3	Under inflation detection	DSG	✓	✓	✓	✓		
Expert 3	Under inflation detection	DSG UDS	✓	✓	✓	✓		
Expert 3	Pneumatic suspension		✓	✓	✓	✓	✓	
Expert 3	Trailer Relay Unit		✓	✓	✓	✓		
Expert 3	Body deformation control box		✓	✓	✓	✓		
Expert 3	Engine relay unit		✓	✓	✓	✓		
Expert 3	Parking Aid(AAS)		✓	✓	✓	✓	✓	
Expert 3	Steering Wheel Switching Module		✓	✓	✓	✓	✓	
Expert 3	Multi function display	Multifunction display A	✓	✓	✓	✓	✓	
Expert 3	Multi function display	Multifunction Display C	✓	✓	✓	✓	✓	
Expert 3	CD player		✓	✓	✓			
Expert 3	Hands Free Kit	KML	✓	✓	✓	✓	✓	
Expert 3	Hands Free Kit	BOITIER NOMADE	✓	✓	✓	✓	✓	
Expert 3	Independent telematic unit (BTA)	RNEG2010	✓	✓	✓	✓		
Expert 3	Independent telematic unit (BTA)	Telematics (RADIONAV RNEG)	✓	✓	✓	✓		
Expert 3	Independent telematic unit (BTA)	TELEMATIC CASE	✓	✓	✓	✓	✓	
Expert 3	Rear air conditioning work panel		✓	✓	✓	✓		
Expert 3	Rain sensor		✓	✓	✓			
Expert 3	High frequency receiver		✓	✓	✓	✓		
Expert 3	Battery charge status unit		✓	✓	✓	✓		S003A
TRAVELLER	Engine	DCM6.2	✓	✓	✓	✓		
TRAVELLER	Engine	EDC17C10 BR2	✓	✓	✓	✓		
TRAVELLER	Engine	EDC17C60	✓	✓	✓	✓		S0037
TRAVELLER	AT BVA AL	BVA AM6 AT6 UDS	✓	✓	✓	✓		
TRAVELLER	AT BVA AL	BVMP MCP UDS	✓	✓	✓	✓		
TRAVELLER	ABS or ESP ECU		✓	✓	✓	✓		S0035, S0038, S0039
TRAVELLER	Airbag		✓	✓	✓	✓		
TRAVELLER	Anti theft alarm		✓	✓	✓	✓		
TRAVELLER	Instrument Panel	COMBINE UDS	✓	✓	✓	✓		

TRAVELLER	Instrument Panel	CIROCCO	√	√	√	√		
TRAVELLER	Air Conditioning		√	√	√	√		
TRAVELLER	BSI		√	√	√			S0033
TRAVELLER	Voltage stabilizing device		√	√	√			
TRAVELLER	Parking Aid(AAS)		√	√	√	√		
TRAVELLER	Steering Wheel Switching Module		√	√	√	√	√	
TRAVELLER	Multi function display	Multifunction display A	√	√	√			
TRAVELLER	Multi function display	Multifunction Display C	√	√	√	√		
TRAVELLER	Electronic steering lock		√	√	√	√		
TRAVELLER	Battery protection and management unit		√	√	√	√		
TRAVELLER	Engine relay unit		√	√	√	√		
TRAVELLER	Trailer Relay Unit		√	√	√	√		
TRAVELLER	Controls on the steering wheel		√	√	√	√		
TRAVELLER	Rain sensor		√	√	√	√		
TRAVELLER	Multiplexed control panel		√	√	√	√		
TRAVELLER	Siren		√	√	√	√		
TRAVELLER	Radio telephone transceiver control unit		√	√	√	√		
TRAVELLER	High field of view		√	√	√	√		
TRAVELLER	Vehicle distance assistance system		√	√	√	√		
TRAVELLER	Battery charge status unit		√	√	√	√		S003A
TRAVELLER	Automatic Gearbox Electric Control Unit		√	√	√	√		
108	Engine		√	√	√	√		
108	AT BVA AL		√	√	√			
108	ABS or ESP ECU		√	√	√	√		
108	Airbag		√	√	√	√		
108	Power steering electric pump unit		√	√	√	√		
108	Instrument Panel		√	√	√			
108	Air Conditioning		√	√	√	√		
108	Stop/Start Control ECU		√	√	√			
108	Multi function display			√	√			

ION	Airbag		✓	✓	✓	✓		
ION	Power steering electric pump unit		✓	✓	✓	✓		
ION	Instrument Panel		✓	✓	✓	✓		S0033
ION	Air Conditioning		✓	✓	✓	✓		
ION	Motor management electronic control unit		✓	✓	✓	✓		
ION	Traction battery electronic control unit		✓	✓	✓	✓	✓	
ION	Electric vehicle management electronic control unit		✓	✓	✓	✓		
ION	ESP		✓	✓	✓	✓		
ION	Steering wheel angle sensor		✓	✓	✓	✓		S0035
ION	Gateway servo control box		✓	✓	✓	✓		
ION	Telematics unit		✓	✓	✓	✓	✓	
ION	Vehicle charger for traction battery		✓	✓	✓	✓		
BOXER3_EUR05/BOXER3_EUR06	Engine	SID208	✓	✓	✓	✓		
BOXER3_EUR05/BOXER3_EUR06	Engine	EDC17CP52_UDS	✓	✓	✓	✓	✓	S0037
BOXER3_EUR05/BOXER3_EUR06	Engine	DCM62_F	✓	✓	✓	✓		
BOXER3_EUR05/BOXER3_EUR06	ABS or ESP ECU	ABS90_F	✓	✓	✓	✓		
BOXER3_EUR05/BOXER3_EUR06	ABS or ESP ECU	ESP90_F	✓	✓	✓	✓		
BOXER3_EUR05/BOXER3_EUR06	Airbag		✓	✓	✓			
BOXER3_EUR05/BOXER3_EUR06	Power steering electric pump unit		✓	✓	✓	✓		
BOXER3_EUR05/BOXER3_EUR06	Instrument Panel		✓	✓	✓	✓	✓	S0033
BOXER3_EUR05/BOXER3_EUR06	Air Conditioning		✓		✓	✓	✓	
BOXER3_EUR05/BOXER3_EUR06	BSI		✓	✓	✓	✓		

BOXER3_EURO5/BOXER3 EURO6	Additional Heating		✓	✓	✓	✓	✓	
BOXER3_EURO5/BOXER3 EURO6	Parking Aid(AAS)		✓	✓	✓	✓		

Special Functions List

No.	Functions Name	System Name
S0033	Maintenance and return to zero	BSI
S0033	Maintenance and return to zero	BSI-BSI 2010
S0033	Maintenance and return to zero	Instrument Panel
S0034	Throttle matching	Engine-1.6 16v BOSCH Motronic ME
S0034	Throttle matching	Engine-BOSCH ME7. 4. 5
S0034	Throttle matching	Engine-BOSCH ME749
S0034	Throttle matching	Engine-EMV17 4 2
S0034	Throttle matching	Engine-J34P
S0034	Throttle matching	Engine-KFU MM6LP
S0034	Throttle matching	Engine-KFU MM6LPC
S0034	Throttle matching	Engine-KFV J34P
S0034	Throttle matching	Engine-KFV S2000PM2
S0034	Throttle matching	Engine-ME744
S0034	Throttle matching	Engine-ME745
S0034	Throttle matching	Engine-ME745 EC5
S0034	Throttle matching	Engine-ME747
S0034	Throttle matching	Engine-ME749
S0034	Throttle matching	Engine-ME749 BIO FLEX
S0034	Throttle matching	Engine-ME749 EC5
S0034	Throttle matching	Engine-MED17 4 2
S0034	Throttle matching	Engine-MED17 4 EURO4
S0034	Throttle matching	Engine-MED17 4 EURO5
S0034	Throttle matching	Engine-MED17 4 4
S0034	Throttle matching	Engine-MEV17 4 2
S0034	Throttle matching	Engine-MEV17 4 EURO4
S0034	Throttle matching	Engine-MEV17 4 EURO5
S0034	Throttle matching	Engine-MEV17. 4
S0034	Throttle matching	Engine-MEVD17 4 2

S0034	Throttle matching	Engine-MM6KP
S0034	Throttle matching	Engine-MM6KP bio
S0034	Throttle matching	Engine-MM6KP Bio Flex1
S0034	Throttle matching	Engine-MM6KP Bio Flex2
S0034	Throttle matching	Engine-MM6KP BioFlex
S0034	Throttle matching	Engine-MM6LP
S0034	Throttle matching	Engine-MM6LPC
S0034	Throttle matching	Engine-N6A ME749 BIO FLEX
S0034	Throttle matching	Engine-NFU BOSCH ME745
S0034	Throttle matching	Engine-NFU ME744
S0034	Throttle matching	Engine-NFU OR N6A ME749
S0034	Throttle matching	Engine-RFH MM6KP
S0034	Throttle matching	Engine-RFJ MM6LPB
S0034	Throttle matching	Engine-RFK MM6LP
S0034	Throttle matching	Engine-RFN MM6LP
S0034	Throttle matching	Engine-V341
S0034	Throttle matching	Service Module(RASTREADOR)
S0035	Steering angle reset	ABS or ESP ECU-ABS 81
S0035	Steering angle reset	ABS or ESP ECU-ABS8 BOSCH
S0035	Steering angle reset	ABS or ESP ECU-ESP
S0035	Steering angle reset	ABS or ESP ECU-ESP 90
S0035	Steering angle reset	ABS or ESP ECU-ESP MK60
S0035	Steering angle reset	ABS or ESP ECU-ESP8 BOSCH
S0035	Steering angle reset	ABS or ESP ECU-ESP81
S0035	Steering angle reset	ABS or ESP ECU-ESPMK60 0
S0035	Steering angle reset	ABS-81 ESP
S0035	Steering angle reset	ABS-ABS 8.1
S0035	Steering angle reset	ABS-ABS ESP8 0
S0035	Steering angle reset	ABS-ABS8
S0035	Steering angle reset	ABS-ABS81
S0035	Steering angle reset	ABS-BOSCH ABS 8.1
S0035	Steering angle reset	ABS-ESP 8.1
S0035	Steering angle reset	ABS-ESP 81
S0035	Steering angle reset	ABS-ESP8
S0035	Steering angle reset	ABS-ESP8 BOSCH

S0035	Steering angle reset	ABS-ESP81
S0035	Steering angle reset	ABS-ESP81 BOSCH
S0035	Steering angle reset	ABS/ESP
S0035	Steering angle reset	ABS/ESP-ESP BOSCH57
S0035	Steering angle reset	ABS/ESP-ESP BOSCH8
S0035	Steering angle reset	ABS/ESP-ESP BOSCH8 KwpECU
S0035	Steering angle reset	ABS/ESP-ESP MK60 0
S0035	Steering angle reset	ABS/ESP-ESP8.1
S0035	Steering angle reset	Flywheel Angle Sensor
S0035	Steering angle reset	Power steering
S0035	Steering angle reset	Steering wheel angle sensor
S0036	Injector code	Engine-9HU EDC16C3
S0036	Injector code	Engine-9HV BOSCH EDC16C3
S0036	Injector code	Engine-DCM3.4
S0036	Injector code	Engine-DCM3.5 BR2
S0036	Injector code	Engine-DCM3.5 RHE/RHH
S0036	Injector code	Engine-DCM34
S0036	Injector code	Engine-DCM35
S0036	Injector code	Engine-DCM35 BR2
S0036	Injector code	Engine-DCM35 HY
S0036	Injector code	Engine-EDC16C3
S0036	Injector code	Engine-EDC16C3 (CAN)
S0036	Injector code	Engine-EDC16C3DV4
S0036	Injector code	Engine-EDC17C10
S0036	Injector code	Engine-EDC17C10 BR2
S0036	Injector code	Engine-EDC17C10 BR2
S0036	Injector code	Engine-EDC17CP11
S0036	Injector code	Engine-RHH DCM3.5
S0036	Injector code	Engine-RHH DW10CTED4-163CV
S0037	DPF regeneration	Engine-4HK EDC16CP39
S0037	DPF regeneration	Engine-4HN EDC16CP39
S0037	DPF regeneration	Engine-BOSCH EDC16C3
S0037	DPF regeneration	Engine-DCM3.4
S0037	DPF regeneration	Engine-DCM3.5 BR2
S0037	DPF regeneration	Engine-DCM3.5 RHE/RHH

S0037	DPF regeneration	Engine-DCM34
S0037	DPF regeneration	Engine-DCM35
S0037	DPF regeneration	Engine-DCM35 BR2
S0037	DPF regeneration	Engine-DCM35 HY
S0037	DPF regeneration	Engine-EDC16C3
S0037	DPF regeneration	Engine-EDC16C3 (CAN)
S0037	DPF regeneration	Engine-EDC16CP39
S0037	DPF regeneration	Engine-EDC17C10
S0037	DPF regeneration	Engine-EDC17C10 BR2
S0037	DPF regeneration	Engine-EDC17C10 BR2
S0037	DPF regeneration	Engine-EDC17C60
S0037	DPF regeneration	Engine-EDC17CP11
S0037	DPF regeneration	Engine-EDC17CP42
S0037	DPF regeneration	Engine-EDC17CP52
S0037	DPF regeneration	Engine-EDC17CP52 UDS
S0037	DPF regeneration	Engine-HDI SID803A
S0037	DPF regeneration	Engine-HDI SID807
S0037	DPF regeneration	Engine-HDI SID807 BR2
S0037	DPF regeneration	Engine-HDI SID803
S0037	DPF regeneration	Engine-RHH DCM3.5
S0037	DPF regeneration	Engine-RHH DW10CTED4-163CV
S0037	DPF regeneration	Engine-SID201
S0037	DPF regeneration	Engine-SID803
S0037	DPF regeneration	Engine-SID807
S0037	DPF regeneration	Engine-SID807 BR2
S0038	Brake pad reset	ABS or ESP ECU-ESP 90
S0038	Brake pad reset	ABS or ESP ECU-ESP81
S0038	Brake pad reset	ABS-ESP81
S0038	Brake pad reset	Electric parking brake
S0038	Brake pad reset	Electric secondary brake
S0039	Exhaust	ABS or ESP ECU
S0039	Exhaust	ABS or ESP ECU-ABS 81
S0039	Exhaust	ABS or ESP ECU-ABS MK100
S0039	Exhaust	ABS or ESP ECU-ABS MK70
S0039	Exhaust	ABS or ESP ECU-ABS MK70.1

S0039	Exhaust	ABS or ESP ECU-ABS8 BOSCH
S0039	Exhaust	ABS or ESP ECU-ABS81
S0039	Exhaust	ABS or ESP ECU-ABSMK70 1
S0039	Exhaust	ABS or ESP ECU-ESP 90
S0039	Exhaust	ABS or ESP ECU-ESP MK60
S0039	Exhaust	ABS or ESP ECU-ESP8 BOSCH
S0039	Exhaust	ABS or ESP ECU-ESP81
S0039	Exhaust	ABS or ESP ECU-ESPMK100
S0039	Exhaust	ABS or ESP ECU-ESPMK60 0
S0039	Exhaust	ABS-81 ESP
S0039	Exhaust	ABS-ABS 8.1
S0039	Exhaust	ABS-ABS ABS8 0
S0039	Exhaust	ABS-ABS ASR8 0
S0039	Exhaust	ABS-ABS ESP8 0
S0039	Exhaust	ABS-ABS MK100
S0039	Exhaust	ABS-ABS8
S0039	Exhaust	ABS-ABS81
S0039	Exhaust	ABS-BOSCH ABS 8.1
S0039	Exhaust	ABS-ESP 8.1
S0039	Exhaust	ABS-ESP8
S0039	Exhaust	ABS-ESP8 BOSCH
S0039	Exhaust	ABS-ESP81
S0039	Exhaust	ABS-ESP81 BOSCH
S0039	Exhaust	ABS-ESPMK100
S0039	Exhaust	ABS/ESP
S0039	Exhaust	ABS/ESP-ABS8 BOSCH
S0039	Exhaust	ABS/ESP-ABS8.1
S0039	Exhaust	ABS/ESP-ESP BOC SH8
S0039	Exhaust	ABS/ESP-ESP BOSCH57
S0039	Exhaust	ABS/ESP-ESP BOSCH8
S0039	Exhaust	ABS/ESP-ESP BOSCH8 KwpECU
S0039	Exhaust	ABS/ESP-ESP MK60 0
S0039	Exhaust	ABS/ESP-ESP8.1
S0039	Exhaust	ABS/ESP-MK70.1
S003A	Battery matching	Battery change status unit-BECB

S003A	Battery matching	Battery charge status unit-BECB GEN2
S003A	Battery matching	Battery charge status unit
S003A	Battery matching	Battery charge status unit-BECB
S003A	Battery matching	Battery charge status unit-BECB GEN2
S003A	Battery matching	Battery charge status unit-BECB GEN2
S0040	Adaptive initialization	Engine-ME745
S0041	Replace the throttle body , Accelerator pedal sensor , Ejector , Oxygen	Engine-ME745
S0042	Replace ECU	Engine-ME745

XTOOL